

ENGINE

TABLE OF CONTENTS

	page		page
ENGINE 2.5L/2.8 TURBO DIESEL		ROCKER ARMS	
DESCRIPTION		DESCRIPTION	37
DESCRIPTION - 2.5L/2.8L COMMON RAIL		OPERATION	37
DIESEL ENGINE	3	REMOVAL	37
DESCRIPTION - ENGINE COVER	3	INSTALLATION	38
REMOVAL		HYDRAULIC LIFTERS	
REMOVAL - 2.5L/2.8L DIESEL ENGINE	4	DESCRIPTION	38
REMOVAL - ENGINE COVER	7	REMOVAL	38
INSTALLATION		INSPECTION	39
INSTALLATION - 2.5L TURBO DIESEL		INSTALLATION	39
ENGINE	7	ENGINE BLOCK	
INSTALLATION - ENGINE COVER	8	DESCRIPTION	39
SPECIFICATIONS		CRANKSHAFT	
SPECIFICATIONS - 2.5L COMMON RAIL		DESCRIPTION	40
DIESEL ENGINE	8	OPERATION	40
SPECIFICATIONS - 2.8L COMMON RAIL		STANDARD PROCEDURE - CHECKING	
DIESEL ENGINE	11	CRANKSHAFT END PLAY	40
SPECIFICATIONS - TORQUE	15	REMOVAL	41
SPECIAL TOOLS	17	INSTALLATION	43
AIR CLEANER HOUSING		FLEX PLATE	
REMOVAL	24	REMOVAL	44
INSTALLATION	24	INSTALLATION	44
CYLINDER HEAD		FLY WHEEL	
STANDARD PROCEDURE		REMOVAL	45
STANDARD PROCEDURE - VALVE		INSTALLATION	45
SERVICE	25	CYLINDER LINERS	
STANDARD PROCEDURE - MEASURING		DESCRIPTION	45
PISTON PROTRUSION	26	REMOVAL	45
REMOVAL	27	INSPECTION	46
CLEANING	28	INSTALLATION	46
INSPECTION	28	INTERNAL VACUUM PUMP	
INSTALLATION	28	DESCRIPTION	47
CAMSHAFT(S)		REMOVAL	47
DESCRIPTION	30	INSTALLATION	47
OPERATION	31	PISTON & CONNECTING ROD	
REMOVAL	31	DESCRIPTION	48
INSTALLATION	31	STANDARD PROCEDURE - PISTON RING	
CYLINDER HEAD COVER(S)		FITTING	48
DESCRIPTION	32	REMOVAL	48
REMOVAL		INSPECTION	50
REMOVAL	32	INSTALLATION	51
REMOVAL	34	CRANKSHAFT OIL SEAL - FRONT	
INSTALLATION		REMOVAL	53
INSTALLATION	34	INSTALLATION	53
INSTALLATION	36	VIBRATION DAMPER	
CAMSHAFT OIL SEAL(S)		REMOVAL	55
REMOVAL	36	INSTALLATION	55
INSTALLATION	36	ENGINE COVER - FRONT	
		DESCRIPTION	55

REMOVAL	55	INSTALLATION	64
INSTALLATION	55	INTAKE MANIFOLD	
CRANKSHAFT MAIN BEARINGS		DESCRIPTION	65
REMOVAL	56	REMOVAL	65
INSTALLATION	57	INSTALLATION	65
CRANKSHAFT OIL SEAL - REAR		EXHAUST MANIFOLD	
DESCRIPTION	58	REMOVAL	65
REMOVAL	58	INSTALLATION	66
INSTALLATION	58	VALVE TIMING	
OIL PAN		STANDARD PROCEDURE - LOCKING ENGINE	
REMOVAL	59	90° AFTER TDC	67
INSTALLATION	59	BALANCE SHAFT	
OIL PUMP		DESCRIPTION	68
REMOVAL		OPERATION	68
REMOVAL	60	REMOVAL	68
REMOVAL	60	INSTALLATION	68
INSTALLATION		TIMING BELT COVER	
INSTALLATION	60	REMOVAL	
INSTALLATION	61	REMOVAL - TIMING BELT OUTER COVER ..	69
OIL PRESSURE SENSOR/SWITCH		REMOVAL - TIMING BELT INNER COVER ..	69
DESCRIPTION	61	INSTALLATION	
REMOVAL	61	INSTALLATION - TIMING BELT OUTER	
INSTALLATION	61	COVER	70
OIL PRESSURE RELIEF VALVE		INSTALLATION - TIMING BELT INNER	
DESCRIPTION	62	COVER	71
REMOVAL	62	TIMING BELT IDLER PULLEY	
INSTALLATION	62	REMOVAL	71
OIL COOLER & LINES		INSTALLATION	72
REMOVAL	63	TIMING BELT TENSIONER & PULLEY	
INSTALLATION	63	REMOVAL	72
OIL FILTER		INSTALLATION	72
DESCRIPTION	64	ADJUSTMENTS	
REMOVAL	64	ADJUSTMENT - TIMING BELT TENSIONER ..	73
INSTALLATION	64	TIMING BELT AND SPROCKETS	
OIL JET		REMOVAL	74
DESCRIPTION	64	INSTALLATION	74
REMOVAL	64		

ENGINE 2.5L/2.8 TURBO DIESEL


DESCRIPTION

DESCRIPTION - 2.5L/2.8L COMMON RAIL DIESEL ENGINE

The 2.5 Liter (2499cc) and 2.8L (2776cc) four-cylinder “common rail” direct injection engines are very similar in design and operability with a few differences. The 2.5L is the engine of choice for the manual transmission and the 2.8L for the automatic transmission. Both 4 cylinder “common rail” direct injection engines are an in-line overhead valve design. The engines utilize a cast iron cylinder block and an aluminum cylinder head with four valves per cylinder and dual overhead cam shafts. Both engines are turbocharged and intercooled. Differences include a longer crankshaft gear, larger cylinder bore and larger intake ducts in the cylinder head of the 2.8L. (Fig. 1).

DESCRIPTION	SPECIFICATION
Displacement 2.5L	2.5L (2499 cc)
Displacement 2.8L	2.8L (2776cc)
Bore - 2.5L	92.00 mm
Bore - 2.8L	94.00 mm
Stroke 2.5L	94.00 mm
Stroke 2.8L	100.00 mm
Compression Ratio	17.5:1
Vacuum at Idle	700 mm/Hg (27.5 In/Hg)
Belt Tension	Automatic Belt Tensioner
Thermostat Opening	80°C ± 2°C
Generator Rating	Denso 12V-95A
Cooling System Capacity	13.8 Liters W/O Auxiliary Heater 16.6 Liters With Auxiliary Heater
Engine Oil Capacity	6.0L W/Filter Change
Timing System	Belt Driven Overhead Camshafts
Air Intake	Dry Filter With Turbocharger and Charge Air Cooler
Fuel Supply	Vane Pump Incorporated In Injection Pump
Fuel System	Direct Fuel Injection Common Rail System

DESCRIPTION	SPECIFICATION
Combustion Cycle	4 Stroke
Cylinder Compression Difference Between Cylinders	5 Bar
Cooling System	Water Cooling
Injection Pump	Common Rail System
Lubrication	Pressure Lubricated By Rotary Pump
Minimum Oil Pressure (Warm)	0.7 Bar at Idle 2 Bar at 3800 rpm
Engine Rotation	Clockwise Viewed From Front Cover
Transmission 2.5L	MTX
Transmission 2.8L	ATX



80cb4237

Fig. 1 2.5L/2.8L COMMON RAIL DIESEL ENGINE

DESCRIPTION - ENGINE COVER


The engine cover is a black plastic cover used to cover the top of the engine (Fig. 10). It is used to isolate engine noises.

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)

REMOVAL

REMOVAL - 2.5L/2.8L DIESEL ENGINE

- (1) Disconnect negative battery cable.
- (2) Remove engine cover (Fig. 2). (Refer to 9 - ENGINE - REMOVAL)




80addf4c

Fig. 2 ENGINE COVER

- 1 - ENGINE COVER MOUNTING BOLTS
- 2 - ENGINE COVER

- (3) Remove air cleaner housing, MAF sensor, and air intake tube assembly (Fig. 3).




80b5cdfb

Fig. 3 MASS AIR FLOW (MAF) SENSOR LOCATION

- 1 - MAF SENSOR ELECTRICAL CONNECTOR
- 2 - RETAINING CLAMPS
- 3 - MASS AIR FLOW (MAF) SENSOR
- 4 - AIR CLEANER HOUSING

- (4) Remove coolant pressure tank pressure cap.
- (5) Raise vehicle on hoist.
- (6) Drain cooling system (Refer to 7 - COOLING/ENGINE/COOLANT - STANDARD PROCEDURE).
- (7) Remove lower splash shield.
- (8) Remove splash shield side panels.
- (9) Remove power steering reservoir hose from power steering pump and drain power steering fluid (Fig. 4).



80c6e1d5

Fig. 4 RESERVOIR AND HOSES - 2.5L DIESEL

- 1 - POWER STEERING FLUID RESERVOIR
- 2 - RESERVOIR BRACKET
- 3 - SUPPLY HOSE BRACKET
- 4 - RETURN HOSE FROM GEAR
- 5 - ROUTING CLIP
- 6 - PRESSURE HOSE TO GEAR
- 7 - SUPPLY HOSE (PUMP END)
- 8 - PRESSURE HOSE (PUMP END)
- 9 - SUPPLY HOSE
- 10 - RETURN HOSE

- (10) Disconnect high pressure power steering line at pump (Fig. 4).

- (11) Disconnect power steering pump return hose clamp (Fig. 4).

- (12) Remove power steering return line retaining clamp (Fig. 4).

- (13) Remove power steering line clamps from oil pan (Fig. 4).

- (14) Remove power steering pump reservoir and bracket (Fig. 4).

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)

(15) Drain coolant system (Refer to 7 - COOLING/ENGINE/COOLANT - STANDARD PROCEDURE).

(16) Remove coolant pressure tank (Fig. 5).




Fig. 5 COOLANT RECOVERY PRESSURE CONTAINER LOCATION

- 1 - PRESSURE/VENT CAP
- 2 - BRAKE MASTER CYLINDER
- 3 - BATTERY
- 4 - BATTERY SHIELD
- 5 - COOLANT RECOVERY PRESSURE CONTAINER RETAINING CLIP
- 6 - ENGINE COVER
- 7 - COOLANT RECOVERY PRESSURE CONTAINER

- (17) Remove battery shield.
- (18) Remove charge air cooler outlet hose.
- (19) Remove charge air cooler inlet hose (Fig. 6).
- (20) Disconnect upper radiator hose at engine (Fig. 7).
- (21) Disconnect lower radiator hose at engine (Fig. 7).
- (22) Disconnect brake booster vacuum supply hose.
- (23) Disconnect heater core return hose at engine.
- (24) Disconnect EGR solenoid vacuum line at brake booster check valve.
- (25) Disconnect fuel injector, cam sensor, boost pressure/intake air temperature sensor, fuel rail high pressure, and EGR solenoid connectors (Fig. 8).
- (26) Disconnect generator electrical connectors.
- (27) Disconnect coolant temperature sensor and glow plug electrical connectors.
- (28) Disconnect high pressure injection pump and A/C compressor electrical connectors.
- (29) Disconnect starter electrical connectors.
- (30) Disconnect ground wires at engine block.
- (31) Raise vehicle on hoist.




Fig. 6 CHARGE AIR COOLER HOSES

- 1 - COOLING MODULE
- 2 - BYPASS HOSE
- 3 - UPPER RADIATOR HOSE
- 4 - CHARGE AIR COOLER OUTLET HOSE
- 5 - CHARGE AIR COOLER INLET HOSE
- 6 - LOWER RADIATOR HOSE
- 7 - CHARGE AIR COOLER





Fig. 7 UPPER AND LOWER RADIATOR HOSES

- 1 - COOLANT BYPASS HOSE
- 2 - RADIATOR ASSEMBLY
- 3 - UPPER RADIATOR HOSE
- 4 - COOLING FAN
- 5 - LOWER RADIATOR HOSE
- 6 - CHARGE AIR COOLER
- 7 - RADIATOR BRACKET

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)



80c5918d

Fig. 8 ENGINE COMPONENT LOCATIONS

- 1 - FUEL INJECTOR RETURN LINE
- 2 - FUEL INJECTOR SUPPLY LINE
- 3 - OIL SEPARATOR
- 4 - FUEL INJECTOR
- 5 - CAMSHAFT POSITION SENSOR
- 6 - BOOST PRESSURE/INTAKE AIR TEMPERATURE SENSOR
- 7 - EGR SOLENOID
- 8 - FUEL PRESSURE SENSOR
- 9 - CYLINDER HEAD COVER/INTAKE MANIFOLD
- 10 - FUEL RAIL
- 11 - WIRING HARNESS RETAINING CLIPS

(32) Disconnect oil pressure switch, engine speed sensor, and vehicle speed sensor electrical connector (Fig. 9).

(33) Raise and support vehicle.

(34) Remove front wheels.

(35) Remove the suspension cradle assembly (Refer to 13 - FRAME & BUMPERS/FRAME/ENGINE CRADLE CROSSMEMBER - REMOVAL).


(36) Remove both axle shaft assemblies (Refer to 3 - DIFFERENTIAL & DRIVELINE/HALF SHAFT - REMOVAL).

(37) Disconnect the clutch slave cylinder quick disconnect line (RHD only) (Refer to 6 - CLUTCH/SLAVE CYLINDER - REMOVAL).

(38) Disconnect reverse lamp connector.

(39) Disconnect shifter cables at the transmission (Refer to 21 - TRANSMISSION/TRANSAXLE/MANUAL/GEAR SHIFT CABLE - REMOVAL).

(40) Disconnect exhaust pipe from the turbo-charger downpipe and reposition to right side of vehicle.



80fe7275

Fig. 9 VIEW-REAR ENGINE

- 1 - SUSPENSION CRADLE
- 2 - ENGINE BLOCK
- 3 - OIL PRESSURE SWITCH
- 4 - VEHICLE SPEED SENSOR
- 5 - TRANSMISSION

(41) Disconnect cabin heater coolant line (Refer to 24 - HEATING & AIR CONDITIONING/CABIN HEATER/HEATER UNIT - REMOVAL).

(42) Remove front engine mount bracket retaining bolts from lower radiator support

(43) Lower vehicle. Evacuate the A/C system (Refer to 24 - HEATING & AIR CONDITIONING/PLUMBING/REFRIGERANT - STANDARD PROCEDURE).

(44) Disconnect the A/C lines at the A/C compressor.

(45) Raise and support vehicle.

(46) Disconnect the fuel supply and return lines.

(47) Position engine cradle under engine and lower vehicle over cradle.

(48) Remove right engine mount bolts.

(49) Remove left engine mount through bolt.


(50) Carefully raise vehicle, leaving engine and transmission on engine cradle.

(51) Lift engine from engine cradle and disassemble as necessary.

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)

REMOVAL - ENGINE COVER

- (1) Remove engine cover retaining bolts.
- (2) Remove engine cover from engine (Fig. 10).



80addf4c

Fig. 10 ENGINE COVER

- 1 - ENGINE COVER MOUNTING BOLTS
2 - ENGINE COVER

INSTALLATION**INSTALLATION - 2.5L TURBO DIESEL ENGINE**

- (1) Reassembly engine and transmission assembly and install on engine cradle.
- (2) Position engine and cradle assembly under vehicle.
- (3) Slowly lower the vehicle down over the engine and cradle assembly.
- (4) Install right engine mount bolts. Torque to 54N·m (40 ft. lbs.)
- (5) Install left engine mount through bolt. Torque to 75N·m (55 ft. lbs.)
- (6) Raise vehicle and engine from engine cradle.
- (7) Attach front engine mount bracket to lower radiator support. Torque to 54N·m (40 ft. lbs.)
- (8) Connect cabin heater coolant hose.
- (9) Connect exhaust pipe to the turbocharger downpipe flange. Torque to 28 N·m (250 in. lbs.)
- (10) Connect reverse lamp electrical connector at transmission.
- (11) Connect both shifter cables (Refer to 21 - TRANSMISSION/TRANSAXLE/MANUAL/GEAR SHIFT CABLE - INSTALLATION).

- (12) Connect the clutch slave cylinder quick disconnect connector (RHD only)(Refer to 6 - CLUTCH/SLAVE CYLINDER - INSTALLATION).
- (13) Install engine harness into bracket on transmission.
- (14) Lower vehicle.
- (15) Connect fuel supply and return lines.
- (16) Connect A/C lines to A/C compressor. Torque to 23N·m (17 ft. lbs.)
- (17) Route engine wiring harness to proper location.
- (18) Connect engine harness ground cables to engine block
- (19) Connect starter solenoid electrical connector and battery positive wire to starter. Torque to 10N·m (90 in. lbs.)
- (20) Connect A/C compressor, injection pump, glow plugs, and coolant temperature sensor electrical connectors.
- (21) Connect generator electrical connector. Torque to 9N·m (75 in. lbs.)
- (22) Connect the fuel injector, fuel pressure sensor, boost pressure/intake air temp sensor, cam sensor, and EGR solenoid electrical connectors (Fig. 8).
- (23) Connect EGR solenoid vacuum supply line to brake boost vacuum supply line.
- (24) Connect brake booster vacuum supply line.
- (25) Connect heater core return hose to coolant pipe.
- (26) Connect lower radiator hose to engine (Fig. 7).
- (27) Install charger air cooler inlet hose (Fig. 6).
- (28) Install charge air cooler outlet hose (Fig. 6).
- (29) Connect upper radiator hose to engine (Fig. 7).
- (30) Install battery shield.
- (31) Install coolant reserve pressure container (Refer to 7 - COOLING/ENGINE/COOLANT RECOVERY PRESS CONTAINER - INSTALLATION).
- (32) Install power steering reservoir and bracket (Fig. 4).
- (33) Raise vehicle
- (34) Connect oil pressure sensor, oil temperature sensor, engine speed sensor, and vehicle speed sensor electrical connector (Fig. 9).
- (35) Install suspension cradle in vehicle (Refer to 13 - FRAME & BUMPERS/FRAME/ENGINE CRADLE CROSSMEMBER - INSTALLATION).
- (36) Install both axle shaft assemblies (Refer to 3 - DIFFERENTIAL & DRIVELINE/HALF SHAFT - INSTALLATION).
- (37) Connect the power steering supply, pressure, and return lines to power steering pump (Fig. 4).
- (38) Install the power steering line brackets on oil pan (Fig. 4).

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)

- (39) Install lower splash shield and side panels.
 (40) Install both front wheel and tire assemblies.
 (41) Lower vehicle.
 (42) Install air cleaner housing, MAF sensor, and air intake tube assembly (Fig. 3).
 (43) Refill transmission to proper level (Refer to 21 - TRANSMISSION/TRANSAXLE/MANUAL/FLUID - STANDARD PROCEDURE).
 (44) Refill engine coolant (Refer to 7 - COOLING/ENGINE/COOLANT - STANDARD PROCEDURE).
 (45) Fill engine crankcase to proper level, with correct viscosity engine oil.
 (46) Connect negative battery cable.
 (47) Recharge A/C system (Refer to 24 - HEATING & AIR CONDITIONING/PLUMBING/REFRIGERANT - STANDARD PROCEDURE).
 Perform fuel system air purge procedure (Refer to 14 - FUEL SYSTEM - STANDARD PROCEDURE).
 (48) Install engine cover (Refer to 9 - ENGINE - INSTALLATION) (Fig. 2).

INSTALLATION - ENGINE COVER

- (1) Install engine cover on engine.
 (2) Install the engine cover mounting bolts (Fig. 10).

SPECIFICATIONS**SPECIFICATIONS - 2.5L COMMON RAIL DIESEL ENGINE***GENERAL DESCRIPTION*

DESCRIPTION	SPECIFICATION
Engine Type	R2516C5
Transmission	MTX
Number of Cylinders	4
Bore	92 mm
Stroke	94 mm
Displacement	2499.5cc
Injection Order	1-3-4-2
Compression Ratio	17.5:1 (± 0.5)
Maximum Power	105kW (143 HP) @ 4000 RPM
Peak Torque	340N·m @ 2000 RPM
Cylinder Compression (Max. Difference Between Cylinders)	5 Bar
Minimum Oil Pressure (Warm)	.7 Bar @ Idle 2 Bar @ 3800 RPM

CRANKSHAFT

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Front Journal Diameter-Nominal	62.985-63.005 mm	2.479-2.480 in.
Front Journal Diameter- minus 0.25	62.735-63.074 mm	2.469-2.471 in.
Front Bearing Diameter-Nominal	63.005-63.034 mm	2.480-2.481 in.
Front Bearing Diameter-minus 0.25	62.775-62.784 mm	2.470-2.471 in.
Clearance Between the Journal and Bearing	0.000-0.049 mm	0.000-0.001 in.
Center Journal Diameter-Nominal	63.005-63.020 mm	0.001-0.003 in.
Center Journal Diameter-minus 0.25	62.775-62.770 mm	2.470-2.471
Center Bearing Diameter-Nominal	63.005-63.020 mm	2.480-2.481 in.
Center Bearing Diameter-minus 0.25	62.775-62.770 mm	2.470-2.471 in.
Clearance Between Journal and Bearing	0.008-0.051 mm	0.0003-0.0002 in
Rear Journal Diameter-Nominal	89.980-90.000 mm	3.542-3.543 in.
Rear Journal Diameter- minus 0.25	89.730-99.750 mm	3.532-3.927 in.
Rear Bearing Diameter-Nominal	90.045-90.065 mm	3.545-3.546 in.
Rear Bearing Diameter- minus 0.25	89.795-89.815 mm	3.535-3.536 in.

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Clearance Between Journal and Bearing	0.045-0.080 mm	0.001-0.003 in.
Connecting Rod Journal-Nominal	53.940-53.955 mm	2.123-2.124 in.
Connecting Rod Journal- minus 0.25	53.690-53.705 mm	2.113-2.114 in.
Connecting Rod Bearing-Nominal	53.997-54.016 mm	2.125-2.126 in.
Connecting Rod Bearing- minus 0.25	53.727-53.766 mm	2.115-2.116 in.
Clearance Between Journal and Bearing	0.022-0.076 mm	0.0008-0.0029 in.
Crankshaft End Play	0.080-0.280 mm	0.003-0.011 in.
Adjustment	Thrust Washers	Thrust Washers
Thrust Washers Available	2.31-2.36 mm	0.090-0.092 in.
	2.41-2.46 mm	0.094-0.096 in.
	2.51-2.56 mm	0.098-0.100
Carrier with Thrush Washers Installed	27.670-27.820 mm	1.089-1.095 in.

MAIL BEARING CARRIERS

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Internal Diameter-Front	67.025-67.050 mm	2.638-2.639 in.
Internal Diameter-Center	66.670-66.690 mm	2.624-2.624 in.
Internal Diameter-Rear	85.985-86.005 mm	3.385-3.386 in.

LINERS

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Internal Diameter	091.997-92.015 mm.	3.621-3.622 in.
Protrusion	0.00-0.05 mm	0.00-0.001 in.

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Available Adjustment Shims	0.15 mm	0.005 in.
	0.17 mm	0.006 in.
	0.20 mm	0.007 in.
	0.23 mm	0.009
	0.25 mm	0.0098

CYLINDER HEAD

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Minimum Thickness	94.95-95.05 mm.	3.738-3.742 in.
Gasket Thickness	1.32 mm \pm 0.08, 0 notches	0.0051 in. \pm 0.003, 0 notches
	1.42 mm \pm 0.08, 1 notch	0.051 in. \pm 0.003, 1 notch
	1.52 mm \pm 0.08, 2 notches	0.059 in. \pm 0.003, 1 notches

CONNECTING RODS

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Small end Bearing Internal Diameter	32.035-32.050 mm	1.2612-1.2618 in.
Large End Internal Diameter	53.997-54.016 mm	2.125-2.126 in.

PISTONS

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Skirt Diameter (measured at approximately 10 mm above the bottom of the skirt)	91.912-91.928 mm.	3.618-3.619 in.
Piston Clearance	0.065-0.83 mm	0.002-0.003 in.
Top of Piston to Cylinder Head	0.69-0.83 mm	0.027-0.032 in.

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Piston Protrusion	0.460-0.609 mm Fit Gasket, Number (1.32mm), 0 notches or holes	0.018-0.023 in. Fit Gasket, Number (0.051 in.), 0 notches
	0.610-0.709 mm Fit Gasket, Number (1.42 mm) 1 notch or hole	0.024-0.027 in. Fit Gasket, Number (0.055 in.) 1 notch or hole
	0.710-0.810 mm Fit Gasket, Number (1.52 mm), 2 notches or holes	0.027-0.031 in. Number (0.059 in) 2 notches or holes

PISTON PINS

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Type	Full Floating	
Pin Diameter	32.004-32.008 mm	1.2599-1.2601 in.
	32.004-32.010 mm	1.2599-1.2602 in.
Clearance	0.010-0.020 mm	0.0001-0.0004 in.
	0.004-0.012 mm	0.0001-0.0004 in.

PISTON RINGS

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Clearance in Groove		
Top Compression Ring	0.078-0.137 mm	0.003-0.005 in.
Second Compression Ring	0.070-0.110 mm	0.002-0.004 in.
Oil Control (Steel Rails)	0.40-0.080 mm	0.001 - 0.003 in.
Fitted Gap		

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Top Compression Ring	.030-0.45 mm	0.011-0.017 in.
Second Compression Ring	0.035 - 0.050 mm	0.0013 - 0.0019 in.
Oil Ring (Steel Ring)	.025 - 0.50 mm	.0009 - .0019 in.

CAMSHAFT

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Journal Diameter-Front	29.960-29.980 mm	1.179-1.180 in.
Bearing Clearance	0.03-0.08 mm	0.0011-0.0031 in.
Journal Diameter-Center	39.250-39.270 mm	1.545-1.546 in.
Bearing Clearance	0.03-0.08 mm	0.001-0.003 in.
Journal Diameter-Rear	39.250-39.270 mm	1.545-1.546 in.
Bearing Clearance	0.03-0.08 mm	0.001-0.003 in.

HYDRAULIC LIFTER

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Outside Diameter	11.994 ± 0.006 mm	0.472 ± 0.0002 in.

VALVES

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Face Angle-Intake	45° 25'-55° 35' mm	-
Face Angle-Exhaust	45° 25'-45° 35' mm	-
Intake Valve Opens	15.6° ± 2° A.T.D.C.	-
Intake Valve Closes	64.4° ± 2° A.B.D.C.	-

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Exhaust Valve Opens	66° ± 2° B.B.D.C.	-
Exhaust Valve Closes	32° ± 2° A.T.D.C.	-
Head Diameter-Intake	32.30-32.50 mm	1.271-1.279 in.
Head Diameter-Exhaust	30.80-31.00 mm	1.212-1.220 in.
Head Stand Down-Intake	1.08-1.34 mm	0.042-0.052 in.
Head Stand Down-Exhaust	0.99-1.25 mm	0.038-0.049 in.
Stem Diameter-Intake	5.952-5.970 mm	0.234-0.235 in.
Stem Diameter-Exhaust	5.942-5.960 mm	0.233-0.234 in.
Clearance in Guide-Intake	0.030-0.060 mm	0.001-0.002 in.
Clearance in Guide-Exhaust	0.040-0.070 mm	0.001-0.002 in.

VALVE GUIDE

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Inside Diameter	6.00-6.012 mm	0.2362-0.2366 in.
Fitted Height-Intake	14.5-15.0 mm	0.570-0.590 in.
Fitted Height-Exhaust	16.5-17.0 mm	0.649-0.669 in.

VALVE SPRING

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Free Length	45.26 mm	1.781 in.
Fitted Length	38.0 mm	1.496 in.
Load at Fitted Length	182 ± 5-10% Kg	-
Load at Top of Lift	395 ± 5% Kg	-
Number of Coils	8	-

LUBRICATION

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Pressure Relief Valve Opens	6.50 bar	94 psi
Pressure Relief Valve Spring-Free Length	51.5 mm	2.02 in.

OIL PUMP

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Outer Rotor End Float	0.060-0.160 mm	0.002-0.006 in.
Inner Rotor End Float	0.060-0.160	0.002-0.006 in.
Outer Rotor to Body Diameter Clearance	0.130-0.240 mm	0.005-0.009 in.
Rotor Body to Drive Gear Clearance (pump not fitted)	0.90-1.50 mm	0.035-0.059 in.

SPECIFICATIONS - 2.8L COMMON RAIL DIESEL ENGINE

GENERAL DESCRIPTION

DESCRIPTION	SPECIFICATION
Engine Type	R2816C5.05A
Transmission	ATX
Number of Cylinders	4
Bore	94 mm
Stroke	100 mm
Displacement	2776cc
Injection Order	1-3-4-2
Compression Ratio	17.5:1 (± 0.5)
Maximum Power	110kW (150 CV) @ 3800 RPM
Peak Torque	360 N·m @ 1800 RPM
Cylinder Compression (Max. Difference Between Cylinders)	5 Bar
Minimum Oil Pressure (Warm)	.7 Bar @ Idle 2 Bar @ 3800 RPM

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)

CRANKSHAFT

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Front Journal Diameter-Nominal	62.985-63.005 mm	2.479-2.480 in.
Front Journal Diameter- minus 0.25	62.735-62.755 mm	2.469-2.470 in.
Front Bearing Diameter-Nominal	63.005-63.034 mm	2.480-2.481 in.
Front Bearing Diameter-minus 0.25	62.755-62.784 mm	2.471-2.478 in.
Clearance Between the Journal and Bearing	0.00-0.049 mm	0.000-0.001 in.
Center Journal Diameter-Nominal	63.005-63.020 mm	0.001-0.003 in.
Center Journal Diameter-minus 0.25	62.775-62.770 mm	2.470-2.471
Center Bearing Diameter-Nominal	63.005-63.020 mm	2.480-2.481 in.
Center Bearing Diameter-minus 0.25	62.775-62.770 mm	2.470-2.471 in.
Clearance Between Journal and Bearing	0.008-0.051 mm	0.0003-0.0002 in
Rear Journal Diameter-Nominal	89.980-90.000 mm	3.542-3.543 in.
Rear Journal Diameter- minus 0.25	89.730-99.750 mm	3.532-3.927 in.
Rear Bearing Diameter-Nominal	90.045-90.065 mm	3.545-3.546 in.
Rear Bearing Diameter- minus 0.25	89.795-89.815 mm	3.535-3.536 in.

Clearance Between Journal and Bearing	0.045-0.080 mm	0.001-0.003 in.
Connecting Rod Journal-Nominal	53.940-53.955 mm	2.123-2.124 in.
Connecting Rod Journal- minus 0.25	53.690-53.705 mm	2.113-2.114 in.
Connecting Rod Bearing-Nominal	53.997-54.016 mm	2.125-2.126 in.
Connecting Rod Bearing- minus 0.25	53.727-53.766 mm	2.115-2.116 in.
Clearance Between Journal and Bearing	0.022-0.076 mm	0.0008-0.0029 in.
Crankshaft End Play	0.080-0.280 mm	0.003-0.011 in.
Adjustment	Thrust Washers	Thrust Washers
Thrust Washers Available	2.31-2.36 mm	0.090-0.092 in.
	2.41-2.46 mm	0.094-0.096 in.
	2.51-2.56 mm	0.098-0.100
Carrier with Thrush Washers Installed	27.670-27.820 mm	1.089-1.095 in.

MAIL BEARING CARRIERS

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Internal Diameter-Front	67.025-67.050 mm	2.638-2.639 in.
Internal Diameter-Center	66.670-66.690 mm	2.624-2.624 in.
Internal Diameter-Rear	85.985-86.005 mm	3.385-3.386 in.

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)

LINERS

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Internal Diameter	091.997-92.015 mm.	3.621-3.622 in.
Protrusion	0.00-0.05 mm	0.00-0.001 in.
Available Adjustment Shims	0.15 mm	0.005 in.
	0.17 mm	0.006 in.
	0.20 mm	0.007 in.
	0.23 mm	0.009
	0.25 mm	0.0098

CYLINDER HEAD

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Minimum Thickness	94.95-95.05 mm.	3.738-3.742 in.
Gasket Thickness	1.32 mm \pm 0.08, 0 notches	0.0051 in. \pm 0.003, 0 notches
	1.42 mm \pm 0.08, 1 notch	0.051 in. \pm 0.003, 1 notch
	1.52 mm \pm 0.08, 2 notches	0.059 in. \pm 0.003, 1 notches

CONNECTING RODS

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Small end Bearing Internal Diameter	32.035-32.050 mm	1.2612-1.2618 in.
Large End Internal Diameter	53.997-54.016 mm	2.125-2.126 in.

PISTONS

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Skirt Diameter (measured at approximately 10 mm above the bottom of the skirt)	93.912-93.928 mm.	3.6973-3.6979 in.
Piston Clearance	0.010-0.22 mm	0.0003-0.0008 in.
Top of Piston to Cylinder Head	0.69-0.83 mm	0.027-0.032 in.
Piston Protrusion	0.460-0.609 mm Fit Gasket, Number (1.32mm), 0 notches or holes	0.018-0.023 in. Fit Gasket, Number (0.051 in.), 0 notches
	0.610-0.709 Fit Gasket, Number (1.42 mm) 1 notch or hole	0.024-0.027 in. Fit Gasket, Number (0.055 in.) 1 notch or hole
	0.710-0.810 Fit Gasket, Number (1.52 mm), 2 notches or holes	0.027-0.031 in. Number (0.059 in) 2 notches or holes

PISTON PINS

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Type	Full Floating	
Pin Diameter	32.004-32.010 mm	1.259-1.260 in.
Clearance	0.010-0.020 mm	0.0003-0.0007 in.

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)

PISTON RINGS

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Clearance in Groove		
Top Compression Ring	0.078-0.137 mm	0.003-0.005 in.
Second Compression Ring	0.070-0.110 mm	0.002-0.004 in.
Oil Control (Steel Rails)	0.40-0.080 mm	0.001 - 0.003 in.
Fitted Gap		
Top Compression Ring	.030-0.45 mm	0.011-0.017 in.
Second Compression Ring	0.030 - 0.050 mm	0.0011 - 0.0019 in.
Oil Ring (Steel Ring)	.025 - 0.50 mm	.0009 - .0019 in.

CAMSHAFT

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Journal Diameter-Front	29.960-29.980 mm	1.179-1.180 in.
Bearing Clearance	0.03-0.08 mm	0.001-0.003 in.
Journal Diameter-Center	39.250-39.270 mm	1.545-1.546 in.
Bearing Clearance	0.03-0.08 mm	0.001-0.003 in.
Journal Diameter-Rear	39.250-39.270 mm	1.545-1.546 in.
Bearing Clearance	0.03-0.08 mm	0.001-0.003 in.
Camshaft End Play	0.10-0.55mm	0.004-0.021 in.

HYDRAULIC LIFTER

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Outside Diameter	11.994 ± 0.006 mm	0.472 ± 0.0002 in.

VALVES

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Face Angle-Intake	45° 25'-55° 35' mm	-
Face Angle-Exhaust	45° 25'-45° 35' mm	-
Intake Valve Opens	15.6° ± 2° A.T.D.C.	-
Intake Valve Closes	64.4° ± 2° A.B.D.C.	-
Exhaust Valve Opens	66° ± 2° B.B.D.C.	-
Exhaust Valve Closes	32° ± 2° A.T.D.C.	-
Head Diameter-Intake	32.30-32.50 mm	1.271-1.279 in.
Head Diameter-Exhaust	30.80-31.00 mm	1.212-1.220 in.
Head Stand Down-Intake	1.08-1.34 mm	0.042-0.052 in.
Head Stand Down-Exhaust	0.99-1.25 mm	0.038-0.049 in.
Stem Diameter-Intake	5.952-5.970 mm	0.234-0.235 in.
Stem Diameter-Exhaust	5.942-5.960 mm	0.233-0.234 in.
Clearance in Guide-Intake	0.030-0.060 mm	0.001-0.002 in.
Clearance in Guide-Exhaust	0.040-0.070 mm	0.001-0.002 in.

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)

VALVE GUIDE

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Inside Diameter	6.00-6.012 mm	0.2362-0.2366 in.
Fitted Height-Intake	14.5-15.0 mm	0.570-0.590 in.
Fitted Height-Exhaust	16.5-17.0 mm	0.649-0.669 in.

LUBRICATION

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Pressure Relief Valve Opens	6.50 bar	94 psi
Pressure Relief Valve Spring-Free Length	51.5 mm	2.02 in.

VALVE SPRING

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Free Length	45.26 mm	1.781 in.
Fitted Length	38.0 mm	1.496 in.
Load at Fitted Length	182 ± 5-10% Kg	-
Load at Top of Lift	395 ± 5% Kg	-
Number of Coils	8	-

OIL PUMP

DESCRIPTION	SPECIFICATION	
	Metric	Standard
Outer Rotor End Float	0.060-0.160 mm	0.002-0.006 in.
Inner Rotor End Float	0.060-0.160	0.002-0.006 in.
Outer Rotor to Body Diameter Clearance	0.130-0.240 mm	0.005-0.009 in.
Rotor Body to Drive Gear Clearance (pump not fitted)	0.90-1.50 mm	0.035-0.059 in.

SPECIFICATIONS - TORQUE

2.5L/2.8L DIESEL TORQUE SPECIFICATIONS


DESCRIPTION	N-m	Ft. Lbs.	In. Lbs.
Oil Pump Bolts	10.8	8	96
Vacuum Pump Bolts	10.8	8	96
Crankshaft Gear Bolts	10.8	8	96
Crankshaft Position Sensor Bolts	10.8	8	96
Flywheel Bolts - 2.5L, Refer to the Service Procedure			
Flex Plate Bolts - 2.8L, Refer to the Service Procedure			
Cylinder Head Bolts - Refer to the Service Procedure			
Reluctor Wheel Bolts	14.6	11	130
Rear Main Bearing Support Bolts	27.5	21	240
Oil Cooler to Engine Block Bolt	38	28	—
Water Pump Housing Nuts	24.4	18	212
Connecting Rod Bolts - Refer to the Service Procedure			
Balance Shaft Bolts	32.4	24	—
Oil Jet Bolts	10.8	8	96
Oil Pan Bolts	11.8	8	96
Crankshaft Hub Bolt	275	202	—

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)

DESCRIPTION	N-m	Ft. Lbs.	In. Lbs.
Front Engine Cover Bolts	11.8	8	96
Transmission to Engine Bolts	83.4	62	—
Cylinder Head Cover / Intake Manifold Bolts	27.5	20	—
Camshaft Access Plugs	80	59	—
Oil Separator Bolts	10.8	8	96
Camshaft Position Sensor Bolt	10.8	8	96
Boost Pressure / Intake Air Temp. Sensor Bolts	5.4	—	48
Accessory Drive Bracket Bolts	47.1	35	—
Vacuum Line Fitting Bolt	56.9	42	—
Rail Pressure Sensor	35	26	—
Fuel Pump Nuts	27.5	21	—
Fuel Line Fittings at Pump	27.5	21	—
Inner Timing Belt Cover Bolts			
8mm	10.8	8	96
10mm	47.1	35	—
Outer Timing Belt Cover Bolts			
3mm	6	—	54
8mm	10.8	8	96
Engine Mount Bracket to Cylinder Head Bolts	47.1	35	—
Intake Inlet Tube Bolts	10.1	8	89
Camshaft Sprocket Bolts	108	80	—
Timing Belt Idler Pulley Bolt	47.1	35	—
Timing Belt Tensioner Bolt	34.7	26	—
Fuel Pump Nut	88.3	65	—
Engine Lift Hook Bolts	32.4	24	—
Thermostat Housing Bolts	27.5	21	—
Turbocharger Oil Feed Line Fitting	24.5	18	217
Exhaust Manifold Nuts (Must recheck each nut after tightening sequence is completed)	36	26.5	—
Exhaust Manifold Heatshield Bolts	27.5	21	—
EGR Valve Nuts	32.4	24	—
EGR Pipe to EGR Bolts	32.4	24	—
Turbocharger Downpipe Nuts	32.4	24	—
Turbocharger Bracket Bolts	47.1	35	—
Vibration Damper to Crankshaft Hub Bolts	27.5	21	—
Crankshaft Support Bolts	44.1	33	—
Turbocharger to Exhaust Manifold Nuts	32.4	24	—


ENGINE 2.5L/2.8 TURBO DIESEL (Continued)

SPECIAL TOOLS




803fd6a2

VM.1001 CYLINDER LINER PULLER




80a1aa46

VM.1013 DIAL INDICATOR




803fd6a6

VM.1005 TORQUE ANGLE GAUGE




808bb90a

VM.1076 CYLINDER RETAINER



80a1aa43


VM.1010 CYLINDER LINER PROTRUSION TOOL



8120d646


VM.1050 CRANKSHAFT REAR SEAL INSTALLER

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)




80c1426c

VM.1051 2.5L-TDC ALIGNMENT PIN




80c1449e

VM.1053 EXHAUST CAMSHAFT ALIGNMENT PIN



80c143ba

VM.1052 INTAKE CAMSHAFT ALIGNMENT PIN



80c14546


**VM.1054 RELIEF VALVE REMOVER/CENTRAL
CARRIER PIN REMOVER/INSTALLER**

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)




80c13cec

**VM.1055 CAMSHAFT/HIGH PRESSURE INJECTION
PUMP GEAR HOLDER**




80c17320

VM.1056 BALANCE SHAFT LOCKING PIN




8121483c

VM.1057 CAMSHAFT OIL SEAL INSTALLER



81214825


VM.1058 CAMSHAFT OIL SEAL REMOVER



80c1570a


VM.1059 OIL PRESSURE RELIEF VALVE INSTALLER

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)




80c17f19

VM.1060 OIL JET REMOVER /INSTALLER




80c17ba4

VM.1062 POWER STEERING PUMP INSTALLER



80c17810


**VM.1061 FRONT COVER AND FRONT OIL SEAL
INSTALLER**



80c17fce


**VM.1064 POWER STEERING PUMP GEAR
REMOVER**

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)




80c17f56

VM.1065 2.5L PISTON RING COMPRESSOR




8120d627

VM.1067 HIGH PRESSURE PUMP REMOVER



80c177d0


VM.1066 VALVE COVER ALIGNMENT PINS



80c141ef


VM.1068 90 DEGREES AFTER TDC ALIGNMENT PIN

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)




80c17f51

VM.1069 CRANKSHAFT REM/INSTALL SLEEVE




80c172d1

VM.1072 COMPRESSION TESTER ADAPTER



8120d5f5


VM.1070 FLYWHEEL LOCKING TOOL



80c17883


**VM.1073 CRANKSHAFT FRONT BEARING
REMOVER/INSTALLER**

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)




80c1727c

VM.1074 TIMING BELT RETAINER




80c17b55

VM.1075 FLYWHEEL ALIGNMENT PINS




80c499af

VM.1077 POWER STEERING BELT REMOVER



8121485c

VM.1079 CENTRAL CARRIER ALIGNMENT PINS



8121521d


VM.1083 2.8L-TDC LOCATING PIN

ENGINE 2.5L/2.8 TURBO DIESEL (Continued)

AIR CLEANER HOUSING


REMOVAL

- (1) Disconnect the negative battery cable.
- (2) Disconnect the air inlet hose from the air cleaner housing cover (Fig. 11).




8121521e

VM.1084 2.8L 90 DEGREES AFTER TDC LOCATING PIN




VM.9075 FUEL INJECTOR EXTRACTOR



81214789

VM.9095 CRANKSHAFT SUPPORT RETAINER



8124b984

Fig. 11 AIR CLEANER HOUSING

- 1 - AIR CLEANER HOUSING
- 2 - AIR DUCT
- 3 - MASS AIR FLOW SENSOR
- 4 - LOCATING PIN
- 5 - LOCATING RINGS
- 6 - BOLT

(3) Remove the air duct from the air cleaner housing cover.

(4) Remove the bolt for air cleaner housing at upper radiator cross member.

(5) Pull air cleaner housing up and off over the locating pins.

(6) Remove housing from vehicle.

INSTALLATION

(1) Install air cleaner housing into vehicle and onto the locating pins (Fig. 11).

(2) Install bolt to hold housing to the upper radiator cross member.

(3) Install the air inlet duct to the housing.

(4) Connect the air inlet hose to the housing.

(5) Connect the negative battery cable.

CYLINDER HEAD

STANDARD PROCEDURE

STANDARD PROCEDURE - VALVE SERVICE

This procedure is done with the engine cylinder head removed from the block.

DISASSEMBLY

(1) Remove the engine cylinder head from the cylinder block. Refer to cylinder head removal and installation in this section.

(2) Use Valve Spring Compressor Tool and compress each valve spring.

(3) Remove the valve locks, retainers, and springs.

(4) Inspect and remove any burrs on the top of the valve stem, especially around the groove for the locks.

(5) Remove the valves, and place them in a rack in the same order as removed.

VALVE CLEANING

(1) Clean all carbon deposits from the combustion chambers, valve ports, valve stems, valve stem guides and head.

(2) Clean all build-up and gasket material from the engine cylinder head machined gasket surface.

INSPECTION

(1) Inspect for cracks in the combustion chambers and valve ports.

(2) Inspect for cracks on the exhaust seat.

(3) Inspect for cracks in the gasket surface at each coolant passage.

(4) Inspect valves for burned, cracked or warped heads.

(5) Inspect for scuffed or bent valve stems.

(6) Replace valves displaying any damage.

(7) Check valve spring height.

VALVE REFACING


(1) Use a valve refacing machine to reface the intake and exhaust valves to the specified angle.

(2) After refacing, a margin of at least 4.52-4.49 mm (.178-.177 inch) must remain (Fig. 12). If the margin is less than 4.49 mm (.177 inch), the valve must be replaced.

VALVE SEAT REFACING

(1) Install a pilot of the correct size in the valve guide bore. Reface the valve seat to the specified angle with a good dressing stone. Remove only enough metal to provide a smooth finish.

(2) Use tapered stones to obtain the specified seat width when required.



80a2d942

Fig. 12 VALVE SPECS.

MEASUREMENT	INTAKE	EXHAUST
A	7.940-7.960	7.922-7.940
B	8.00-8.015	8.000-8.015
C	1.08-1.34	0.990-1.250 +0.07
D	2.2 ± 0.08	2.09 -0.09
E	1.80-2.20	1.65-2.05
F	2.73-3.44	2.45-3.02
G	41.962-41.985	35.964-35.987
H	42.070-42.086	36.050-36.066
I	7.14-7.19	7.00-7.05
L	3.11-3.26	3.10-3.25

CYLINDER HEAD (Continued)


VALVE STAND DOWN

Valve stand down is to maintain the adequate compression ratio.

- (1) Invert cylinder head.
- (2) Fit each valve to its respective valve guide.
- (3) Using a straight edge and feeler gauge, check valve head stand down: Inlet valve head stand down 1.08 to 1.34 mm (.042 to .052 ins.) and exhaust valve stand down .99 to 1.25 mm (.035 to .049 ins.).
- (4) If valve head stand down is not in accordance with above, discard original valves, check stand down with new valves and recut valve seat inserts to obtain correct stand down.

VALVE GUIDES

- (1) Valve Guides height requirement.
- (2) Measurement A (Fig. 13): 16.50 - 17.00 mm.
- Measurement B : 14.50 - 15.00 mm.



80e026d4

Fig. 13 VALVE GUIDE HEIGHT

VALVE STEM-TO-GUIDE CLEARANCE MEASUREMENT


- (1) Measure and record internal diameter of valve guides. Valve guide internal diameter is 8.0 to 8.015 mm (.3149 to .3155 ins.).
- (2) Measure valve stems and record diameters. Intake valve stem diameter 7.94 to 7.96 mm (.3125 to .3133 in). Exhaust valve stem diameter 7.92 to 7.94 mm (.3118 to .31215 in).

- (3) Subtract diameter of valve stem from internal diameter of its respective valve guide to obtain valve stem clearance in valve guide. Clearance of inlet valve stem in valve guide is .040 to .075 mm (.0015 to .0029 in). Clearance of exhaust valve stem in valve guide is .060 to .093 mm (.0023 to .0036 in).

- (4) If valve stem clearance in valve guide exceeds tolerances, new valve guides must be installed.

STANDARD PROCEDURE - MEASURING PISTON PROTRUSION

- (1) Use special tool VM.1010 with dial indicator special tool VM.1013 (Fig. 14).



811454e4

Fig. 14 PISTON PROTRUSION

- (2) Bring the piston of cylinder no. 1 exactly to top dead center.
- (3) Zero the dial indicator on the cylinder block mating surface.
- (4) Setup the dial indicator on the piston crown (above the center of the piston pin) 5mm (1/8 in.) from the edge of the piston and note the measurement (Fig. 14).
- (5) Repeat the procedure with the rest of the cylinders.
- (6) Establish the thickness of the steel gasket by averaging the four piston protrusion readings.

CYLINDER HEAD (Continued)

Measure Dimension (mm)	0.460-0.609
Cylinder Head Gasket Thickness (mm)	1.32 No Holes or Notches
Piston Clearance (mm)	0.71-0.86
Measure Dimension (mm)	0.610-0.709
Cylinder Head Gasket Thickness (mm)	1.42 1 Hole or Notch
Piston Clearance (mm)	0.711-0.81
Measure Dimension (mm)	0.710-0.810
Cylinder Head Gasket Thickness (mm)	1.52 2 Holes or Notches
Piston Clearance (mm)	0.71-0.81

REMOVAL

- (1) Disconnect negative battery cable.
- (2) Remove front wiper unit (Refer to 8 - ELECTRICAL/WIPERS/WASHERS/WIPER MODULE - REMOVAL).
- (3) Remove engine cover (Refer to 9 - ENGINE - REMOVAL).
- (4) Drain cooling system (Refer to 7 - COOLING/ENGINE/COOLANT - STANDARD PROCEDURE).
- (5) Remove power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (6) Remove accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (7) Remove generator (Refer to 8 - ELECTRICAL/CHARGING/GENERATOR - REMOVAL).
- (8) Support engine and remove right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - REMOVAL).


CAUTION: Before removing the cylinder head cover/intake manifold or timing belt the engine must put at 90° after TDC. Failure to do so could result in valve and/or piston damage during reassembly. (Refer to 9 - ENGINE/VALVE TIMING - STANDARD PROCEDURE)

(9) Remove timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).

(10) Remove timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - REMOVAL).

(11) Remove timing belt inner cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).

(12) Remove cylinder head cover/intake manifold (Fig. 15)(Refer to 9 - ENGINE/CYLINDER HEAD/CYLINDER HEAD COVER(S) - REMOVAL).



8122a525

Fig. 15 CYLINDER HEADCOVER/INTAKE MANIFOLD ASSEMBLY

- 1 - CYLINDER HEAD COVER/INTAKE MANIFOLD BOLTS(LONG)
- 2 - CYLINDER HEAD COVER/INTAKE MANIFOLD
- 3 - CYLINDER HEAD
- 4 - CYLINDER HEAD COVER/INTAKE MANIFOLD GASKET
- 5 - CYLINDER HEAD COVER/INTAKE MANIFOLD BOLTS(SHORT)

(13) Remove rocker arm and lifter assemblies from cylinder head.

(14) Remove cylinder head cover/intake manifold gasket from cylinder head (Fig. 15).


(15) Disconnect glow plug and engine coolant temperature electrical connectors.

CYLINDER HEAD (Continued)

(16) Remove coolant recovery pressure container (Refer to 7 - COOLING/ENGINE/COOLANT RECOVERY PRESS CONTAINER - REMOVAL).

(17) Remove thermostat housing to upper radiator hose pipe (Fig. 16).

(18) Remove turbocharger outlet to charge air cooler pipe (Fig. 16).



813c580a

Fig. 16 TURBOCHARGER AND COOLANT PIPES

- 1 - TURBOCHARGER OUTLET PIPE RETAINING BOLT
- 2 - TURBOCHARGER OUTLET PIPE
- 3 - ADAPTOR HOSE
- 4 - HOSE CLAMPS
- 5 - TURBOCHARGER INLET PIPE RETAINING BOLT
- 6 - TURBOCHARGER INLET PIPE
- 7 - ADAPTOR HOSE
- 8 - HOSE CLAMPS
- 9 - EGR VALVE TO INTAKE AIR INLET PIPE
- 10 - CLAMP
- 11 - THERMOSTAT HOUSING TO UPPER RADIATOR HOSE PIPE

(19) Remove exhaust manifold heat shield (Fig. 17).

(20) Remove exhaust manifold retaining nuts (Fig. 17).


(21) Slide exhaust manifold and turbocharger off of exhaust manifold studs (Fig. 17).

(22) Remove cylinder head bolts.

(23) Remove cylinder head assembly from engine block (Fig. 18).

CLEANING

Thoroughly clean the engine cylinder head and cylinder block mating surfaces. Clean the intake and exhaust manifold and engine cylinder head mating surfaces. Remove all gasket material and carbon.



80fe9d3c

Fig. 17 EXHAUST MANIFOLD AND TURBOCHARGER

- 1 - TURBOCHARGER OIL SUPPLY BANJO BOLT
- 2 - COPPER WASHER
- 3 - EXHAUST MANIFOLD GASKET
- 4 - COPPER WASHER
- 5 - TURBOCHARGER
- 6 - HEAT SHIELD RETAINING BOLT
- 7 - ENGINE LIFT HOOK
- 8 - LIFT HOOK RETAINING BOLT
- 9 - EXHAUST MANIFOLD RETAINING NUT
- 10 - TURBOCHARGER RETURN HOSE
- 11 - EXHAUST MANIFOLD STUD

Check to ensure that no coolant or foreign material has fallen into the tappet bore area.

Remove the carbon deposits from the combustion chambers and top of the pistons.

INSPECTION


Use a straightedge and feeler gauge to check the flatness of the engine cylinder head and block mating surfaces.

The minimum cylinder head thickness is 89.95mm (3.541 in.).

INSTALLATION

CAUTION: Piston protrusion must be measured to determine cylinder head gasket thickness if one or more cylinder liners have been replaced (Refer to 9 - ENGINE/CYLINDER HEAD - STANDARD PROCEDURE).

CYLINDER HEAD (Continued)



81246ed5

Fig. 18 CYLINDER HEAD ASSEMBLY

- 1 - VALVE SPRING
- 2 - CYLINDER HEAD BOLT
- 3 - GLOW PLUG
- 4 - COOLANT TEMPERATURE SENSOR
- 5 - CYLINDER HEAD ALIGNMENT DOWEL
- 6 - CYLINDER BLOCK
- 7 - CYLINDER LINER
- 8 - ENGINE BLOCK DECK
- 9 - CYLINDER HEAD GASKET
- 10 - CYLINDER HEAD
- 11 - ROCKER ARM AND LIFTER ASSEMBLY


NOTE: If cylinder liner(s) have not been removed, the same thickness head gasket that was removed can be used.

- (1) Clean and inspect gasket mating surfaces.
- (2) Position correct head gasket on engine block.
- (3) Place cylinder head on engine block (Fig. 18).

CAUTION: New cylinder head bolts must be used.

(4) Tighten cylinder head bolts following procedure below:

- Lubricate the new cylinder head bolts with engine oil.
- Torque bolts to 30N·m in numerical starting with bolt #1 (Fig. 19).
- Tighten all bolts an additional 75°, starting with bolt #4 then 5-6-7-8-9-10-1-2-3 (Fig. 19).
- Tighten all bolts an additional 50° in numerical order starting with bolt #11 then 12-13-14-15-16-17-18 (Fig. 19).
- Without loosening any bolts tighten all bolts an additional 75° in the following sequence: 4-5-6-7-8-9-10-1-2-3-11-12-13-14-15-16-17-18.



80c5ddfe

Fig. 19 CYLINDER HEAD TORQUE SEQUENCE

(5) Slide exhaust manifold and turbocharger on exhaust manifold studs (Fig. 20).

(6) Install exhaust manifold retaining nuts. Torque nuts to 32.4N·m.

(7) Install exhaust manifold heat shield (Fig. 20). Torque bolts to 27.5N·m.

(8) Install turbocharger outlet to charge air cooler pipe (Fig. 21).

(9) Install thermostat housing to upper radiator hose pipe (Fig. 21). Install retaining bolt and torque to 47.1N·m.

(10) Install coolant recovery pressure container (Refer to 7 - COOLING/ENGINE/COOLANT RECOVERY PRESS CONTAINER - INSTALLATION).

(11) Connect glow plug and coolant temperature sensor electrical connectors.

(12) Install new cylinder head cover/intake manifold gasket.

(13) Install rocker arm and lifter assemblies. **Be sure to put rocker arm and lifter assemblies in same location as removed.**


(14) Install cylinder head cover/intake manifold (Fig. 15)(Refer to 9 - ENGINE/CYLINDER HEAD/CYLINDER HEAD COVER(S) - INSTALLATION).

(15) Install timing belt inner cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

(16) Install timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - INSTALLATION).

(17) Install timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

CYLINDER HEAD (Continued)



80fe9d3c

Fig. 20 EXHAUST MANIFOLD AND TURBOCHARGER

- 1 - TURBOCHARGER OIL SUPPLY BANJO BOLT
- 2 - COPPER WASHER
- 3 - EXHAUST MANIFOLD GASKET
- 4 - COPPER WASHER
- 5 - TURBOCHARGER
- 6 - HEAT SHIELD RETAINING BOLT
- 7 - ENGINE LIFT HOOK
- 8 - LIFT HOOK RETAINING BOLT
- 9 - EXHAUST MANIFOLD RETAINING NUT
- 10 - TURBOCHARGER RETURN HOSE
- 11 - EXHAUST MANIFOLD STUD

(18) **Remove crankshaft and both camshaft locking pins at this time** (Refer to 9 - ENGINE/ VALVE TIMING - STANDARD PROCEDURE) .

(19) Install generator (Refer to 8 - ELECTRICAL/ CHARGING/GENERATOR - INSTALLATION).

(20) Install accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(21) Install power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(22) Install right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - INSTALLATION).


(23) Install air cleaner housing assembly.

(24) Refill cooling system (Refer to 7 - COOLING/ ENGINE/COOLANT - STANDARD PROCEDURE).

(25) Install engine cover (Refer to 9 - ENGINE - INSTALLATION).

(26) Install front wiper unit (Refer to 8 - ELEC- TRICAL/WIPERS/WASHERS/WIPER MODULE - INSTALLATION).

(27) Connect negative battery cable.



813c580a


Fig. 21 TURBOCHARGER AND COOLANT PIPES

- 1 - TURBOCHARGER OUTLET PIPE RETAINING BOLT
- 2 - TURBOCHARGER OUTLET PIPE
- 3 - ADAPTOR HOSE
- 4 - HOSE CLAMPS
- 5 - TURBOCHARGER INLET PIPE RETAINING BOLT
- 6 - TURBOCHARGER INLET PIPE
- 7 - ADAPTOR HOSE
- 8 - HOSE CLAMPS
- 9 - EGR VALVE TO INTAKE AIR INLET PIPE
- 10 - CLAMP
- 11 - THERMOSTAT HOUSING TO UPPER RADIATOR HOSE PIPE

CAMSHAFT(S)

DESCRIPTION

The camshafts are made of gray cast iron with eight machined lobes and four bearing journals (Fig. 22).



80c58df5

Fig. 22 CAMSHAFTS

- 1 - INTAKE CAMSHAFT
- 2 - EXHAUST CAMSHAFT

CAMSHAFT(S) (Continued)

OPERATION


When the camshaft rotates the lobes actuate the hydraulic lifters and rocker arms, forcing downward on the rocker arms which opens the valves.

REMOVAL

- (1) Disconnect negative battery cable.
- (2) Remove front wiper unit (Refer to 8 - ELECTRICAL/WIPERS/WASHERS/WIPER MODULE - REMOVAL).
- (3) Remove engine cover (Refer to 9 - ENGINE - REMOVAL).
- (4) Drain cooling system (Refer to 7 - COOLING/ENGINE/COOLANT - STANDARD PROCEDURE).
- (5) Remove air cleaner housing.
- (6) Remove power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (7) Remove accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (8) Remove generator (Refer to 8 - ELECTRICAL/CHARGING/GENERATOR - REMOVAL).
- (9) Support engine and remove right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - REMOVAL).

CAUTION: Before removing the cylinder head cover/intake manifold or timing belt the engine must put at 90° after TDC. Failure to do so could result in valve and/or piston damage during reassembly. (Refer to 9 - ENGINE/VALVE TIMING - STANDARD PROCEDURE)

- (10) Remove timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).
- (11) Remove timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - REMOVAL).
- (12) Remove timing belt inner cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).
- (13) Remove cylinder head cover/intake manifold (Refer to 9 - ENGINE/CYLINDER HEAD/CYLINDER HEAD COVER(S) - REMOVAL).
- (14) With cylinder head cover/intake manifold on work bench, remove plugs at rear of cylinder head cover/intake manifold.
- (15) Remove camshaft oil seals (Fig. 23).
- (16) Remove snapping and thrust washer from camshaft (Fig. 23).
- (17) Slide camshaft through access hole at rear of cylinder head cover/intake manifold.



8120342e

Fig. 23 CAMSHAFT ASSEMBLY

- 1 - INTAKE CAMSHAFT
- 2 - SNAPPING
- 3 - CAMSHAFT OIL SEAL
- 4 - THRUST WASHER
- 5 - CYLINDER HEAD COVER/INTAKE MANIFOLD
- 6 - EXHAUST MANIFOLD

INSTALLATION

- (1) Lubricate the camshafts with Mopar® Engine Oil Supplement, or equivalent.
- (2) Carefully install camshafts into access holes in rear of cylinder head cover/intake manifold.
- (3) Install thrust washer, snap ring, and camshaft oil seal (Fig. 23).
- (4) After camshafts are properly installed in cylinder head cover check end play of camshafts with a dial indicator. The end play should be between .10 mm – .55 mm.

NOTE: If the camshaft end play is not within specification, measure thickness of the camshaft spacer. Camshaft spacer thickness should be $2.8 \pm .02\text{mm}$.

- (5) Install access hole plugs and gaskets at rear of cylinder head cover/intake manifold. Torque plugs to 80N·m.
- (6) Install cylinder head cover/intake manifold on engine block (Refer to 9 - ENGINE/CYLINDER HEAD/CYLINDER HEAD COVER(S) - INSTALLATION).
- (7) Install timing belt inner cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

CAMSHAFT(S) (Continued)

(8) Install timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - INSTALLATION).

(9) Install timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

(10) Install right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - INSTALLATION).

(11) Install generator (Refer to 8 - ELECTRICAL/CHARGING/GENERATOR - INSTALLATION).

(12) Install accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).


(13) Install power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(14) Install air cleaner housing.

(15) Refill cooling system (Refer to 7 - COOLING/ENGINE/COOLANT - STANDARD PROCEDURE).

(16) Install front wiper unit (Refer to 8 - ELECTRICAL/WIPERS/WASHERS/WIPER MODULE - INSTALLATION).

(17) Connect negative battery cable.



81203537

Fig. 24 CYLINDER HEAD COVER/INTAKE MANIFOLD

CYLINDER HEAD COVER(S)

DESCRIPTION

The cylinder head cover is made of cast aluminum and is also the intake manifold on this engine. The cylinder head cover is equipped with a double breather port and an internal oil return pipe (Fig. 24).

REMOVAL

REMOVAL

CAUTION: Before removing the cylinder head cover/intake manifold the engine must put at 90° after TDC. Failure to do so could result in valve and/or piston damage during reassembly. (Refer to 9 - ENGINE/VALVE TIMING - STANDARD PROCEDURE)

(1) Disconnect negative battery cable.

(2) Remove front wiper unit (Refer to 8 - ELECTRICAL/WIPERS/WASHERS/WIPER MODULE - REMOVAL).

(3) Remove engine cover (Refer to 9 - ENGINE - REMOVAL).

(4) Drain cooling system (Refer to 7 - COOLING/ENGINE/COOLANT - STANDARD PROCEDURE).

(5) Rotate engine until 90° after TDC is reached. Install both camshaft locking pins and the crankshaft locking pin. (Refer to 9 - ENGINE/VALVE TIMING - STANDARD PROCEDURE)

(6) Remove air cleaner housing assembly.

(7) Remove power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).

(8) Remove accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).

(9) Remove generator (Refer to 8 - ELECTRICAL/CHARGING/GENERATOR - REMOVAL).

(10) Support engine and remove right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - REMOVAL).

(11) Remove outer timing belt cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).

(12) Remove timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - REMOVAL).

(13) Remove inner timing belt cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).

(14) Disconnect camshaft position sensor, boost pressure/intake air temperature sensor, EGR solenoid, and fuel pressure sensor electrical connectors (Fig. 25).

(15) Disconnect vacuum lines at EGR solenoid.

(16) Position electrical harness out of way.

(17) Remove fuel injectors (Refer to 14 - FUEL SYSTEM/FUEL INJECTION/FUEL INJECTOR - REMOVAL).

(18) Remove fuel rail (Refer to 14 - FUEL SYSTEM/FUEL DELIVERY/FUEL RAIL - REMOVAL).

CYLINDER HEAD COVER(S) (Continued)




Fig. 25 ENGINE COMPONENT LOCATIONS

- 1 - FUEL INJECTOR RETURN LINE
- 2 - FUEL INJECTOR SUPPLY LINE
- 3 - OIL SEPARATOR
- 4 - FUEL INJECTOR
- 5 - CAMSHAFT POSITION SENSOR
- 6 - BOOST PRESSURE/INTAKE AIR TEMPERATURE SENSOR
- 7 - EGR SOLENOID
- 8 - FUEL PRESSURE SENSOR
- 9 - CYLINDER HEAD COVER/INTAKE MANIFOL
- 10 - FUEL RAIL
- 11 - WIRING HARNESS RETAINING CLIPS




Fig. 26 CYLINDER HEAD COVER/INTAKE MANIFOLD ASSEMBLY

- 1 - CYLINDER HEAD COVER/INTAKE MANIFOLD BOLTS(LONG)
- 2 - CYLINDER HEAD COVER/INTAKE MANIFOLD
- 3 - CYLINDER HEAD
- 4 - CYLINDER HEAD COVER/INTAKE MANIFOLD GASKET
- 5 - CYLINDER HEAD COVER/INTAKE MANIFOLD BOLTS(SHORT)

(19) Remove power steering pump reservoir from bracket.

(20) Remove oil dipstick tube retaining bolt at intake manifold inlet.

(21) Disconnect oil separator outlet hose at separator.

(22) Remove turbo inlet tube retaining bolt at intake manifold.

(23) Disconnect EGR tube at intake manifold inlet tube.

(24) Remove cylinder head cover/intake manifold retaining bolts (Fig. 26).

(25) Lift cylinder head cover/intake manifold from cylinder head (Fig. 26).

NOTE: While cleaning the oil return passage in the cylinder head cover, be sure to clean the drain back tube in the cylinder head as well.

(26) Clean the oil return hole in the oil separator access hole with compressed air (Fig. 27).





Fig. 27 OIL RETURN PASSAGE

- 1 - CYLINDER HEAD COVER/INTAKE MANIFOLD
- 2 - OIL RETURN PASSAGE

CYLINDER HEAD COVER(S) (Continued)

NOTE: When removing rocker arm and lifter assemblies, be sure to keep them in order as they were removed from the cylinder head. Always keep lifters in an upright position when removed from cylinder head.

(27) Remove rocker arm and lifter assemblies from cylinder head (Fig. 28).



80c5d515

Fig. 28 CYLINDER HEAD COVER/INTAKE MANIFOLD GASKET LOCATION


- 1 - THERMOSTAT HOUSING
- 2 - ROCKER ARM AND LIFTER ASSEMBLY
- 3 - CYLINDER HEAD COVER/INTAKE MANIFOLD
- 4 - CYLINDER HEAD

(28) Remove cylinder head cover/intake manifold gasket from cylinder head.

REMOVAL

- (1) Disconnect the negative battery cable.
- (2) Remove the engine cover (Refer to 9 - ENGINE - REMOVAL).
- (3) Remove the engine oil separator fastener and remove the separator (Fig. 29).
- (4) Using compressed air, blow out the oil drain back passage in the cylinder head cover/intake manifold assembly.

NOTE: If the cylinder head cover/intake manifold is removed, be sure to clean the oil drain back tube as well.



8122b7a9

Fig. 29 ENGINE OIL SEPARATOR

- 1 - SCREW
- 2 - ENGINE OIL SEPARATOR
- 3 - O-RINGS

INSTALLATION

INSTALLATION

- (1) Clean and inspect sealing surfaces.
- (2) Clean and inspect the breather oil return passage in the cylinder head/intake manifold cover (Fig. 27).
- (3) Install new gasket on cylinder head.

NOTE: Apply a small amount of grease on each valve stem. This will help hold the rocker arm in position during the cylinder head cover installation.

(4) Install rocker arm and lifter assemblies in cylinder head (Fig. 28). **Be sure to put rocker arm and lifter assemblies in same location as removed.**

(5) Install cylinder head cover/intake manifold alignment studs in cylinder head (Fig. 30).

(6) Install cylinder head cover/intake manifold over alignment stud.

NOTE: Be sure to lubricate cylinder head cover/intake manifold retaining bolts with engine oil before assembly. If new bolts are being installed, **DO NOT** lubricate before assembly.

(7) Install two cylinder head cover/intake manifold retaining bolts and tighten finger tight.

CYLINDER HEAD COVER(S) (Continued)




Fig. 30 CYLINDER HEAD COVER/INTAKE MANIFOLD ALIGNMENT STUDS VM.1066

1 - CYLINDER HEAD COVER/INTAKE MANIFOLD ALIGNMENT STUDS VM.1066
2 - CYLINDER HEAD

(8) Remove alignment studs and install remaining retaining bolts (Fig. 26). Tighten retaining bolts finger tight.

(9) Torque cylinder head cover/intake manifold retaining bolts following procedure below.

CYLINDER HEAD COVER/INTAKE MANIFOLD TIGHTENING PROCEDURE

- Coat all bolts being reused with clean engine oil.
 - Install the M8x35 bolts into holes 1,2,3,4,5, and 12. Install the M8x85 bolts into holes 6,7,8,9,10,11,13,14,15, and 16. Tighten all bolt **hand tight**.
 - Alternate between bolts #11 and #16 to seat cylinder head cover/intake manifold on cylinder head (Fig. 31). Torque bolts to 7 N·m.
 - Torque all cylinder head cover/intake manifold retaining bolts to 25 N·m in numerical order starting with #1 and ending with #16 (Fig. 31).
- (10) Connect EGR tube at intake manifold inlet tube. Torque clamp to 10.8 N·m.
- (11) Install turbo inlet tube retaining bolt at intake manifold. Torque bolt to 27.5 N·m.
- (12) Connect oil separator outlet hose at separator.
- (13) Install oil dipstick tube retaining bolt at intake manifold inlet. Torque bolt to 10 N·m.
- (14) Install power steering pump reservoir in bracket.




Fig. 31 CYLINDER HEAD COVER/INTAKE MANIFOLD TIGHTENING SEQUENCE

(15) Install fuel rail (Refer to 14 - FUEL SYSTEM/FUEL DELIVERY/FUEL RAIL - INSTALLATION).

(16) Install fuel injectors and fuel injector supply lines (Refer to 14 - FUEL SYSTEM/FUEL INJECTION/FUEL INJECTOR - INSTALLATION).

(17) Connect vacuum lines at EGR solenoid.

(18) Clip wiring harness retainers on studs on fuel rail (Fig. 25).

(19) Connect camshaft position sensor, boost pressure/intake air temperature sensor, EGR solenoid, and fuel pressure sensor electrical connectors (Fig. 25).

(20) Install inner timing belt cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

(21) Install timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - INSTALLATION).

(22) Install outer timing belt cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

(23) Install right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - INSTALLATION).

(24) Install generator (Refer to 8 - ELECTRICAL/CHARGING/GENERATOR - INSTALLATION).

(25) Install accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(26) Install power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

812035ae

CYLINDER HEAD COVER(S) (Continued)

- (27) Install air cleaner housing assembly.
- (28) Remove crankshaft and both camshaft locking pins (Refer to 9 - ENGINE/VALVE TIMING - STANDARD PROCEDURE).
- (29) Refill cooling system (Refer to 7 - COOLING/ENGINE/COOLANT - STANDARD PROCEDURE).
- (30) Install engine cover (Refer to 9 - ENGINE - INSTALLATION).
- (31) Install front wiper unit (Refer to 8 - ELECTRICAL/WIPERS/WASHERS/WIPER MODULE - INSTALLATION).
- (32) Connect negative battery cable.

INSTALLATION

NOTE: Using compressed air, blow out the oil return passage in the cylinder head cover/ intake manifold assembly. If the cylinder head cover/intake manifold has been removed, be sure to clean the oil drain back tube as well.

- (1) Lubricate the O-rings with clean engine oil and position in the cover (Fig. 29).
- (2) Seat the oil separator, being careful not to damage the O-rings (Fig. 29).
- (3) Install the retaining fastener and torque the bolt to 10.8 N·m (8 lbs. ft.).
- (4) Install the engine cover (Refer to 9 - ENGINE - INSTALLATION).
- (5) Connect the negative battery cable.


CAMSHAFT OIL SEAL(S)

REMOVAL

- (1) Disconnect negative battery cable.
- (2) Remove air cleaner housing assembly.
- (3) Support engine and remove right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - REMOVAL).
- (4) Remove outer timing belt cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).

WARNING: Before removing the timing belt the engine must put at 90° after TDC. Failure to do so could result in valve and/or piston damage during reassembly. (Refer to 9 - ENGINE/VALVE TIMING - STANDARD PROCEDURE)

- (5) Remove timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - REMOVAL).
- (6) Using VM.1055, remove both camshaft gears (Fig. 32).
- (7) Remove both camshaft oil seals.




80c5f3ef

Fig. 32 CAMSHAFT GEAR REMOVAL/INSTALLATION

- 1 - TIMING BELT INNER COVER
- 2 - CAMSHAFT SPROCKET
- 3 - IDLER PULLEYS
- 4 - CAMSHAFT SPROCKET
- 5 - VM.1055

INSTALLATION

- (1) Install new camshaft oil seal using VM.1057 (Fig. 33).



812467c0

Fig. 33 CAMSHAFT OIL SEAL INSTALLER

- 1 - VM.1057
- 2 - CAMSHAFT SEAL
- 3 - CYLINDER HEAD COVER/INTAKE MANIFOLD


CAMSHAFT OIL SEAL(S) (Continued)

- (2) Install camshaft sprockets and tighten retaining bolts finger tight.
- (3) Install timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - INSTALLATION).
- (4) Torque camshaft sprockets to 108 N·m using VM.1055 (Fig. 32).
- (5) Install outer timing belt cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).
- (6) Install right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - INSTALLATION).
- (7) Install air cleaner housing assembly.
- (8) Connect negative battery cable.

ROCKER ARMS

DESCRIPTION

The rocker arms are made of stamped steel (Fig. 34).



81246ed5

Fig. 34 CYLINDER HEAD ASSEMBLY


- 1 - VALVE SPRING
- 2 - CYLINDER HEAD BOLT
- 3 - GLOW PLUG
- 4 - COOLANT TEMPERATURE SENSOR
- 5 - CYLINDER HEAD ALIGNMENT DOWEL
- 6 - CYLINDER BLOCK
- 7 - CYLINDER LINER
- 8 - ENGINE BLOCK DECK
- 9 - CYLINDER HEAD GASKET
- 10 - CYLINDER HEAD
- 11 - ROCKER ARM AND LIFTER ASSEMBLY

OPERATION

The rocker arms are used as a link between the camshaft and valves. As the camshaft rotates the lobes of the camshafts apply downward pressure on the rocker arms. This pressure is then transmitted to the valves which causes the valves to open.

REMOVAL

- (1) Disconnect negative battery cable.
- (2) Remove front wiper unit (Refer to 8 - ELECTRICAL/WIPERS/WASHERS/WIPER MODULE - REMOVAL).
- (3) Remove air cleaner housing assembly.
- (4) Support engine and remove right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - REMOVAL).
- (5) Remove outer timing belt cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).
- (6) Remove timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - REMOVAL).
- (7) Remove inner timing belt cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).
- (8) Remove cylinder head cover/intake manifold (Refer to 9 - ENGINE/CYLINDER HEAD/CYLINDER HEAD COVER(S) - REMOVAL).
- (9) Remove rocker arm and lifter (Fig. 35).



80fecfda

Fig. 35 ROCKER ARM ASSEMBLY

- 1 - ROCKER ARM ASSEMBLY
- 2 - CYLINDER HEAD COVER/INTAKE MANIFOLD
- 3 - HYDRAULIC LIFTER
- 4 - CYLINDER HEAD
- 5 - VALVE

ROCKER ARMS (Continued)

INSTALLATION

- (1) Clean and inspect gasket sealing surfaces.
- (2) Install new gasket on cylinder head.
- (3) Lubricate lifter ball end of lifter(s), valve(s), and rocker arm roller(s) with Mopar® Engine Oil Supplement or equivalent.
- (4) Connect rocker arm(s) to lifter and reposition on valve(s) (Fig. 35).
- (5) Install cylinder head cover/intake manifold (Refer to 9 - ENGINE/CYLINDER HEAD/CYLINDER HEAD COVER(S) - INSTALLATION).
- (6) Install inner timing belt cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).
- (7) Install timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - INSTALLATION).
- (8) Install outer timing belt cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).
- (9) Install right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - INSTALLATION).
- (10) Install air cleaner housing assembly.
- (11) Install front wiper unit (Refer to 8 - ELECTRICAL/WIPERS/WASHERS/WIPER MODULE - INSTALLATION).
- (12) Connect negative battery cable.


HYDRAULIC LIFTERS

DESCRIPTION

Valve lash is controlled by hydraulic tappets located inside the cylinder head, in tappet bores below the camshafts (Fig. 36).

REMOVAL

- (1) Disconnect negative battery cable.
- (2) Remove front wiper unit (Refer to 8 - ELECTRICAL/WIPERS/WASHERS/WIPER MODULE - REMOVAL).
- (3) Remove engine cover (Refer to 9 - ENGINE - REMOVAL).
- (4) Support engine and remove right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - REMOVAL).
- (5) Remove outer timing belt cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).



81246ed5


Fig. 36 CYLINDER HEAD ASSEMBLY

- 1 - VALVE SPRING
- 2 - CYLINDER HEAD BOLT
- 3 - GLOW PLUG
- 4 - COOLANT TEMPERATURE SENSOR
- 5 - CYLINDER HEAD ALIGNMENT DOWEL
- 6 - CYLINDER BLOCK
- 7 - CYLINDER LINER
- 8 - ENGINE BLOCK DECK
- 9 - CYLINDER HEAD GASKET
- 10 - CYLINDER HEAD
- 11 - ROCKER ARM AND LIFTER ASSEMBLY

CAUTION: Before removing the cylinder head cover/intake manifold or the timing belt the engine must put at 90° after TDC. Failure to do so could result in valve and/or piston damage during reassembly. (Refer to 9 - ENGINE/VALVE TIMING - STANDARD PROCEDURE)

- (6) Remove timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - REMOVAL).
- (7) Remove inner timing belt cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).
- (8) Remove cylinder head cover/intake manifold (Fig. 37)(Refer to 9 - ENGINE/CYLINDER HEAD/CYLINDER HEAD COVER(S) - REMOVAL).
- (9) Remove rocker arm and lifter assemblies from lifter bores.

HYDRAULIC LIFTERS (Continued)



8122a525

Fig. 37 CYLINDER HEADCOVER/INTAKE MANIFOLD ASSEMBLY

- 1 - CYLINDER HEAD COVER/INTAKE MANIFOLD BOLTS(LONG)
- 2 - CYLINDER HEAD COVER/INTAKE MANIFOLD
- 3 - CYLINDER HEAD
- 4 - CYLINDER HEAD COVER/INTAKE MANIFOLD GASKET
- 5 - CYLINDER HEAD COVER/INTAKE MANIFOLD BOLTS(SHORT)

INSPECTION

Clean each lifter assembly in cleaning solvent to remove all varnish and sludge deposits. Inspect for indications of scuffing on the side and base of each lifter body.

INSTALLATION

- (1) Install rocker arm and lifter assemblies in lifter bores.
- (2) Install cylinder head cover/intake manifold (Fig. 37) (Refer to 9 - ENGINE/CYLINDER HEAD/CYLINDER HEAD COVER(S) - INSTALLATION).
- (3) Install timing belt inner cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).
- (4) Install timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - INSTALLATION).
- (5) Install timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).
- (6) Install right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - INSTALLATION).
- (7) Install engine cover (Refer to 9 - ENGINE - INSTALLATION).


- (8) Install front wiper unit (Refer to 8 - ELECTRICAL/WIPERS/WASHERS/WIPER MODULE - INSTALLATION).

- (9) Connect negative battery cable.

ENGINE BLOCK


DESCRIPTION

The 2.5L/2.8L CRD Diesel engine uses a cast iron engine block with wet cast iron cylinder liners (Fig. 38), (Fig. 39).



80c6aef8

Fig. 38 ENGINE BLOCK 2.5L




813c6834

Fig. 39 ENGINE BLOCK 2.8L

CRANKSHAFT

DESCRIPTION


The crankshaft used for the 2.5L is a forged steel design with five main bearing journals (Fig. 40). The crankshaft used for the 2.8L is of the same basic construction and design except the rear alignment pin is shorter (0.12mm) and the rear crankshaft diameter is slightly larger (0.33mm) (Fig. 41). These crankshafts ARE NOT interchangeable. The crankshaft is located at the bottom of the engine block and is held in place with three main bearing supports



8120b297

Fig. 40 CRANKSHAFT

- 1 - CRANKSHAFT SUPPORT HALVE
- 2 - MAIN BEARING HALVE
- 3 - CRANKSHAFT
- 4 - MAIN BEARING HALVE
- 5 - CRANKSHAFT SUPPORT HALVE
- 6 - MAIN BEARING SUPPORT BOLTS



813c9f68

Fig. 41 2.8L CRANKSHAFT END VIEW

- 1 - DIAMETER
- 2 - CRANKSHAFT
- 3 - REAR ALIGNMENT PIN

OPERATION

The crankshaft transfers force generated by combustion within the cylinder bores to the flywheel or flexplate.

STANDARD PROCEDURE - CHECKING CRANKSHAFT END PLAY

NOTE: Checking crankshaft end play is similar for both the 2.5L and the 2.8L.

- (1) Mount a dial indicator to a stationary point at rear of engine. Locate the probe perpendicular against the flywheel or flex plate (Fig. 42).
- (2) Move the crankshaft all the way to the front of its travel.
- (3) Zero the dial indicator.
- (4) Move the crankshaft all the way to the rear and read dial indicator. For crankshaft end play clearances (Refer to 9 - ENGINE - SPECIFICATIONS) .

CRANKSHAFT (Continued)




Fig. 42 CHECKING CRANKSHAFT END PLAY

- 1 - DIAL INDICATOR
- 2 - ADAPTER PLATE
- 3 - REAR MAIN BEARING SUPPORT
- 4 - SEALING RING
- 5 - SEALING RING
- 6 - ALIGNMENT PIN
- 7 - CRANKSHAFT
- 8 - RELUCTOR WHEEL
- 9 - RELUCTOR WHEEL RETAINING BOLT
- 10 - REAR MAIN BEARING SUPPORT RETAINING BOLTS
- 11 - FLYWHEEL
- 12 - FLYWHEEL BOLTS

REMOVAL

- (1) Remove engine from vehicle (Refer to 9 - ENGINE - REMOVAL).
- (2) Mount engine on an engine stand.
- (3) Drain engine oil and remove oil filter.
- (4) Remove timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).

(5) Remove timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - REMOVAL).

(6) Remove timing belt inner cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).

(7) Remove cylinder head cover/intake manifold (Refer to 9 - ENGINE/CYLINDER HEAD/CYLINDER HEAD COVER(S) - REMOVAL).

(8) Remove cylinder head (Refer to 9 - ENGINE/CYLINDER HEAD - REMOVAL).

(9) Remove flywheel (2.5L), Remove flex plate (2.8L).

(10) Remove rear main bearing support/adapter plate retaining bolts and remove adapter plate (Fig. 43).





Fig. 43 2.5L REAR MAIN BEARING SUPPORT

- 1 - ADAPTER PLATE
- 2 - REAR MAIN BEARING SUPPORT
- 3 - CRANKSHAFT
- 4 - REAR MAIN BEARING SUPPORT RETAINING BOLTS

(11) Remove rear main bearing support by threading two retaining bolts in holes provided. Tighten bolts equally to push main bearing support out of block (Fig. 44), (Fig. 45).

CRANKSHAFT (Continued)



80c6ea3e

**Fig. 44 2.5L REAR MAIN BEARING SUPPORT
REMOVAL**

- 1 - BOLTS
- 2 - REAR MAIN BEARING SUPPORT
- 3 - CRANKSHAFT

(12) Remove front engine cover (Refer to 9 - ENGINE/ENGINE BLOCK/ENGINE COVER - REMOVAL).

(13) Remove crankshaft sprocket.

(14) Remove oil pan (Refer to 9 - ENGINE/LUBRICATION/OIL PAN - REMOVAL).


(15) Remove oil pump pickup tube (Refer to 9 - ENGINE/LUBRICATION/OIL PUMP - REMOVAL).

(16) Remove balance shaft assembly (Refer to 9 - ENGINE/VALVE TIMING/BALANCE SHAFT - REMOVAL).

(17) Remove oil jets (Refer to 9 - ENGINE/LUBRICATION/OIL JET - REMOVAL).

(18) Remove piston and connecting rod assemblies (Refer to 9 - ENGINE/ENGINE BLOCK/PISTON & CONNECTING ROD - REMOVAL).


(19) Slide special tool VM.1069 on crankshaft (Fig. 46).



813ca5c6

**Fig. 45 2.8L REAR MAIN BEARING SUPPORT
REMOVAL**

- 1 - ENGINE BLOCK
- 2 - PLATE
- 3 - REAR MAIN BEARING SUPPORT
- 4 - CRANKSHAFT
- 5 - FLEX PLATE
- 6 - BACKING PLATE
- 7 - BOLTS




80c6ca52

Fig. 46 CRANKSHAFT SLEEVE VM.1069

- 1 - CRANKSHAFT SLEEVE VM.1069
- 2 - ENGINE BLOCK

CRANKSHAFT (Continued)

(20) Using special tool VM.1054, remove crankshaft support retainers (Fig. 47).



**Fig. 47 CRANKSHAFT SUPPORT RETAINERS/
BALANCE SHAFT OIL FEED**

- 1 - CRANKSHAFT SUPPORT RETAINERS/BALANCE SHAFT OIL FEED
- 2 - O-RINGS (3)
- 3 - ENGINE BLOCK
- 4 - CRANKSHAFT SUPPORT RETAINER/BALANCE SHAFT OIL FEED REMOVER - INSTALLER VM.1054

(21) Slide crankshaft out rear of engine block.

INSTALLATION

CAUTION: IT IS CRITICAL THAT BOTH HALVES OF THE CRANKSHAFT SUPPORT ARE ALIGNED PROPERLY WITH THE ENGINE TO SUPPORT ENGINE OIL MANAGEMENT.

NOTE: Before installing crankshaft in engine block, be sure the notches in the crankshaft supports are facing towards the front of the engine.

(1) Install crankshaft in engine block. **Be sure to align oil holes in crankshaft supports and engine block.**

NOTE: There are two identical holes in the crankshaft support. Care must be taken to insert the special tool into the correct hole (Fig. 48).

(2) Insert crankshaft alignment dowel into the vacuum pump access hole, through the proper crankshaft support holes, then slide the tool guide flush against the engine block and retain with a vacuum pump retaining bolt (Fig. 48).




Fig. 48 CRANKSHAFT SUPPORT ALIGNMENT

- 1 - CRANKSHAFT ALIGNMENT TOOL VM9095
- 2 - BALANCE SHAFT OIL SUPPLY

NOTE: Before installing the crankshaft support retainers/balance shaft oil supply be sure that special tool VM 1079, alignment pins, and VM 9095 are installed (Fig. 49).

(3) Install crankshaft support retainers using special tool VM 1054. (Fig. 47).

(4) Install crankshaft support retainers O-rings.

(5) Remove special tool VM.1069 from crankshaft (Fig. 46).

(6) Remove special tool VM 9095 from the engine block.


(7) Install crankshaft sprocket.

(8) Install front engine cover (Refer to 9 - ENGINE/ENGINE BLOCK/ENGINE COVER - INSTALLATION).

(9) Install rear main bearing support in engine block. **Be sure to align oil hole in rear main bearing support with hole in block.**

(10) Install adapter plate and retaining bolts (Fig. 43). Torque bolts to 27.5N·m.

CRANKSHAFT (Continued)



80fefdaf

**Fig. 49 CRANKSHAFT SUPPORT RETAINERS/
BALANCE SHAFT OIL SUPPLY ALIGNMENT PINS**


- 1 - ENGINE BLOCK
2 - ALIGNMENT PINS VM 1079

- (11) Install flywheel (2.5L), Install flex plate (2.8L).
- (12) Install piston and connecting rod assemblies (Refer to 9 - ENGINE/ENGINE BLOCK/PISTON & CONNECTING ROD - INSTALLATION).
- (13) Install oil jets (Refer to 9 - ENGINE/LUBRICATION/OIL JET - INSTALLATION).
- (14) Install balance shaft assembly (Refer to 9 - ENGINE/VALVE TIMING/BALANCE SHAFT - INSTALLATION).
- (15) Install oil pump pickup tube (Refer to 9 - ENGINE/LUBRICATION/OIL PUMP - INSTALLATION).
- (16) Install oil pan (Refer to 9 - ENGINE/LUBRICATION/OIL PAN - INSTALLATION).
- (17) Install cylinder head (Refer to 9 - ENGINE/CYLINDER HEAD - INSTALLATION).
- (18) Install cylinder head cover/intake manifold (Refer to 9 - ENGINE/CYLINDER HEAD/CYLINDER HEAD COVER(S) - INSTALLATION).
- (19) Install timing belt inner cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).
- (20) Install timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - INSTALLATION).
- (21) Install timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).
- (22) Install engine in vehicle.
- (23) Fill engine oil with proper oil to correct level.

FLEX PLATE

REMOVAL

- (1) Remove the transmission (Refer to 21 - TRANSMISSION/TRANSAXLE/MANUAL REMOVAL).
- (2) Paint mark the flex plate to crankshaft relationship.
- (3) Remove the flex plate fasteners and fly wheel (Fig. 50).



813ca5c6

**Fig. 50 2.8L REAR MAIN BEARING SUPPORT
REMOVAL**

- 1 - ENGINE BLOCK
2 - PLATE
3 - REAR MAIN BEARING SUPPORT
4 - CRANKSHAFT
5 - FLEX PLATE
6 - BACKING PLATE
7 - BOLTS

INSTALLATION


NOTE: Do Not Lubricate new bolts because they are already coated with an anti scuff treatment.

- (1) Position the flex plate and install the fasteners hand tight (Fig. 50).
- (2) Tighten each fastener to 50 N·m (37 lbs. ft.) following a clockwise cross sequence.
- (3) At this point, loosen only one fastener at a time and with a torque wrench set to 25 N·m (19 lbs. ft.) tighten the bolt, then with a torque angle gauge tighten that bolt an additional 60 degrees.
- (4) Perform the above procedure for each fastener in a cross sequence.

FLY WHEEL

REMOVAL

- (1) Remove the transmission (Refer to 21 - TRANSMISSION/TRANSAXLE/MANUAL REMOVAL).
- (2) Paint mark the fly wheel to crankshaft relationship.
- (3) Remove the fly wheel fasteners and fly wheel (Fig. 51).



81201815

Fig. 51 FLY WHEEL

- 1 - 60 MM FLY WHEEL BOLTS
- 2 - FLY WHEEL
- 3 - TRANSMISSION ADAPTOR PLATE
- 4 - REAR MAIN BEARING SUPPORT
- 5 - O-RING
- 6 - DOWL
- 7 - ENGINE BLOCK
- 8 - CRANKSHAFT
- 9 - RELUCTOR WHEEL
- 10 - ADAPTOR PLATE BOLT

INSTALLATION

NOTE: Do Not Lubricate new bolts because they are already coated with an anti scuff treatment.

(1) Position the fly wheel and install the fasteners hand tight (Fig. 51).

(2) Tighten each fastener to 50 N·m (37 lbs. ft.) following a clockwise cross sequence.

(3) At this point, loosen only one fastener at a time and with a torque wrench set to 25 N·m (19 lbs. ft.) tighten the bolt, then with a torque angle gauge tighten that bolt an additional 60 degrees.

(4) Perform the above procedure for each fastener in a cross sequence.


CYLINDER LINERS

DESCRIPTION

The cylinder wall liner used on this engine is of the wet design. O-rings are used to seal the liner to the engine block.

REMOVAL

- (1) Remove engine from vehicle.
- (2) With engine completely disassembled, use special tool VM.1001 to remove liner assembly (Fig. 52).




J9509-12

Fig. 52 CYLINDER LINER REMOVER

(3) Tighten bolt on VM.1001 to remove liner from block (Fig. 53).

(4) Remove shims from cylinder liner or cylinder block recess. Keep shims with each cylinder liner.

CYLINDER LINERS (Continued)



80c6cac1


Fig. 53 CYLINDER LINER REMOVAL

- 1 - SPECIAL TOOL VM.1001
- 2 - CYLINDER LINER
- 3 - ENGINE BLOCK

INSPECTION

The cylinder walls should be checked for out-of-round and taper with a dial bore gauge. The cylinder bore out-of-round is 0.100 mm (.0039 in.) maximum and cylinder bore taper is 0.100 mm (.0039 in.) maximum. If the cylinder walls are badly scuffed or scored, new liners should be installed and honed, and new pistons and rings fitted.

Measure the cylinder bore at three levels in directions A and B (Fig. 54). Top measurement should be 10 mm (3/8 in.) down and bottom measurement should be 10 mm (3/8 in.) up from the bottom bore.




J9509-13

Fig. 54 LINER INSPECTION**INSTALLATION**

CAUTION: Cylinder liner O-rings have different diameters. Care should be taken when installing replacement O-rings because they are engine specific.

(1) Carefully clean liner and engine block, and degrease the engine block where it comes into contact with the liners. Install the liners in the engine block as shown, rotating them back and forth by 45° in order to guarantee correct positioning (Fig. 55).



80c70677

Fig. 55 LINER INSTALLATION

- 1 - CYLINDER LINER
- 2 - SHIMS
- 3 - O-RINGS
- 4 - BLOCK LEDGE
- 5 - ENGINE BLOCK

(2) Measure the liner recess relative to block deck with a dial indicator mounted on a special tool VM-1010 A. **All the measurements must be taken on high pressure pump side of engine block.** Zero dial gauge on block deck.

(3) Move dial gauge to cylinder liner record reading on dial gauge.

(4) Remove liner and special tool.

(5) Then select the correct shim thickness to give proper protrusion (0.00 - 0.05 mm).

(6) Fit the shim and the O-rings onto the liner.

(7) Lubricate the lower liner location in the block.

CYLINDER LINERS (Continued)

(8) Fit the liners in the crankcase making sure that the shim is positioned correctly in the seat. Lock the liners in position using special tool (VM.1076) and bolts (Fig. 56).




Fig. 56 LINER CLAMP LOCATION

- 1 - ENGINE BLOCK
- 2 - LINER RETAINER VM.1076
- 3 - CYLINDER LINER

- (9) Recheck the liner protrusion. It should be 0.00 - 0.05 mm.
- (10) Reassemble engine.
- (11) Install engine in vehicle.


INTERNAL VACUUM PUMP

DESCRIPTION

The diesel engine uses an internal vacuum pump. This vacuum pump is mounted in the front of the engine block under the engine front cover (Fig. 57). The vacuum pump is driven by a sprocket on the crankshaft.

REMOVAL

- (1) Disconnect negative battery cable.
- (2) Remove air cleaner housing.
- (3) Remove power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (4) Remove accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).



80c6c9ea

Fig. 57 VACUUM PUMP

- (5) Support engine and remove right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - REMOVAL).
- (6) Remove vibration damper/crankshaft pulley (Refer to 9 - ENGINE/ENGINE BLOCK/VIBRATION DAMPER - REMOVAL).
- (7) Remove outer timing belt cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).
- (8) Remove timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - REMOVAL).
- (9) Remove timing belt inner cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).

NOTE: Crankshaft hub has LHD thread.


- (10) Remove crankshaft hub.
- (11) Remove front engine cover (Refer to 9 - ENGINE/ENGINE BLOCK/ENGINE COVER - REMOVAL).
- (12) Remove crankshaft sprocket (Fig. 58).
- (13) Remove vacuum pump (Fig. 58).

INSTALLATION

NOTE: Verify the 3 blades on the vacuum pump are in place and correctly assembled. The tapered edge should be on the outer side. Make sure the pump rotates before installation.

- (1) Lubricate vacuum pump blades and install in vacuum pump body as shown (Fig. 59).
- (2) Install vacuum pump in engine block (Fig. 58). Torque bolts to 10.8N·m.
- (3) Install crankshaft sprocket (Fig. 58). Torque bolts to 10.8N·m.
- (4) Install front engine cover (Refer to 9 - ENGINE/ENGINE BLOCK/ENGINE COVER - INSTALLATION).
- (5) Install front crankshaft hub. Torque bolt to 304N·m.


INTERNAL VACUUM PUMP (Continued)



80ae90d8

Fig. 58 OIL PUMP AND VACUUM PUMP

- 1 - VACUUM PUMP
- 2 - CRANKSHAFT SPROCKET
- 3 - OIL PUMP
- 4 - ENGINE BLOCK
- 5 - CRANKSHAFT



80e07e7c

Fig. 59 VACUUM PUMP COMPONENTS

- 1 - VACUUM PUMP BODY
- 2 - VACUUM PUMP BLADE TAPERED EDGE
- 3 - VACUUM PUMP BLADE

(6) Install timing belt inner cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

(7) Install timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - INSTALLATION).

(8) Install timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

(9) Install vibration damper/crankshaft pulley.

(10) Install right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - INSTALLATION).

(11) Install accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(12) Install power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(13) Install air cleaner housing.

(14) Connect negative battery cable.

PISTON & CONNECTING ROD

DESCRIPTION

The pistons are of a free floating design. Oil jets in the engine block lubricate and cool the piston and pin assembly. The connecting rods have a pressed in place wrist pin bushing which is lubricated by the oil jets (Fig. 60).

STANDARD PROCEDURE - PISTON RING FITTING

(1) Wipe cylinder bore clean. Insert ring and push down with piston to ensure it is square in bore. The ring gap measurement must be made with the ring positioning at least 12 mm (0.50 in.) from bottom of cylinder bore (Fig. 61). Check gap with feeler gauge. Top compression ring gap .30 to .45mm (.0118 to .0177 in.). Second compression ring gap .30 to .45mm (.0118 to .0177 in.). Oil control ring gap .25 to .50mm (.0098 to .0196 in.).

(2) If ring gaps exceed dimension given, new rings or cylinder liners must be fitted. Keep piston rings in piston sets.

(3) Check piston ring to groove clearance (Fig. 62). Top compression ring gap .080 to .130mm (.0031 to .0051 in.). Second compression ring gap .070 to .110mm (.0027 to .0043 in.). Oil control ring gap .040 to .080mm (.0015 to .0031 in.).

REMOVAL

(1) Disconnect negative battery cable.

(2) Remove cylinder head (Refer to 9 - ENGINE/CYLINDER HEAD - REMOVAL).

PISTON & CONNECTING ROD (Continued)




Fig. 60 PISTON AND CONNECTING ROD ASSEMBLY

- 1 - PISTON PIN
- 2 - PISTON
- 3 - SNAP RING
- 4 - PAINTED CONNECTING ROD ALIGNMENT NUMBERS
- 5 - CONNECTING ROD BOLT
- 6 - CONNECTING ROD BEARING
- 7 - CONNECTING ROD
- 8 - SNAP RING

- (3) Raise vehicle on hoist.
- (4) Remove oil pan (Refer to 9 - ENGINE/LUBRICATION/OIL PAN - REMOVAL).
- (5) Remove oil pump pickup tube.(Refer to 9 - ENGINE/LUBRICATION/OIL PUMP - REMOVAL)
- (6) Remove balance shaft assembly (Refer to 9 - ENGINE/VALVE TIMING/BALANCE SHAFT - REMOVAL).
- (7) Remove top ridge of cylinder bores with a ridge reamer before removing pistons from cylinder block. **Be sure to keep top of pistons covered during this operation.**
- (8) Piston and connecting rods must be removed from top of cylinder block. Rotate crankshaft so that each connecting rod is centered in cylinder bore.




Fig. 61 RING END GAP MEASUREMENT

- 1 - FEELER GAUGE




Fig. 62 PISTON RING TO GROOVE CLEARANCE

NOTE: Be careful not to nick or scratch crankshaft journals, connecting rod cap can be separated by tapping with a plastic hammer on a clean surface.

- (9) After removal, install bearing cap on the mating rod and mark piston and connecting rod with painted matching cylinder number when removed from engine block.

PISTON & CONNECTING ROD (Continued)

PISTON PIN - REMOVAL

- (1) Secure connecting rods in a soft jawed vice.
- (2) Remove 2 snap rings securing piston pin (Fig. 63).
- (3) Push piston pin out of piston and connecting rod (Fig. 63).




Fig. 63 PISTON AND CONNECTING ROD ASSEMBLY

- 1 - PISTON PIN
- 2 - PISTON
- 3 - SNAP RING
- 4 - PAINTED CONNECTING ROD ALIGNMENT NUMBERS
- 5 - CONNECTING ROD BOLT
- 6 - CONNECTING ROD BEARING
- 7 - CONNECTING ROD
- 8 - SNAP RING

PISTON RING - REMOVAL

- (1) ID mark on face of top and second piston rings must point toward piston crown.
- (2) Using a suitable ring expander, remove top and second piston rings (Fig. 64).
- (3) Remove upper oil ring side rail, lower oil ring side rail and then the oil expander from piston.
- (4) Carefully clean carbon from piston crowns, skirts and ring grooves ensuring the 4 oil holes in the oil control ring groove are clear.




Fig. 64 PISTON RINGS - REMOVAL/INSTALLATION INSPECTION

PISTONS

- (1) Piston Diameter: Size: 91.912-91.928mm (3.6185-3.6192 in.) Maximum wear limit .05mm (.0019 in.).
- (2) Check piston pin bores in piston for roundness. Make 3 checks at 120° intervals. Maximum out of roundness .05mm (.0019in.).
- (3) The piston diameter should be measured approximately 15 mm (.590 in.) up from the base.
- (4) Skirt wear should not exceed 0.1 mm (.00039 in.).
- (5) The clearance between the cylinder liner and piston should not exceed 0.065-0.083 mm (.0025-.0032 in.).

CONNECTING RODS

CAUTION: Connecting rod bolts must be replaced when disassembled. When assembling the connecting rod, be sure that the pawl on each of the connecting rod caps is facing the rear (fly wheel) side of the engine (Fig. 65).

NOTE: Do Not lubricate the new connecting rod bolts. They are already coated with a anti scuff treatment.

- (1) Assemble bearing shells and bearing caps to their respective connecting rods ensuring that the serrations on the cap and reference marks are aligned (Fig. 65).
- (2) Tighten connecting cap bolts to 10 N·m (88 in. lbs.).
- (3) Without loosening connecting rod bolts, tighten all bolts to 30N·m (22 ft.lbs.).
- (4) Using a torque angle gauge, tighten each bolt an additional 40°.

PISTON & CONNECTING ROD (Continued)

(5) Recheck all bolt tightening with a torque wrench set to 88N·m (65 ft.lbs.).

(6) Check and record internal diameter of crank end of connecting rod.

CAUTION: When changing connecting rods, DO NOT use a stamp to mark the cylinder location. Identify the connecting rods and caps location using a paint marker. All four must have the same weight and the same number. Replacement connecting rods will only be supplied in sets of four (Fig. 65).

Connecting rods are supplied in sets of four since they all must be of the same weight category. Max allowable weight difference is 5 gr.




Fig. 65 CONNECTING ROD IDENTIFICATION

- 1 - CONNECTING ROD PAWL
- 2 - CONNECTING ROD
- 3 - PAINTED CYLINDER IDENTIFIER
- 4 - CONNECTING ROD BEARINGS
- 5 - CONNECTING ROD

PISTON PINS

(1) Measure the diameter of piston pin in the center and both ends. For specification, (Refer to 9 - ENGINE - SPECIFICATIONS), (Refer to 9 - ENGINE - SPECIFICATIONS)

INSTALLATION

PISTON PIN INSTALLATION

- (1) Secure connecting rod in soft jawed vice.
- (2) Lubricate piston pin and piston with clean engine oil.
- (3) Position piston on connecting rod (Fig. 66).

CAUTION: Ensure arrow on piston crown and the bearing cap numbers on the connecting rod are on the opposite side.

- (4) Install piston pin (Fig. 66).
- (5) Install clips in piston to retain piston pin (Fig. 66).




Fig. 66 PISTON AND CONNECTING ROD ASSEMBLY

- 1 - PISTON PIN
- 2 - PISTON
- 3 - SNAP RING
- 4 - PAINTED CONNECTING ROD ALIGNMENT NUMBERS
- 5 - CONNECTING ROD BOLT
- 6 - CONNECTING ROD BEARING
- 7 - CONNECTING ROD
- 8 - SNAP RING


- (6) Remove connecting rod from vice.

PISTON RINGS - INSTALLATION

(1) Install rings on the pistons using a suitable ring expander (Fig. 67).

(2) Top compression ring is tapered and chromium plated. The second ring is of the scraper type and must be installed with scraping edge facing bottom of the piston. The third is an oil control ring. Ring gaps must be positioned, before inserting piston into the liners, as follows.


PISTON & CONNECTING ROD (Continued)

**Fig. 67 PISTON RINGS-INSTALLATION**

(3) Top ring gap must be positioned at the #3 position (looking at the piston crown from above) (Fig. 68).

(4) Second piston ring gap should be positioned at the #1 position (Fig. 68).

(5) Oil control ring gap should be positioned at the #2 position (Fig. 68).

**Fig. 68 PISTON RING GAP LOCATION**

- 1 - SECOND COMPRESSION RING GAP POSITION
- 2 - OIL CONTROL RING GAP POSITION
- 3 - TOP COMPRESSION RING GAP POSITION

(6) When assembling pistons check that components are installed in the same position as before disassembly, determined by the numbers stamped on the crown of individual pistons. Engine cylinders are numbered starting from gear train end of the engine. **Face arrow on top of piston toward front of engine.** Therefore, the numbers stamped on connecting rod big end should face toward the injection pump side of engine. To insert piston into cylinder use a ring compressor (VM.1065) as shown in (Fig. 69).

INSTALLATION

(1) Before installing pistons, and connecting rod assemblies into the bore, be sure that compression ring gaps are staggered so that neither is in line with oil ring rail gap (Fig. 68).


(2) Before installing the ring compressor, make sure the oil ring expander ends are butted together.

(3) Immerse the piston head and rings in clean engine oil, slide the ring compressor, over the piston and tighten (Fig. 69). **Ensure position of rings does not change during this operation.**

NOTE: Be sure arrow on top of piston faces towards front of engine and the connecting rod pawl faces the rear (flywheel) side of the engine.

NOTE: Be careful not to nick crankshaft journals.

(4) Rotate crankshaft so that the connecting rod journal is on the center of the cylinder bore. Insert rod and piston into cylinder bore and guide rod over the crankshaft journal.

**Fig. 69 PISTON INSTALLATION USING VM.1065**


- 1 - PISTON
- 2 - PISTON RING COMPRESSOR VM.1065
- 3 - ENGINE BLOCK

(5) Tap the piston down in cylinder bore, using a hammer handle. At the same time, guide connecting rod into position on connecting rod journal.

PISTON & CONNECTING ROD (Continued)

NOTE: Connecting rod bolts must be replaced when disassembled. DO NOT lubricate new connecting rod bolts as they are already coated.

(6) Install connecting rod caps (Fig. 70). Install rod bolts and tighten each bolt to 10N·m (89 lbs. in.). Tighten each bolt again to 30N·m (22 lbs. ft.) plus 40°. Then torque to 88N·m (65 ft.lb.).



80c6e51b

Fig. 70 PISTON AND CONNECTING ROD INSTALLATION

- 1 - PISTON AND CONNECTING ROD ASSEMBLY
- 2 - PAINTED CYLINDER IDENTIFIER
- 3 - CONNECTING ROD BOLT
- 4 - PAINTED CYLINDER IDENTIFIER

(7) Install cylinder head (Refer to 9 - ENGINE/CYLINDER HEAD - INSTALLATION).

(8) Install balance shaft assembly (Refer to 9 - ENGINE/VALVE TIMING/BALANCE SHAFT - INSTALLATION).

(9) Install oil pump pickup tube (Refer to 9 - ENGINE/LUBRICATION/OIL PUMP - INSTALLATION).

(10) Install oil pan (Refer to 9 - ENGINE/LUBRICATION/OIL PAN - INSTALLATION).

(11) Connect negative battery cable.

CRANKSHAFT OIL SEAL - FRONT

REMOVAL

- (1) Disconnect negative battery cable.
- (2) Remove air cleaner housing.
- (3) Support engine and remove right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - REMOVAL).
- (4) Remove power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (5) Remove accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (6) Remove vibration damper/crankshaft pulley (Refer to 9 - ENGINE/ENGINE BLOCK/VIBRATION DAMPER - REMOVAL).
- (7) Remove outer timing belt cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).
- (8) Remove timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - REMOVAL).
- (9) Remove timing belt inner cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).

NOTE: Crankshaft hub retaining bolt has LHD thread.

- (10) Remove crankshaft hub (Fig. 71).
- (11) Remove front engine cover (Fig. 71) (Refer to 9 - ENGINE/ENGINE BLOCK/ENGINE COVER - REMOVAL).
- (12) With cover on work bench, pry out old seal.


INSTALLATION

CAUTION: Do Not use a hammer to install the crankshaft oil seal.

NOTE: To prevent potential oil leaks, DO NOT touch the front crankshaft inner seal. Always handle the seal from the outer diameter.

- (1) Clean engine block and front engine cover sealing surfaces.
- (2) Install crankshaft oil seal on VM.1061 (Fig. 72).
- (3) Place sleeve for VM.1061 on press bench as shown (Fig. 72).


CRANKSHAFT OIL SEAL - FRONT (Continued)



8124732c

Fig. 71 ENGINE COVER - FRONT


- 1 - CRANKSHAFT HUB RETAINING BOLT
- 2 - FRONT ENGINE COVER RETAINING BOLTS
- 3 - ENGINE BLOCK
- 4 - FRONT ENGINE COVER ALIGNMENT DOWELS
- 5 - FRONT ENGINE COVER
- 6 - CRANKSHAFT HUB



812466f0

Fig. 73 ENGINE FRONT COVER

- 1 - ENGINE BLOCK
- 2 - FRONT ENGINE COVER
- 3 - VM.1061



80c6ca57

Fig. 72 VM.1061 PLACEMENT

- 1 - VM.1061
- 2 - FRONT ENGINE COVER
- 3 - PRESS BENCH
- 4 - SLEEVE FROM VM.1061

- (4) Press the new seal into front engine cover.
- (5) Install front engine cover using VM 1061 as a guide, care must be taken not to damage the seal (Fig. 73).

- (6) Install crankshaft hub and retaining bolt. Torque bolt to 304N·m (224 lbs. ft.).

- (7) Install timing belt inner cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

- (8) Install timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - INSTALLATION).

- (9) Install timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

- (10) Install vibration damper/crankshaft pulley (Refer to 9 - ENGINE/ENGINE BLOCK/VIBRATION DAMPER - INSTALLATION).

- (11) Install accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

- (12) Install power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

- (13) Install right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - INSTALLATION).


- (14) Install air cleaner housing.

- (15) Connect negative battery cable.

VIBRATION DAMPER

REMOVAL

- (1) Remove power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (2) Remove accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (3) Remove vibration damper retaining bolts and damper (Fig. 74).



812473de

Fig. 74 VIBRATION DAMPER

- 1 - BELT TENSIONER RETAINING BOLT
- 2 - BELT TENSIONER
- 3 - IDLER PULLEY
- 4 - VIBRATION DAMPER/CRANKSHAFT PULLEY
- 5 - VIBRATION DAMPER/CRANKSHAFT PULLEY RETAINING BOLTS

INSTALLATION

- (1) Install vibration damper and retaining bolts (Fig. 74). Torque bolts to 27.5N·m.
- (2) Install accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).
- (3) Install power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

ENGINE COVER - FRONT

DESCRIPTION

The front engine cover on this engine is a stamped steel cover which covers the oil pump and vacuum pump.

REMOVAL

- (1) Disconnect negative battery cable.
- (2) Remove air cleaner housing.
- (3) Support engine and remove right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - REMOVAL).
- (4) Remove power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (5) Remove accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (6) Remove vibration damper (Refer to 9 - ENGINE/ENGINE BLOCK/VIBRATION DAMPER - REMOVAL).
- (7) Remove timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).

CAUTION: Before removing the cylinder head cover/intake manifold or timing belt the engine must put at 90° after TDC. Failure to do so could result in valve and/or piston damage during reassembly. (Refer to 9 - ENGINE/VALVE TIMING - STANDARD PROCEDURE)

- (8) Remove timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - REMOVAL).

- (9) Remove timing belt inner cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).


NOTE: Crankshaft hub has LHD thread.

- (10) Remove crankshaft hub.
- (11) Remove front engine cover (Fig. 75).

INSTALLATION

- (1) Clean engine block and front engine cover sealing surfaces.
- (2) Apply a continuous 3mm bead of Silicone Sealer to cover, install within 10 minutes (Fig. 75). Torque bolts to 11.8N·m.

ENGINE COVER - FRONT (Continued)



8124732c

Fig. 75 ENGINE COVER - FRONT

- 1 - CRANKSHAFT HUB RETAINING BOLT
- 2 - FRONT ENGINE COVER RETAINING BOLTS
- 3 - ENGINE BLOCK
- 4 - FRONT ENGINE COVER ALIGNMENT DOWELS
- 5 - FRONT ENGINE COVER
- 6 - CRANKSHAFT HUB

(3) Install crankshaft hub (Fig. 75). Torque bolt to 304N·m.

(4) Install timing belt inner cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

(5) Install timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - INSTALLATION).

(6) Install timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

(7) Install vibration damper (Refer to 9 - ENGINE/ENGINE BLOCK/VIBRATION DAMPER - INSTALLATION).

(8) Install right engine mount (Refer to 9 - ENGINE/ENGINE MOUNTING/RIGHT MOUNT - INSTALLATION).

(9) Install accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(10) Install power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(11) Install air cleaner housing.

(12) Connect negative battery cable.

CRANKSHAFT MAIN BEARINGS

REMOVAL


NOTE: Refer to crankshaft description for proper identification of the crankshaft (Refer to 9 - ENGINE/ENGINE BLOCK/CRANKSHAFT - DESCRIPTION).

The engine must be removed from vehicle and completely disassembled to replace the front main bearing.

CRANKSHAFT MAIN BEARINGS

(1) With crankshaft assembly removed from engine.

(2) Remove crankshaft supports from crankshaft and remove bearing halves from supports (Fig. 76).



8120b297


Fig. 76 2.5L CRANKSHAFT

- 1 - CRANKSHAFT SUPPORT HALVE
- 2 - MAIN BEARING HALVE
- 3 - CRANKSHAFT
- 4 - MAIN BEARING HALVE
- 5 - CRANKSHAFT SUPPORT HALVE
- 6 - MAIN BEARING SUPPORT BOLTS

CRANKSHAFT MAIN BEARINGS (Continued)

CRANKSHAFT FRONT MAIN BEARING

(1) Using special tool VM.1073 push front main bearing out of front of engine block (Fig. 77).



80c6ca73

Fig. 77 FRONT MAIN BEARING REMOVAL

- 1 - VM.1073
- 2 - FRONT CRANKSHAFT MAIN BEARING
- 3 - ENGINE BLOCK


INSTALLATION

CRANKSHAFT MAIN BEARINGS

NOTE: Refer to crankshaft description for proper identification of the crankshaft (Refer to 9 - ENGINE/ENGINE BLOCK/CRANKSHAFT - DESCRIPTION).

- (1) Install bearing halves in crankshaft supports.
- (2) Lubricate crankshaft and main bearings with clean engine oil.

(3) Install crankshaft supports on crankshaft (Fig. 78). Torque bolts to 44.1N·m.



8120b297


Fig. 78 2.5L CRANKSHAFT

- 1 - CRANKSHAFT SUPPORT HALVE
- 2 - MAIN BEARING HALVE
- 3 - CRANKSHAFT
- 4 - MAIN BEARING HALVE
- 5 - CRANKSHAFT SUPPORT HALVE
- 6 - MAIN BEARING SUPPORT BOLTS

CRANKSHAFT MAIN BEARINGS (Continued)

FRONT CRANKSHAFT MAIN BEARING

(1) Using special tool VM.1073, push front crankshaft main bearing in engine block (Fig. 79).




80c6ca80

Fig. 79 FRONT MAIN BEARING INSTALLATION

- 1 - FRONT CRANKSHAFT MAIN BEARING
- 2 - ENGINE BLOCK
- 3 - SPECIAL TOOL VM.1073

(2) Be sure oil hole in bearing lines up with oil gallery in engine block (Fig. 80).



80c6cad4

Fig. 80 FRONT MAIN BEARING ALIGNMENT


- 1 - ENGINE BLOCK
- 2 - OIL HOLE IN BEARING
- 3 - FRONT CRANKSHAFT MAIN BEARING

(3) Reassemble engine and install in vehicle.

CRANKSHAFT OIL SEAL - REAR

DESCRIPTION

The rear crankshaft seal consists of two parts that reside in a third part, the rear support assembly. The rear seal is inserted into the rear cup (Fig. 81). These pieces should be assembled **WITH OUT** removing one from the other. The rear support assembly, once assembled, should not be separated as well, to reduced possibility of damage to the internal rear seal lip (Fig. 82).



8120baaf

Fig. 81 REAR CRANKSHAFT SEAL ASSEMBLY

- 1 - REAR SEAL
- 2 - REAR CUP

REMOVAL


This must be done with either the engine or transmission removed from vehicle.

- (1) Remove flywheel assembly.
- (2) Pry out old crankshaft oil seal.

INSTALLATION

NOTE: To prevent potential oil leaks, **DO NOT** touch or separate the rear crankshaft inner seal. Always handle the seal from the outer diameter (Refer to 9 - ENGINE/ENGINE BLOCK/CRANKSHAFT OIL SEAL - REAR - DESCRIPTION).


CRANKSHAFT OIL SEAL - REAR (Continued)



8120baae

Fig. 82 REAR SUPPORT ASSEMBLY

(1) Using special tool VM.1050, install rear crankshaft oil seal in rear main bearing support (Fig. 83).



80ff304a


Fig. 83 2.5L REAR CRANKSHAFT OIL SEAL INSTALLATION USING VM.1050

- 1 - SPECIAL TOOL VM.1050
- 2 - REAR MAIN BEARING SUPPORT
- 3 - OIL PAN
- 4 - ENGINE TO TRANSMISSION ADAPTER PLATE

OIL PAN

REMOVAL

- (1) Disconnect negative battery cable.
- (2) Raise vehicle on hoist.
- (3) Drain engine oil from engine.
- (4) Remove all oil pan retaining bolts and oil pan (Fig. 84).



813cab3a

Fig. 84 OIL PAN

- 1 - OIL PAN RETAINING BOLTS
- 2 - POWER STEERING LINE BRACKETS
- 3 - OIL PAN GASKET
- 4 - OIL PRESSURE SENSOR
- 5 - ENGINE BLOCK
- 6 - OIL PRESSURE RELIEF VALVE
- 7 - OIL PAN RETAINING BOLTS
- 8 - OIL PAN

INSTALLATION

- (1) Clean oil pan and sealing surfaces. Inspect oil pan and engine block.
- (2) Install oil pan, gasket, and retaining bolts (Fig. 84).
- (3) Be sure power steering line brackets are in proper location (Fig. 84).
- (4) Torque oil pan bolts to 11.8N·m.
- (5) Lower vehicle.
- (6) Refill engine oil to proper level.
- (7) Connect negative battery cable.

(2) Install engine or transmission in vehicle.

OIL PUMP

REMOVAL

REMOVAL

- (1) Disconnect negative battery cable.
- (2) Remove power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (3) Remove accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (4) Remove timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).
- (5) Remove timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - REMOVAL).
- (6) Remove timing belt inner cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).
- (7) Remove front engine cover (Refer to 9 - ENGINE/ENGINE BLOCK/ENGINE COVER - REMOVAL).
- (8) Remove crankshaft sprocket (Fig. 85).
- (9) Remove oil pump retaining bolts and remove pump from engine block (Fig. 85).


REMOVAL

- (1) Disconnect negative battery cable.
- (2) Raise vehicle on hoist.
- (3) Remove oil pan (Refer to 9 - ENGINE/LUBRICATION/OIL PAN - REMOVAL).
- (4) Remove oil pump pickup tube retaining bolt and pull pickup tube from engine block (Fig. 86).

INSTALLATION

INSTALLATION

- (1) Lubricate oil pump rotor with engine oil.
- (2) Install oil pump in bore in engine block (Fig. 85).
- (3) Install oil pump retaining bolts (Fig. 85). Torque bolts to 10.8N·m.
- (4) Install crankshaft sprocket (Fig. 85). Torque bolts to 10.8N·m.
- (5) Install front engine cover (Refer to 9 - ENGINE/ENGINE BLOCK/ENGINE COVER - INSTALLATION).



80ae90d8

Fig. 85 OIL PUMP AND VACUUM PUMP

- 1 - VACUUM PUMP
- 2 - CRANKSHAFT SPROCKET
- 3 - OIL PUMP
- 4 - ENGINE BLOCK
- 5 - CRANKSHAFT

(6) Install timing belt inner cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

(7) Install timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - INSTALLATION).

(8) Install timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

(9) Install accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(10) Install power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(11) Connect negative battery cable.

OIL PUMP (Continued)




Fig. 86 OIL PUMP PICKUP TUBE ASSEMBLY

- 1 - BALANCE SHAFT
- 2 - OIL JET RETAINING BOLT
- 3 - OIL JET
- 4 - ENGINE BLOCK
- 5 - CRANKSHAFT
- 6 - O- RING(S)
- 7 - BALANCE SHAFT RETAINING BOLTS
- 8 - OIL DIPSTICK TUBE RETAINER
- 9 - RUBBER BUSHING
- 10 - RETAINING BOLT

INSTALLATION

- (1) Lubricate o-ring on oil pump pickup tube with engine oil.
- (2) Install pickup tube in engine block and install retaining bolt (Fig. 86). Torque bolt to 32.4N·m.
- (3) Install oil pan (Refer to 9 - ENGINE/LUBRICATION/OIL PAN - INSTALLATION).
- (4) Refill engine oil to proper level.
- (5) Connect negative battery cable.

NOTE: If a slight oil witness mark is present, retighten the oil pan bolts to 12N·m (106 in.lbs.).

- (6) Start engine and inspect for leaks.

OIL PRESSURE SENSOR/ SWITCH

DESCRIPTION

The oil pressure switch is located on the right side of the engine block. The switch screws into the engines main oil gallery (Fig. 87).




Fig. 87 VIEW-REAR ENGINE

- 1 - SUSPENSION CRADLE
- 2 - ENGINE BLOCK
- 3 - OIL PRESSURE SWITCH
- 4 - VEHICLE SPEED SENSOR
- 5 - TRANSMISSION

REMOVAL

- (1) Disconnect negative battery cable.
- (2) Raise vehicle on hoist.
- (3) Disconnect oil pressure switch electrical connector (Fig. 87).
- (4) Remove oil pressure switch from engine block.

INSTALLATION

- (1) Apply Mopar® Thread Sealant to the switch threads.
- (2) Install oil pressure switch in engine block.
- (3) Connect oil pressure switch electrical connector (Fig. 87).
- (4) Lower vehicle.
- (5) Start engine and check for leaks.
- (6) Check and adjust oil level as necessary.

OIL PRESSURE RELIEF VALVE

DESCRIPTION

The oil pressure relief valve mounts in the front of the engine block and is used to control oil flow through the engines lubrication system (Fig. 88).




Fig. 88 OIL PRESSURE RELIEF VALVE

- 1 - O-RING
- 2 - OIL PRESSURE RELIEF VALVE CAP
- 3 - CLIP
- 4 - OIL PRESSURE RELIEF VALVE SPRING
- 5 - OIL PRESSURE RELIEF VALVE PLUNGER

REMOVAL

(1) Remove engine oil pan (Refer to 9 - ENGINE/LUBRICATION/OIL PAN - REMOVAL).

(2) Using special tool VM.1054, remove oil pressure relief valve from engine block (Fig. 89).

INSTALLATION

(1) Thoroughly clean all components and relief valve pocket in cylinder block.

(2) Lubricate all oil pressure relief valve components with engine oil.




Fig. 89 OIL PRESSURE RELIEF VALVE REMOVAL


- 1 - VM.1054
- 2 - OIL PRESSURE RELIEF VALVE
- 3 - ENGINE BLOCK
- 4 - OIL PUMP

(3) Install oil pressure relief valve plunger, spring, and cap.

(4) Using special tool VM.1059, push oil pressure relief valve cap in until flush with engine block (Fig. 90).

(5) Install oil pan (Refer to 9 - ENGINE/LUBRICATION/OIL PAN - INSTALLATION).

OIL PRESSURE RELIEF VALVE (Continued)



**Fig. 90 OIL PRESSURE RELIEF VALVE
INSTALLATION**

- 1 - VM.1059
- 2 - OIL PRESSURE RELIEF VALVE
- 3 - ENGINE BLOCK
- 4 - OIL PUMP




Fig. 91 OIL FILTER

- 1 - OIL FILTER
- 2 - ENGINE OIL COOLER


OIL COOLER & LINES

REMOVAL

- (1) Drain cooling system (Refer to 7 - COOLING/ENGINE/COOLANT - STANDARD PROCEDURE).
- (2) Raise vehicle on hoist.
- (3) Remove oil filter (Refer to 9 - ENGINE/LUBRICATION/OIL FILTER - REMOVAL).
- (4) Disconnect coolant hoses at cooler (Fig. 92).
- (5) Remove oil cooler retaining bolt at engine block (Fig. 92).
- (6) Remove oil cooler retaining stud and remove oil cooler from engine block (Fig. 92).

INSTALLATION

- (1) Clean oil cooler and engine block sealing surfaces.
- (2) Install oil cooler, retaining bolt, and stud (Fig. 92). Torque retaining bolt to 47.1N·m (35 lbs.ft.) and stud to 37.2 N·m (28 lbs.ft.).
- (3) Connect coolant hoses at cooler (Fig. 92).
- (4) Install oil filter (Fig. 91)
- (5) Lower vehicle.
- (6) Refill cooling system (Refer to 7 - COOLING/ENGINE/COOLANT - STANDARD PROCEDURE).
- (7) Start engine and check for leaks.
- (8) Check and adjust oil level as necessary.



**Fig. 92 WATER PUMP AND OIL COOLER
ASSEMBLIES**

- 1 - WATER PUMP HOUSING STUDS
- 2 - WATER PUMP
- 3 - RETAINING NUTS
- 4 - OIL COOLER RETAINING STUD
- 5 - COOLANT HOSE
- 6 - ENGINE BLOCK

OIL FILTER

DESCRIPTION

The oil filter is a high quality, full flow, disposable style. (Fig. 93).

REMOVAL

NOTE: Capture any residual oil spill while removing filter and wipe any oil that comes in contact with other components

- (1) Raise vehicle on hoist.
- (2) Twist oil filter counterclockwise with a suitable oil filter wrench to remove. (Fig. 93)




Fig. 93 OIL FILTER

- 1 - OIL FILTER
- 2 - ENGINE OIL COOLER

INSTALLATION

- (1) Lubricate oil filter seal with clean engine oil.
- (2) Turning clockwise, seat the oil filter then tighten the oil filter 1/2 turn more (Fig. 93).
- (3) Lower vehicle from hoist.
- (4) Start engine and check for leaks.
- (5) Check and adjust oil level as necessary.

OIL JET

DESCRIPTION

There are four oil jets installed in the engine block. These oil jets are used to cool and lubricate the piston assemblies (Fig. 94).




Fig. 94 OIL JET ASSEMBLY

- 1 - RETAINING BOLT
- 2 - OIL JET
- 3 - O-RING

REMOVAL

CAUTION: Use caution when removing and installing oil jets. Damage to oil jet nozzle could cause severe engine damage.

NOTE: Remove oil jets Before removing pistons, crankshaft or liners

- (1) Disconnect negative battery cable.
- (2) Raise vehicle on hoist.
- (3) Remove oil pan (Refer to 9 - ENGINE/LUBRICATION/OIL PAN - REMOVAL).
- (4) Using special tool VM.1060 to hold oil jet. Remove oil jet retaining bolt and remove oil jet from engine block (Fig. 95).

INSTALLATION

CAUTION: Use caution when removing and installing oil jets. Damage to oil jet nozzle could cause severe engine damage.

NOTE: Carefully install the oil jets After assembling the engine liners, crankshaft and pistons.

- (1) Lubricate o-ring on oil jet.
- (2) Using special tool VM.1060, install oil jet in engine block (Fig. 95).
- (3) Install oil jet retaining bolt. Torque bolt to 10.8N·m.

OIL JET (Continued)




Fig. 95 OIL JET REMOVAL/INSTALLATION

- 1 - SPECIAL TOOL VM.1060
- 2 - OIL JET
- 3 - CONNECTING ROD
- 4 - CRANKSHAFT

(4) Install oil pan (Refer to 9 - ENGINE/LUBRICATION/OIL PAN - INSTALLATION).

(5) Refill engine oil to proper level.

(6) Connect negative battery cable.

INTAKE MANIFOLD

DESCRIPTION

(Refer to 9 - ENGINE/CYLINDER HEAD/CYLINDER HEAD COVER(S) - DESCRIPTION)

REMOVAL

(1) (Refer to 9 - ENGINE/CYLINDER HEAD/CYLINDER HEAD COVER(S) - REMOVAL)

INSTALLATION

(1) (Refer to 9 - ENGINE/CYLINDER HEAD/CYLINDER HEAD COVER(S) - INSTALLATION)

EXHAUST MANIFOLD

REMOVAL

(1) Remove the battery and tray assembly (Refer to 8 - ELECTRICAL/BATTERY SYSTEM/TRAY - REMOVAL).

(2) Remove the wiper cowl assembly (Refer to 23 - BODY/EXTERIOR/COWL GRILLE - REMOVAL).

(3) Raise and support the vehicle.

(4) Drain the cooling system (Refer to 7 - COOLING/ENGINE/COOLANT - STANDARD PROCEDURE).

(5) Loosen the clamp retaining the upper charge air tube to the turbocharger (Fig. 96).




Fig. 96 TURBOCHARGER AND COOLANT PIPES

- 1 - TURBOCHARGER OUTLET PIPE RETAINING BOLT
- 2 - TURBOCHARGER OUTLET PIPE
- 3 - ADAPTOR HOSE
- 4 - HOSE CLAMPS
- 5 - TURBOCHARGER INLET PIPE RETAINING BOLT
- 6 - TURBOCHARGER INLET PIPE
- 7 - ADAPTOR HOSE
- 8 - HOSE CLAMPS
- 9 - EGR VALVE TO INTAKE AIR INLET PIPE
- 10 - CLAMP
- 11 - THERMOSTAT HOUSING TO UPPER RADIATOR HOSE PIPE

(6) Lower the vehicle.

(7) Remove the auxiliary heater coolant pipe upper retaining nut.

(8) Remove the coolant recovery pressure container (Refer to 7 - COOLING/ENGINE/COOLANT RECOVERY PRESS CONTAINER - REMOVAL).

(9) Disconnect the upper radiator hose from the coolant tube.

(10) Remove the coolant tube fasteners and tube.

EXHAUST MANIFOLD (Continued)

(11) Disconnect the charger air inlet at the tube and remove the tube.

(12) Disconnect the EGR cooler coolant hoses.

(13) Disconnect the EGR cooler tube clamp.

(14) Disconnect the EGR vacuum hose.

(15) Remove the engine lift bracket (Fig. 97).

(19) Remove the turbocharger (Refer to 11 - EXHAUST SYSTEM/TURBOCHARGER SYSTEM/TURBOCHARGER - REMOVAL).

(20) Remove the lower exhaust manifold fasteners and exhaust manifold (Fig. 97).

INSTALLATION

(1) Clean exhaust manifold mating surfaces.

NOTE: The exhaust manifold tightening sequence must be repeated after the original sequence is completed.

(2) Install the exhaust manifold gasket and carefully position the exhaust manifold onto the cylinder head. Tighten the fasteners in a cross pattern working from the inside out to 36 N·m (26.5 lbs. ft.) (Fig. 97).

(3) Install the turbocharger (Refer to 11 - EXHAUST SYSTEM/TURBOCHARGER SYSTEM/TURBOCHARGER - INSTALLATION).

(4) Lower the vehicle

(5) Install the exhaust manifold heat shields. Tighten shield fasteners to 27.5 N·m (21 lbs. ft.) (Fig. 97).

(6) Connect the EGR vacuum hose and cooler hoses.

(7) Connect the EGR Cooler tube.

(8) Install the engine lift bracket (Fig. 97).

(9) Install the charge air tube (Fig. 96).

(10) Install the coolant tube and fasteners (Fig. 96).

(11) Connect the upper radiator to the coolant tube.

(12) Install the coolant reservoir (Refer to 7 - COOLING/ENGINE/COOLANT RECOVERY PRESS CONTAINER - INSTALLATION).

(13) Install the auxiliary heater tube fastener. Tighten fastener to 27.5 N·m (21 lbs. ft.).

(14) Raise and support the vehicle.

(15) Connect and tighten the charge air hose to the turbocharger (Fig. 96).

(16) Lower the vehicle.

(17) Install the wiper cowl assembly (Refer to 23 - BODY/EXTERIOR/COWL GRILLE - INSTALLATION).

(18) Install the battery and tray assembly (Refer to 8 - ELECTRICAL/BATTERY SYSTEM/TRAY - INSTALLATION).

(19) Start engine and inspect for leaks.




Fig. 97 EXHAUST MANIFOLD AND TURBOCHARGER

- 1 - TURBOCHARGER OIL SUPPLY BANJO BOLT
- 2 - COPPER WASHER
- 3 - EXHAUST MANIFOLD GASKET
- 4 - COPPER WASHER
- 5 - EXHAUST MANIFOLD HEAT SHIELD RETAINING BOLT
- 6 - TURBOCHARGER
- 7 - ENGINE LIFT HOOK
- 8 - ENGINE LIFT HOOK RETAINING BOLT
- 9 - SPACER
- 10 - EXHAUST MANIFOLD RETAINING NUT
- 11 - TURBOCHARGER OIL RETURN HOSE
- 12 - HOSE CLAMPS
- 13 - EXHAUST MANIFOLD STUDS

(16) Remove the exhaust manifold shields (Fig. 97).

(17) Remove the exhaust manifold upper fasteners (Fig. 97).

(18) Raise and support the vehicle.


VALVE TIMING

STANDARD PROCEDURE - LOCKING ENGINE 90° AFTER TDC

- (1) Disconnect negative battery cable.
- (2) Remove starter motor (Refer to 8 - ELECTRICAL/STARTING/STARTER MOTOR - REMOVAL).

NOTE: Crankshaft hub retaining bolt is left hand thread.

- (3) Rotate engine until notch in hub is in the following position (Fig. 98).



80e08e25

Fig. 98 CRANKSHAFT HUB ALIGNMENT

- 1 - VIBRATION DAMPER/CRANKSHAFT PULLEY
- 2 - CRANKSHAFT HUB NOTCH
- 3 - VIBRATION DAMPER/CRANKSHAFT PULLEY TO CRANKSHAFT HUB BOLTS
- 4 - ACCESSORY DRIVE BELT


- (4) Remove the yellow plastic plug and install special tool VM.1068 in the engine block as shown at this time (Fig. 99). This will lock the engine at 90° after TDC.

- (5) Remove front wiper unit (Refer to 8 - ELECTRICAL/WIPERS/WASHERS/WIPER MODULE - REMOVAL).

- (6) Remove engine cover (Refer to 9 - ENGINE - REMOVAL).

- (7) Remove plug in cylinder head cover/intake manifold and insert VM.1053 to lock exhaust camshaft in position (Fig. 100).


- (8) Remove generator (Refer to 8 - ELECTRICAL/CHARGING/GENERATOR - REMOVAL).



80c7599b

Fig. 99 90 DEGREES AFTER TDC ALIGNMENT PIN LOCATION

- 1 - ENGINE BLOCK
- 2 - VM.1051 TDC PIN OR VM.1068 90 DEGREES ATDC PIN
- 3 - FLYWHEEL



80c759d9

**Fig. 100 EXHAUST CAMSHAFT LOCKING PIN
VM.1053**

- 1 - EXHAUST MANIFOLD HEAT SHIELD
- 2 - EXHAUST CAMSHAFT LOCKING PIN VM.1053
- 3 - COOLANT TUBE FROM THERMOSTAT HOUSING TO UPPER RADIATOR HOSE
- 4 - CYLINDER HEAD COVER/INTAKE MANIFOLD

VALVE TIMING (Continued)

(9) Remove plug in cylinder head cover/intake manifold and insert VM.1052 to lock intake camshaft in position (Fig. 101).




Fig. 101 INTAKE CAMSHAFT LOCKING PIN VM.1052

- 1 - TIMING BELT INNER COVER
- 2 - GLOW PLUG ELECTRICAL CONNECTOR
- 3 - CYLINDER HEAD COVER/INTAKE MANIFOLD
- 4 - FUEL RAIL
- 5 - INTAKE CAMSHAFT LOCKING PIN VM.1052

(10) At this point the timing belt can be removed for service.

(11) After engine service is completed and timing belt reinstalled, remove both camshaft locking pins from cylinder head cover/intake manifold.

(12) Install both camshaft access plugs.

(13) Remove 90° after TDC engine locking pin and install the plastic cover.

(14) Install starter motor (Refer to 8 - ELECTRICAL/STARTING/STARTER MOTOR - INSTALLATION).

(15) Install generator (Refer to 8 - ELECTRICAL/CHARGING/GENERATOR - INSTALLATION).

(16) Install engine cover (Refer to 9 - ENGINE - INSTALLATION).

(17) Install front wiper unit (Refer to 8 - ELECTRICAL/WIPERS/WASHERS/WIPER MODULE - INSTALLATION).

(18) Connect negative battery cable.

BALANCE SHAFT

DESCRIPTION

The 2.5L/2.8L Common Rail Diesel engine is equipped with two nodular cast iron balance shafts in a cast aluminum carrier. The balance shaft assembly is mounted to the engine block (Fig. 102).

OPERATION

The balance shaft is driven by the crankshaft. The balance shafts are connected by helical gears. The dual-counter rotating shafts decrease second order vertical shaking forces caused by component movement.

REMOVAL

- (1) Disconnect negative battery cable.
- (2) Raise vehicle on hoist.
- (3) Before installation of the balance shaft assembly, the # 1 cylinder must be brought to TDC. Using special tool VM.1051, roll engine over by hand until tool can be inserted into engine block locking fly-wheel from turning.
- (4) Remove oil pan (Refer to 9 - ENGINE/LUBRICATION/OIL PAN - REMOVAL).
- (5) Remove balance shaft assembly (Fig. 102).

INSTALLATION

(1) Before installation of the balance shaft assembly, the # 1 cylinder must be brought to TDC. Using special tool VM.1051, roll engine over by hand until tool can be inserted into engine block locking fly-wheel from turning (Fig. 103). Once the # 1 cylinder is brought to TDC, the balance shaft assembly can be installed.

(2) With balance shaft assembly on work bench. Insert special tool VM.1056 into balance shaft assembly (Fig. 104). This will ensure proper balance shaft and crankshaft timing after assembly.


(3) Install balance shaft assembly and retaining bolts (Fig. 102). Torque bolts to 32.4N·m.

(4) Install oil pan (Refer to 9 - ENGINE/LUBRICATION/OIL PAN - INSTALLATION).

(5) Refill engine oil to proper level.

(6) Connect negative battery cable.


BALANCE SHAFT (Continued)



80ff3586

Fig. 102 OIL PUMP PICKUP TUBE ASSEMBLY

- 1 - BALANCE SHAFT
- 2 - OIL JET RETAINING BOLT
- 3 - OIL JET
- 4 - ENGINE BLOCK
- 5 - CRANKSHAFT
- 6 - O- RING(S)
- 7 - BALANCE SHAFT RETAINING BOLTS
- 8 - OIL DIPSTICK TUBE RETAINER
- 9 - RUBBER BUSHING
- 10 - RETAINING BOLT



80c7595e

**Fig. 104 BALANCE SHAFT ALIGNMENT PIN
VM.1056**

- 1 - VM.1056
- 2 - BALANCE SHAFT ASSEMBLY

TIMING BELT COVER


REMOVAL

REMOVAL - TIMING BELT OUTER COVER

- (1) Disconnect negative battery cable.
- (2) Remove engine cover (Refer to 9 - ENGINE - REMOVAL).
- (3) Remove air cleaner housing.
- (4) Support engine and remove right engine mount and bracket.
- (5) Remove power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (6) Remove accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (7) Remove vibration damper (Refer to 9 - ENGINE/ENGINE BLOCK/VIBRATION DAMPER - REMOVAL).
- (8) Remove timing belt outer cover retaining bolts and remove cover (Fig. 105).

REMOVAL - TIMING BELT INNER COVER

- (1) Disconnect negative battery cable.
- (2) Remove engine cover (Refer to 9 - ENGINE - REMOVAL).
- (3) Remove air cleaner housing.




80c7599b

Fig. 103 TDC ALIGNMENT PIN LOCATION

- 1 - ENGINE BLOCK
- 2 - VM.1051 TDC PIN OR VM.1068 90 DEGREES ATDC PIN
- 3 - FLYWHEEL

TIMING BELT COVER (Continued)



80ae1afd

Fig. 105 TIMING BELT COVER (OUTER)

- 1 - SEAL
- 2 - TIMING BELT OUTER COVER
- 3 - RETAINING BOLTS

(4) Support engine and remove right engine mount and bracket.

(5) Remove power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).

(6) Remove accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).


(7) Remove vibration damper (Refer to 9 - ENGINE/ENGINE BLOCK/VIBRATION DAMPER - REMOVAL).

(8) Remove timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).

(9) Remove timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - REMOVAL).

(10) Remove timing belt idler pulleys (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT IDLER PULLEY - REMOVAL).

(11) Using special tool VM.1055, remove camshaft sprockets (Fig. 106).



80c5f3ef

Fig. 106 CAMSHAFT SPROCKET REMOVAL/INSTALLATION

- 1 - TIMING BELT INNER COVER
- 2 - CAMSHAFT SPROCKET
- 3 - IDLER PULLEYS
- 4 - CAMSHAFT SPROCKET
- 5 - VM.1055

(12) Remove timing belt tensioner (Refer to 9 - ENGINE/VALVE TIMING/TMNG BELT/CHAIN TENSIONER&PULLEY - REMOVAL).

(13) Remove injection pump sprocket (Refer to 14 - FUEL SYSTEM/FUEL DELIVERY/FUEL INJECTION PUMP - REMOVAL).

(14) Remove timing belt inner cover retaining bolts and remove cover (Fig. 107).

INSTALLATION**INSTALLATION - TIMING BELT OUTER COVER**


(1) Install timing belt outer cover seal and cover (Fig. 105). Torque 3mm bolts to 10.8N·m and 8mm bolts to 10.8N·m.

(2) Install vibration damper (Refer to 9 - ENGINE/ENGINE BLOCK/VIBRATION DAMPER - INSTALLATION).

(3) Install accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(4) Install power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

TIMING BELT COVER (Continued)



80c6c90e

Fig. 107 TIMING BELT COVER - INNER

- 1 - TIMING BELT COVER TO CYLINDER HEAD COVER GASKET
- 2 - TIMING BELT COVER TO FRONT ENGINE COVER SEAL
- 3 - RUBBER GROMMET
- 4 - BUSHING
- 5 - TIMING BELT COVER - INNER
- 6 - RETAINING BOLT
- 7 - RETAINING BOLT
- 8 - RETAINING BOLT
- 9 - BUSHING
- 10 - RUBBER GROMMET

- (5) Install right engine mount.
- (6) Install air cleaner housing.
- (7) Install engine cover (Refer to 9 - ENGINE - INSTALLATION).
- (8) Connect negative battery cable.

INSTALLATION - TIMING BELT INNER COVER

- (1) Install timing belt inner cover to engine front cover seal (Fig. 107).
- (2) Install timing belt inner cover to cylinder head cover gaskets (Fig. 107).
- (3) Install timing belt inner cover and retaining bolts (Fig. 107). Torque 10mm bolts to 47.1N·m and 8mm bolts to 10.8N·m.
- (4) Install injection pump sprocket (Refer to 14 - FUEL SYSTEM/FUEL DELIVERY/FUEL INJECTION PUMP - INSTALLATION).
- (5) Install camshaft sprockets (Fig. 106). Torque bolts to 108N·m.

(6) Install timing belt idler pulleys (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT IDLER PULLEY - INSTALLATION).

(7) Install timing belt and tensioner (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - INSTALLATION).

(8) Install timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

(9) Install vibration damper (Refer to 9 - ENGINE/ENGINE BLOCK/VIBRATION DAMPER - INSTALLATION).

(10) Install accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(11) Install power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(12) Install right engine mount assembly.

(13) Install air cleaner housing.

(14) Install engine cover (Refer to 9 - ENGINE - INSTALLATION).

(15) Connect negative battery cable.


TIMING BELT IDLER PULLEY**REMOVAL**

- (1) Disconnect negative battery cable.
- (2) Remove engine cover (Refer to 9 - ENGINE - REMOVAL).
- (3) Remove air cleaner housing.
- (4) Support engine and remove right engine mount.
- (5) Remove power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (6) Remove accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (7) Remove vibration damper (Refer to 9 - ENGINE/ENGINE BLOCK/VIBRATION DAMPER - REMOVAL).
- (8) Remove timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).
- (9) Remove timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - REMOVAL).

NOTE: Idler pulley retaining bolts are LHD thread.

- (10) Remove timing belt idler pulleys (Fig. 108).

TIMING BELT IDLER PULLEY (Continued)



812067b9

Fig. 108 TIMING BELT AND SPROCKETS

- 1 - CAMSHAFT SPROCKETS
- 2 - INJECTION PUMP SPROCKET
- 3 - INJECTION PUMP SPROCKET RETAINING NUT
- 4 - TIMING BELT TENSIONER
- 5 - TIMING BELT
- 6 - IDLER PULLEY

INSTALLATION

- (1) Install timing belt idler pulleys (Fig. 108). Torque bolts to 47.1N·m.
- (2) Install timing belt (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT/CHAIN AND SPROCKETS - INSTALLATION).
- (3) Install timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).
- (4) Install vibration damper (Refer to 9 - ENGINE/ENGINE BLOCK/VIBRATION DAMPER - INSTALLATION).
- (5) Install accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).
- (6) Install power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).
- (7) Install right engine mount.
- (8) Install air cleaner housing.
- (9) Install engine cover (Refer to 9 - ENGINE - INSTALLATION).
- (10) Connect negative battery cable.

TIMING BELT TENSIONER & PULLEY**REMOVAL**

CAUTION: INSPECT THE TOOTHED BELT, PULLEYS AND BEARINGS FOR DAMAGE, SEIZURE AND LEAKS.

NOTE: DO NOT expose the toothed belt to oil, grease or water contamination. **DO NOT** clean belt, pulleys or tensioner with solvent. **DO NOT** crimp the timing belt at a sharp angle. **DO NOT** install belt with levered tools forcing the belt onto the pulleys.

- (1) Disconnect negative battery cable.
- (2) Remove engine cover (Refer to 9 - ENGINE - REMOVAL).
- (3) Remove air cleaner housing.
- (4) Support engine and remove right engine mount.
- (5) Remove power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (6) Remove accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (7) Remove vibration damper (Refer to 9 - ENGINE/ENGINE BLOCK/VIBRATION DAMPER - REMOVAL).
- (8) Remove timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).
- (9) Loosen and remove timing belt tensioner (Fig. 109).


INSTALLATION

CAUTION: INSPECT THE TOOTHED BELT, PULLEYS AND BEARINGS FOR DAMAGE, SEIZURE AND LEAKS.

NOTE: DO NOT expose the toothed belt to oil, grease or water contamination. **DO NOT** clean belt, pulleys or tensioner with solvent. **DO NOT** crimp the timing belt at a sharp angle. **DO NOT** install belt with levered tools forcing the belt onto the pulleys.

- (1) Install timing belt tensioner and retaining bolt (Fig. 109).
- (2) Adjust timing belt tensioner (Refer to 9 - ENGINE/VALVE TIMING/TMNG BELT/CHAIN TENSIONER&PULLEY - ADJUSTMENTS).


TIMING BELT TENSIONER & PULLEY (Continued)



812067b9

Fig. 109 TIMING BELT AND SPROCKETS

- 1 - CAMSHAFT SPROCKETS
- 2 - INJECTION PUMP SPROCKET
- 3 - INJECTION PUMP SPROCKET RETAINING NUT
- 4 - TIMING BELT TENSIONER
- 5 - TIMING BELT
- 6 - IDLER PULLEY



80c6ca1b

Fig. 110 TIMING BELT TENSIONER ADJUSTMENT

- 1 - TIMING BELT IDLER PULLEY
- 2 - ENGINE FRONT COVER
- 3 - CRANKSHAFT HUB
- 4 - TIMING BELT TENSIONER
- 5 - TIMING BELT

(3) Install timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

(4) Install vibration damper (Refer to 9 - ENGINE/ENGINE BLOCK/VIBRATION DAMPER - INSTALLATION).

(5) Install accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(6) Install power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(7) Install right engine mount.

(8) Install air cleaner housing.

(9) Install engine cover (Refer to 9 - ENGINE - INSTALLATION).

(10) Connect negative battery cable.


ADJUSTMENTS

ADJUSTMENT - TIMING BELT TENSIONER

(1) With timing belt outer cover removed and timing belt installed.

(2) Loosen timing belt tensioner (Fig. 110).

(3) Align timing belt tensioner spring stop with tensioner as shown (Fig. 111) and torque timing belt tensioner retaining bolt to 34.7N-m.



80c6c9fa

Fig. 111 TIMING BELT TENSIONER ALIGNMENT

- 1 - TENSIONER SPRING STOP
- 2 - TIMING BELT TENSIONER
- 3 - TIMING BELT TENSIONER
- 4 - TIMING BELT
- 5 - TIMING BELT INNER COVER

TIMING BELT TENSIONER & PULLEY (Continued)

(4) Rotate engine 2 complete revolution and then recheck tensioner alignment. Readjust tensioner alignment as necessary.

TIMING BELT AND SPROCKETS

REMOVAL

CAUTION: BEFORE REMOVING THE TIMING BELT, THE ENGINE MUST BE PLACED AT 90° ATDC. FAILURE TO DO SO COULD RESULT IN VALVE AND/OR PISTON DAMAGE DURING REASSEMBLY. (Refer to 9 - ENGINE/VALVE TIMING - STANDARD PROCEDURE)

CAUTION: INSPECT THE TOOTHED BELT, PULLEYS AND BEARINGS FOR DAMAGE, SEIZURE AND LEAKS.

NOTE: DO NOT expose the toothed belt to oil, grease or water contamination. **DO NOT** clean belt, pulleys or tensioner with solvent. **DO NOT** crimp the timing belt at a sharp angle. **DO NOT** install belt with levered tools forcing the belt onto the pulleys.

- (1) Disconnect negative battery cable.
- (2) Remove engine cover (Refer to 9 - ENGINE - REMOVAL).
- (3) Remove air cleaner housing assembly.
- (4) Support engine and remove right engine mount.
- (5) Remove power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (6) Remove accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - REMOVAL).
- (7) Remove the generator.
- (8) Rotate engine until #1 piston is at TDC, crankshaft notch on the crankshaft hub will be at 12 o'clock.
- (9) Looking at the engine from the belt side, rotate the crankshaft 90° clockwise.
- (10) Install the 90° alignment pin, VM 1068 into the crankcase threaded hole to lock crankshaft (make sure the crankshaft will not rotate).
- (11) Paint mark the crankshaft hub and the oil pump cover. This will assist during assembly.
- (12) Remove vibration damper (Refer to 9 - ENGINE/ENGINE BLOCK/VIBRATION DAMPER - REMOVAL).

(13) Remove timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - REMOVAL).


(14) Remove the intake and exhaust camshaft plugs from the camshaft cover to introduce the camshaft timing pins.

NOTE: If the engine is already timed, install the camshaft alignment pins (intake cam alignment pin, VM 1052, exhaust cam alignment pin, VM 1053).

(15) Loosen timing belt tensioner and remove timing belt (Fig. 112).

(16) Using intake camshaft gear bolt, rotate intake camshaft until the intake alignment hole lines up with the hole in the camshaft cover. Install the intake cam alignment pin VM 1052. Repeat the operation for the exhaust camshaft with alignment pin VM 1053 (Fig. 112).

(17) Using VM 1055 hold the cam gears to remove the bolts.



812067b9

Fig. 112 TIMING BELT AND SPROCKETS


- 1 - CAMSHAFT SPROCKETS
- 2 - INJECTION PUMP SPROCKET
- 3 - INJECTION PUMP SPROCKET RETAINING NUT
- 4 - TIMING BELT TENSIONER
- 5 - TIMING BELT
- 6 - IDLER PULLEY

INSTALLATION

(1) With both camshaft alignment pins still installed and the engine locked at 90° after TDC, install the timing gears finger tight.

(2) Align timing mark on high pressure injection pump sprocket with timing mark on cover (Fig. 113).

TIMING BELT AND SPROCKETS (Continued)



80c75938

Fig. 113 INJECTION PUMP GEAR TIMING MARKS

- 1 - TIMING MARK ON COVER
- 2 - TIMING MARK ON INJECTION PUMP SPROCKET
- 3 - INJECTION PUMP SPROCKET

(3) Install timing belt on crankshaft hub, fix it with VM1074, then around high pressure injection pump, idler pulley, intake camshaft gear, exhaust camshaft gear, idler pulley and water pump gear.

NOTE: To uniform the belt tension, slightly rotate the intake camshaft pulley counterclockwise with VM 1055.

(4) Adjust the timing belt tensioner (turn it clockwise), lining up the tensioner center notch with aluminum cover dowel pin (Fig. 114). Tighten the tensioner bolt to 28N·m (20.5 lbs. ft.).

(5) Torque camshaft gear bolts to 60 N·m (44 lbs.ft.) (pre setting) holding gears with VM 1055.

(6) Remove both camshaft alignment pins from cylinder head cover/intake manifold. (Refer to 9 - ENGINE/VALVE TIMING - STANDARD PROCEDURE) .


(7) Torque camshaft gear bolts to 108 N·m (80 lbs.ft.) while holding gears with VM 1055.

(8) Remove 90° ATDC engine locking pin from engine block.

CAUTION: Wait 30 minutes before rotating crankshaft after installing camshaft cover.

(9) Rotate crankshaft 2 times (looking at it from the belt side)

(10) Carefully line up the painted mark on the crankshaft hub and oil pump cover.



81208457

Fig. 114 TIMING BELT TENSIONER ALIGNMENT

- 1 - TENSIONER SPRING
- 2 - 1MM ALIGNMENT POINTER OVERLAP
- 3 - TENSIONER ALIGNMENT POINTER
- 4 - TENSIONER ASSEMBLY

CAUTION: IF THE CAMSHAFT ALIGNMENT PINS CAN NOT BE INSTALLED, REPEAT THIS PROCEDURE.

(11) Check that the intake and exhaust cam alignment pins CAN be installed, if so remove them.

(12) Install the intake and exhaust camshaft plugs.

(13) Install timing belt outer cover (Refer to 9 - ENGINE/VALVE TIMING/TIMING BELT / CHAIN COVER(S) - INSTALLATION).

(14) Install vibration damper (Refer to 9 - ENGINE/ENGINE BLOCK/VIBRATION DAMPER - INSTALLATION).

(15) Install the alternator.

(16) Install accessory drive belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(17) Install power steering belt (Refer to 7 - COOLING/ACCESSORY DRIVE/DRIVE BELTS - INSTALLATION).

(18) Install right engine mount.

(19) Install air cleaner housing.

(20) Install engine cover (Refer to 9 - ENGINE - INSTALLATION).

(21) Connect negative battery cable.

