

2006 Hyundai Santa Fe GLS

2006 ENGINE Engine Mechanical System (G6BA-GSL 2.7) - Santa Fe

2006 ENGINE**Engine Mechanical System (G6BA-GSL 2.7) - Santa Fe****GENERAL****SPECIFICATIONS****GENERAL SPECIFICATIONS TABLE**

Description	Specification	Limit
General		
Type	V-type, DOHC	
Number of cylinder	6	
Bore	86.7 mm (3.4133 in.)	
Stroke	75 mm (2.9528 in.)	
Total displacement	2,656 cc	
Compression ratio	10: 1	
Firing order	1-2-3-4-5-6	
Valve timing		
Intake valve		
Open (BTDC) 6°		
Close (ABDC)	46°	
Exhaust valve		
Open (BBDC)	44°	
Close (ATDC)	8°	
Camshaft		
Driver mechanism	Cogged type belt	
Cam height		
Intake	43.95 ~ 44.15 mm (1.7303 ~ 1.7382 in.)	43.45 mm (1.7106 in.)
Exhaust	43.95 ~ 44.15 mm (1.7303 ~ 1.7382 in.)	43.45 mm (1.7106 in.)
Journal dynamiter	25.964 ~ 25.980 mm (1.0222 ~ 1.0228 in.)	25.914 mm
Bearing oil clearance	0.02 ~ 0.061 mm (0.0007 ~ 0.0024 in.)	(1.0202 in.)
Endplay	0.1 ~ 0.15 mm (0.0039 ~ 0.0059 in.)	0.1 mm (0.0039 in.)
Cylinder head		
Flatness of cylinder head surface	Max. 0.03 mm (0.0012 in.)	0.05 mm (0.0020 in.)
Flatness of manifold mounting surface		
Intake	Max. 0.15 mm (0.0059 in.)	0.15 mm (0.0059 in.)
Exhaust	Max. 0.15 mm (0.0059 in.)	0.15 mm (0.0059 in.)

2006 Hyundai Santa Fe GLS

2006 ENGINE Engine Mechanical System (G6BA-GSL 2.7) - Santa Fe

Valve guide hole diameter 0.05 (0.002) O.S. 0.25 (0.010) O.S. 0.50 (0.020) O.S. Intake valve seat ring hole diameter. 0.3 (0.012) O.S. Exhaust valve seat ring hole diameter 0.3 (0.012) O.S.	11.05 ~ 11.068 mm (0.435 ~ 0.436 in.) 11.25 ~ 11.268 mm (0.443 ~ 0.444 in.) 11.50 ~ 11.518 mm (0.453 ~ 0.453 in.) 3.300-33.325 mm (1.311-1.312 in.) 28.600 ~ 28.621 mm (1.126 ~ 1.127 in.)	
Valve Overall length Intake Exhaust Stem diameter Intake Exhaust Face angle Margin Intake Exhaust Clearance (stem-to-guide) Intake Exhaust	96.1 mm (3.783 in.) 97.15 mm (3.825 in.) 5.965 ~ 5.98 mm (0.235 ~ 0.2354 in.) 5.95 ~ 5.965 mm (0.234 ~ 0.235 in.) 45° ~ 45.5° 1.0 mm (0.0394 in.) 1.3 mm (0.0512 in.) 0.02 ~ 0.05 mm (0.0008 ~ 0.0020 in.) 0.035 ~ 0.065 mm (0.0014 ~ 0.0026 in.)	0.5 mm (0.0197 in.) 0.8 mm (0.0315 in.) 0.10 mm (0.0039 in.) 0.15 mm (0.0059 in.)
Valve spring Free height 42.5 mm (1.6732 in.) Load Out of squareness	41.5 mm (1.6339 in.) 21.9 kg/ 35 mm (48.4 lb/1.3780 in.) Max 1.5°	21.9 kg/34 mm (48.4 lb/1.3386 in.) Max 3°
Piston Diameter (Standard) Clearance (Piston-to-cylinder) Ring groove width No. 1 No. 2 Oil Piston for service	86.68 ~ 86.71 mm (3.413 ~ 3.414 in.) 0.01 ~ 0.03 mm (0.0004 ~ 0.0012 in.) 1.230 ~ 1.250 mm (0.0484 ~ 0.0492 in.) 1.220 ~ 1.240 mm (0.0480 ~ 0.0488 in.) 2.515 ~ 2.535 mm (0.0990 ~ 0.0998 in.) 0.25 mm (0.010 in.), 0.50 mm (0.020 in.)	
Piston ring Number of rings per piston Compression ring Oil ring	3 2 1	

2006 Hyundai Santa Fe GLS

2006 ENGINE Engine Mechanical System (G6BA-GSL 2.7) - Santa Fe

Compression ring type		
No. 1	Inner bevel type	
No. 2	Under cut type	
Oil ring type	3-piece type	
Ring end gap		
No. 1	0.20 ~ 0.35 mm (0.0079 ~ 0.0138 in.)	0.8 mm (0.031 in.)
No. 2	0.37 ~ 0.52 mm (0.0146 ~ 0.0205 in.)	0.8 mm (0.031 in.)
Oil ring side rail	0.2 ~ 0.7 mm (0.0079 ~ 0.0276 in.)	1.0 mm (0.039 in.)
Ring side clearance		
No. 1	0.04 ~ 0.08 mm (0.0016 ~ 0.0031 in.)	0.1 mm (0.004 in.)
No. 2	0.03 ~ 0.07 mm (0.0012 ~ 0.0028 in.)	0.1 mm (0.004 in.)
Rings for service	0.25 mm (0.010 in.), 0.50 mm (0.020 in.)	
Connecting rod		
Piston pin installation force	2,450 ~ 12,255 N (250 ~ 1,250 kg, 551 ~ 2,755 lb)	
Side clearance	0.10 ~ 0.25 mm (0.0039 ~ 0.0098 in.)	0.4 mm (0.016 in.)
Bend	0.05 mm or less/100 mm (0.0020 in. or less/3.937 in.)	
Bearing oil clearance	0.018 ~ 0.036 mm (0.0007 ~ 0.0014 in.)	0.1 mm (0.004 in.)
Crankshaft		
Journal O.D.	61.982 ~ 62.000 mm (2.4402 ~ 2.4409 in.)	
Pin O.D.	47.982 ~ 48.000 mm (1.8891 ~ 1.8898 in.)	
Out-of-round of journal and pin	Max. 0.003 mm (0.00012 in.)	
Taper of journal and pin	Max. 0.005 mm (0.00020 in.)	
End play	0.070 ~ 0.250 mm (0.0028 ~ 0.0098 in.)	0.4 mm (0.016 in.)
Main bearing oil clearance	0.004 ~ 0.022 mm (0.0002 ~ 0.0009 in.)	0.1 mm (0.004 in.)
Cylinder block		
Cylinder bore	86.7 mm (3.4134 in.)	
Flatness of gasket surface	Max. 0.03 mm (0.0012 in.)	0.05 mm (0.002 in.)
Out-of-round of cylinder bore	Max. 0.02 mm (0.0008 in.)	
Oil pump		
Body clearance	0.100 ~ 0.181 mm (0.0039 ~ 0.0071 in.)	
Side clearance	0.040 ~ 0.095 mm (0.0016 ~ 0.0037 in.)	
Relief spring		
Free length	43.8 mm (1.724 in.)	
Load	4.6 kg/39.3 mm (10 lb / 1.547 in.)	
Oil filter		
Type	Cartridge, full flow	
Engine oil pressure	50 kPa (7.3 psi) or more [Conditions: Oil temperature is 75 to 90°C (167 to 194°F)]	
Cooling method	Engine coolant cooling, forced circulation with electric fan	

2006 Hyundai Santa Fe GLS

2006 ENGINE Engine Mechanical System (G6BA-GSL 2.7) - Santa Fe

Cooling system quantity	7.0 lit (7.4 U.S. qts., 6.1 Imp. qts.) [For V6]	
Thermostat		
Type	Wax pellet type with jiggle valve	
Normal opening temperature	82 +/- 2.0°C (179.6 +/- 35.6°F)	
Opening temperature range	80°C ~ 84°C (176 ~ 183.2°F)	
Wide open temperature	95°C (203°F)	
Radiator cap		
Main valve opening pressure	107.9 +/- 14.7 kPa (1.1 +/- 0.15 kg/cm ² , 15.64 +/- 2.13 psi)	
Main valve closing pressure	83.4 kPa (0.85 kg/cm ² , 12.1 psi)	
Vacuum valve opening pressure	-6.86 kPa (-0.07 kg/cm ² , -1.00 psi)	
Air cleaner		
Type	Dry	
Element	Paper	
Exhaust pipe		
Muffler Expansion resonance type		
Suspension system	Rubber hangers	

SERVICE STANDARD**SERVICE STANDARD TABLE**

Standard value	
Coolant concentration	
Tropical areas	40%
Other areas	50%

COOLANT**COOLANT SPECIFICATIONS TABLE**

Engine coolant	Ethylene glycol base for aluminum radiator
----------------	--

SEALANT**SEALANT SPECIFICATIONS TABLE**

Engine coolant temperature sensor	LOCTITE 262 or equivalent, Three bond No. 1324 or equivalent
Oil pressure switch	3M ATD No. 8660 or Three bond No. 1141E
PCV valve	LOCTITE 242 or equivalent

TIGHTENING TORQUE**TIGHTENING TORQUE**

--	--	--	--

2006 Hyundai Santa Fe GLS

2006 ENGINE Engine Mechanical System (G6BA-GSL 2.7) - Santa Fe

Item	N.m	kg.cm	lb.ft
Camshaft sprocket bolt	90 ~ 110	900 ~ 1,100	65 ~ 80
Cylinder head cover bolt	8 ~ 10	80 ~ 100	5.8 ~ 7.2
Main bearing cap bolt			
M10	27--33+(90°~94°)	270~330+(90°~94°)	19.5~24+(90°~94°)
M8	13~19+(90°~94°)	130~190+(90°~94°)	10~14+(90°~94°)
Connecting rod bolt	16~20+(90°~94°)	160~200+(90°~94°)	12~15+(90°~94°)
Cylinder head bolt (Cold engine)	25+(58°~62°)+(43~47°)	250+(58°~62°) (43~47°)	18+(58°~62°)+(43~47°)
Oil pan drain plug	35 ~ 45	350 ~ 450	25 ~ 33
Lower oil pan bolt	10 ~ 12	100 ~ 120	7 ~ 9
Upper oil pan bolt			
[10x38 mm (0.937x1.4961 in.)]	30 ~ 42	300 ~ 420	22 ~ 30
[8x22 mm (0.3150x0.8661 in.)]	19 ~ 28	190 ~ 280	14 ~ 20
[161.5 mm (6.3582 in.)]	5 ~ 7	50 ~ 70	4 ~ 5
[152.5 mm (6.0039 in.)]	5 ~ 7	50 ~ 70	4 ~ 5
Oil screen bolt	15 ~ 22	150 ~ 220	11 ~ 16
Oil pump case bolt	12 ~ 15	120 ~ 150	9 ~ 11
Oil relief valve plug	40 ~ 50	400 ~ 500	29 ~ 36
Oil pressure switch	15 ~ 22	150 ~ 220	11 ~ 16
Oil pump cover screw	8 ~ 12	80 ~ 120	6 ~ 9
Oil filter	12 ~ 16	120 ~ 160	9 ~ 12
Fly wheel bolt	73 ~ 77	730 ~ 770	53 ~ 56
Drive plate and adaptor plate bolt	73 ~ 77	730 ~ 770	53 ~ 56
Air cleaner body installation bolt	8 ~ 12	80 ~ 120	6 ~ 9
Surge tank stay	15 ~ 20	150 ~ 200	11 ~ 14
Air intake surge tank to intake manifold (bolt)	15 ~ 20	150 ~ 200	11 ~ 14
Air intake surge tank to intake manifold (nut)	15 ~ 20	150 ~ 200	11 ~ 14
Intake manifold to cylinder head	19 ~ 21	190 ~ 210	14 ~ 15
Heat protector to exhaust manifold	12 ~ 15	120 ~ 150	9 ~ 11
Exhaust manifold to cylinder head (Self-locking nut)	30 ~ 35	300 ~ 350	22 ~ 26
Oil level gauge guide to engine	12 ~ 15	120 ~ 150	9 ~ 11

2006 Hyundai Santa Fe GLS

2006 ENGINE Engine Mechanical System (G6BA-GSL 2.7) - Santa Fe

Water outlet fitting bolt	17 ~ 20	170 ~ 200	12 ~ 14
Power steering oil pump bracket to cylinder head	17 ~ 26	170 ~ 260	12 ~ 19
Power steering oil pump to bracket	17 ~ 26	170 ~ 260	12 ~ 19
Crank position sensor wheel screw	5 ~ 6	50 ~ 60	3.6 ~ 4.3
Engine mounting insulator bolt	40 ~ 55	400 ~ 550	29 ~ 40
Engine mounting bracket nut	60 ~ 80	600 ~ 800	43 ~ 58
Engine mounting bracket bolt	60 ~ 80	600 ~ 800	43 ~ 58
Item	Nm	kg.cm	lb.ft
Engine support bracket stud	30 ~ 40	300 ~ 400	22 ~ 29
Front roll stopper bracket to sub cross member bolt	40 ~ 55	400 ~ 550	29 ~ 40
Front roll stopper insulator bolt and nut	50 ~ 65	500 ~ 650	36 ~ 47
Rear roll stopper bracket to cross member bolt	40 ~ 55	400 ~ 550	29 ~ 40
Rear roll stopper insulator bolt and nut	50 ~ 65	500 ~ 650	36 ~ 47
Transaxle mounting bracket bolt	40 ~ 55	400 ~ 550	29 ~ 40
Transaxle mounting insulator bolt	90 ~ 110	900 ~ 1,100	65 ~ 80
Fuel hose clamp to rear cylinder head assembly	12 ~ 15	120 ~ 150	9 ~ 11
Transaxle mounting plate	10 ~ 12	100 ~ 120	7 ~ 9
Rear plate	10 ~ 12	100 ~ 120	7 ~ 9
Oil seal case	10 ~ 12	100 ~ 120	7 ~ 9
Crankshaft pulley bolt	180 ~ 190	1,800 ~ 1,900	130 ~ 138
Timing belt cover bolt	10 ~ 12	100 ~ 120	7 ~ 9
Engine hanger bracket to engine	20 ~ 27	200 ~ 270	14 ~ 20
Alternator mounting bracket to engine	20 ~ 30	200 ~ 300	14 ~ 22
Alternator mounting nut (Engine front case side)	20 ~ 30	200 ~ 300	14 ~ 22
Alternator mounting bolt (Alternator mounting bracket side)	20 ~ 30	200 ~ 300	14 ~ 22

2006 Hyundai Santa Fe GLS

2006 ENGINE Engine Mechanical System (G6BA-GSL 2.7) - Santa Fe

Starter to transmission (Nut)	20 ~ 30	200 ~ 300	14 ~ 22
Starter to transmission (Bolt)	27 ~ 34	270 ~ 340	20 ~ 25
Drive belt pulley bolt	35 ~ 55	350 ~ 550	25 ~ 40
Drive belt tensioner bolt	20 ~ 27	200 ~ 270	14 ~ 22
Engine coolant pump to cylinder block bolt (Head mark "7" bolt)	15 ~ 22	150 ~ 220	11 ~ 16
Engine coolant temperature sensor	20 ~ 40	200 ~ 400	14 ~ 29
Engine coolant inlet fitting attaching bolt	17 ~ 20	170 ~ 200	12 ~ 14
Throttle body to surge tank bolt	15 ~ 20	150 ~ 200	11 ~ 14
Oxygen sensor to exhaust manifold	40 ~ 50	400 ~ 500	29 ~ 36
Front exhaust pipe to exhaust manifold nut	30 ~ 40	300 ~ 400	22 ~ 29
Front exhaust pipe to catalytic converter bolt	40 ~ 60	400 ~ 600	29 ~ 43
Catalytic converter to center exhaust pipe nut	30 ~ 40	300 ~ 400	22 ~ 29
Center exhaust pipe to main muffler nut	30 ~ 40	300 ~ 400	22 ~ 29
Main muffler hanger support bracket bolt	10 ~ 15	100 ~ 150	7 ~ 11
Delivery pipe installation bolt	10 ~ 15	100 ~ 150	7 ~ 11
Timing belt tensioner pulley bolt	43 ~ 55	430 ~ 550	31 ~ 40
Timing belt idler pulley bolt	50 ~ 60	500 ~ 600	36 ~ 43
Timing belt tensioner arm Fixed bolt	35 ~ 55	350 ~ 550	25 ~ 40
Engine support bracket stud	30 ~ 40	300 ~ 400	22 ~ 29
Auto tensioner fixed bolt	20 ~ 27	200 ~ 270	14 ~ 20
Accelerator cable bracket	4 ~ 6	40 ~ 60	3 ~ 4
Spark plug	20 ~ 30	200 ~ 300	14 ~ 22

CHECKING ENGINE OIL

1. Position a vehicle on a level surface.

2. Turn off the engine.

NOTE: In the case of a vehicle that has not been used for a prolonged period, run the engine for several minutes. Turn off the engine and wait for 5 minutes at least, then check the oil level.

3. Check that the engine oil level is within the level range indicated on the oil dipstick. If the oil level is found to have fallen to the lower limit (the "L" mark), refill to the "F" mark.

NOTE: When refilling, use the proper grade of engine oil.

4. Check that the oil is not dirty or mixed with coolant or gasoline, and that it has the proper viscosity.




Fig. 1: Identifying Engine Oil Level Range
Courtesy of HYUNDAI MOTOR CO.


SELECTION OF ENGINE OIL

Recommended API classification: SH OR ABOVE

RECOMMENDED SAE VISCOSITY GRADES:

2006 Hyundai Santa Fe GLS

2006 ENGINE Engine Mechanical System (G6BA-GSL 2.7) - Santa Fe



G03844712

Fig. 2: Recommended SAE Viscosity Grades Chart
Courtesy of HYUNDAI MOTOR CO.

NOTE: For best performance and maximum protection of all types of operation, select only those lubricants which:

1. Satisfy the requirements of the API classification.
2. Have the proper SAE grade number for expected ambient temperature range.

Lubricants which do not have both an SAE grade number and an API service classification on the container should not be used.

CHANGE ENGINE OIL


1. Run the engine until it reaches normal operating temperature.

2. Turn off the engine.
3. Remove the oil filler cap and oil filter and then drain plug.
4. Drain the engine oil.
5. Tighten the drain plug to the specified torque.

Tightening torque

Oil pan drain plug:

35 ~ 45 Nm (350 ~ 450 kg.cm, 25 ~ 33 lb.ft)



G03844713

Fig. 3: Identifying Oil Pan

Courtesy of HYUNDAI MOTOR CO.

NOTE: Whenever tightening the oil drain plug, use a new drain plug gasket.

6. Fill the new engine oil through the oil filler cap.

Drain and Refill

Oil quantity: 4.5 lit (4.74 U.S. qts., 3.95 Imp. qts.)

NOTE: Do not over fill. This will cause oil aeration and loss of oil pressure.

7. Install the oil filler cap.
8. Start and run the engine.
9. Turn off the engine and then check the oil level. Add oil if necessary.

REPLACEMENT OIL FILTER

FILTER SELECTION

All Hyundai Motor Company engines are equipped with a high quality, disposable oil filter. This filter is recommended as a replacement filter for all vehicles. The quality of after market replacement filters vary considerably.

High quality of replacement filters should be used to assure the most efficient service. Make sure that the rubber gasket from the old oil filter is completely removed from the contact surface on the engine block before installing a new filter.




Fig. 4: Locating Oil Filter Part Number
Courtesy of HYUNDAI MOTOR CO.

PROCEDURE FOR REPLACING OIL FILTER


1. Use a filter wrench to remove the oil filter.
2. Before installing a new oil filter on the engine, apply clean engine oil to the surface of the rubber gasket.

3. Tighten the oil filter of the specified torque.

Tightening torque

Oil filter: 12 ~ 16 Nm (120 ~ 160 kg.cm, 9 ~ 12 lb.ft)

4. Start and run the engine and check engine oil leaks.
5. After stopping the engine, check the oil level and add oil as necessary.



G03844715


Fig. 5: Applying Engine Oil
Courtesy of HYUNDAI MOTOR CO.

CHECKING COOLANT LEAK CHECK

1. Loosen the radiator cap.
2. Confirm that the coolant level is up to the filler neck.
3. Install a radiator cap tester to the radiator filler neck and apply 150 kPa (21 psi, 1.53 kg/cm²) pressure. Hold for two minutes, then check for leakage from the radiator, hoses or connections.

CAUTION: 1. Radiator coolant may be extremely hot. Do not open the system while hot, or scalding engine coolant could gush out, causing personal injury. Allow the vehicle to cool before servicing this system.

2. When the tester is removed, be careful not to spill any coolant from it.
 3. Be sure to clean away completely any coolant from the area.
 4. Be careful, when installing and removing the tester and when testing, not to deform the filler neck of the radiator.
4. If there is leakage, repair or replace with the appropriate part.



G03844716

Fig. 6: Pressure Testing Radiator
Courtesy of HYUNDAI MOTOR CO.

RADIATOR CAP PRESSURE TEST

1. Use an adapter to attach the cap to the tester.
2. Increase the pressure until the indicator of the gauge stops moving.

Main valve opening pressure:


107.9 +/- 14.7 kPa (1.1 +/- 0.15 kg/cm², 15.64 +/- 2.13 psi)

Main valve closing pressure:

83.4 kPa (0.85 kg/cm², 12.1 psi)

3. Check that the pressure level is maintained at or above the limit.
4. Replace the radiator cap if the reading does not remain at or above the limit.

NOTE: Be sure that the cap is clean before testing, since rust or other foreign material on the cap seal will cause an incorrect reading.




G03844717

Fig. 7: Pressure Testing Radiator Cap
Courtesy of HYUNDAI MOTOR CO.

SPECIFIC GRAVITY TEST

1. Measure the specific gravity of the coolant with a hydrometer.
2. Measure the coolant temperature and calculate the concentration from the relation between the specific gravity and temperature. Use the following table for reference.



G03844718

Fig. 8: Measuring Specific Gravity Of Coolant
 Courtesy of HYUNDAI MOTOR CO.

RELATION BETWEEN COOLANT CONCENTRATION AND SPECIFIC GRAVITY

RELATION BETWEEN COOLANT CONCENTRATION AND SPECIFIC GRAVITY

Coolant temperature °C (°F) and specific gravity					Freezing temperature °C (°F)	Sage Operating temperature °C (°F)	Coolant Concentration (Specific volume)
10 (50)	20 (68)	30 (86)	40 (104)	50 (122)			
1.054	1.050	1.046	1.042	1.036	-16 (3.2)	-11 (12.2)	30%
1.063	1.058	1.054	1.049	1.044	-15 (5)	-15 (5)	35%
1.071	1.067	1.062	1.057	1.052	-25 (-13)	-20 (-4)	40%
1.079	1.074	1.069	1.064	1.058	-30 (-22)	-25 (-13)	45%
1.087	1.082	1.076	1.070	1.064	-36 (-32.8)	-31 (-23.8)	50%
1.095	1.090	4.084	1.077	1.070	-42 (-44)	-37 (-35)	55%
1.103	1.098	1.092	1.084	1.076	-50 (-58)	-45 (-49)	60%

Example

The safe operating temperature is -15°C (5°F) when the measured specific gravity is 1.058 at coolant temperature of 20°C (68°F)

CAUTION:

- If the concentration of the coolant is below 30%, its anti-corrosion property will be adversely affected.
- If the concentration is above 60%, the engine cooling property will decrease, affecting the engine adversely. For these reasons, be sure to maintain the concentration level within the specified range.
- Do not mix types of anti-freeze.

RECOMMENDED COOLANT**RECOMMENDED COOLANT**


Antifreeze	Mixture ratio of antifreeze in coolant
ETHYLENE GLYCOL BASE FOR ALUMINUM	50% [Except tropical areas]
	40% [Tropical areas]

CHECKING COMPRESSION PRESSURE

1. Before checking the engine compression, check the engine oil level. Also check that the starter motor and battery are all in normal operating condition.
2. Start the engine and wait until the engine coolant temperature reaches 80--95°C (176~205°F).
3. Stop the engine and disconnect the spark plug cables.
4. Remove the spark plugs.
5. Crank the engine to remove any foreign material in the cylinders.
6. Insert the compression gauge into the spark plug hole.
7. Depress the accelerator pedal to open the throttle fully.
8. Crank the engine and read the gauge.

Standard value: 1,200 kPa (12.2 kg / cm² , 170 psi)

Limit: 1,050 kPa (10.7 kg / cm² , 149 psi)



G03844719

Fig. 9: Checking Compression Pressure
Courtesy of HYUNDAI MOTOR CO.

9. Repeat steps 6 to 8 for all cylinders, making sure that the pressure difference for each of the cylinders is within the specified limit.

Limit

Max. 100 kPa (1.0 kg / cm² , 14 psi) between cylinders

10. If a cylinder's compression or pressure differential is outside the specification, add a small amount of oil through the spark plug hole, and repeat steps 6 to 9.
 1. If the addition of oil causes the compression to rise, it is possible that the piston ring is be worn.
 2. If the compression remains the same, valve seizure, poor valve seating or a compression leak in the cylinder head gasket are all possible causes.

Tightening torque

Spark plug: 20 ~ 30 Nm (200 ~ 300 kg.cm, 14 ~ 22 lb.ft)


TIGHTENING CYLINDER HEAD BOLTS

1. First loosen slightly and then tighten to the specified torque.

Tightening torque

Cylinder head bolts cold [Engine temperature approximately 20°C (68°F)]:

25 Nm (250 kg.cm, 18 lb ft) + (58° ~ 62°)+(43° ~ 47°)




G03844720

Fig. 10: Tightening Cylinder Head Bolts
Courtesy of HYUNDAI MOTOR CO.

2. Use the torque - angle method to torque the head bolts.
3. Be sure to follow the specific torque sequence as shown in **Fig. 11**.

NOTE: Run the engine to normal operating temperature and let it cool, then re-torque the bolts to specifications.



G03844721

Fig. 11: Identifying Torque Sequence
 Courtesy of HYUNDAI MOTOR CO.

ADJUSTING VALVE CLEARANCE

As the intake and exhaust valves are equipped with hydraulic lash adjusters, there is no need to adjust the valve clearance. The proper function of the hydraulic lash mechanism may be determined by checking for tappet noise. When there is a tappet noise or any unusual noise, check the hydraulic lash adjuster by removing and bleeding or replacing it.

ADJUSTING DRIVE BELT AND TENSIONER


1. Hang the belt on the pulley of the tensioner and install the tensioner.

(If the tensioner is already installed, loosen its mounting bolts to allow belt installation.)

Tightening torque

Tensioner assembly bolt:

20 ~ 27 Nm (200 ~ 270 kg.cm, 14 ~ 20 lb.ft)




G03844722

Fig. 12: Adjusting Drive Belt And Tensioner
 Courtesy of HYUNDAI MOTOR CO.

2. Install the belt in the following order.


[Alternator => Power steering => Air conditioner pulley => Crankshaft pulley.]



G03844723

Fig. 13: Identifying Auto Tensioner
Courtesy of HYUNDAI MOTOR CO.


3. Rotate the tensioner arm clockwise (about 14°) with a spanner (16 mm) and fit the belt to the idler pulley.



G03844724

Fig. 14: Rotating Tensioner Arm
Courtesy of HYUNDAI MOTOR CO.

4. When installing the belt on the pulley, make sure it is centered on the pulley.



G03844725

Fig. 15: Identifying Correct Way Of Installing Belt On pulley
Courtesy of HYUNDAI MOTOR CO.

5. The tensioner mark should be between the "MIN" and "MAX" position. If not, replace the belt.




Fig. 16: Identifying Tensioner Mark
 Courtesy of HYUNDAI MOTOR CO.







SPECIAL TOOLS


SPECIAL TOOLS SPECIFICATIONS

Tool (Number and name)	Illustration	Use
Crankshaft front oil seal installer (09214-33000)	G03844727	Installation of the crankshaft front oil seal
Camshaft oil seal installer (09221-21000)		Installation of the camshaft oil seal

2006 Hyundai Santa Fe GLS

2006 ENGINE Engine Mechanical System (G6BA-GSL 2.7) - Santa Fe

	 G03844728	
Valve guide installer (09221-3F100 A/B)	 G03844729	Removal and installation of the valve guide
Valve stem oil seal installer (09222-22001)	 G03844730	Installation of the valve stem oil seal
Valve spring compressor (09222-28000) (09222-28100)	 G03844731	Removal and installation of the intake or exhaust valve
Valve stem oil seal remover (09222-29000)	 G03844732	Removal of the valve stem oil seal
Crankshaft rear oil seal installer (09231-33000)	 G03844733	Installation of the crankshaft rear oil seal
Crankshaft wrench (09231-33100)		Used if the crankshaft needs to be rotated to attach the timing belt, etc.



G03844734

TROUBLESHOOTING

TROUBLESHOOTING CHART

Symptom	Probable cause	Remedy
Knocking of crankshaft and bearing	Worn main bearing	Replace
	Seized bearing	Replace
	Bent crankshaft	Replace
	Excessive crankshaft end play	Replace thrust bearing
Piston and connecting rod knock	Worn bearing	Replace
	Seized bearing	Replace
	Worn piston pin	Replace piston and pin or connecting rod
	Worn piston in cylinder	Recondition cylinder
	Broken piston ring	Repair or replace
	Improper connecting rod alignment	Replace
Noisy valves	Faulty auto-lash adjuster	Replace
	Thin or diluted engine oil (low oil pressure)	Change
	Worn or damaged valve stem or valve guide	Replace
Excessively worn cylinder and piston	Shortage of engine oil	Add or replace
	Dirty engine oil	Replace
	Poor quality of engine oil	Use proper oil
	Improperly assembled piston and connecting rod	Repair or replace
	Improper piston ring end clearance	Replace
	Dirty air cleaner	Clean air cleaner assembly and replace the air filter
Connecting rod and main bearing noise	Insufficient oil supply	Check engine oil level

2006 Hyundai Santa Fe GLS

2006 ENGINE Engine Mechanical System (G6BA-GSL 2.7) - Santa Fe


	Thin or diluted engine oil Excessive bearing clearance	Change and determine cause Replace
Damaged crankshaft bearing	Shortage of engine oil Faulty oil pump Low oil pressure Poor quality of engine oil Worn or out-of-round of crankshaft journal Restricted oil passage in crankshaft Worn bearing Bearing improperly installed Non-concentric crankshaft or bearing	Add or replace Repair or replace Adjust or repair Use proper engine oil Replace Clean Replace bearing and check engine oil and lubrication system Replace Replace
Timing belt noise	Incorrect belt tension	Adjust belt tension
Low compression	Damaged cylinder head gasket Worn or damaged piston rings Worn piston or cylinder Worn or damaged valve seat	Replace gasket Replace rings Repair or replace piston and/or cylinder block Repair or replace valve and/or seat ring
Oil pressure drop	Low engine oil level Faulty oil pressure switch Clogged oil filter Worn oil pump gears or cover Thin or diluted engine oil Oil relief valve stuck (open) Excessive bearing clearance	Check engine oil level Replace Replace Replace Change and determine cause Repair Replace
High oil pressure	Oil relief valve stuck (closed)	Repair or replace
Excessive engine rolling and vibration	Misfire Loose engine roll stopper (front, rear) Loose transaxle mount bracket Loose engine mount bracket Loose center member Broken transaxle mount insulator Broken engine mount insulator Broken engine roll stopper insulator	Correct Re-tighten Re-tighten Re-tighten Re-tighten Replace Replace Replace
Low coolant level	Leakage of coolant Damaged radiator core joint Corroded or cracked hoses	Correct Replace Replace

2006 Hyundai Santa Fe GLS

2006 ENGINE Engine Mechanical System (G6BA-GSL 2.7) - Santa Fe

	(Radiator hose, heater hose, etc.) Faulty radiator cap valve or setting of spring Faulty thermostat Faulty engine coolant pump	Replace Replace Replace
Clogged radiator	Foreign material in coolant	Replace
Abnormally high coolant temperature	Faulty thermostat Faulty radiator cap Restriction of flow in cooling system Loose or missing drive belt Faulty engine coolant pump Faulty temperature gauge or wiring Faulty electric fan Faulty thermo-sensor on radiator Insufficient coolant	Replace parts Replace Replace Adjust or replace Replace Repair or replace Repair or replace Replace Refill coolant
Abnormally low coolant temperature	Faulty thermostat Faulty temperature gauge or wiring	Replace Repair or replace
Leakage from oil cooling system	Loose hose and pipe connection Blocked or collapsed hose and pipe	Repair or replace Repair or replace
Inoperative electrical cooling fan	Damaged, loose wires or inoperative sensor	Replace or repair
Exhaust gas leakage	Loose connections Broken pipe or muffler	Re-tighten Repair or replace
Abnormal noise	Detached baffle plate in muffler Broken rubber hanger Pipe or muffler contacting vehicle body Broken pipe or muffler	Replace Replace Correct Repair or replace

ENGINE BLOCK**ENGINE BLOCK****COMPONENTS**



TORQUE : Nm (kg·cm, lb·ft)

G03844735

Fig. 17: Identifying Engine Block Components - With Torque Specifications
 Courtesy of HYUNDAI MOTOR CO.

DISASSEMBLY

Remove the timing belt, cylinder head assembly, drive plate, transaxle mounting plate, oil pan and oil pump case.

For further details, refer to appropriate procedure.

INSPECTION


CYLINDER BLOCK

1. Check the cylinder block for scores, rust and corrosion. Also check for cracks or any other defects. Replace the block if defective.
2. Measure the cylinder bore with a cylinder gauge at the three levels indicated, in the directions A and B.

Level 1: No. 1 piston ring position at TDC

Level 2: Center of cylinder

Level 3: Bottom of cylinder



G03844736

Fig. 18: Measuring Cylinder Bore
Courtesy of HYUNDAI MOTOR CO.

3. If the cylinder bores show more than the specified out-of-round or taper, or if the cylinder walls are badly scuffed or scored, the cylinder block should be rebored and honed. New oversize pistons and rings should be installed.

Standard value

Cylinder bore: 86.7 mm (3.41 in.)

Out-of-round and taper of cylinder bore:

Max. 0.02 mm (0.0008 in.)

4. If a ridge exists at the top of the cylinder, cut it off with a ridge reamer.
5. Oversize pistons are available in two sizes.

Piston service size and mark mm (in.)


0.25 (0.010) O.S: 0.25

0.50 (0.020) O.S: 0.50

6. To rebore the cylinder bore to the oversize, maintain the specified clearance between the oversize piston and the bore and make sure that all used pistons are the same oversize. The standard measurement of the piston outside diameter is taken at a level of 15.5 mm (0.61 in.) above the bottom of the piston skirt and across the thrust faces.

Piston-to-cylinder clearance

0.01 ~ 0.03 mm (0.0004 ~ 0.0012 in.)



G03844737

Fig. 19: Checking Piston-To-Cylinder Clearance
Courtesy of HYUNDAI MOTOR CO.

7. Check for damage or cracks in the cylinders.
8. Check the top surface of the cylinder block for flatness. If the top surface exceeds the limit, grind to the minimum limit or replace.


Standard value

Flatness of gasket surface: Max. 0.03 mm (0.0012 in.)

Service limit

Flatness of gasket surface: 0.05 mm (0.0020 in.)

CAUTION: When the cylinder head is assembled, grinding less than 0.2 mm (0.008 in.) is permissible.



G03844738

Fig. 20: Checking Top Surface Of Cylinder Block For Flatness
Courtesy of HYUNDAI MOTOR CO.

BORING CYLINDER

1. Oversize pistons should be selected according to the largest bore cylinder.

BORING CYLINDER SIZE

Identification Mark	Size
0.25	0.25 mm (0.010 in.)
0.50	0.50 mm (0.020 in.)

NOTE: The size of piston is stamped on top of the piston.

2. Measure the outside diameter of the piston to be used.
3. According to the measured O.D., calculate the new bore size.

New bore size = Piston O.D + 0.01 to 0.03 mm (0.0004 to 0.0012 in.) (clearance between piston and cylinder) - 0.01 mm (0.0004 in.) (honing margin.)

4. Bore each of the cylinders to the calculated size.

CAUTION: To prevent distortion that may result from temperature rise during honing, bore the cylinder holes in the firing order.

- 5.hone the cylinders, finishing them to the proper dimension (piston outside diameter + gap with cylinder).
6. Check the clearance between the piston and cylinder.

Standard: 0.01 ~ 0.03 mm (0.0004 ~ 0.0012 in.)


NOTE: When boring the cylinders, finish all of the cylinders to the same oversize. Do not bore only one cylinder to the oversize.

REASSEMBLY

Install the following parts by referring to their respective procedures.

1. Crankshaft
2. Drive plate
3. Piston
4. Cylinder head
5. Timing belt
6. Oil pump case

ENGINE MOUNTS**COMPONENTS**




TORQUE : Nm (kg·cm, lb·ft)

G03844739

Fig. 21: Identifying Engine Mounts Components - With Torque Specifications
 Courtesy of HYUNDAI MOTOR CO.

REMOVAL

Attach a chain or cable to the engine hooks and lift enough so that there is no pressure on the motor mounts.




G03844740

Fig. 22: Attaching Chain Or Cable To Engine Hooks
Courtesy of HYUNDAI MOTOR CO.

ENGINE MOUNTING

1. Remove the engine mounting insulator bolts.
2. Remove the engine mounting bracket from the engine.




G03844741

Fig. 23: Removing Engine Mounting
Courtesy of HYUNDAI MOTOR CO.

TRANSAXLE MOUNTING

1. Remove the transaxle mounting insulator bolts.
2. Remove the transaxle mounting bracket from the transaxle.




G03844742

Fig. 24: Removing Transaxle Mounting
Courtesy of HYUNDAI MOTOR CO.

FRONT ROLL STOPPER

Remove the front roll stopper bracket from the sub-frame.




G03844743

Fig. 25: Removing Front Roll Stopper
Courtesy of HYUNDAI MOTOR CO.

REAR ROLL STOPPER

1. Remove the bolt from the rear roll stopper.
2. Remove the rear roll stopper from the subframe.




G03844744


Fig. 26: Removing Rear Roll Stopper
Courtesy of HYUNDAI MOTOR CO.

INSPECTION ITEMS


Transaxle mount




Engine mount



Front roll stopper assembly



Rear roll stopper assembly




G03844745

Fig. 27: Identifying Inspection Items
Courtesy of HYUNDAI MOTOR CO.

ENGINE AND TRANSAXLE ASSEMBLY

REMOVAL


1. Remove the battery.
2. Detach the air cleaner.



G03844746


Fig. 28: Detaching Air Cleaner
Courtesy of HYUNDAI MOTOR CO.

3. Disconnect the engine harness connectors.
 1. Engine wiring connectors (alternator, starter, etc.)
 2. TPS connector
 3. Oil pressure gauge connector.
 4. Back up lamp switch connector.
 5. A/T solenoid, inhibitor switch connector.
 6. Coolant temperature sensor.
 7. Ignition coil, power TR connector.
 8. Idle speed control valve (ISC) connector.
 9. MAP and ATS connectors.
 10. Oxygen sensor connector.



G03844747

Fig. 29: Disconnecting Engine Harness Connectors (1 Of 2)
Courtesy of HYUNDAI MOTOR CO.



G03844748


Fig. 30: Disconnecting Engine Harness Connectors (2 Of 2)
Courtesy of HYUNDAI MOTOR CO.

4. Drain the engine coolant.
5. For a vehicle with automatic transaxles, disconnect the transaxle oil cooler hoses.

NOTE: When disconnecting hoses, make identification marks to avoid making any mistake when installing them again.

CAUTION: Be careful not to spill any of oil or fluid out of the hoses. Plug the openings to prevent the entry of foreign material.


6. Disconnect the radiator upper and lower hoses on the engine side then remove the radiator assembly.



G03844749

Fig. 31: Disconnecting Radiator Upper Hose
Courtesy of HYUNDAI MOTOR CO.


7. Disconnect the engine ground.
8. Disconnect the brake booster vacuum hose.



G03844750

Fig. 32: Disconnecting Brake Booster Vacuum Hose
Courtesy of HYUNDAI MOTOR CO.


9. Disconnect the heater hoses (inlet and outlet) on the engine side.
10. Disconnect the accelerator cable at the engine side.



G03844751

Fig. 33: Disconnecting Accelerator Cable
Courtesy of HYUNDAI MOTOR CO.


11. Using a special tool, remove the main fuel line at the delivery pipe (supply/return).
12. Disconnect the speedometer cable from the transaxle.
13. Disconnect the clutch cable or control cable from the transaxle.



G03844752

Fig. 34: Disconnecting Clutch Cable Or Control Cable From Transaxle
Courtesy of HYUNDAI MOTOR CO.

14. Disconnect the power steering suction hose and return hose from the pump.




G03844753

Fig. 35: Disconnecting Power Steering Suction Hose And Return Hose From Pump
Courtesy of HYUNDAI MOTOR CO.

15. Detach the steering dust cover in the engine compartment and then disconnect the gear box universal joint bolt.


NOTE: Make sure to make identification marks between the universal joint and the gear box for reassembly.



G03844754

Fig. 36: Disconnecting Gear Box Universal Joint Bolt
Courtesy of HYUNDAI MOTOR CO.


16. Raise the vehicle and then remove the front tire.
17. Remove the caliper assembly from the knuckle. Using wire, hang it from the suspension.



G03844755

Fig. 37: Removing Caliper Assembly From Knuckle
Courtesy of HYUNDAI MOTOR CO.


18. Loosen the strut lower bolts and then remove it.



G03844756

Fig. 38: Loosening Strut Lower Bolts
Courtesy of HYUNDAI MOTOR CO.


19. Remove the front muffler bolts.



G03844757

Fig. 39: Removing Front Muffler Bolts
Courtesy of HYUNDAI MOTOR CO.

20. Remove the transaxle control rod and extension rod (M/T only).




G03844758

Fig. 40: Removing Transaxle Control Rod And Extension Rod (M/T Only)
Courtesy of HYUNDAI MOTOR CO.

21. Put the special fixture on the T/M jack and then adjust it to the sub-frame.


NOTE: Check that all the cables, harness connector and hose are disconnected from the engine and transaxle assembly.



G03844759


Fig. 41: Putting Special Fixture On T/M Jack
Courtesy of HYUNDAI MOTOR CO.

22. Remove the engine mounting bracket and the transaxle mounting bracket.



G03844760


Fig. 42: Removing Engine Mounting Bracket
Courtesy of HYUNDAI MOTOR CO.



G03844761

Fig. 43: Removing Transaxle Mounting Bracket
Courtesy of HYUNDAI MOTOR CO.


23. Remove the sub-frame installation bolts.



G03844762

Fig. 44: Removing Sub-Frame Installation Bolts
Courtesy of HYUNDAI MOTOR CO.

24. Lower the engine and transaxle assembly on the jack then, remove the front roll stopper and the rear roll stopper.



G03844763


Fig. 45: Lowering Engine And Transaxle Assembly
Courtesy of HYUNDAI MOTOR CO.

25. Remove the engine and transaxle assembly as a unit.

MAIN MOVING SYSTEM

CAMSHAFT

COMPONENTS




TORQUE : Nm (kg.cm, lb.ft)

G03844764

Fig. 46: Identifying Main Moving System Components (Camshaft) - With Torque Specifications
Courtesy of HYUNDAI MOTOR CO.

DISASSEMBLY


1. Remove the engine cover and intake manifold.



G03844765

Fig. 47: Removing Engine Cover
Courtesy of HYUNDAI MOTOR CO.


2. Disconnect the breather hose and the engine harness.
3. Remove the power steering pulley, air conditioner pulley, crankshaft pulley, idler pulley and tensioner pulley.
4. Remove the timing belt cover.
5. Loosen the auto tensioner.
6. Remove the timing belt from the camshaft sprocket.
7. Remove the spark plug cables.
8. Loosen the cylinder head cover bolts and then remove it.



G03844766

Fig. 48: Removing Cylinder Head
Courtesy of HYUNDAI MOTOR CO.


9. Remove the camshaft sprockets.
10. Remove the camshaft bearing caps.



G03844767

Fig. 49: Removing Camshaft Bearing Caps
Courtesy of HYUNDAI MOTOR CO.

11. Remove the camshafts.



G03844768

Fig. 50: Removing Camshafts
Courtesy of HYUNDAI MOTOR CO.

INSPECTION

CAMSHAFTS

1. Check the camshaft journals for wear. If the journals are badly worn out, replace the camshaft.
2. Check the cam lobes for damage. If the lobe is damaged or excessively worn out, replace the camshaft.

Cam height


Standard

Intake: 43.95 ~ 44.15 mm (1.7303 ~ 1.7382 in.)

Exhaust: 43.95 ~ 44.15 mm (1.7303 ~ 1.7382 in.)

Limit

Intake / Exhaust: 43.45 mm (1.7106 in.)



G03844769

Fig. 51: Checking Cam Height
Courtesy of HYUNDAI MOTOR CO.

3. Check the cam surface for abnormal wear or damage, and replace if necessary.
4. Check each bearing for damage. If the bearing surface is excessively damaged, replace the cylinder head assembly or camshaft bearing cap, as necessary.

Camshaft end play


0.1 ~ 0.15 mm (0.0039 ~ 0.0059 in.)

OIL SEAL (CAMSHAFT FRONT)

1. Check the lips for wear. If lip threads are worn out, replace the oil seal with new one.
2. Check a contact surface of oil seal lip on camshaft. If there stratified wear, replace the camshaft.

HLA (HYDRAULIC LASH ADJUSTER)

With the HLA filled with engine oil, hold A and press B by hand. If B moves, replace the HLA.



G03844770


Fig. 52: Inspecting Hydraulic Lash Adjuster
Courtesy of HYUNDAI MOTOR CO.

PROBLEM POSSIBLE CAUSE TABLE

Problem	Possible	Action
1. Temporary noise when starting a cold engine	Normal	This noise will disappear after the oil in the engine reaches the normal pressure.
2. Continuous noise when the engine is started after parking more than 48 hours.	Oil leakage of the high pressure chamber on the HLA, allowing air to get in.	Noise will disappear within 15 minutes when engine runs at 2000-3000 RPM. If it doesn't disappear, refer to step 7 in this table.
3. Continuous noise when the engine is first started after rebuilding cylinder head.	Insufficient oil in cylinder head oil gallery	
4. Continuous noise when the engine is started after excessively cranking the engine by the starter motor or band.	Oil leakage of the high-pressure chamber in the HLA, allowing air to get in. Insufficient oil in the HLA.	
5. Continuous noise when the engine is running after changing the HLA. Do not run engine at a speed higher than 3000 RPM, as this may damage the HLA.		CAUTION: Do not run engine at a speed higher than 3000 RPM, as this may damage the HLA.
6. Continuous noise during idle after high engine speed.	Engine oil level too high or too low	Check oil level Drain or add as necessary.
	Excessive amount of air in the oil at high engine speed.	Check oil supply system.
	Deteriorated oil.	Check oil quality. If deteriorated, replace with specified type.
7. Noise continues for more than 15 minutes.	Low oil pressure.	Check oil pressure and oil supply system of each part of engine
	Faulty HLA.	Remove the cylinder head cover and press HLA down by hand. If it moves, replace the HLA. WARNING: Be careful with the hot HLAS.

TIMING CHAIN

Check the bushing and plate of timing chain for wear. Replace if there is severe wear.




G03844771

Fig. 53: Checking Bushing And Plate Of Timing Chain For Wear
Courtesy of HYUNDAI MOTOR CO.

REASSEMBLY

1. Install the HLA.
2. Align the camshaft timing chain with the intake timing chain sprocket and exhaust timing chain sprocket as shown in **Fig. 54**.




G03844772

Fig. 54: Aligning Camshaft Timing Chain With Intake Timing Chain Sprocket And Exhaust Timing Chain Sprocket
 Courtesy of HYUNDAI MOTOR CO.

3. Install the camshafts after lubricating the journals of the camshaft with engine oil.

NOTE: To check the press fit, the camshaft (IN) and timing chain sprocket should be separable by a force greater than 1000 kg (MIN.) at room temperature.



G03844773


Fig. 55: Installing Camshafts

Courtesy of HYUNDAI MOTOR CO.

4. Install the bearing caps. Check the markings on the caps for intake/exhaust identification symbol.

I: Intake camshaft

E: Exhaust camshaft



G03844774

Fig. 56: Identifying Camshafts

Courtesy of HYUNDAI MOTOR CO.


5. Tighten the bearing caps to the specified torque in two or three increments as shown.

Tightening torque

Bearing cap bolt

M6 (38 mm): 10 ~ 12 Nm (100 ~ 120 kg.cm, 7 ~ 9 lb.ft)

M6 (50 mm): 14 ~ 16 Nm (140 ~ 160 kg.cm, 10 ~ 12 lb.ft)



G03844775

Fig. 57: Tightening Bearing Caps
Courtesy of HYUNDAI MOTOR CO.

6. Using the special tool, the camshaft oil seal installer (09221-21000), install the camshaft oil seal. Be sure to apply engine oil to the external surface of the oil seal.

Insert the oil seal along the camshaft front end and install it with a hammer until it is seated.





Fig. 58: Installing Camshaft Oil Seal
Courtesy of HYUNDAI MOTOR CO.

7. Install the camshaft sprocket to the specified torque.

Tightening torque

Camshaft sprocket bolt:

90 ~ 110 Nm (900 ~ 1100 kg.cm, 65 ~ 80 lb.ft)



G03844777

Fig. 59: Installing Camshaft Sprocket
Courtesy of HYUNDAI MOTOR CO.

8. Install the cylinder head cover.


Tightening torque

Cylinder head cover bolts:

8 ~ 10 Nm (80 ~ 100 kg.cm, 5.8 ~ 7.2 lb.ft)

(Tightening procedure)


1. Tighten all bolts temporarily to half of the specified torque in the sequence 1.2.3.4.5.6.7.8.
2. Retighten all bolts to the specified torque.



G03844778

Fig. 60: Identifying Tightening Sequence Of Cylinder Head Cover Bolts
 Courtesy of HYUNDAI MOTOR CO.


9. Install the spark plug cables and, center cover.
10. Install the timing belt and then tighten the auto tensioner pulley.
11. Install the timing belt cover.
12. Install the power steering pulley, air conditioner pulley, crankshaft pulley and tensioner pulley.



G03844779

Fig. 61: Identifying Auto Tensioner
Courtesy of HYUNDAI MOTOR CO.

13. Connect the breather hose and engine harness.
14. Install the intake manifold and engine cover.




G03844780

Fig. 62: Installing Engine Cover
Courtesy of HYUNDAI MOTOR CO.

PISTON

COMPONENTS



TORQUE : Nm (kg·cm, lb·ft)

G03844781


Fig. 63: Identifying Piston Components - With Torque Specifications
 Courtesy of HYUNDAI MOTOR CO.

DISASSEMBLY

CONNECTING ROD CAP

CAUTION: Keep the bearings in order with their corresponding connecting rods (according to cylinder numbers) for proper reassembly.

1. Remove the connecting rod cap bolts, then remove the caps and the big end lower bearing mark for reassembly.
2. Push each piston connecting rod assembly toward the top of the cylinder.




G03844782

Fig. 64: Identifying Connecting Rod Cap Notches
Courtesy of HYUNDAI MOTOR CO.

DISASSEMBLY AND REASSEMBLY OF THE PISTON PIN


1. Using the special tools 09234-33001 and 09234-3002, disassemble and reassemble the piston and connecting rod.



G03844783

Fig. 65: Disassembling And Reassembling Piston And Connecting Rod
Courtesy of HYUNDAI MOTOR CO.

2. The piston pin is a press fit in the rod little end, and the piston floats on the pin.
3. The tool consists of a support fixture with fork inserts, guides, adapters, an installer and a remover. The piston is supported in the support fixture while the pin is being installed or removed. Guides help position the pin as it is installed or removed, while the rod is supported by fork inserts.
4. To remove the pin from the piston, place the piston in the support fixture with the rod resting on the fork inserts. Pass the remover tool through the top of the support fixture and use it to press out the pin.




G03844784

Fig. 66: Removing Piston Pin

Courtesy of HYUNDAI MOTOR CO.

5. To install a new pin, the proper fork inserts must be in place to support the rod.
6. Position the rod inside the piston. Insert the proper pin guide through one side of the piston and through the rod. Hand tap the pin guide so it is held by the piston. Insert the new pin into the piston from the other side and set the assembly into the support fixture with the pin guide facing down.

NOTE: The pin guide should be centered on the connecting rod through the piston. If assembled correctly, the pin guide will sit exactly under the center of the hole in the tool's arch, and rest evenly on the fork inserts. If the wrong size pin guide is used, the piston and pin will not up with the support fixture.



G03844785

Fig. 67: Inserting Pin Into Piston
Courtesy of HYUNDAI MOTOR CO.

7. Insert the installer tool through the hole in the arch of the support fixture and use an hydraulic press to force the piston pin through the rod little end. Continue pressing until the pin guide falls free and the installer tool seats against the top of the arch.

CAUTION: Do not exceed 1250 +/- 500 kg (2765 +/- 1100 lb) of force when the installing tool seats against the top of the arch.

INSPECTION

PISTONS AND PISTON PINS

1. Check each piston for scuffing, scoring, wear and other defects. Replace any piston that is defective.
2. Check each piston ring for breakage, damage and abnormal wear. Replace the defective rings. When the piston requires replacement, its rings should also be replaced.
3. Check that the piston pin fits in the piston pin hole. Replace any piston and pin assembly that is defective. The piston pin must be pressed smoothly by hand into the pin hole (at room temperature).

PISTON RINGS

1. Measure the piston ring side clearance. If the measured value exceeds the service limit, insert a new ring in the ring groove to measure the side clearance. If the clearance still exceeds the service limit, replace the piston and rings together. If it is less than the service limit, replace only the piston rings.

Piston ring side clearance

No. 1: 0.04 ~ 0.08 mm (0.0016 ~ 0.0031 in.)

No. 2: 0.03 ~ 0.07 mm (0.0012 ~ 0.0028 in.)

Limit

No. 1: 0.1 mm (0.004 in.)

No. 2: 0.1 mm (0.004 in.)

2. To measure the piston ring end gap, insert a piston ring into the cylinder bore. Position the ring at right angles to the cylinder wall by gently pressing it down with a piston. Measure the gap with a feeler gauge. If the gap exceeds the service limit, replace the piston ring.

Piston ring end gap

Standard dimensions

No. 1: 0.20 ~ 0.35 mm (0.0079 ~ 0.0138 in.)

No. 2: 0.37 ~ 0.52 mm (0.0146 ~ 0.0205 in.)

Limit

No. 1, No. 2 0.8 mm (0.031 in.)

Oil ring side rail: 1.0 mm (0.039 in.)


When replacing the ring without correcting the cylinder bore, check the gap with the ring situated at the lower part of cylinder that is less worn out.

PISTON RING SERVICE SIZE AND MARK

PISTON RING SERVICE SIZE AND MARK

Standard	None
0.25 mm (0.010 in.) O.S	25
0.50 mm (0.020 in.) O.S	50

NOTE: The mark can be found on the upper side of the ring next to the end.




G03844786

Fig. 68: Identifying Piston Ring Mark
Courtesy of HYUNDAI MOTOR CO.

CONNECTING RODS

1. When the connecting rod cap is installed, make sure that the cylinder numbers, marked on rod end cap at disassembly, match. When a new connecting rod is installed, make sure that the notches holding the bearing in place are on the same side.
2. Replace the connecting rod if it is damaged at either end of the thrust faces. If it has a stratified wear, or if the surface of the inside diameter of the small end is severely rough, replace the rod.




G03844787

Fig. 69: Identifying Connecting Rod Notches
Courtesy of HYUNDAI MOTOR CO.


REASSEMBLY

1. Install the spacer.



G03844788

Fig. 70: Installing Spacer
Courtesy of HYUNDAI MOTOR CO.




G03844789

Fig. 71: Identifying Spacer Gap Positions
Courtesy of HYUNDAI MOTOR CO.

2. Install the upper side rail. To install the side rail, first put one end of the side rail between the piston ring groove and spacer, hold it firmly, and press down with finger on the portion to be inserted into the groove (as illustrated).

CAUTION: Do not use a piston ring expander when installing the side rail.


3. Install the lower side rail by the same procedure described in Step 2.



G03844790

Fig. 72: Identifying Side Rail Gap
Courtesy of HYUNDAI MOTOR CO.

4. Apply engine oil around the piston and piston grooves.
5. Using a piston ring expander, install the No. 2 piston ring.
6. Install the No. 1 piston ring.



G03844791

Fig. 73: Installing No. 1 Piston Ring
Courtesy of HYUNDAI MOTOR CO.

7. Position each piston ring end gap as far away from its neighboring gaps as possible. Make sure that the gaps are not positioned in the thrust and pin directions.





Fig. 74: Identifying Piston Ring Gaps
Courtesy of HYUNDAI MOTOR CO.

8. Hold the piston rings firmly with a piston ring compressor as they are inserted into cylinder.
9. Install the upper main bearings in the cylinder block.
10. Install the lower main bearings in the main bearing caps.


CAUTION: Install the bearing so it matches the oil hole in the block.



G03844793

Fig. 75: Installing Lower Main Bearings In Main Bearing Caps
Courtesy of HYUNDAI MOTOR CO.


11. Install the thrust washers in the No. 3 main bearing cap with the oil grooves facing outward.



G03844794

Fig. 76: Installing Thrust Washers In No. 3 Main Bearing Cap
Courtesy of HYUNDAI MOTOR CO.

12. Make sure that the front mark of the piston and the front mark (identification mark) of the connecting rod are directed toward the front of the engine.
13. When the connecting rod cap is installed, make sure that any cylinder numbers placed on the rod and cap at disassembly match.
14. When a new connecting rod is installed, make sure that the notches for holding the bearing in place are on the same side.



G03844795

Fig. 77: Identifying Connecting Rod Notches
Courtesy of HYUNDAI MOTOR CO.

15. When assembling, bolts should be fastened using the plastic angle technique as follows.

1. Apply oil to the threads and matching areas.
2. Tighten the connecting rod bolt.

Tightening torque

Connecting rod bolt:

16 ~ 20 Nm (160 ~ 200 kg.cm, 12 ~ 15 lb.ft) + (90° ~ 94°)


CAUTION: After removing the connecting rod bolt, do not use it again.
When using a new bolt, do not tighten the bolt more than 3 times.

16. Check the connecting rod side clearance.

Connecting rod side clearance

Standard: 0.10 ~ 0.25 mm (0.0039 ~ 0.0098 in.)

Limit: 0.4 mm (0.0157 in.)




G03844796

Fig. 78: Checking Connecting Rod Side Clearance
Courtesy of HYUNDAI MOTOR CO.

CRANKSHAFT

COMPONENTS



TORQUE : Nm (kg·cm, lb·ft)

G03844797

Fig. 79: Identifying Crankshaft Components - With Torque Specifications
Courtesy of HYUNDAI MOTOR CO.

DISASSEMBLY

1. Remove the timing belt train, front case, flywheel, cylinder head assembly and oil pan.
2. Remove the rear plate and the rear oil seal.
3. Remove the connecting rod caps.

NOTE: **Mark the main bearing caps to be able to reassemble in the original position and direction.**

4. Remove the main bearing caps and remove the crankshaft. Keep the bearings in order according to the cap number.

INSPECTION

1. Check the crankshaft journals and pins for damage, uneven wear and cracks. Also check the oil holes for restrictions. Repair or replace any defective parts.
2. Inspect the crankshaft journal and pin for out-of-round and taper.


Standard value

Crankshaft journal O.D:

61.982 ~ 62.000 mm (2.4402 ~ 2.4409 in.)

Crankshaft pin O.D:

47.982 ~ 48.000 mm (1.8890 ~ 1.8898 in.)



G03844798

Fig. 80: Measuring Crankshaft Journal O.D
Courtesy of HYUNDAI MOTOR CO.

MAIN BEARINGS AND CONNECTING ROD BEARINGS

Visually inspect each bearing for peeling, melting, seizure and improper contact. Replace any defective bearings.

MEASURING OIL CLEARANCE

Check for oil clearance by measuring the outside diameter of the crankshaft journal and the inside diameter of the bearing. The clearance can be obtained by calculating the difference between the measured outside diameters.

Standard value

Oil clearance


Crankshaft main bearing:

0.004 ~ 0.022 mm (0.00015 ~ 0.00087 in.)

Connecting rod bearing:

0.018 ~ 0.036 mm (0.00071 ~ 0.00141 in.)

Limit: 0.1 mm (0.004 in.)



G03844799

Fig. 81: Measuring Oil Clearance
Courtesy of HYUNDAI MOTOR CO.

PLASTIC GAUGE METHOD

Plastic gauge (plastigauge) may be used to measure the clearance.

1. Remove oil, grease and any other dirt from the bearings and journals.
2. Cut the plastic gauge the same length as the width of the bearing and place it in parallel with the journal, avoiding the oil holes.
3. Install the crankshaft, bearings and caps and tighten them to the specified torques. During this operation, do not turn the crankshaft. Remove the caps. Measure the width of the plastigauge at the widest part by using the scale printed on the gauge package.

If the clearance exceeds the service limit, the bearing should be replaced or an undersize bearing should be used. When installing a new crankshaft, be sure to use standard size bearings.

If the standard clearance can not be obtained even after replacing the bearing, the journal and pin should be ground to the undersize and a bearing of the corresponding size should be installed.




Fig. 82: Measuring Oil Clearance (Plastigauge Method)
Courtesy of HYUNDAI MOTOR CO.

OIL SEAL

Check the front and rear oil seals for damage or worn surfaces. Replace any seal that is defective.

DRIVE PLATE (A/T)

Replace distorted, damaged, or cracked drive plates.

REASSEMBLY

MAIN BEARING

1. Install a grooved main bearing (upper bearing) on the cylinder block side.
2. Install a grooveless main bearing (lower bearing) on the main bearing cap side.
3. Install the crankshaft. Apply engine oil to journal and pin.
4. Install the bearing caps with the arrow mark directed toward the front of the engine. Cap number must be correct.
5. Tighten the cap bolts to the specified torque.

Tightening torque


Main bearing cap bolts

M8 (9 ~ 15):

13 ~ 19 Nm (130 ~ 190 kg.cm, 10 ~ 14 lb.ft) + (90° ~ 94°)


M10 (1 ~ 8):

27 ~ 33 Nm (270 ~ 330 kg.cm, 19.5 ~ 24 lb.ft) + (90° ~ 94°)




Lower bearing

G03844801



Upper bearing

Fig. 83: Identifying Lower And Upper Bearing
Courtesy of HYUNDAI MOTOR CO.



G03844802

Fig. 84: Identifying Tightening Sequence Of Bearing Cap Bolts
 Courtesy of HYUNDAI MOTOR CO.

6. Cap bolts should be tightened evenly in stages 4 to 5 increments before they are tightened to the specified torque.
7. Make certain that crankshaft turns freely and check the end play of the crankshaft.

Crankshaft end play

Standard: 0.070 ~ 0.250 mm (0.0028 ~ 0.0098 in.)

Limit: 0.4 mm (0.016 in.)




Fig. 85: Checking Crankshaft End Play
Courtesy of HYUNDAI MOTOR CO.

8. Using special tool (09231-33000), install the rear oil seal in oil seal case.
9. Apply sealant to the area shown in **Fig. 87**. Install the oil seal case in the cylinder block.

Tightening torque

Oil seal case bolt:

10 ~ 12 Nm (100 ~ 120 kg.cm, 7 ~ 9 lb.ft)





Fig. 86: Installing Rear Oil Seal In Oil Seal Case
Courtesy of HYUNDAI MOTOR CO.



G03844805

Fig. 87: Identifying Sealing Agent Coating Location
 Courtesy of HYUNDAI MOTOR CO.

10. Tighten the rear plate to the specified torque.

Tightening torque

Rear plate: 10 ~ 12 Nm (100 ~ 120 kg.cm, 7 ~ 9 lb.ft)

11. Tighten the drive plate and the adapter plate (A/T).

Tightening torque

Drive plate and adapter plate bolt:

73 ~ 77 Nm (730 ~ 770 kg.cm, 53 ~ 56 lb.ft)


(A/T)**G03844806**


Fig. 88: Tightening Drive Plate And Adapter Plate (A/T)
Courtesy of HYUNDAI MOTOR CO.

12. Tighten the flywheel (M/T).

Tightening torque

Flywheel installation bolt:

73 ~ 77 Nm (730 ~ 770 kg.cm, 53 ~ 56 lb.ft)




G03844807

Fig. 89: Tightening Flywheel (M/T)
Courtesy of HYUNDAI MOTOR CO.

COOLING SYSTEM

ENGINE COOLANT HOSE / PIPES

COMPONENTS



TORQUE : Nm (kg·cm, lb·ft)

G03844808

Fig. 90: Identifying Engine Coolant Hose / Pipes Components - With Torque Specifications
Courtesy of HYUNDAI MOTOR CO.

INSPECTION

Check the engine coolant pipe and hose for cracks, damage and restrictions. Replace if necessary.


REASSEMBLY

Fit the O-ring in the groove of the engine coolant inlet pipe end. Wet the periphery of the O-ring with water and

insert the engine coolant inlet pipe.

NOTE:

1. Do not apply oil or grease to the engine coolant pipe O-ring.
2. Keep the engine coolant pipe connections free of sand, dust, etc.
3. Insert the engine coolant pipe into the end of the engine coolant pump inlet.
4. Whenever installing the engine coolant inlet pipe, always replace the O-ring with a new one.



G03844809

Fig. 91: Installing Engine Coolant Inlet Pipe
Courtesy of HYUNDAI MOTOR CO.

COOLING SYSTEM

INLET CONTROL




Fig. 92: Cooling System Inlet Control Diagram
Courtesy of HYUNDAI MOTOR CO.

FLOW CHART





Fig. 93: Cooling System Inlet Control Flow Chart
Courtesy of HYUNDAI MOTOR CO.

ENGINE COOLANT PUMP


COMPONENTS



TORQUE : Nm (kg·cm, lb·ft)

G03844812

Fig. 94: Identifying Engine Coolant Pump Components - With Torque Specifications
 Courtesy of HYUNDAI MOTOR CO.



G03844813

Fig. 95: Sectional View Of Coolant Pump
 Courtesy of HYUNDAI MOTOR CO.

REMOVAL


1. Using the drain plug, drain the coolant.
2. Remove the drive belt and the engine coolant pump pulley.
3. Remove the timing belt cover, the auto tensioner and idler pulley.
4. Remove the engine coolant pump mounting bolts.
5. Remove the engine coolant pump assembly from the cylinder block.

INSPECTION

1. Check the engine coolant pump for cracks, damage or wear, and replace the pump assembly if necessary.
2. Check the bearing for damage, abnormal noise and sluggish rotation and replace the pump assembly if necessary.
3. Check the seal for leaks and replace the pump assembly if necessary.

INSTALLATION

1. Clean the gasket surfaces of the engine coolant pump body and the cylinder block.



G03844814

Fig. 96: Installing O Ring

Courtesy of HYUNDAI MOTOR CO.

2. Install the new engine coolant pump gasket and pump assembly. Tighten the bolts to the specified torque.

Tightening torque

Engine coolant pump bolt

Head mark "7": 15 ~ 22 (150 ~ 220, 11 ~ 16)



**G03844815**

Fig. 97: Installing Engine Coolant Pump Gasket And Pump Assembly
Courtesy of HYUNDAI MOTOR CO.

3. Install the auto tensioner and timing belt. Adjust the timing belt tension, then install the timing belt cover.
4. Install the drive belt, coolant pump pulley and then adjust the auto tensioner.
5. Refill the radiator with coolant.
6. Run the engine and check for leaks.

RADIATOR

COMPONENTS




G03844816

Fig. 98: Identifying Radiator Components
 Courtesy of HYUNDAI MOTOR CO.

REMOVAL

1. Disconnect the ground cable from the battery terminal.
2. Disconnect the fan motor connector.
3. Loosen the radiator drain plug to drain the coolant.
4. Disconnect the upper and lower hoses and overflow tube after making marks on the radiator hose and the hose clamp.




G03844817

Fig. 99: Disconnecting Upper Hose
Courtesy of HYUNDAI MOTOR CO.

5. For vehicles with automatic transaxles, disconnect the oil cooler hoses from the automatic transaxle.

CAUTION: Cover or plug the hose and inlets of the radiator so that dust and other foreign materials can not enter after the hose is disconnected from the radiator.

6. Remove the radiator upper mounting bolt.



G03844818

Fig. 100: Removing Radiator Upper Mounting Bolt
Courtesy of HYUNDAI MOTOR CO.

7. Remove the radiator together with the fan motor.
8. Remove the radiator fan motor and condenser fan motor from the radiator.

INSPECTION

1. Check for foreign material between the radiator fins.
2. Check the radiator fins for damage and straighten if necessary.
3. Check the radiator for corrosion, damage, rust or scale.
4. Check the radiator hoses for cracks, damage or deterioration.
5. Check the reservoir tank for damage.
6. Check the automatic transaxle oil cooler hoses for cracking, damage or deterioration (only A/T).


INSTALLATION

1. Fill the radiator and reservoir tank with a clean coolant mixture.
2. Run the engine until the coolant warms up enough so that the thermostat valve opens and then turn off the engine.
3. Remove the radiator cap and pour the coolant up to the filler neck of the radiator. Fill the reservoir tank to the upper level.

4. Check that there are no leaks from the radiator, hoses or connections.

RADIATOR CAP

COMPONENTS



Pressure : 107.9±14.7 (1.1±0.15, 15.64±2.13)

Pressure : 83.4 (0.85, 12.1)


PRESSURE : kPa (kg/cm², psi)

G03844819

Fig. 101: Identifying Radiator Cap Components
Courtesy of HYUNDAI MOTOR CO.

INSPECTION


1. Check the radiator cap for damage, cracks or weakening.



G03844820

Fig. 102: Checking Radiator Cap For Weakening
Courtesy of HYUNDAI MOTOR CO.

2. Connect the tester to the radiator cap.
3. Increase the pressure until the indicator of the gauge stops moving.
4. Replace the radiator cap if the reading does not hold steady for about 10 seconds.




G03844821

Fig. 103: Testing Radiator Cap
Courtesy of HYUNDAI MOTOR CO.

THERMOSTAT

COMPONENTS



TORQUE : Nm (kg·cm, lb·ft)

G03844822

Fig. 104: Identifying Thermostat Components - With Torque Specifications
Courtesy of HYUNDAI MOTOR CO.

REMOVAL


1. Drain the coolant to thermostat level or below.
2. Remove the inlet fitting and gasket.
3. Remove the thermostat.

INSPECTION

1. Heat the thermostat as shown in **Fig. 105**.
2. Check that the valve operates properly.
3. Verify the temperature at which the valve begins to open.

Valve opening temperature: 80 ~ 84°C (176 ~ 183.2°F)

Full opening temperature: 95°C (203°C)




G03844823

Fig. 105: Inspecting Thermostat
Courtesy of HYUNDAI MOTOR CO.

INSTALLATION

1. Check that the flange of the thermostat is correctly placed in the socket of the thermostat housing.



G03844824

Fig. 106: Installing Thermostat
Courtesy of HYUNDAI MOTOR CO.

2. Install the inlet fitting.

Tightening torque

Engine coolant inlet fitting bolt:


17 ~ 20 Nm (170 ~ 200 kg.cm, 12 ~ 14 lb.ft)

3. Refill the coolant.

LUBRICATION SYSTEM

OIL PUMP

COMPONENTS



TORQUE : Nm (kg·cm, lb·ft)


G03844825

Fig. 107: Identifying Oil Pump Components - With Torque Specifications
Courtesy of HYUNDAI MOTOR CO.

DISASSEMBLY

1. Remove the oil pressure switch, using 24 mm deep socket.

NOTE: Since a sealant is used on the threaded area, be careful not to damage the oil pressure switch.



G03844826

Fig. 108: Removing Oil Pressure Switch
Courtesy of HYUNDAI MOTOR CO.

2. Remove the oil filter and the oil pan.
3. Remove the oil screen and gasket.
4. Remove the three bracket securing bolts and remove the oil filter bracket and gasket.
5. Remove the oil relief valve plug from the oil pump case.
6. Remove the oil pump case.

INSPECTION

1. Visually check the parts of the oil pump case for cracks and damage.
2. Assemble the rotor on the oil pump and then check the clearance with a thickness gauge.

Oil pump side clearance


Standard value

Body clearance:

0.100 ~ 0.181 mm (0.0039 ~ 0.0071 in.)

Side clearance:

0.040 ~ 0.095 mm (0.0016 ~ 0.0037 in.)



G03844827

Fig. 109: Checking Oil Pump Side And Body Clearance
Courtesy of HYUNDAI MOTOR CO.


**G03844828**

Fig. 110: Checking Oil Pump Tip Clearance
Courtesy of HYUNDAI MOTOR CO.

RELIEF PLUNGER AND SPRING

1. Check the relief plunger for smooth operation.
2. Check the relief spring for deformation or breaks.


OIL FILTER BRACKET

1. Make sure that there is no damage on the surface that mates with the oil filter.
2. Check the oil filter bracket for oil leaks or cracks.

OIL PRESSURE SWITCH

1. Check the continuity between the terminal and the body with an ohmmeter.

If there is no continuity, replace the oil pressure switch.



G03844829

Fig. 111: Checking Oil Pressure Switch Continuity
Courtesy of HYUNDAI MOTOR CO.


2. Check the continuity between the terminal and the body when the fine wire is pushed. If there is continuity even when the fine wire is pushed, replace the switch.
3. If there is no continuity when a 50 kPa (7 psi) vacuum is applied through the oil hole, the switch is operating properly.

Check for air leakage. If air leaks, the diaphragm is broken Replace it.

Operation Pressure

Oil pressure switch:

20 ~ 40 kPa (0.2 ~ 0.4 kg/cm² . 2.9 ~ 5.8 psi)



G03844830

Fig. 112: Checking Oil Pressure Switch Continuity When Fine Wire Is Pushed
Courtesy of HYUNDAI MOTOR CO.

REASSEMBLY

1. Install the oil pump case with the gasket.

Tightening torque


Oil pump case bolt:

12 ~ 15 Nm (120 ~ 150 kg.cm, 9 ~ 11 lb.ft)


Oil pump cover screw:

8 ~ 12 Nm (80 ~ 120 kg.cm, 6 ~ 9 lb.ft)

<Front view>




<Rear view>



G03844831

Fig. 113: Identifying Front And Rear View Of Oil Pump Case
Courtesy of HYUNDAI MOTOR CO.

2. Install the oil seal into the oil pump case as tightly as possible, using the special tool (09214-33000).



G03844832


Fig. 114: Installing Oil Seal Into Oil Pump Case
 Courtesy of HYUNDAI MOTOR CO.

3. Install the relief plunger and spring, and tighten the oil relief valve plug to the specified torque.

Tightening torque

Oil relief valve plug

10 ~ 50 Nm (400 ~ 500 kg.cm, 29 ~ 36 lb.ft)



G03844833

Fig. 115: Installing Relief Plunger And Spring
Courtesy of HYUNDAI MOTOR CO.

4. Install the oil screen and a new gasket.

Tightening torque

Oil screen bolt:

15 ~ 22 Nm (150 ~ 220 kg.cm, 11 ~ 15 lb.ft)

5. Clean the gasket surfaces of the cylinder block and the oil pan.
6. Apply sealant to the groove of the oil pan flange.

NOTE:

- 1. Make the first cut approx. 4 mm from the end of the nozzle furnished with the sealant. After application of the sealant, do not exceed 15 minutes-before installing the oil pan.**
- 2. Make sure that the sealant doesn't enter the inside of the oil pan.**

7. Install the oil pan and tighten the bolts to the specified torque. See **Fig. 116**.


Tightening torque

Oil pan bolt

*: 19 ~ 28 Nm (190 ~ 280 kg.cm, 14 ~ 20 lb.ft)

**: 5 ~ 7 Nm (50 ~ 70 kg.cm, 4 ~ 5 lb.ft)


***: 30 ~ 42 Nm (300 ~ 420 kg.cm, 22 ~ 30 lb.ft)



G03844834

Fig. 116: Installing Oil Pump Bolts
Courtesy of HYUNDAI MOTOR CO.

8. Tighten the oil pan bolts as shown in **Fig. 117**.



G03844835

Fig. 117: Identifying Tightening Sequence Of Oil Pan Bolts
 Courtesy of HYUNDAI MOTOR CO.

9. Using a 24 mm deep socket, install the oil pressure switch after applying sealant to the threaded area.

Sealant: Three bond No. 1141E or 3M ATD

No. 8660 or equivalent

NOTE: Do not torque the oil pressure switch too much.

Tightening torque

Oil pressure switch:

15 ~ 22 Nm (150 ~ 220 kg.cm, 11 ~ 16 lb.ft)





Fig. 118: Installing Oil Pressure Switch
Courtesy of HYUNDAI MOTOR CO.

10. Tighten the lower oil pan bolts as shown in **Fig. 119**.




G03844837

Fig. 119: Identifying Tightening Sequence Of Oil Pan Bolts
Courtesy of HYUNDAI MOTOR CO.

INTAKE AND EXHAUST SYSTEM

EXHAUST MANIFOLD

COMPONENTS




TORQUE : Nm (kg-cm, lb.ft)

G03844838

Fig. 120: Identifying Exhaust Manifold Components - With Torque Specifications
Courtesy of HYUNDAI MOTOR CO.

REMOVAL


1. Remove the heat protector.



G03844839

Fig. 121: Removing Heat Protector
Courtesy of HYUNDAI MOTOR CO.

2. Remove the exhaust manifold.



G03844840

Fig. 122: Removing Exhaust Manifold
Courtesy of HYUNDAI MOTOR CO.


3. Remove the exhaust manifold gasket.

INSPECTION

1. Check for damage or cracks.
2. Using a straight edge and feeler gauge, check for distortion on the cylinder head matching surface.

Standard value: 0.15 mm (0.006 in.) or less

Service limit: 0.3 mm (0.012 in.) or less



G03844841

Fig. 123: Checking For Distortion On Cylinder Head Matching Surface
Courtesy of HYUNDAI MOTOR CO.

3. Check the exhaust manifold for damage and cracks.

INSTALLATION


1. Install the exhaust manifold with gasket.

Tightening torque

Exhaust manifold:

30 ~ 35 Nm (300 ~ 350 kg.cm, 22 ~ 26 lb.ft)


NOTE: **Do not re-use an exhaust manifold gasket.**



G03844842

Fig. 124: Installing Exhaust Manifold With Gasket
Courtesy of HYUNDAI MOTOR CO.

2. Install the heat protector.




G03844843

Fig. 125: Installing Heat Protector
Courtesy of HYUNDAI MOTOR CO.

INTAKE MANIFOLD

COMPONENTS




TORQUE : Nm (kg-cm, lb-ft)

G03844844

Fig. 126: Identifying Intake Manifold Components - With Torque Specifications
Courtesy of HYUNDAI MOTOR CO.

REMOVAL


1. Remove the air intake hose connected to the throttle body.



G03844845

Fig. 127: Removing Air Intake Hose Connected To Throttle Body
Courtesy of HYUNDAI MOTOR CO.


2. Remove the accelerator and cruise control cables.



G03844846

Fig. 128: Removing Accelerator And Cruise Control Cables
Courtesy of HYUNDAI MOTOR CO.


3. Remove the engine coolant hose and throttle body.
4. Remove the PCV hose and brake booster vacuum hoses.
5. Disconnect the vacuum hose connections.



G03844847

Fig. 129: Disconnecting Vacuum Hose Connections
Courtesy of HYUNDAI MOTOR CO.


6. Remove the surge tank stay.



G03844848

Fig. 130: Removing Surge Tank Stay
Courtesy of HYUNDAI MOTOR CO.


7. Bleed off the pressure in the fuel pipe line to prevent the fuel from spilling.
8. Disconnect the connector from high pressure hose.



G03844849

Fig. 131: Disconnecting Connector From High Pressure Hose
Courtesy of HYUNDAI MOTOR CO.


9. Remove the surge tank.



G03844850

Fig. 132: Removing Surge Tank
Courtesy of HYUNDAI MOTOR CO.


10. Remove the surge tank gasket.



G03844851

Fig. 133: Removing Surge Tank Gasket
Courtesy of HYUNDAI MOTOR CO.

11. Disconnect the fuel injector harness connector.




G03844852

Fig. 134: Disconnecting Fuel Injector Harness Connector
Courtesy of HYUNDAI MOTOR CO.

12. Remove the delivery pipe with the fuel injector and the pressure regulator.

NOTE: When the delivery pipe is removed, be careful not to drop an injector.



G03844853

Fig. 135: Removing Delivery Pipe With Fuel Injector And Pressure Regulator
Courtesy of HYUNDAI MOTOR CO.

13. Disconnect the wiring harness of the coolant sensor assembly.


**G03844854**

Fig. 136: Disconnecting Wiring Harness Of Coolant Sensor Assembly
Courtesy of HYUNDAI MOTOR CO.


INSPECTION

SURGE TANK AND INTAKE MANIFOLD

1. Check the surge tank and intake manifold for damage, cracking or restriction of the vacuum outlet port, water or gas passages.
2. Check for distortion on the surface using a straight edge and feeler gauge.

Standard value: 0.15 mm (0.006 in.) or less

Service limit: 0.2 mm (0.0078 in.)



G03844855

Fig. 137: Checking Surge Tank And Intake Manifold For Damage
Courtesy of HYUNDAI MOTOR CO.

INSTALLATION

1. Install the intake manifold and delivery pipe reversing the order of the removal procedure.


Tightening torque

Intake manifold:

19 ~ 21 Nm (190 ~ 210 kg.cm, 14 ~ 15 lb.ft)


Surge tank:

15 ~ 20 Nm (150 ~ 200 kg.cm, 11 ~ 14 lb.ft)



G03844856

Fig. 138: Identifying Tightening Sequence Of Intake Manifold Bolts
Courtesy of HYUNDAI MOTOR CO.




G03844857

Fig. 139: Installing Surge Tank
Courtesy of HYUNDAI MOTOR CO.

MUFFLER

COMPONENTS



TORQUE : Nm (kg·cm, lb·ft)

G03844858


Fig. 140: Identifying Muffler Components - With Torque Specifications
Courtesy of HYUNDAI MOTOR CO.

REMOVAL

MAIN MUFFLER

CAUTION: Before removing or inspecting the exhaust system, ensure that the exhaust system is cool.


1. Disconnect the main muffler from the center exhaust pipe.



G03844859


Fig. 141: Disconnecting Main Muffler From Center Exhaust Pipe
Courtesy of HYUNDAI MOTOR CO.

2. Remove the rubber hangers and the main muffler.



G03844860

Fig. 142: Removing Rubber Hangers
Courtesy of HYUNDAI MOTOR CO.




G03844861

Fig. 143: Removing Main Muffler
Courtesy of HYUNDAI MOTOR CO.

FRONT EXHAUST PIPE (INCLUDING CATALYTIC CONVERTER)


1. Remove the front exhaust pipe from the center exhaust pipe.
2. Remove the front exhaust pipe bolt and the exhaust manifold pipe mounting nuts.



G03844862


Fig. 144: Removing Front Exhaust Pipe Bolt And Exhaust Manifold Pipe Mounting Nuts
Courtesy of HYUNDAI MOTOR CO.

3. Remove the front exhaust pipe from the rubber hanger.



G03844863

Fig. 145: Removing Front Exhaust Pipe
Courtesy of HYUNDAI MOTOR CO.



G03844864

Fig. 146: Removing Rubber Hanger
Courtesy of HYUNDAI MOTOR CO.

INSPECTION


1. Check the mufflers and pipes for leaks, corrosion and damage.
2. Check the rubber hangers for deterioration and cracks.

INSTALLATION

1. Temporarily install the front exhaust pipe, the catalytic converter assembly, the center exhaust pipe and the main muffler, in this order.
2. Install the rubber hangers so that they hang equally left and right.
3. Tighten the parts securely and then confirm that there is no interference with any components.

AIR CLEANER (ACL)

COMPONENTS




G03844865

Fig. 147: Identifying Air Cleaner (ACL) Components
Courtesy of HYUNDAI MOTOR CO.

REMOVAL

1. Disconnect the air flow sensor connector.
2. Remove the air intake hose and air duct connected to the air cleaner.
3. Remove the three bolts attaching the air cleaner mounting brackets.
4. Detach the air cleaner.



G03844866


Fig. 148: Detaching Air Cleaner
Courtesy of HYUNDAI MOTOR CO.

5. Remove the air flow sensor from the air intake hose.

CAUTION: Do not pull on the air flow sensor wires.

INSPECTION

1. Check the air intake hose, air cleaner cover for damage.
2. Check the air duct for damage.




G03844867

Fig. 149: Checking Air Duct For Damage
Courtesy of HYUNDAI MOTOR CO.

3. Check the air cleaner element for restriction, contamination or damage.

If the element is slightly restricted, remove dust and debris by blowing compressed air from the inside of the element. Replace the element if it cannot be cleaned.



G03844868

Fig. 150: Cleaning Air Cleaner
Courtesy of HYUNDAI MOTOR CO.


INSTALLATION

1. Install the air cleaner assembly following the reverse order of removal.

CYLINDER HEAD ASSEMBLY

CYLINDER HEAD

COMPONENTS



TORQUE : Nm (kg·cm, lb·ft)


G03844869

Fig. 151: Identifying Cylinder Head Components - With Torque Specifications
Courtesy of HYUNDAI MOTOR CO.

DISASSEMBLY


1. Drain the coolant and disconnect the upper radiator hose.
2. Remove the breather hose and air-intake hose.
3. Remove the vacuum hose, fuel hose and coolant hose.
4. Remove the intake manifold.
5. Remove the cables from the spark plugs. The cables should be removed by holding the boot portion.
6. Remove the ignition coil.
7. Remove the upper and lower timing belt cover.

8. Remove the timing belt and camshaft sprockets.
9. Remove the heat protector and exhaust manifold assembly.
10. Remove the coolant pump pulley and head cover.
11. Remove the intake and exhaust camshaft.



G03844870

Fig. 152: Identifying Auto Tensioner
Courtesy of HYUNDAI MOTOR CO.




G03844871

Fig. 153: Removing Intake And Exhaust Camshaft
Courtesy of HYUNDAI MOTOR CO.

12. Remove the cylinder head assembly. The cylinder head bolts should be removed using the S12 mm socket, in two or three steps.
13. Clean the gasket pieces from the cylinder block top surface and cylinder head bottom surface.

NOTE: **Make sure that fragments from the gasket do not fall in the engine.**



G03844872

Fig. 154: Removing Cylinder Head Bolts
Courtesy of HYUNDAI MOTOR CO.


INSPECTION

1. Remove scale, sealing compound and carbon deposits. After cleaning oil passages, apply compressed air to make certain that the passages are not clogged.
2. Visually check the cylinder head for cracks, damage or water leakage.
3. Check the cylinder head surface for flatness with a straight edge and feeler gauge as shown in **Fig. 155**.

Cylinder head flatness

Standard dimensions: Max. 0.03 mm (0.0059 in.)

Service limit: 0.05 mm (0.0020 in.)



G03844873

Fig. 155: Checking Cylinder Head Surface For Flatness
Courtesy of HYUNDAI MOTOR CO.

VALVE GUIDES

Check the valve stem-to-guide clearance. If the clearance exceeds the service limit, replace the valve guide with a new oversize guide.

Valve stem-to-guide clearance

Standard value


Intake: 0.02 ~ 0.05 mm (0.0009 ~ 0.0020 in.)

Exhaust: 0.035 ~ 0.065 mm (0.0014 ~ 0.0026 in.)

Service limit

Intake: 0.10 mm (0.0039 in.)

Exhaust: 0.15 mm (0.0059 in.)



G03844874

Fig. 156: Checking Valve Stem-To-Guide Clearance
Courtesy of HYUNDAI MOTOR CO.




Fig. 157: Checking Valve Stem Diameter
Courtesy of HYUNDAI MOTOR CO.

VALVE

1. Replace the valve if its stem is bent, worn or damaged. Also replace it if the stem end (the surface contacting the hydraulic-lash adjuster) is hollowed out.
2. Check the valve face contact area, and recondition or replace as necessary.
3. Replace the valve if the width of the margin (thickness of the valve head) is less than the minimum specified.

Valve margin

Standard value


Intake: 1.0 mm (0.0397 in.)

Exhaust: 1.3 mm (0.0512 in.)

Service limit

Intake: 0.5 mm (0.0197 in.)

Exhaust: 0.8 mm (0.0315 in.)



G03844876

Fig. 158: Checking Valve Face Contact Area
Courtesy of HYUNDAI MOTOR CO.

VALVE SPRING

1. Check the free height of each valve spring and replace if necessary.
2. Using a square, test the squareness of each valve spring. If the spring is excessively out-of-square, replace it.

Valve spring

Standard value

Free height: 42.5 mm (1.6732 in.)

Load: 21.9 kg / 35 mm (48.4 lb / 1.3780 in.)

Out of squareness: Max. 1.5°

2006 Hyundai Santa Fe GLS


2006 ENGINE Engine Mechanical System (G6BA-GSL 2.7) - Santa Fe

Service limit

Free height: 41.5 mm (1.6339 in.)

Load: 21.9 kg / 34 mm (48.4 lb / 1.3386 in.)

Out of squareness: Max. 3°



G03844877

Fig. 159: Checking Free Height Of Valve Spring
 Courtesy of HYUNDAI MOTOR CO.

REPLACING VALVE GUIDE

1. Using the special tool (09221-3F100 A/B), withdraw the old valve guide out the bottom of the cylinder head.
2. Recondition the valve guide hole so that it can receive the newly press-fitted oversize valve guide.

VALVE GUIDE OVERSIZES

VALVE GUIDE OVERSIZES TABLE

Size mm (in.)	Size Mark	Oversize valve guide hole size mm (in.)
0.05 (0.002) O.S.	5	11.050 ~ 11.068 (0.435 ~ 0.4357)
0.25 (0.010) O.S.	25	11.250 ~ 11.268 (0.443 ~ 0.04436)
0.50 (0.020) O.S.	50	11.500 ~ 11.518 (0.453 ~ 0.4535)





Fig. 160: Removing/Installing Valve Guide
Courtesy of HYUNDAI MOTOR CO.

3. Using the special tool (09221-3F100(A), 09221-3F100(B)) press-fit the valve guide. The valve guide must be press-fitted from the upper side of the cylinder head. Keep in mind that the intake and exhaust valve guides are different in length.
4. After the valve guide is press-fitted, insert a new valve and check for proper clearance.
5. After the valve guide is replaced, check that the valve is fully seated. Recondition the valve seats as necessary.

NOTE: Do not install a valve guide unless it is oversize.




G03844879

Fig. 161: Identifying Valve Guide Dimensions
Courtesy of HYUNDAI MOTOR CO.

REPLACING VALVE SEAT RING


1. Cut away the inner face of the valve seat to reduce the wall thickness.



G03844880

Fig. 162: Identifying Cut-Away Area Of Inner Valve Seat
Courtesy of HYUNDAI MOTOR CO.

2. Enlarge the diameter of the valve seat so that it matches the specified hole diameter of the new valve seat ring.



G03844881

Fig. 163: Identifying Height Of Valve Seat Ring And Diameter Of Oversize Hole
 Courtesy of HYUNDAI MOTOR CO.

VALVE SEAT RING OVERSIZES

VALVE SEAT RING OVERSIZES TABLE

Description	Size mm (in.)	Size Mark	Seat ring height H mm (in.)	Oversize hole I.D. mm (in.)
Intake valve	0.3 (0.012)	30	7.9 ~ 8.1	33.300 ~

2006 Hyundai Santa Fe GLS

2006 ENGINE Engine Mechanical System (G6BA-GSL 2.7) - Santa Fe

seat ring	O.S.		(0.311 ~ 0.319)	33.325 (1.311 ~ 1.312)
Exhaust valve seat ring	0.3 (0.012) O.S	30	7.9 ~ 8.1 (0.311 ~ 0.319)	28.600 ~ 28.625 (1.126 ~ 1.127)

- Heat the cylinder head to about 250°C (480°F) and press-fit an oversize seat ring for the bore in the cylinder head.
- Using lapping compound, lap the valve to the new seat.

Valve seat contact width

Intake: 1.1 ~ 1.5 mm (0.043 ~ 0.059 in.)


Exhaust: 1.3 ~ 1.7 mm (0.051 ~ 0.067 in.)

REASSEMBLY

- Install the spring seats.
- Using special tool (09222-22001), lightly tap the seal in position.

NOTE:

- Do not reuse old valve stem seals.
- Incorrect installation of the seal could result in oil leakage of from the valve guides.




G03844882

Fig. 164: Tapping Seal

Courtesy of HYUNDAI MOTOR CO.

3. Apply engine oil to each valve. Insert the valve into their guides. Avoid pushing the valve into the seal by force. After installing the valve, check that it moves smoothly.
4. Place valve springs so that the side coated with enamel faces toward the valve spring retainer.




G03844883

Fig. 165: Identifying Placement Of Valve Spring

Courtesy of HYUNDAI MOTOR CO.

5. Using the special tool (09222-28000, 09222-28100), compress the spring and install the retainer locks. After installing the valves, ensure that the retainer locks are correctly in place before releasing the valve spring compressor.

NOTE: When the spring is compressed, check that the valve stem seal is not pressed against the bottom of the retainer.




G03844884

Fig. 166: Compressing Spring
Courtesy of HYUNDAI MOTOR CO.

6. Clean both gasket surfaces of the cylinder head and cylinder block.
7. Verify the identification marks on the cylinder head gasket.
8. Install the gasket so that the surface with the identification mark faces toward the cylinder head.

NOTE: **Do not apply sealant to these surfaces.**


Identification mark



G03844885

Fig. 167: Identifying Identification Mark On Cylinder Head Gasket
Courtesy of HYUNDAI MOTOR CO.

9. Tighten the cylinder head bolts in the sequence shown in **Fig. 168** with a torque wrench.



G03844886


Fig. 168: Tightening Cylinder Head Bolts
Courtesy of HYUNDAI MOTOR CO.

10. Tighten the cylinder head bolts using the torque - angle method. Starting at top center, tighten all cylinder head bolts in sequence as shown in **Fig. 169**, using the 12 mm socket.

Tightening procedure


Cylinder head bolt:

25 Nm (250 kg.cm, 18.1 lb.ft)+(58° ~ 62°)+(43° ~ 47°)



G03844887

Fig. 169: Identifying Tightening Sequence Of Cylinder Head Bolts
Courtesy of HYUNDAI MOTOR CO.




G03844888

Fig. 170: Identifying Tightening Angle Of Cylinder Head Bolts
Courtesy of HYUNDAI MOTOR CO.

TIMING SYSTEM

TIMING BELT


COMPONENTS



TORQUE : Nm (kg.cm, lb.ft)

G03844889

Fig. 171: Identifying Timing System Components (1 Of 2) - With Torque Specifications
 Courtesy of HYUNDAI MOTOR CO.




TORQUE : Nm (kg.cm, lb.ft)

G03844890

Fig. 172: Identifying Timing System Components (2 Of 2) - With Torque Specifications
Courtesy of HYUNDAI MOTOR CO.

REMOVAL


1. Remove the engine cover.



G03844891

Fig. 173: Removing Engine Cover
Courtesy of HYUNDAI MOTOR CO.


2. Using a 16 mm wrench, rotate the tensioner arm clockwise (about 14°) and remove the belt from the pulley.
3. Remove the power steering pump pulley, idler pulley, tensioner pulley and crankshaft pulley.



G03844892

Fig. 174: Removing Belt From Pulley
Courtesy of HYUNDAI MOTOR CO.

4. Remove the upper and lower timing belt covers.




G03844893

Fig. 175: Removing Upper And Lower Timing Belt Covers
Courtesy of HYUNDAI MOTOR CO.

5. Remove the auto tensioner.

NOTE: Rotate the crankshaft clockwise and align the timing mark to set the No. 1 cylinder's piston to TDC (compression stroke). At this time, the timing marks of the camshaft sprocket and cylinder head cover should coincide with each other.




G03844894

Fig. 176: Removing Auto Tensioner
Courtesy of HYUNDAI MOTOR CO.

6. Unbolt the tensioner to remove the timing belt.

NOTE: If you plan to use the timing belt again, mark the rotation direction on the belt so you reinstall it correctly.




G03844895

Fig. 177: Removing Timing Belt
Courtesy of HYUNDAI MOTOR CO.

INSPECTION

1. Inspect the belt closely. If the following problems are evident, replace the belt with a new one.
 1. Hardened back surface of rubber


Back surface is glossy, non-elastic and so hard that when the nail of your finger is pressed into it, no mark is produced.



G03844896

Fig. 178: Inspecting Timing Belt (1 Of 4)
Courtesy of HYUNDAI MOTOR CO.

2. Cracked back surface of rubber.




G03844897


Fig. 179: Inspecting Timing Belt (2 Of 4)
Courtesy of HYUNDAI MOTOR CO.

3. Side of belt is badly worn.

NOTE: A belt in good condition should have clear-cut sides as if it were cut with a sharp knife.



Rounded belt side



Abnormal wear
(Fluffy canvas fiber)

G03844898

Fig. 180: Inspecting Timing Belt (3 Of 4)
Courtesy of HYUNDAI MOTOR CO.

4. Teeth are badly worn out.

Initial stage: Canvas on load side of the tooth flank worn (fluffy canvas fibers, rubber gone, color changed to white, and unclear canvas texture)

Last stage: Canvas on the load side of the tooth flank worn down and rubber exposed (tooth width reduced).

5. Missing tooth




Fig. 181: Inspecting Timing Belt (4 Of 4)
Courtesy of HYUNDAI MOTOR CO.

2. If backlash or an irregular noise is observed when rotating the pulley, replace the timing belt tensioner and idler pulley.




G03844900

Fig. 182: Inspecting Timing Belt Tensioner And Idler Pulley
Courtesy of HYUNDAI MOTOR CO.

INSTALLATION

1. Install the idler pulley to water pump boss.


NOTE: Insert and install the idler pulley to the roll pin that is pressed in the water pump boss.



G03844901

Fig. 183: Installing Idler Pulley
Courtesy of HYUNDAI MOTOR CO.

2. Install the tensioner arm and plain washer to the cylinder block.
3. Install the tensioner pulley to the tensioner arm.
4. Install the camshaft sprockets and align the timing marks.



G03844902

Fig. 184: Installing Camshaft Sprocket
Courtesy of HYUNDAI MOTOR CO.


NOTE:

- When installing the camshaft sprockets, fasten them tightly while holding the hexagonal part of the camshaft.
- Before installing the timing belt, if the timing marks of the cam sprocket and the cylinder head cover do not coincide, do not rotate the cam sprocket more than 3 teeth in either direction.
- Rotating the sprocket more than 3 teeth may allow the valve and piston to touch each other.

- **If the cam sprocket is rotated more than 3 teeth unavoidably, rotate the crankshaft counter clock wise a bit before rotating the cam sprocket.**

5. Install the auto tensioner to the front case.

NOTE: **At this time auto tensioner's set pin should be compressed and secured with set pin.**




G03844903

Fig. 185: Installing Auto Tensioner
Courtesy of HYUNDAI MOTOR CO.

6. Align the timing marks of each sprocket and install the timing belt in the following order.
1. Crankshaft sprocket => 2. Idler pulley => 3. Camshaft sprocket (LH side) => 4. Water pump pulley =>
 5. Camshaft sprocket (RH side) => 6. Tensioner pulley.

NOTE:


- In this step, No. 1 cylinder is in the TDC (Compression stroke).
- Be very careful if you use your fingers.



G03844904

Fig. 186: Identifying Installation Order Of Timing Belt
Courtesy of HYUNDAI MOTOR CO.

7. Pull out the set pin of the auto tensioner.



G03844905


Fig. 187: Pulling Out Set Pin Of Auto Tensioner
Courtesy of HYUNDAI MOTOR CO.

8. Install the upper and lower timing belt covers.
9. Install the power steering pump pulley, idler pulley, tensioner pulley and crankshaft pulley.
10. Using the wrench [16 mm], rotate the tensioner arm clockwise (about 14°) and install the belt to the pulley.
11. Install the engine cover.

HOW TO ADJUST THE TENSION OF THE TIMING BELT

1. Rotate the crankshaft 2 turns clockwise and measure the projected length of the auto tensioner at TDC (# 1 Compression stroke) after 5 minutes.
2. The projected length should be 7 ~ 9 mm (0.27 ~ 0.31 in.).
3. Verify that the timing marks of each sprocket are in their specified position.

NOTE: If the timing marks are not in their specified position, repeat from 6 above.



G03844906

Fig. 188: Identifying Projected Length
Courtesy of HYUNDAI MOTOR CO.