

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent

2004 ENGINES**1.6L 4-Cylinder - Accent****GENERAL****SPECIFICATIONS****General Engine Specifications**

Description	Specification	Limit
General		
Type	In-line, Double Over Head Camshaft	
Number of cylinders	4	
Bore	76.5 mm (3.0118 in)	
Stroke	87 mm (3.4252 in)	
Total displacement	1599 cc (97.54 cu.in)	
Compression ratio	10	
Firing order	1-3-4-2	
Valve timing		
Intake valve		
Opens (BTDC)	5°	
Closes (ABDC)	35°	
Exhaust valve		
Opens (BBDC)	43°	
Closes (ATDC)	5°	
Valve overlap	10°	
Cylinder head		
Flatness of cylinder head surface	Max. 0.03 mm (0.0012 in.)	0.1 mm (0.0039 in.)
Flatness of manifold mounting surface	0.15 mm (0.0059 in.)	0.2 mm (0.008 in.)
Oversize rework dimension of valve seat hole Intake		
0.3 mm (0.012 in.) O.S.	30.7 ~ 30.721 mm (1.2087 ~ 1.2095 in.)	
0.6 mm (0.024 in.) O.S.	31.0 ~ 31.021 mm (1.2205 ~ 1.2213 in.)	
Exhaust		
0.3 mm (0.012 in.) O.S.	27.3 ~ 27.321 mm (1.0748 ~ 1.0756 in.)	
0.6 mm (0.024 in.) O.S	27.6 ~ 27.621 mm (1.0866 ~ 1.0874 in.)	
Oversize rework dimensions of valve		

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent

Guide hole		
0.05 mm (0.002 in.) O.S.	11.05 ~ 11.068 mm (0.435 ~ 0.4357 in.)	
0.25 mm (0.010 in.) O.S.	11.25 ~ 11.268 mm (0.443 ~ 0.4436 in.)	
0.50 mm (0.020 in.) O.S.	11.50 ~ 11.518 mm (0.453 ~ 0.4535 in.)	
Camshaft		
Cam lobe height		
Intake	43.4484 mm (1.7106 in.)	42.9484 mm (1.6909 in.)
Exhaust	43.8489 mm (1.7263 in.)	43.3489 mm (1.766 in.)
Journal O.D	Ø27 mm (1.0630 in.)	
Bearing oil clearance	0.035 ~ 0.072 mm (0.0014 ~ 0.0028 in.)	
End play	0.1 ~ 0.2 mm (0.004 ~ 0.008 in.)	
Valve		
Valve length		
Intake	91.7 mm (3.6102 in.)	
Exhaust	92.3 mm (3.6339 in.)	
Stem O.D.		
Intake	5.955 ~ 5.97 mm (0.2344 ~ 0.2350 in.)	
Exhaust	5.935 ~ 5.95 mm (0.2337 ~ 0.2343 in.)	
Face angle thickness of valve head (Margin)		
Intake	1.1 mm (0.0433 in.)	0.8 mm (0.031 in.)
Exhaust	1.3 mm (0.0512 in.)	1.0 mm (0.039 in.)
Valve stem to valve guide clearance		
Intake	0.03 ~ 0.06 mm (0.0012 ~ 0.0024 in.)	0.10 mm (0.0039 in.)
Exhaust	0.05 ~ 0.08 mm (0.0020 ~ 0.0031 in.)	0.15 mm (0.0059 in.)
Valve guide		
Installed dimension O.D.		
Intake	12.8 mm (0.504 in.)	
Exhaust	12.8 mm (0.504 in.)	
Service size	0.05, 0.25, 0.50 mm (0.002, 0.010, 0.020 in.) oversize	
Valve seat		
Width of seat contact		
Intake	0.8 ~ 1.2 mm (0.031 ~ 0.047 in.)	
Exhaust	1.3 ~ 1.7 mm (0.051 ~ 0.066 in.)	

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent

Seat angle	45°	
Oversize	0.3, 0.6 mm (0.012, 0.024 in.) oversize	
Valve spring		
Free length	44.00 mm (1.7323 in.)	
Load	21.6kg/35 mm (47.6lb/1.3780 in.) 45.1 kg/27.2 mm (99.4lb/1.071 in.)	
Squareness	1.5° or less	
Cylinder block		
Cylinder bore	76.50 ~ 76.53 mm (3.0118 ~ 3.0130 in.)	
Out-of-round and taper of cylinder bore	Less than 0.01 mm (0.0004 in.)	
Clearance with piston	0.025 ~ 0.045 mm (0.0009 - 0.0017 in.)	
Piston		
O.D.	76.465 ~ 76.495 mm (3.0104 ~ 3.0116 in.)	
Service size	0.25 mm (0.010 in.) oversize	
Piston ring		
Side clearance		
No. 1	0.04 ~ 0.085 mm (0.0015 ~ 0.0033 in.)	0.1 mm (0.004 in.)
No. 2	0.04 ~ 0.085 mm (0.0015 ~ 0.0033 in.)	0.1 mm (0.004 in.)
Endgap		
No. 1	0.15 ~ 0.30 mm (0.0059 ~ 0.012 in.)	1.0 mm (0.039 in.)
No. 2	0.30 ~ 0.45 mm (0.012 ~ 0.0177 in.)	1.0 mm (0.039 in.)
Oil ring side rail	0.2 ~ 0.7 mm (0.0078 ~ 0.0275 in.)	1.0 mm (0.039 in.)
Service size	0.25 mm (0.010 in.) oversize	
Connecting rod		
Bend	0.05 mm (0.0020 in.) or less	
Twist	0.1 mm (0.0039 in.) or less	
Connecting rod big end to crankshaft side clearance	0.100-0.250 mm (0.0039-0.0098 in.)	0.4 mm (0.0157 in.)
Connecting rod bearing oil clearance	0.018-0.036 mm (0.0007-0.0014 in.)	
Undersize	0.25, 0.50, 0.75 mm (0.010, 0.020, 0.030 in.)	
Crankshaft		

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent

Pin O.D.	45 mm (1.77 in.)	
Journal O.D.	50 mm (1.97 in.)	
Berid	0.03 mm (0.0012 in.) or less	
Out- of- round, taper of journal and pin	0.005 mm (0.0002 in.) or less	
End play	0.05 - 0.175 mm (0.0019 - 0.0068 in.)	
Undersize rework dimension of pin		
0.25 mm (0.010 in.)	44.725 ~ 44.74 mm (1.7608 ~ 1.7614 in.)	
0.50 mm (0.020 in.)	44.475 ~ 44.49 mm (1.7509 ~ 1.7516 in.)	
0.75 mm (0.030 in.)	44.225 ~ 44.24 mm (1.7411 ~ 1.7417 in.)	
Undersize rework dimension of journal		
0.25 mm (0.010 in.)	49.727 ~ 49.742 mm (1.9577 ~ 1.9583 in.)	
0.50 mm (0.020 in.)	49.477 ~ 49.492 mm (1.9479 ~ 1.9485 in.)	
0.75 mm (0.030 in.)	49.227 ~ 49.242 mm (1.9380 ~ 1.9386 in.)	
Flywheel		
Runout	0.1 mm (0.0039 in.)	0.13 mm (0.0051 in.)
Oil pump		
Clearance between outer circumference and front case (body clearance)	0.12 ~ 0.18 mm (0.0047 ~ 0.0070 in.)	
Front case tip clearance	0.025 ~ 0.069 mm (0.001 ~ 0.0027 in.)	
Side clearance		
Inner gear	0.04 ~ 0.085 mm (0.0016 ~ 0.0033 in.)	
Outer gear	0.04 ~ 0.09 mm (0.0016 ~ 0.0035 in.)	
Engine oil pressure		
Engine at idle [Oil temperature is 90 to 100°C (194 to 215°F)]	147 KPa (1.5 kg/ cm ² , 21.33 psi)	
Relief spring		
Free height	46.6 mm (1.8346 in.)	
Load	6.1kg at 40.1 mm (13.42lb/1.578 in.)	
Cooling method	Water-cooled, pressurized, forced circulation with electrical fan	

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent

Coolant		
Quantity	6.5 liter	
Radiator		
Type	Pressurized corrugated fin type	
Radiator cap		
Main valve opening pressure	81.4 ~ 108 kpa (11.8 ~ 15.6 psi., 0.83 ~ 1.1 kg/cm ²)	
Vacuum valve opening pressure	-6.86 kpa (-1.00 psi, -0.07 kg/cm ² or less	
Coolant pump	Centrifugal type impeller	
Thermostat		
Type	Wax pellet type with jiggle valve	
Valve opening temperature	82°C (180°F)	
Full-opening temperature	95°C (203°F)	
Engine coolant temperature sensor		
Type	Heat-sensitive thermistor type	
Resistance	2.31 ~ 2.59kohms at 20°C(68°F) 146.9 ~ 147.3 ohms at 110°C(230°F)	
Air cleaner		
Type	Dry type	
Element	Un woven cloth type	
Exhaust pipe		
Muffler	Expansion resonance type	
Suspension system	Rubber hangers	

NOTE:**O.D. = Outer Diameter****I.D. = Inner Diameter****O.S. = Oversize Diameter****U.S. = Undersize Diameter****TIGHTENING TORQUE****TORQUE SPECIFICATIONS**

Application	Ft Lbs. (N.m)
Alternator Brace Bolt	15-21 (20-28)
Alternator Support Bolt & Nut	15-18 (20-25)
Camshaft Sprocket Bolt	59-74 (80-100)
Connecting Rod Cap Nut	24-26 (32-35)
Coolant Temperature Sensor	18-22 (25-30)
Crankshaft Bearing Cap Bolt	41-44 (55-60)

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent


Crankshaft Pulley Bolt	103-111 (140-150)
Cylinder Head Bolts ⁽¹⁾	
Step 1	22 (30)
Step 2	Tighten An Additional 90 Degrees
Step 3	Release All Bolts
Step 4	22 (30)
Step 5	Tighten An Additional 90 Degrees
Driveplate/Flywheel Bolts	96-103 (130-140)
Engine Mounting Components	
Front Roll Stopper Bracket-To-Sub Frame	22-30 (30-40)
Front Roll Stopper Insulator Bolt	33-44 (45-60)
Rear Roll Stopper Bracket Subframe Bolts	22-30 (30-40)
Rear Roll Stopper Insulator Nut	33-44 (45-60)
Right Mounting Insulator (Large) Bolt	66-81 (90-110)
Right Mounting Insulator (Small) Nut	37-48 (50-65)
Transaxle Insulator Bracket-To-Side Member Nut	22-30 (30-40)
Transaxle Mount Insulator Bolt	66-81 (90-110)
Engine Support Bracket Stay	33-41 (45-55)
Exhaust Components	
Exhaust Manifold Cover-To-Exhaust Manifold Bolts	11-15 (15-20)
Exhaust Manifold Nut	18-22 (25-30)
Exhaust Pipe-To-Catalytic Converter	30-40 (40-60)
Exhaust Pipe-To-Exhaust Manifold Nut	22-30 (30-40)
Front Exhaust Bracket Bolts	22-30 (30-40)
Front Case Bolt	15-20 (20-27)
Front Engine Support Bracket Bolt & Nut	33-41 (45-55)
Intake Manifold Bolts & Nuts	11-15 (15-20)
Oil Filter	9-12 (12-16)
Oil Pan Drain Plug	30-33 (40-45)
Oil Screen Bolts	11-16 (15-22)
Oxygen Sensor	37-44 (50-60)
Rear Plate Bolt	24-26 (32-35)
Surge Tank Stay-To-Cylinder Block Bolts	13-18 (18-25)
Thermostat Housing Bolt	11-15 (15-20)
Throttle Body-To-Surge Tank Bolts	11-15 (15-20)
Timing Belt Idler Bolt	32-41 (43-55)
Timing Belt Tensioner Bolt	15-20 (20-27)
	INCH Lbs. (N.m)
Air Cleaner Body Mounting Bolts	71-89 (8-10)

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent

Alternator Lock Bolt	106-133 (12-15)
Camshaft Bearing Cap Bolts	106-124 (12-14)
Coolant Pump Bolt	106-133 (12-15)
Coolant Pump Pulley Bolt	71-89 (8-10)
Cylinder Head Cover Bolts	71-89 (8-10)
Oil Pan Bolts	88-106 (10-12)
Oil Pressure Switch	115-133 (13-15)
Resonator Mounting Bolt	35-53 (4-6)
Timing Belt Cover Bolt	71-88 (8-10)

(1) Tighten cylinder head bolts in sequence. See **Fig. 1**.



G00355781

Fig. 1: Identifying Cylinder Head Tightening Sequence
Courtesy of HYUNDAI MOTOR CO.

SERVICE STANDARD

Standard value	
Antifreeze	Mixture ratio of anti-freeze in coolant
ETHYLENE GLYCOL BASE FOR ALUMINUM	50%

G00334747

Fig. 2: Identifying Engine Coolant & Mixture
Courtesy of HYUNDAI MOTOR CO.

CHECKING ENGINE OIL

1. Position the vehicle on a level surface.
2. Warm up the engine.

NOTE: If a vehicle has been out of service for a prolonged period of time, warm up the engine for approximately 20 minutes.

3. Turn off the engine, and wait 2 or 3 minutes, then check the oil level.
4. Check that the engine oil level is within the level range indicated on the oil dipstick if the oil level is found to have fallen to the lower limit (the L mark), refill to the "F" mark.




Fig. 3: Identifying Engine Oil Dipstick
Courtesy of HYUNDAI MOTOR CO.


NOTE: When refilling, use the same type of engine oil.

5. Check that the oil is not dirty or contaminated with coolant or gasoline, and that it has the proper viscosity.

CHANGING ENGINE OIL

CAUTION: Be careful not to burn yourself, as the engine oil is hot.

1. Run the engine until it reaches normal operating temperature.
2. Turn off the engine
3. Remove the oil filler cap and the drain plug (on the oil pan). Drain the engine oil.



G00334749

Fig. 4: Locating Engine Oil Drain Plug
Courtesy of HYUNDAI MOTOR CO.

4. Install and tighten the drain plug to the specified torque.

Tightening torque

Drain plug: 40 ~ 45 Nm (400 ~ 450 kg.cm, 30 ~ 33 lb.ft)

5. Fill the crankcase with fresh engine oil through the oil filler cap opening.

Drain and Refill Without oil filter:

3.0 liter (3.17 U.S.qts, 2.64 Imp.qts)

Draining and Refill With oil filter:

3.3 liter (3.48 U.S.qts, 2.64 Imp.qts)

6. Install the oil filler cap.
7. Start and run the engine.
8. Turn off the engine and then check the oil level. Add oil if necessary.

FILTER SELECTION

All Hyundai engines are equipped with a high quality, disposable oil filter. This filter is recommended as a replacement filter on all vehicles. The quality of replacement filters varies considerably. Only high quality filters should be used to assure the most efficient service. Make sure that the rubber gasket from the old oil filter is completely removed from the contact surface on the engine block before installing the new filter.





Fig. 5: Locating Engine Oil Filter Part Number
Courtesy of HYUNDAI MOTOR CO.

PROCEDURE FOR REPLACING THE OIL FILTER

CAUTION: Be careful not to burn yourself, as the engine and engine oil are hot.


1. Use a filter wrench to remove the oil filter.



G00334752

Fig. 6: Locating Engine Oil Filter
Courtesy of HYUNDAI MOTOR CO.

2. Before installing the new oil filter on the engine, apply clean engine oil to the surface of the rubber gasket.



G00334751

Fig. 7: Removing Engine Oil Filter & Applying Engine Oil To New Filter
Courtesy of HYUNDAI MOTOR CO.

3. Tighten the oil filter to the specified torque.

Tightening torque

Oil filter: 12 ~ 16 Nm (120 ~ 160 kg.cm, 9 ~ 12 lb.ft)

4. Run the engine to check for engine oil leaks.
5. After turning off the engine, check the oil level and add oil as necessary.


SELECTION OF ENGINE OIL

Recommended API classification: SH OR ABOVE

Recommended SAE viscosity grades:

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent



^{*1} Restricted by driving condition and environment.

^{*2} Not recommended for sustained high speed vehicle operation

G00334753

Fig. 8: Identifying Recommended SAE Viscosity Grades
Courtesy of HYUNDAI MOTOR CO.

NOTE: For best performance and maximum protection of all types of operation, select only those lubricants which:

1. Satisfy the requirements of the API classification.
2. Have proper SAE grade number for expected ambient temperature range.

Lubricant that does not have both an SAE grade number and an API service classification on the container should not be used.

CHECKING COOLANT LEAK


1. Wait until the engine is cool, then carefully remove the radiator cap.
2. Confirm that the coolant level is up to the filler neck.
3. Install a radiator cap tester to the radiator filler neck and apply 140 KPa (1.4 kg/cm², 20psi) pressure.

Hold it for two minutes in that condition, while checking for leakage from the radiator, hoses or connections.

NOTE:

1. Radiator coolant may be extremely hot. Do not open the system because hot, or scalding water could gush out causing personal injury. Allow the vehicle to cool before servicing this system.
2. Be sure to clean away any moisture from the places checked completely.
3. When the tester is removed, be careful not to spill any coolant from it.
4. Be careful, when installing and removing the tester and when testing, not to deform the filler neck of the radiator.

4. If there is leakage, repair or replace with the appropriate part.



G00334754

Fig. 9: Testing Coolant System for Leak
Courtesy of HYUNDAI MOTOR CO.

RADIATOR CAP PRESSURE TEST

1. Remove the radiator cap, wet its seal with engine coolant, then install it on the tester.
2. Increase the pressure until the gauge stops moving.

Main valve opening pressure:


83 ~ 110 kPa (0.83 ~ 1.1 kg/cm² , 12 ~ 16 psi)

Vacuum valve opening pressure:

-7 kPa (-0.07 kg/cm² , -1.0 psi)

3. Check that the pressure level is maintained at or above the limit.
4. Replace the radiator cap if the reading does not remain at or above the limit.

NOTE: Be sure that the cap is clean before testing, since rust or other foreign material on the cap seal will cause an incorrect reading.




G00334755

Fig. 10: Pressure Testing Radiator Cap
Courtesy of HYUNDAI MOTOR CO.

SPECIFIC GRAVITY TEST

1. Measure the specific gravity of the coolant with a hydrometer.



G00334756

Fig. 11: Using Hydrometer To Test Coolant Gravity
Courtesy of HYUNDAI MOTOR CO.

2. Measure the coolant temperature and calculate the concentration from the relation between the specific gravity and temperature, using the following table for reference.

Coolant temperatur °C (°F) and specific gravity					Freezing temperature °C (°F)	Safe operating temperature °C (°F)	Coolant concentration (Specific volume)
10 (50)	20 (68)	30 (86)	40 (104)	50 (122)			
1.054	1.050	1.046	1.042	1.036	-16 (3.2)	-11 (12.2)	30%
1.063	1.058	1.054	1.049	1.044	-20 (-4)	-15 (5)	35%
1.071	1.067	1.062	1.057	1.052	-25 (-13)	-20 (-4)	40%
1.079	1.074	1.069	1.064	1.058	-30 (-22)	-25(-13)	45%
1.087	1.082	1.076	1.070	1.064	-36 (-32.8)	-31 (-23.8)	50%
1.095	1.090	1.084	1.077	1.070	-42 (-44)	-37 (-35)	55%
1.103	1.098	1.092	1.084	1.076	-50 (-58)	-45 (-49)	60%

G00334757

Fig. 12: Coolant Concentration & Specific Gravity Specifications
Courtesy of HYUNDAI MOTOR CO.

Example

The safe operating temperature is -15°C (5°F) when the measured specific gravity is 1.058 at coolant temperature of 20°C (68°F)

CAUTION:

- If the concentration of the coolant is below 30%, its anti-corrosion properties will be adversely affected.
- If the concentration is above 60%, both the anti-freeze and engine cooling property will decrease, affecting the engine adversely. For these reasons, be sure to maintain the concentration level within the specified range.
- Do not use together with another brands product.

RECOMMENDED COOLANT

Antifreeze	Mixture ratio of anti freeze in coolant
ETHYLENE GLYCOL BASE FOR ALUMINUM	50% [Except tropical areas] 40% [Tropical areas]


G00334758

Fig. 13: Recommended Coolant Mixtures
Courtesy of HYUNDAI MOTOR CO.

CHANGING ENGINE COOLANT

CAUTION: When pouring engine coolant, be sure to shut the relay box lid and not to let coolant spill on electrical parts or the paint. If any coolant spills, rinse it off immediately.

1. Slide the heater temperature control lever to maximum heat. Make sure the engine and radiator are cool to the touch.
2. Remove the radiator cap.
3. Loosen the drain plug, and drain the coolant.



G00334759

Fig. 14: Locating Coolant Drain Plug
Courtesy of HYUNDAI MOTOR CO.

4. Tighten the radiator drain plug securely.
5. Remove, drain and reinstall the reservoir.

Fill the tank halfway to the MAX mark with water, then up to the MAX mark with antifreeze.

6. Pour coolant into the radiator up to the base of the filler neck, and install the radiator cap loosely.
7. Start the engine and let it run until it warms up (the radiator fan comes on at least twice).
8. Turn off the engine.


Check the level in the radiator, add coolant if needed.

9. Put the radiator cap on tightly, then run the engine again and check for leaks.

CHECKING COMPRESSION PRESSURE

1. Before checking engine compression, check the engine oil level. Also check that the starter motor and battery are all in normal operating condition.
2. Check the DTC and note it. Use the scan tool to clear the ECM'S memory.


3. Start the engine and wait until engine coolant temperature reaches 80 ~ 95°C (176 ~ 205°F).
4. Disconnect the fuel pump connector.
5. Turn off engine and disconnect the spark plug cables.



G00334760

Fig. 15: Removing Spark Plug Cable From Cylinder Head
Courtesy of HYUNDAI MOTOR CO.

6. Remove the spark plugs.
7. Disconnect the I.G. connector.
8. Crank the engine to remove any foreign material in the cylinders.
9. Insert the compression gauge into the spark plug hole.



G00334761

Fig. 16: Inserting Compression Gauge Into Spark Plug Hole
Courtesy of HYUNDAI MOTOR CO.

10. Depress the accelerator pedal to open the throttle fully.
11. Crank the engine and read the gauge.

Standard value: 1500kpa (15Kg/cm² , 218 psi)

Limit: 1400kpa (14Kg/cm² , 203 psi)

12. Repeat steps 9 to 11 over all cylinders, ensuring that the pressure differential for each of the cylinders is within the specified limit.

Limit

Max 100 kpa (1.0 kg/cm² , 14 psi) between cylinders

13. If a cylinder's compression or pressure differential is outside the specification, add a small amount of oil through the spark plug hole, and repeat steps 9 to 12.
 1. If the addition of oil makes the compression to rise, it is likely that there may be wear between the piston ring and cylinder wall.
 2. If compression remains the same, valve seizure, poor valve seating or a compression leak from the cylinder head gasket are all possible causes.

Tightening torque


Spark plug: 20 ~ 30 Nm (200 ~ 300 kg.cm, 14 ~ 22 lb.ft)

ADJUSTING TIMING BELT TENSION

1. Rotate the steering wheel counter-clockwise thoroughly.

NOTE: **Do watch not to over load.**


2. Lift the vehicle by using of jack.



G00334762

Fig. 17: Lifting Vehicle With Jack
Courtesy of HYUNDAI MOTOR CO.


3. Remove the engine support bracket. (14mm bolt and 2nuts, 17mm bolt)



G00334763

Fig. 18: Removing Engine Support Bracket
Courtesy of HYUNDAI MOTOR CO.


4. Remove the drive belts and the water pump pulley. (10 mm 4 bolts)



G00334764

Fig. 19: Removing Water Pump Pulley
Courtesy of HYUNDAI MOTOR CO.


5. Remove the timing belt upper cover. (10 mm 4 bolts)



G00334765

Fig. 20: Removing Timing Belt Upper Cover
Courtesy of HYUNDAI MOTOR CO.

6. Remove the crankshaft pulley.




G00334766

Fig. 21: Removing Crankshaft Pulley
Courtesy of HYUNDAI MOTOR CO.

7. Remove the timing belt lower cover.
8. Place the piston of No. 1 cylinder to TDC of the compression stroke by rotating the crankshaft clockwise.

NOTE: **Crankshaft is to be rotated clockwise otherwise, the tension is inadequately adjusted.**

9. Loosen the tensioner bolt of pivot side and slotside.




G00334768

Fig. 22: Loosening Tensioner Bolt
Courtesy of HYUNDAI MOTOR CO.

10. Rotate the crankshaft clockwise as many as 2 teeth of camshaft sprocket.
11. Check that the teeth of the sprocket and belt coincide with each other.
12. Tighten the slot side bolt first and then tighten the bolt of pivot side.
13. Check the tension of the timing belt.

When the tensioner and the tension side of the timing belt are pushed in horizontally with a moderate force [approx. 49N (11 lb)], the timing belt log end is approx. half of the tensioner mounting bolt head radius (cross flats) away from the bolt head center.




G00334769

Fig. 23: Checking Timing Belt Tension
Courtesy of HYUNDAI MOTOR CO.

14. Rotate the crankshaft pulley two turns clockwise so that the timing belt positions on the pulleys.
15. Install the timing belt lower cover.
16. Install the crankshaft pulley.
17. Install the timing belt upper cover.
18. Install the water pump pulley and engine support bracket.

ADJUSTING DRIVE BELT TENSION

1. Check that the belts are not damaged and are properly fit for the pulley grooves.
2. Apply 100 N (22 lbs.) force to the back and midway portion of the belt between the pulleys as shown in the illustration, measure the amount of deflection with a tension gauge.



G00334770

Fig. 24: Checking Drive Belt Alignment
Courtesy of HYUNDAI MOTOR CO.

- CAUTION:**
1. When installing the V-ribbed belt, check that the V-ribs are properly aligned.
 2. If noise or slippage is detected, check the belt for wear, damage, or breakage on the pulley contact surface, and check the pulley for scoring. Also check the amount that the belt is deflected.


Items		Inspection	Adjustment	
			New	Used
For alternator	Deflection mm (in.)	5.1~6.0(0.200~0.236)	4.0~4.4(0.157~0.173)	5.0~5.7(0.200~0.224)
	Tension N (lb)	350~500(79~112)	650~750(143~165)	400~500(88~110)
For air conditioner	Deflection mm (in.)	8(0.31)	5.0~5.5(0.20~0.22)	6.0~7.0(0.24~0.28)
	Tension N (lb)	250~500(56~112)	470~570(106~128)	320~400(72~90)
For power steering	Deflection mm (in.)	6.0~9.0(0.24~0.35)	-	-

G00334771

Fig. 25: Drive Belt Tension & Deflection Specifications
Courtesy of HYUNDAI MOTOR CO.

- NOTE:**
1. The belt tension must be measured half - way between the specified pulleys.

2. When a new belt is installed, adjust the tension to the central value of the standard range indicated under "New" in Fig. 25. Let the engine idle for 5 minutes or more, and check the standard value indicated under "Inspection" in Fig. 25.
3. When adjusting a belt which has been used, or newly installed, after 5 minutes or more of operation, refer to "Used" in Fig. 25.
4. Refer to Fig. 25 for periodic inspections.




G00334772

Fig. 26: Locating Drive Belt Pulleys
Courtesy of HYUNDAI MOTOR CO.

TYPE A TENSION GAUGE

Do not let the dial section of the tension gauge contact other objects during measurement.




G00334773

Fig. 27: Measuring Drive Belt Tension
Courtesy of HYUNDAI MOTOR CO.

TYPE B TENSION GAUGE

1. When measuring, turn the reset button in the direction of the arrow and set the gauge needle to the RESET position.
2. If the tension gauge is removed from the belt, the needle will still indicate the tension. Read the tension value after removing the gauge.



G00334774

Fig. 28: Identifying Tension Gauge
Courtesy of HYUNDAI MOTOR CO.

ADJUSTING THE ALTERNATOR BELT

CAUTION: If the belt is too loose, it will cause noise or sudden wear.

If the belt is too tight, the engine coolant pump bearing or the alternator can get damaged.

1. Loosen the alternator nut "A" and the tension adjuster lock bolt "B".
2. Using the tension adjuster bolt, adjust the belt tension to the specification. See **Fig. 25**.
3. Tighten the adjuster lock bolt "B".
4. Tighten the alternator nut "A".
5. Check the tension or the deflection of belt, readjust if necessary.

Tightening torque

Alternator support bolt and nut:


20 ~ 25 Nm (200 ~ 250 kg.cm, 14 ~ 18 lb.ft)

Alternator lock bolt B:

12 ~ 15 Nm (120 ~ 150 kg.cm, 9 ~ 11 lb.ft)

Alternator brace mounting bolt:

20 ~ 27 Nm (200 ~ 270 kg.cm, 15 ~ 20 lb.ft)



G00334775

Fig. 29: Adjusting Alternator Belt
Courtesy of HYUNDAI MOTOR CO.

ENGINE AND TRANSAXLE ASSEMBLY

REMOVAL

WARNING:

- Make sure jacks and safety stands are placed properly and hoist brackets are attached to the correct position on the engine.


2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent

- **Make sure the vehicle will not roll off stands and fall while you are working under it.**

CAUTION: Use fender covers to avoid damaging painted surface.


1. Remove the battery.



G00334780

Fig. 30: Removing Battery
Courtesy of HYUNDAI MOTOR CO.


2. Detach the air cleaner.



G00334781


Fig. 31: Removing Air Cleaner
Courtesy of HYUNDAI MOTOR CO.

3. Disconnect the connectors for engine harness.



G00334782


Fig. 32: Disconnecting Engine Harness Connectors (1 Of 2)
Courtesy of HYUNDAI MOTOR CO.



G00334783

Fig. 33: Disconnecting Engine Harness Connectors (1 Of 2)
Courtesy of HYUNDAI MOTOR CO.


4. Disconnect the engine ground.
5. Disconnect the connectors for the alternator harness and the oil pressure gauge wiring.



G00334784

Fig. 34: Disconnecting Connectors For Alternator Harness & Oil Pressure Gauge
Courtesy of HYUNDAI MOTOR CO.


6. Disconnect the brake booster vacuum hose.



G00334785


Fig. 35: Disconnecting Brake Booster Vacuum Hose
Courtesy of HYUNDAI MOTOR CO.

7. Remove the main fuel line, the return and vapor hoses from the engine side.



G00334786


Fig. 36: Removing Main Fuel Line, Return & Vapor Hoses From Engine Side (1 Of 2)
Courtesy of HYUNDAI MOTOR CO.



G00334787

Fig. 37: Removing Main Fuel Line, Return & Vapor Hoses From Engine Side (2 Of 2)
Courtesy of HYUNDAI MOTOR CO.

8. Disconnect the transaxle oil cooler hoses. (A/T)




G00334788

Fig. 38: Disconnecting Transaxle Oil Cooler Hoses (A/T)
Courtesy of HYUNDAI MOTOR CO.

NOTE: When disconnecting hoses, make identification marks to ensure they are reconnected correctly.

CAUTION: Be careful not to spill oil or fluid from hoses. Plug the openings to prevent foreign material from entering.


9. Drain the engine coolant.



G00334789

Fig. 39: Locating Engine Coolant Drain Plug
Courtesy of HYUNDAI MOTOR CO.



10. Disconnect the radiator upper and lower hoses on the engine side, then remove the radiator assembly.
11. Disconnect the heater hoses (inlet and outlet) on the engine side.



G00334790

Fig. 40: Disconnecting Heater Hoses (Inlet & Outlet) On Engine Side
Courtesy of HYUNDAI MOTOR CO.



12. Disconnect the accelerator cable at the engine side.
13. For vehicles with automatic transmission, remove the control cable from the transmission.



G00334791

Fig. 41: Removing Control Cable From Transmission (A/T)
Courtesy of HYUNDAI MOTOR CO.


14. Disconnect the inhibitor switch and solenoid valve connector.



G00334792

Fig. 42: Disconnect Inhibitor Switch & Solenoid Valve Connector
Courtesy of HYUNDAI MOTOR CO.


15. Disconnect the vehicle speed sensor connector.



G00334793

Fig. 43: Disconnecting Vehicle Speed Sensor Connector
Courtesy of HYUNDAI MOTOR CO.


16. Disconnect the clutch tube.



G00334794

Fig. 44: Disconnecting Clutch Tube
Courtesy of HYUNDAI MOTOR CO.


17. Disconnect the air conditioner compressor from the mounting bracket.



G00334795


Fig. 45: Disconnecting Air Conditioner Compressor From Mounting Bracket
Courtesy of HYUNDAI MOTOR CO.

18. Jack up the vehicle.
19. Disconnect the start motor connector and ground.



G00334796


Fig. 46: Disconnecting Starter Motor Connector & Ground (1 Of 2)
Courtesy of HYUNDAI MOTOR CO.



G00334797

Fig. 47: Disconnecting Starter Motor Connector & Ground (2 Of 2)
Courtesy of HYUNDAI MOTOR CO.

20. Disconnect the front exhaust pipe from the manifold.




G00334798

Fig. 48: Disconnecting Front Exhaust Pipe From Manifold
Courtesy of HYUNDAI MOTOR CO.

NOTE: Use wire to suspend the exhaust pipe from the bottom of the vehicle.


21. Remove the knuckle from the front damper.



G00334799

Fig. 49: Removing Knuckle Form Front Damper
Courtesy of HYUNDAI MOTOR CO.


22. Remove the caliper from the knuckle and hang the caliper from the front damper with wire.



G00334800

Fig. 50: Removing Caliper From Knuckle & Hang Caliper From Front Damper With Wire
Courtesy of HYUNDAI MOTOR CO.


23. Remove the wheel speed sensor form the knuckle. (with ABS)



G00334801

Fig. 51: Removing Wheel Speed Sensor Form Knuckle (With ABS)
Courtesy of HYUNDAI MOTOR CO.


24. Attach a chains or cables to the engine. Use an engine hoist or a chain hoist to slightly raise the engine (enough to support the engine's weight while processing with the following steps).



G00334802

Fig. 52: Attaching Chains Or Cables To Remove Engine
Courtesy of HYUNDAI MOTOR CO.


25. Remove the steering joint bolt.



G00334803

Fig. 53: Removing Steering Joint Bolt
Courtesy of HYUNDAI MOTOR CO.

26. Remove the engine mounting bracket from the engine.




G00334804

Fig. 54: Removing Engine Mounting Bracket From Engine
Courtesy of HYUNDAI MOTOR CO.

27. Slowly raise the engine (to the extent that the weight of the engine and transmission assembly is not applied to the mounting portions) and temporarily hold it in the raised position.

CAUTION: Check that all cables, hoses, harnesses, connectors etc. are disconnected from the engine.


28. Remove the caps from the inside of the right fender shield and remove the transaxle mount bracket bolts.



G00334805

Fig. 55: Removing Caps From Inside Of Right Fender Shield
Courtesy of HYUNDAI MOTOR CO.

29. Remove the sub frame fixing bolts and nuts.



G00334806






Fig. 56: Removing Sub Frame Fixing Bolts & Nuts
Courtesy of HYUNDAI MOTOR CO.

30. While directing the transmission side downward, lift the engine and transmission assembly down and out of the vehicles.

SPECIAL TOOLS

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent




Tool (Number and name)	Illustration	Use
Crankshaft front oil seal installer (09231 - 22000)		Installation of the front oil seal
Crankshaft front oil seal guide (09231 - 22100)		Guide of oil seal
Camshaft oil seal installer (09221 - 21000)		Installation of the camshaft oil seal
Valve guide installer (09221 - 3F100 A/B)		Removal and installation of valve guides
Valve stem oil seal installer (09222 - 22001)		Installation of valve stem oil seals

G00334776

Fig. 57: Identifying Special Tools (1 Of 2)
Courtesy of HYUNDAI MOTOR CO.

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent

Tool (Number and name)	Illustration	Use
Valve spring compressor (09222 - 28000) Valve spring compressor holder (09222 - 28100)		Removal and installation of intake and exhaust valves
Water temperature sensor socket wrench (09221 - 25100)		Removal and installation of the water temperature sensor
Crankshaft rear oil seal installer (09231 - 21000)		Installation of engine rear oil seal and crankshaft rear oil seal

G00334777

Fig. 58: Identifying Special Tools (2 Of 2)

Courtesy of HYUNDAI MOTOR CO.

TROUBLESHOOTING

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent

Symptom	Probable cause	Remedy
Low compression	Blown cylinder head gasket	Replace gasket
	Worn or damaged piston rings	Replace rings
	Worn piston or cylinder	Repair or replace piston and/or cylinder block
	Worn or damaged valve seat	Repair or replace valve and/or seat ring
Low oil pressure	Low engine oil level	Check engine oil level
	Faulty oil pressure switch	Replace
	Clogged oil filter	Replace
	Worn oil pump gears or cover	Replace
	Thin or diluted engine oil	Change and determine cause
	Oil relief valve stuck (open)	Repair
	Excessive bearing clearance	Replace
High oil pressure	Oil relief valve stuck (closed)	Repair
Excessive engine vibration	Loose engine roll stopper (front, rear)	Re-tighten
	Loose transaxle mount bracket	Re-tighten
	Loose engine mount bracket	Re-tighten
	Loose center member	Re-tighten
	Broken transaxle mount insulator	Replace
	Broken engine mount insulator	Replace
	Broken engine roll stopper insulator	Replace
Noisy valves	Thin or diluted engine oil (low oil pressure)	Change
	Worn or damaged valve stem or valve guide	Replace
	HLA abnormal operation	Speed the engine up (for venting) or Replace the HLA
Connecting rod and/or main bearing noise	Insufficient oil supply	Check engine oil level
	Thin or diluted engine oil	Change and determine cause
	Excessive bearing clearance	Replace
Timing belt noise	Incorrect belt tension	Adjust belt tension
Low coolant level	Leakage of coolant	
	1. Heater or radiator hose	Repair or replace parts
	2. Faulty radiator cap	Tighten or replace clamps
	3. Thermostat housing	Replace gasket or housing
	4. Radiator	Repair or replace
	5. Engine coolant pump	Replace parts
Clogged radiator	Foreign material in coolant	Replace coolant

G00334778

Fig. 59: Trouble Shooting Table (1 Of 2)
Courtesy of HYUNDAI MOTOR CO.

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent

Symptom	Probable cause	Remedy
Abnormally high coolant temperature	Faulty thermostat	Replace parts
	Faulty radiator cap	Replace parts
	Restricted flow in cooling system	Clear restriction or replace parts
	Loose or missing drive belt	Adjust or replace
	Faulty water pump	Replace
	Faulty electric fan	Repair or replace
	Insufficient coolant	Refill coolant
Abnormally low coolant temperature	Faulty thermostat	Replace
	Faulty temperature sensor wiring	Repair or replace
Inoperative electrical cooling fan	Damaged thermo sensor, electrical motor, radiator fan relay and wiring, fuse	Replace or repair
Exhaust gas leakage	Loose connections	Retighten
	Broken pipe or muffler	Repair or replace
Abnormal noise	Detached baffle plate in muffler	Replace
	Broken rubber hanger	Replace
	Pipe or muffler contacting vehicle body	Correct
	Broken pipe or muffler	Repair or replace


G00334779

Fig. 60: Trouble Shooting Table (2 Of 2)
Courtesy of HYUNDAI MOTOR CO.

TIMING SYSTEM

TIMING BELT

COMPONENTS




TORQUE : Nm (kgf-cm, lbf-ft)

G00334807

Fig. 61: Identifying Timing Belt Components
Courtesy of HYUNDAI MOTOR CO.

DISASSEMBLY


1. Lift the vehicle by using of jack.



G00334808

Fig. 62: Lifting Vehicle With Jack
Courtesy of HYUNDAI MOTOR CO.



2. Remove the engine support bracket. (14 mm bolt and 2 nuts, 17 mm bolt)



G00334809

Fig. 63: Removing Engine Support Bracket
Courtesy of HYUNDAI MOTOR CO.


3. Remove the power steering belt.
4. Remove the air conditioning compressor belt.
5. Remove the alternator belt.



G00334810

Fig. 64: Locating Alternator Adjuster Bolt
Courtesy of HYUNDAI MOTOR CO.


6. Remove the coolant pump pulley.



G00334811

Fig. 65: Removing Coolant Pump Pulley
Courtesy of HYUNDAI MOTOR CO.


7. Remove the crankshaft pulley.



G00334812

Fig. 66: Removing Crankshaft Pulley
Courtesy of HYUNDAI MOTOR CO.


8. Remove the timing belt cover.



G00334813

Fig. 67: Removing Timing Belt Cover
Courtesy of HYUNDAI MOTOR CO.

9. Move the timing belt tensioner pulley toward the coolant pump and temporarily secure it.




G00334814

Fig. 68: Loosening Timing Belt Tensioner
Courtesy of HYUNDAI MOTOR CO.

10. Remove the timing belt.


NOTE: If the timing belt is reused, mark with an arrow to indicate direction of rotation (on the front of the engine) to make sure that the belt is reinstalled in the same direction as before.



G00334815

Fig. 69: Marking Timing Belt For Installation
Courtesy of HYUNDAI MOTOR CO.

11. Remove the camshaft from the camshaft sprocket.
12. Remove the crankshaft sprocket and flange.
13. Remove the timing belt idler.
14. Remove the timing belt tensioner.



G00334816

Fig. 70: Removing Timing Belt Tensioner
Courtesy of HYUNDAI MOTOR CO.


INSPECTION

SPROCKETS TENSIONER PULLEY, AND IDLER PULLEY

1. Check the camshaft sprocket, crankshaft sprocket, tensioner pulley, and idler pulley for abnormal wear, cracks, or damage.

Replace as necessary.

2. Inspect the tensioner pulley and the idler pulley for easy and smooth rotation and check for play or noise. Replace as necessary.
3. Replace the pulley if there is a grease leak from its bearing.



G00334817

Fig. 71: Inspecting Pulley
Courtesy of HYUNDAI MOTOR CO.

TIMING BELT

1. Check the belt for oil or dust deposits. Replace, if necessary.

Small deposits should be wiped away with a dry cloth or paper. Do not clean with solvent.

2. When the engine is overhauled or belt tension adjusted, check the belt carefully. If any of the following flaws are evident, replace the belt with a new one.










Fig. 72: Inspecting Timing Belt (1 Of 3)
Courtesy of HYUNDAI MOTOR CO.


Description	Flaw conditions
1. Hardened back surface Back surface is glossy, non-elastic and so hard that when your fingernail is pressed into it, no mark is produced.	
2. Cracked back surface rubber	
3. Cracked or separating canvas	
	
	
4. Badly worn teeth (initial stages) Canvas on load side of tooth flank worn (Fluffy canvas fibers, rubber gone and color changed to white, and unclear canvas texture)	
5. Badly worn teeth (last stage) Canvas on load side of tooth flank worn down and rubber exposed (tooth width reduced)	

G00334819

Fig. 73: Inspecting Timing Belt (2 Of 3)
Courtesy of HYUNDAI MOTOR CO.

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent


Description	Flaw conditions
6. Cracked tooth bottom	 Crack
7. Missing tooth	 Tooth missing and canvas fiber exposed
8. Side of belt badly worn  NOTE <i>Normal belt should have precisely cut sides as if cut by a sharp knife.</i>	
9. Side of belt cracked	

G00334820

Fig. 74: Inspecting Timing Belt (3 Of 3)
Courtesy of HYUNDAI MOTOR CO.

REASSEMBLY

1. Install the flange and crankshaft sprocket as shown. Pay close attention to their mounting directions.



G00334821

Fig. 75: Installing Flange & Crankshaft Sprocket
Courtesy of HYUNDAI MOTOR CO.

2. Install the camshaft sprocket and tighten the bolt to the specified torque.

Tightening torque


Camshaft sprocket bolt:

80 ~ 100 Nm (800 ~ 1000 kg.cm, 59 ~ 74 lb.ft)

3. Install the idler and tighten the idler bolt to the specified torque.

Tightening torque

Idler bolt: 43 ~ 55 Nm (430 ~ 550 kg.cm, 32 ~ 41 lb.ft)




G00334822

Fig. 76: Installing Idler
Courtesy of HYUNDAI MOTOR CO.


4. Align the timing marks of the camshaft sprocket (A) and camshaft bearing cap (B).

Then align the timing marks of crankshaft sprocket and front case with the No.1 piston placed at top dead center on its compression stroke as shown in the illustration.



G00334823


Fig. 77: Identifying Camshaft Sprocket Timing Marks
Courtesy of HYUNDAI MOTOR CO.



G00334824

Fig. 78: Aligning Timing Marks Of Crankshaft Sprocket & Front Case
Courtesy of HYUNDAI MOTOR CO.


5. To install the timing belt tensioner, first mount the tensioner, spring, and spacer. Temporarily tighten the bolts. Next, temporarily tighten the tensioner long hole side washer and bolts. Install the bottom end of the spring against the front case as shown in the illustration.



G00334825

Fig. 79: Installing Timing Belt Tensioner
Courtesy of HYUNDAI MOTOR CO.

6. Secure the tensioner, positioned towards the water pump.
7. Install the timing belt on the crankshaft sprocket. (1) Crankshaft sprocket --> (2) Timing belt idler --> (3) Camshaft sprocket --> (4) Timing belt tensioner.



G00334826

Fig. 80: Locating Timing Components
Courtesy of HYUNDAI MOTOR CO.


8. Install the timing belt on the camshaft sprocket. When the timing belt is installed on the camshaft sprocket, make sure that the tension side is tight. Then, check to ensure that when the tension side is tightened by turning the camshaft sprocket in a reverse direction and all timing marks are in line.
9. Tighten the tensioner bolts.

Tightening torque

Tensioner attaching bolt:

20 ~ 27 Nm (200 ~ 270 kg.cm, 15 ~ 20 lb.ft)


10. Turn the crankshaft two turns in its operating direction (clock-wise) and realign the camshaft sprocket timing mark with the top dead center position.
11. Then recheck the belt tension. Verify that when the tensioner and the tension side of the timing belt are pushed in horizontally with a moderate force [approx. 49N (11 lb)], the timing belt cog end is approx. 1/2 of the tensioner mounting bolt head radius (across flats) away from the bolt head center.



G00334827

Fig. 81: Checking Timing Belt Tension
Courtesy of HYUNDAI MOTOR CO.

12. Install the timing belt cover.



G00334828

Fig. 82: Identifying Timing Belt Cover
Courtesy of HYUNDAI MOTOR CO.

Tightening torque

Timing belt cover bolt:

8 ~ 10 Nm (80 ~ 100 kg.cm, 6 ~ 7 lb.ft)


13. Install the crankshaft pulley. Make sure that the crankshaft sprocket pin fits the small hole in the pulley.

Tightening torque

Crankshaft pulley bolt:

140 ~ 150 Nm (1400 ~ 1500 kg.cm, 103 ~ 111 lb.ft)

14. Install the water pump pulley.



G00334829


Fig. 83: Installing Water Pump Pulley
Courtesy of HYUNDAI MOTOR CO.

15. Install the alternator belt and adjust the belt tension.
16. Install the air conditioning compressor belt and adjust the belt tension.
17. Install the power steering belt and adjust the belt tension.

CYLINDER HEAD ASSEMBLY

CYLINDER HEAD


COMPONENTS



TORQUE : Nm (kgf.cm, lbf.ft)

G00334830

Fig. 84: Identifying Cylinder Head Components (1 Of 2)
Courtesy of HYUNDAI MOTOR CO.



TORQUE : Nm (kgf-cm, lbf-ft)

G00334831

Fig. 85: Identifying Cylinder Head Components (2 Of 2)
Courtesy of HYUNDAI MOTOR CO.

DISASSEMBLY

1. Using a tool remove the cylinder head bolts in the order shown in the illustration.





Fig. 86: Identifying cylinder Head Bolt Removal Sequence
Courtesy of HYUNDAI MOTOR CO.

2. Using the special tool (09222-28000, 09222-28100), remove the valve retainer lock. Next remove the spring retainer, valve spring, spring seat and valve.

NOTE: **Arrange these parts so that they can be reinstalled in their original positions.**




G00334833

Fig. 87: Removing Valve Retainer Locks
Courtesy of HYUNDAI MOTOR CO.

3. Remove the valve stem seals with pliers.

NOTE: Do not reuse the valve stem seals.





G00334834

Fig. 88: Removing Valve Stem Seals
Courtesy of HYUNDAI MOTOR CO.

INSPECTION

CYLINDER HEAD

1. Check the cylinder head for cracks, damage and coolant leakage. If cracked, replace the cylinder head.
2. Remove scale, sealing compound and carbon deposits completely. After cleaning the oil passages, apply compressed air to verify that the passages are not clogged.



G00334835

Fig. 89: Removing Scale, Sealing Compound & Carbon Deposits From Cylinder Head
Courtesy of HYUNDAI MOTOR CO.

3. Check the cylinder head surface for flatness in the direction as shown in the illustration. If flatness exceeds the service limit in any direction, either replace the cylinder head or machine the cylinder head matching surface lightly.


Flatness of cylinder head gasket surface

Standard: Less than 0.03 mm (0.0012 in.)

Limit: 0.05 mm (0.002 in.)

VALVES

1. Using a wire brush, clean the valve thoroughly.



G00334836

Fig. 90: Cleaning Valve With Wire Brush
Courtesy of HYUNDAI MOTOR CO.

2. Check each valve for wear, damage and distortion of the head and the stem at B position. Replace, if necessary. If stem end, A, is hollowed out or worn, resurface as necessary. This correction must be limited to a minimum. Also resurface the valve face.

Replace the valve if the margin has decreased to less than the service limit.

Margin

[Standard]


Intake: 1.1 mm (0.043 in.)

Exhaust: 1.3 mm (0.051 in.)

[Limit]

Intake: 0.8 mm (0.028 in.)

Exhaust: 1.0 mm (0.040 in.)



G00334837

Fig. 91: Identifying Valve Servicing Limit
Courtesy of HYUNDAI MOTOR CO.

VALVE SPRINGS

1. Check the free height of each valve spring. If they exceed the serviced limit, replace the springs.
2. Using a square, test the squareness of each spring. If a spring is excessively out - of - square, replace it.

Valve spring

[Standard]

Free height: 44 mm (1.7323 in.)

Load:

21.6 kg/35 mm (47.6 lb/1.3780 in.)

45.1 kg/27.2 mm (99.4 lb/1.0709 in.)


Out of square: 1.5°

[Limit]

Free height: - 1.0 mm (-0.039 in.)

Out of square: 3°

Out-of-square



G00334838

Fig. 92: Testing Valve Spring Squareness
Courtesy of HYUNDAI MOTOR CO.

Check the valve stem-to-guide clearance. If the clearance exceeds the service limit, replace the valve guide with the next oversize part.

Valve stem-to-clearance

[Standard]


Intake: 0.03 ~ 0.06 mm (0.0012 ~ 0.0024 in.)

Exhaust: 0.05 ~ 0.08 mm (0.0020 ~ 0.0031 in.)

[Limit]

Intake: 0.1 mm (0.0040 in.)

Exhaust: 0.15 mm (0.0059 in.)



G00735313

Fig. 93: Checking Valve Stem-To-Guide Clearance
Courtesy of HYUNDAI MOTOR CO.

REPLACING THE VALVE SEAT RING

1. Cut away the inner face of the valve seat to reduce the wall thickness.




Fig. 94: Cutting Away Inner Face Of Valve Seat To Reduce Wall Thickness
 Courtesy of HYUNDAI MOTOR CO.

2. Enlarge the diameter of the valve seat so that it matches the specified oversize hole diameter of the new valve seat ring.
3. Heat the cylinder head to about 250°C (480°F) and press - fit an oversize seat ring for the bore in the cylinder head.
4. Using lapping compound, lap the valve to the new seat.

Valve seat contact width

Intake: 0.8 ~ 1.2 mm (0.0315 ~ 0.0472 in.)

Exhaust: 1.3 ~ 1.7 mm (0.0512 ~ 0.0670 in.)

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent



Description	Size mm (in.)	Size mark	Seat ring height H mm (in.)	Oversize hole diameter I.D. mm (in.)
Intake valve Seat ring	0.3 (0.012) O.S.	30	5.1~5.3(0.2008~0.2087)	30.7~30.721 (1.2087~1.2095)
	0.6 (0.024) O.S.	60	5.4~5.6(0.2126~0.2205)	31.0~31.021(1.2205~1.2213)
Exhaust valve Seat ring	0.3 (0.012) O.S.	30	6.2~6.4(0.2441~0.2520)	27.3~27.321(1.0748~1.0756)
	0.6 (0.024) O.S.	60	6.5~6.7(0.2560~0.2638)	27.6~27.621(1.0866~1.0874)

G00334841

Fig. 95: Valve Seat Insert Oversizes
Courtesy of HYUNDAI MOTOR CO.

REPLACING VALVE GUIDE

1. Using the special tool (09221-3F100 A/B), withdraw the old valve guide toward the bottom of cylinder head.
2. Recondition the valve guide hole so that it can match the newly press-fitted oversize valve guide.



G00334842

Fig. 96: Installing Valve Guide
Courtesy of HYUNDAI MOTOR CO.

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent

3. Using the special tool (09221-3F100 A/B), press-fit the valve guide. The valve guide must be press-fitted from the upper side of the cylinder head.
4. After the valve guide is press-fitted, insert a new valve and check for proper the clearance
5. After the valve guide is replaced, check that the valve is seated properly. Recondition the valve seats as necessary.

Over size mm (in.)	Size mark	Oversize valve guide hole size mm (in.)
0.05 (0.002)	5	11.05~11.068 (0.4350~0.4357)
0.25 (0.010)	25	11.25~11.268 (0.4429~0.4436)
0.50 (0.020)	50	11.50~11.518 (0.4528~0.4535)

G00334843

Fig. 97: Valve Guide Oversizes
Courtesy of HYUNDAI MOTOR CO.

REASSEMBLY

NOTE:

1. Clean each part before assembly.
2. Apply engine oil to the sliding and rotating parts.

1. Install the spring seats.

Using a special tool (09222-22001), tap the seal in position lightly.

NOTE:

- Do not reuse old valve stem seals.
- Incorrect installation of the seal could result in oil leakage past the valve guides.

2. Apply engine oil to each valve. Insert the valve into the valve guide.

Avoid pushing the valve into the seal by force. After inserting the valve, check that it moves smoothly.





Fig. 98: Inserting Valve Into Valve Guide
Courtesy of HYUNDAI MOTOR CO.

3. Place valve springs so that the side coated with enamel faces toward the valve spring retainer and then install the retainer.




G00334845

Fig. 99: Positioning Valve Springs So Side Coated With Enamel Faces Toward Valve Spring Retainer

Courtesy of HYUNDAI MOTOR CO.

4. Using the special tool (09222-28000, 09222-28100), compress the spring and install the retainer locks. After installing the valves, ensure that the retainer locks are correctly in place before releasing the valve spring compressor.




G00334846

Fig. 100: Compressing Spring To Install Retainer Locks
Courtesy of HYUNDAI MOTOR CO.

NOTE: When the spring is compressed, Check that the valve stem seal is not pressed against the bottom of the retainer.

5. Clean both gasket surfaces of the cylinder block and cylinder head.
6. Verify the identification marks on the cylinder head gasket.
7. Install the gasket so that the surface with the identification mark faces toward the cylinder head.
8. Tighten the bolts to the specified torque in the sequence shown.



G00334847

Fig. 101: Cylinder Head Bolt Tightening Sequence
Courtesy of HYUNDAI MOTOR CO.


Cylinder head bolt

30 Nm (300 kg.cm, 22 lb.ft) + 90° + Release all bolts + 30 Nm(300kg.cm, 22 lb.ft)+90°

MAIN MOVING SYSTEM

CAMSHAFT

COMPONENTS




TORQUE : Nm (kg.cm, lb.ft)

G00334848

Fig. 102: Identifying Camshaft Components
Courtesy of HYUNDAI MOTOR CO.

DISASSEMBLY


1. Disconnect the breather hose and the P.C.V. hose.
2. Loosen the center cover bolts and then remove the center cover.
3. Remove the ignition coil assembly and the spark plug cables.



G00334849

Fig. 103: Removing Spark Plug Cable
Courtesy of HYUNDAI MOTOR CO.

4. Loosen the cylinder head cover bolts and then remove the cylinder head cover.




G00334850

Fig. 104: Removing Cylinder Head Cover
Courtesy of HYUNDAI MOTOR CO.

5. Remove the camshaft sprocket.

6. Remove the camshaft bearing caps and timing chain.



G00334851

Fig. 105: Removing Camshaft Bearing Caps & Timing Chain
Courtesy of HYUNDAI MOTOR CO.

7. Remove the camshaft.
8. Remove the HLA.

INSPECTION

Camshaft

1. Check the camshaft journals for wear. If the journals are badly worn, replace the camshaft.
2. Check the cam lobes for damage. If the lobe is damaged or worn excessively, replace the camshaft.

Standard value


Intake: 43.4484 mm (1.7106 in.)

Exhaust: 43.8489 mm (1.7263 in.)

Limit

Intake: 42.9484 mm (1.6909 in.)

Exhaust: 43.3489 mm (1.7066 in.)



G00334852

Fig. 106: Checking Cam Lobes For Damage
Courtesy of HYUNDAI MOTOR CO.

3. Check the cam surface for abnormal wear or damage, and replace if necessary.
4. Check each bearing for damage. If the bearing surface is excessively damaged, replace the cylinder head assembly or camshaft bearing cap, as necessary.

Camshaft end play: 0.1 - 0.2 mm (0.0039 - 0.0079 in.)

OIL SEAL

2004 Hyundai Accent


2004 ENGINES 1.6L 4-Cylinder - Accent

1. Check the lips for wear. If the lip threads are worn, replace.
2. Check the oil seal lip contacting surface of the camshaft. If it is worn, replace the camshaft.

HLA (HYDRAULIC LASH ADJUSTER)

With the HLA filled with engine oil, hold A and press B by hand. If B moves, replace the HLA.

For other specific troubleshooting regarding HLA, refer to the table below.



G00334853

Fig. 107: Hydraulic Lash Adjuster (HLA) Trouble Shooting (1 Of 2)
Courtesy of HYUNDAI MOTOR CO.

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent

Problem	Possible cause	Action
Temporary noise on starting a cold engine.	Normal	This noise will disappear after the oil in the engine has reached normal pressure.
Continuous noise when engine is running after sitting more than 48 hours.	Oil leakage of the high pressure chamber on HLA, allowing air to get in.	Noise will disappear within 15 minutes when engine runs at 2000~3000 rpm If it doesn't disappear, refer to item 7 below
Continuous noise when engine is first started after rebuilding cylinder head.	Insufficient oil in cylinder head oil gallery.	
Continuous noise when engine is running after excessive cranking.	Oil drain out of the high-pressure chamber in HLA, allowing air to get in.	
Continuous noise when engine is running after changing HLA.	Insufficient oil in HLA.	 CAUTION <i>Do not run engine at a speed higher than 3000 rpm as this may damage HLA.</i>
Continuous noise during idle after high speed running.	Engine oil level too high or too low.	Check oil level. Drain or add oil as necessary.
	Excessive amount of air in the oil at high engine speed.	Check oil supply system
	Deteriorated oil	Check oil quality.
Noise continuous for more than 15 minutes.	Low oil pressure	Check oil pressure and oil supply system of each part of engine
	Faulty HLA.	Remove the cylinder head cover and press down on the HLA by hand. If it move, replace HLA.  CAUTION <i>Be careful of hot HLA.</i>


G00334854

Fig. 108: Hydraulic Lash Adjuster (HLA) Trouble Shooting (2 Of 2)
 Courtesy of HYUNDAI MOTOR CO.

NOTE: HLA noise could occur to your engine due to malfunction of HLA if you use additives besides engine oil regulated to HMC.

TIMING CHAIN

Check the bushing and plate of timing chain for wear. Replace if wear is severe.




G00334855

Fig. 109: Inspecting Timing Chain
Courtesy of HYUNDAI MOTOR CO.

REASSEMBLY


1. Install the HLA.
2. Align the camshaft timing chain with intake timing chain sprocket and exhaust timing chain sprocket as shown.



G00334856

Fig. 110: Aligning Camshaft Timing Chain
Courtesy of HYUNDAI MOTOR CO.

3. Install the camshaft after lubricating the camshaft journals with engine oil.



G00334857

Fig. 111: Installing Camshaft
Courtesy of HYUNDAI MOTOR CO.

4. Install the bearing caps. The markings on the caps are for intake/exhaust identification.

I: Intake camshaft

E: Exhaust camshaft




Fig. 112: Install Bearing Caps

Courtesy of HYUNDAI MOTOR CO.


5. Tighten the bearing caps to the specified torque in two or three steps as shown.

Tightening torque

Bearing cap bolt:

12 ~ 14 Nm (120 ~ 140 kg.cm, 9 ~ 10 lb.ft)


Camshaft sprocket side



G00334859

Fig. 113: Tightening Bearing Caps
Courtesy of HYUNDAI MOTOR CO.

6. Using the special tool, camshaft oil seal installer (09221-21000), press fit the camshaft oil seal. Be sure to apply engine oil to the oil seal lip. Insert the oil seal along the camshaft front end and install by driving the installer with a hammer until the oil seal is fully seated.



G00334860


Fig. 114: Press Fitting Camshaft Oil Seal
Courtesy of HYUNDAI MOTOR CO.

7. Install the camshaft sprocket bolts to the specified torque.

Tightening torque

Camshaft sprocket bolt:

80 ~ 100Nm (800 ~ 1000 kg.cm, 59 ~ 74 lb.ft)



G00334861


Fig. 115: Installing Camshaft Sprocket Bolts
Courtesy of HYUNDAI MOTOR CO.

8. Align the camshaft sprocket and crankshaft sprocket timing marks. Place the piston in the No. 1 cylinder to top dead center on the compression stroke. (Refer to the **TIMING BELT**)
9. Install the cylinder head cover.

Tightening torque

Cylinder head cover bolts:

8 ~ 10 Nm (80 ~ 100 kg.cm, 6 ~ 7 lb.ft)



G00334862

Fig. 116: Installing Cylinder Head Cover


Courtesy of HYUNDAI MOTOR CO.

10. Install the spark plug cables, ignition coil assembly and cylinder head center cover.
11. Install the timing belt and then tighten the timing belt tensioner pulley.
12. Install the timing belt cover.

Tightening torque

Timing belt cover: 8 ~ 10Nm (80 ~ 100 kg.cm, 6 ~ 7 lb.ft)

CRANKSHAFT**COMPONENTS**



TORQUE : Nm (kgf.cm, lbf.ft)

G00334863

Fig. 117: Identifying Crankshaft Components
Courtesy of HYUNDAI MOTOR CO.

DISASSEMBLY

1. Remove the timing belt, front case, flywheel, cylinder head assembly and oil pan.
2. Remove the rear plate and the rear oil seal.
3. Remove the connecting rod caps.
4. Remove the main bearing caps and remove the crankshaft.

5. Remove the crankshaft position sensor wheel.

CAUTION: Mark the main bearing caps to permit reassembly in the original position and direction.

INSPECTION

CRANKSHAFT

1. Check the crankshaft journals and pins for damage, uneven wear, and cracks. Also check oil holes for clogging. Correct or replace any defective part.
2. Inspect the crankshaft journal for taper and out - of - round.

Standard value

Crankshaft journal O.D: 50 mm (1.9685 in.)

Crankshaft pin O.D: 45 mm (1.7717 in.)

Crankshaft journal, pin out-of-roundness and taper:

0.005 mm (0.0002 in.) or less

MAIN BEARINGS AND CONNECTING ROD BEARINGS

Visually inspect each bearing for peeling, melting, seizure, and improper contact. Replace the defective bearings.

OIL SEAL

Check front and rear oil seals for damage or wear. Replace any seal that is defective.

OIL CLEARANCE MEASUREMENT

1. Measure the diameter of the crankshaft journal and pin.
2. Measure the diameter of the crankshaft bore and connecting rod bore.
3. Measure the thickness of the crankshaft bearing and connecting rod bearing.
4. Measure the clearance by the value that subtract the diameter of journal and pin and the thickness of bearing from the diameter of bore.

Connecting rod bearing oil clearance: 0.018 ~ 0.036 mm (0.0007 ~ 0.0014 in.)

Crankshaft main bearing oil clearance NO. 1,2,4,5: 0.022 ~ 0.040 mm (0.0009 ~ 0.0018 in.)

NO.3: 0.028 ~ 0.046 mm (0.0011 ~ 0.0018 in.)


CRANKSHAFT SENSOR WHEEL

1. Remove the sensor wheel.
2. Check the sensor wheel for damage, cracks and wear, and replace if necessary.
3. Check the clearance between the sensor wheel and the crank position sensor with a depth gage.

Standard value

Clearance between sensor wheel and crank position sensor:

0.5 ~ 1.1 mm (0.020 ~ 0.043 in.)



G00334864

Fig. 118: Checking Clearance Between Sensor Wheel & Crank Position Sensor
Courtesy of HYUNDAI MOTOR CO.

NOTE:

1. Measure the depth of the top of sensor wheel tooth and the cylinder block mounting block.
2. Measure the difference between sensor length and depth.
3. Sensor length is the distance between the end of the sensor and the

inner point of the contacting face.

REPLACEMENT

1. Check the cylinder block crankshaft bore size code.




Fig. 119: Check Cylinder Block Crankshaft Bore Size Code
Courtesy of HYUNDAI MOTOR CO.

NOTE: Record the cylinder block crankshaft bore size code letters on cylinder block as shown. Reading order is from left to right with front crankshaft bore size code shown first.


Class	Crankshaft bore diameter	Size code
a	54~54.006mm (2.1259~2.1262in.)	A
b	54.006~54.012mm (2.1262~2.1264in.)	B
c	54.012~54.016mm (2.1264~2.1266in.)	C

G00334866

Fig. 120: Crankshaft Bore Size Table
Courtesy of HYUNDAI MOTOR CO.

2. Check the crankshaft main journal size code.

NOTE: Record the main journal size code letters on the crankshaft balance weight. Reading order is from left to right as shown, with No. 1 main journal size code shown first.



G00334867

Fig. 121: Recording Main Journal Size Code Letters On Crankshaft Balance Weight
Courtesy of HYUNDAI MOTOR CO.

CRANKSHAFT MAIN JOURNAL DIAMETER

Class	Main journal diameter	Size code
I	49.968 ~ 49.962 mm (1.9672 ~ 1.9670 in.)	Λ
II	49.962 ~ 49.956 mm (1.9670 ~ 1.9667 in.)	b
III	49.956 ~ 49.950 mm (1.9667 ~ 1.9665 in.)	c

G00334868

Fig. 122: Crankshaft Main Journal Diameter Table
Courtesy of HYUNDAI MOTOR CO.

MAIN JOURNAL BEARING THICKNESS

Color	Main journal bearing thickness
Yellow	2.002 ~ 2.005 mm (0.0788 ~ 0.0789 in.)
Green	2.005 ~ 2.008 mm (0.0789 ~ 0.0790 in.)
No color	2.008 ~ 2.011 mm (0.0790 ~ 0.0791 in.)
Black	2.011 ~ 2.014 mm (0.0791 ~ 0.0793 in.)
Blue	2.014 ~ 2.017 mm (0.0793 ~ 0.0794 in.)

G00334869

Fig. 123: Main Journal Bearing Thickness (No. 1, 2, 4 & 5) Table
Courtesy of HYUNDAI MOTOR CO.

Color	Main journal bearing thickness
Yellow	1.999 ~ 2.002 mm (0.0787 ~ 0.0788 in.)
Green	2.002 ~ 2.005 mm (0.0788 ~ 0.0789 in.)
No color	2.005 ~ 2.008 mm (0.0788 ~ 0.0790 in.)
Black	2.008 ~ 2.011 mm (0.0790 ~ 0.0791 in.)
Blue	2.011 ~ 2.014 mm (0.0791 ~ 0.0793 in.)

G00334870

Fig. 124: Main Journal Bearing Thickness (No.3) Table
Courtesy of HYUNDAI MOTOR CO.

3. Choose proper main journal bearing in table.

REASSEMBLY

1. Install the upper main bearing inserts in the cylinder block.

When reusing the main bearings, remember to install them by referring to the location marks made at the time of disassembly.

2. Install the crankshaft. Apply engine oil to the journals.
3. Install bearing caps and tighten cap bolts to the specified torque in the following sequence; center, No.2, No.4, front, and rear caps.

Cap bolts should be tightened evenly in 2 to 3 stages before they are tightened to the specified torque. The caps should be installed with the arrow mark directed toward the crank pulley side of engine. Cap numbers must be correct.


Tightening torque

Main bearing cap bolt:

55 ~ 60 Nm (550 ~ 600 kg.cm, 41 ~ 44 lb.ft)

Connecting rod cap bolt:

32 ~ 35 Nm (320 ~ 350 kg.cm, 24 ~ 26 lb.ft)



G00334871


Fig. 125: Installing Main Bearing Caps
Courtesy of HYUNDAI MOTOR CO.

4. Make certain that the crankshaft turns freely and has the proper clearance between the center main bearing thrust flange and the connecting rod big end bearing.

Standard value

Crankshaft end play:


0.05 ~ 0.175 mm (0.0019 ~ 0.0068 in.)



G00334872

Fig. 126: Checking Crankshaft End Play
Courtesy of HYUNDAI MOTOR CO.

5. Install the oil seal in the crankshaft rear oil seal case. Use the Special Tool, Crankshaft Rear Oil Seal Installer (09231 - 21000) as shown. Press fit the oil seal all the way in, being careful not to misalign it.




G00334873

Fig. 127: Installing Crankshaft Oil Seal
Courtesy of HYUNDAI MOTOR CO.

6. Install the rear plate and tighten the bolts.
7. Install the connecting rod caps.
8. Install the **flywheel**, **front case**, **oil pan** and **timing belt**. For further details, refer to the respective chapters.

FLY WHEEL

COMPONENTS



TORQUE : Nm (kg.cm, lb.ft)

G00334874

Fig. 128: Identifying Flywheel Components
Courtesy of HYUNDAI MOTOR CO.

M/T: Manual Transmission Vehicles

A/T: Automatic Transmission Vehicles

DISASSEMBLY

1. Remove the Transmission and clutch.
2. Remove the flywheel.

INSPECTION

1. Check the clutch disc contacting surface of the fly wheel for damage and wear. Replace the flywheel if excessively damaged or worn.
2. Check the clutch disc contacting surface of the flywheel for runout.

Standard value

Flywheel run - out: 0.1 mm (0.0039 in.)

Check the ring gear for damage, cracks, and wear, and replace if necessary.

REASSEMBLY


Install the flywheel assembly and tighten the bolts to the specified torque.

Tightening torque

Flywheel bolt:

120 ~ 130 Nm (1200 ~ 1300 kg.cm, 89 ~ 96 lb.ft)

PISTON**COMPONENTS**



TORQUE : Nm (kgf.cm, lbf.ft)


G00334875

Fig. 129: Identifying Piston Components
Courtesy of HYUNDAI MOTOR CO.

DISASSEMBLY OF CONNECTING ROD CAP

CAUTION: Keep the bearings in order with their corresponding connecting rods (according to cylinder numbers) for proper reassembly.

1. Remove the connecting rod cap bolts, then remove the caps and the big end lower bearing.
2. Push each piston connecting rod assembly toward the top of the cylinder.




G00334876

Fig. 130: Disassembling Connecting Rod Cap
Courtesy of HYUNDAI MOTOR CO.

DISASSEMBLY AND REASSEMBLY OF THE PISTON PIN

1. Using the special tools, disassemble and reassemble the piston and connecting rod.
2. The piston pin is press fit into the rod little end, and the piston floats on the pin.
3. The tool consists of a support fixture with fork inserts, guides, adapters, an installer and a remover. The piston is supported in the support fixture while the pin is being installed or removed. Guides help position the pin as it is installed or removed, while the rod is supported by fork inserts.
4. To remove the pin from the piston, place the piston in the support fixture with the rod resting on the fork inserts. Pass the remove tool through the top of the support fixture and use it to press out the pin.




G00334877

Fig. 131: Removing Pin From Piston
Courtesy of HYUNDAI MOTOR CO.

5. To install a new pin, the proper fork inserts must be in place to support the rod.
6. Position the rod inside the piston. Insert the proper pin guide through one side of the piston and through the rod.

Hand tap the pin guide so it is held by the piston. Insert the new pin into the piston from the other side and set the assembly into the support fixture with the pin guide facing down.

NOTE: The pin guide should be centered on the connecting rod through the piston. If assembled correctly, the pin guide will sit exactly under the center of the hole in the tool's arch, and rest evenly on the fork inserts. If the wrong size pin guide is used, the piston and pin will not line up with the support fixture.




G00334878

Fig. 132: Installing Pin Guide
Courtesy of HYUNDAI MOTOR CO.

7. Insert the installer tool through the hole in the arch of the support fixture and use an hydraulic press to force the piston pin through the rod little end. Continue pressing until the pin guide falls free and the installer tool seats against the top of the arch.

CAUTION: Do not exceed 1250 +/- 500 kg (2765 +/- 1102 lb) of force when the installing tool seats against the top of the arch.



G00334879

Fig. 133: Installing Piston Pin
Courtesy of HYUNDAI MOTOR CO.

INSPECTION**PISTONS AND PISTON PINS**

1. Check each piston for scuffing, scoring, wear and other defects. Replace any piston that is defective.
2. Check each piston ring for breakage, damage and abnormal wear. Replace the defective rings. When the piston requires replacement, its rings should also be replaced.
3. Check that the piston pin fits in the piston pin hole. Replace any piston and pin assembly that is defective. The piston pin must be smoothly pressed by hand into the pin hole (at room temperature).

PISTON RINGS

1. Measure the piston ring side clearance. If the measured value exceeds the service limit, insert a new ring in the ring groove to measure the side clearance. If the clearance still exceeds the service limit, replace the piston and rings together. If it is less than the service limit, replace the piston rings only.

Piston ring side clearance


No.1: 0.04 ~ 0.085 mm (0.0016 ~ 0.0033 in.)

No. 2: 0.04 ~ 0.085 mm (0.0016 ~ 0.0033 in.)

Limit

No. 1: 0.1 mm (0.004 in.)

No. 2: 0.1 mm (0.004 in.)



G00334880

Fig. 134: Measuring Piston Ring Side Clearance
Courtesy of HYUNDAI MOTOR CO.

2. To measure the piston ring end gap, insert a piston ring into the cylinder bore. Position the ring at right angles in the cylinder wall by gently pressing it down with a piston. Measure the gap with a feeler gauge. If the gap exceeds the service limit, replace the piston ring.

Piston ring end gap

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent

[Standard dimensions]

No. 1: 0.15 ~ 0.30 mm (0.0059 ~ 0.012 in.)


No. 2: 0.30 ~ 0.45 mm (0.012 ~ 0.018 in.)

Oil ring side rail: 0.2 ~ 0.7 mm (0.0079 ~ 0.0276 in.)

[Limit]

No. 1, No. 2: 1.0 mm (0.039 in.)

Oil ring side rail: 1.0 mm (0.039 in.)



G00334881

Fig. 135: Measuring Piston Ring End Gap
Courtesy of HYUNDAI MOTOR CO.

When replacing the ring without correcting the cylinder bore, check the gap with the ring situated at the low part of cylinder that is less worn out.

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent

Standard	None
0.25 mm (0.010 in.) O.S	25

G00334882

Fig. 136: Piston Ring Service Size & Mark Table
Courtesy of HYUNDAI MOTOR CO.


NOTE: The mark can be found on the upper side of the ring next to the end.

CONNECTING RODS

1. When the connecting rod cap is installed, make sure that the cylinder numbers, marked on rod end cap at disassembly, match.

When a new connecting rod is installed, make sure that the notches holding the bearing in place are on the same side.

2. Replace the connecting rod if it is damaged at either end of the thrust faces. If it has a stratified wear in, or if the surface of the inside diameter of the small end is severely rough, replace the rod.




G00334883

Fig. 137: Inspecting Connecting Rods
Courtesy of HYUNDAI MOTOR CO.

REPLACEMENT

1. Check the cylinder bore size code on the cylinder block bottom face.



G00334884


Fig. 138: Check Cylinder Bore Size Code On Cylinder Block Bottom Face
 Courtesy of HYUNDAI MOTOR CO.

Class	Cylinder bore inner diameter	Size code
A	76.5~76.51mm (3.0118~3.0121in.)	A
B	76.51~76.52mm (3.0121~3.0126in.)	B
C	76.52~76.53mm (3.0126~3.0129in.)	C

G00334885

Fig. 139: Cylinder Bore Inner Diameter Table
Courtesy of HYUNDAI MOTOR CO.

2. Check the piston size code on the piston top face.



G00334886

Fig. 140: Check Piston Size Code On Piston Top Face
Courtesy of HYUNDAI MOTOR CO.

NOTE: Stamp the grade mark of basic diameter with rubber stamp.

Class	Piston outer diameter	Size code
A	76.465~76.475mm (3.0104~3.0108in.)	A
B	76.475~76.485mm (3.0108~3.0112in.)	B
C	76.485~76.495mm (3.0112~3.0116in.)	C

G00334887

Fig. 141: Piston Outer Diameter Table
 Courtesy of HYUNDAI MOTOR CO.



3. Select the piston related to cylinder bore class.

Oil clearance

0.025 ~ 0.045mm (0.00098 ~ 0.00177in.)

REASSEMBLY

1. Install the spacer.




G00334888

Fig. 142: Installing Spacer & Side Rail
Courtesy of HYUNDAI MOTOR CO.

2. Install the upper side rail. To install the side rail, first put one end of the side rail between the piston ring groove and spacer, hold it firmly, and press down with a finger on the portion to be inserted into the groove (as illustrated).

CAUTION: Do not use a piston ring expander when installing side rail.


3. Install the lower side rail by the same procedure described in Step 2.



G00334889

Fig. 143: Installing Lower Side Rail
Courtesy of HYUNDAI MOTOR CO.


4. Apply engine oil around the piston and piston grooves.
5. Using a piston ring expander, install the No. 2 piston ring.
6. Install the No. 1 piston ring.



G00334890

Fig. 144: Installing Piston Ring
Courtesy of HYUNDAI MOTOR CO.

7. Position each piston ring end gap as far away from its neighboring gaps as possible. Make sure that the gaps are not positioned in the thrust and pin directions.
8. Hold the piston rings firmly with a piston ring compressor as they are inserted into cylinder.



G00334891

Fig. 145: Identifying Ring Gaps
Courtesy of HYUNDAI MOTOR CO.

9. Install the upper main bearings in the cylinder block.
10. Install the lower main bearings in the main bearing caps.
11. Make sure that the front mark of the piston and the front mark (identification mark) of the connecting rod are directed toward the front of the engine.
12. When a new connecting rod is installed, make sure that the notches for holding the bearing in place are on the same side.
13. When assembling, bolts should be fastened by the angle - torque controlled method as the following.
 1. Apply oil to the thread of nuts and spot areas.
 2. Tighten the connecting rod bolt.

Tightening torque

Connecting rod cap nut:

32 ~ 35 Nm (320 ~ 350 kg.cm, 24 . 26 lb.ft)

CAUTION: After removing the connecting rod bolt, do not use it again.


When using a new bolt, do not tighten the bolt more than 3 times.

14. Check the connecting rod side clearance.

Connecting rod side clearance

Standard: 0.10 ~ 0.25 mm (0.0039 ~ 0.0098 in.)

Limit: 0.4 mm (0.0157 in.)



G00334892


Fig. 146: Checking Connecting Rod Side Clearance
Courtesy of HYUNDAI MOTOR CO.

15. Install the oil screen.
16. Install the oil pan.
17. Install the cylinder head.

LUBRICATION SYSTEM

OIL PUMP

COMPONENTS




TORQUE : Nm (kgf.cm, lbf.ft)

G00334910

Fig. 147: Identifying Lubrication System Components
Courtesy of HYUNDAI MOTOR CO.

DISASSEMBLY


1. Remove the timing belt.
2. Remove all the oil pan bolts.
3. Remove the oil pan.
4. Remove the oil screen.
5. Remove the front case assembly.



G00334911

Fig. 148: Removing Front Case Assembly
Courtesy of HYUNDAI MOTOR CO.

6. Remove the oil pump cover.



G00334912

Fig. 149: Removing Oil Pump Cover
Courtesy of HYUNDAI MOTOR CO.

7. Remove the inner and outer gears from the front case. The matching marks on the inner and outer gears indicate the direction of installation.

INSPECTION

FRONT CASE

1. Check the front case for cracks or damage. Replace as necessary.
2. Check the front oil seal for worn or damaged lips. Replace if defective.

OIL PAN AND OIL SCREEN

1. Check the oil pan for failure, damage or cracks. Replace if defective.
2. Check the oil screen for failure, damage and cracks and replace if defective.

FRONT CASE AND OIL PUMP COVER

Check the surfaces contacting the gears for damage or wear.

OIL PUMP GEARS

1. Check the gear tooth surfaces for wear or damage.
2. Measure the clearance between outer gear and front case.


Body clearance: 0.12 ~ 0.185 mm (0.0047 ~ 0.0073 in.)

Tip clearance: 0.025 ~ 0.069 mm (0.0010 ~ 0.0027 in.)

Side clearance

Inner gear: 0.06 ~ 0.11 mm (0.0023 ~ 0.0043 in.)


Outer gear: 0.04 ~ 0.085 mm (0.0016 ~ 0.0033 in.)



G00334913

Fig. 150: Measuring Clearance Between Outer Gear & Front Case
Courtesy of HYUNDAI MOTOR CO.

3. Check the tip clearance on the pump rotor.



G00334914

Fig. 151: Checking Tip Clearance On Pump Rotor
Courtesy of HYUNDAI MOTOR CO.

RELIEF VALVE AND SPRING

1. Check sliding condition of the relief valve inserted in the front case.
2. Inspect for distorted or broken relief valve spring.


Standard value

Free height: 46.6 mm (1.8346 in.)

Load: 6.1 kg/40.1 mm (13.42 lb/1.578 in.)

OIL PRESSURE SWITCH


1. Use an ohmmeter to check the continuity between the terminal and the body. If there is no continuity, replace the oil pressure switch.



G00334915

Fig. 152: Checking Oil Pressure Switch
Courtesy of HYUNDAI MOTOR CO.

2. Check the continuity between the terminal and the body when the fine wire is pushed. If there is continuity even when the fine wire is pushed, replace the switch.



G00334916

Fig. 153: Testing Oil Pressure Switch
Courtesy of HYUNDAI MOTOR CO.

3. If there is no continuity when a 50 kPa (7 psi) vacuum is applied through the oil hole, the switch is operating properly.

Check for air leaks. If air does leak, the diaphragm is broken. Replace the switch.

REASSEMBLY

OIL PUMP


1. Install the outer and inner gears into the front case. Make sure that the inner and outer gears are installed in the same direction as shown.

2. Install the oil pump cover and tighten the bolts to the specified torque. After the bolts have been tightened, check to ensure that the gear turns smoothly.

Tightening torque

Oil pump cover bolt :

8~ 12 Nm (80 ~ 120 kg.cm, 6 ~ 9 lb.ft)




G00334917

Fig. 154: Installing Oil Pump Cover
Courtesy of HYUNDAI MOTOR CO.

3. Install the relief valve and spring. Tighten the plug to the specified torque. Apply engine oil to the relief valve.

Relief valve plug

40 ~ 50 Nm (400 ~ 500 kg.cm, 30 ~ 37 lb.ft)



G00334918

Fig. 155: Installing Relief Valve & Spring
Courtesy of HYUNDAI MOTOR CO.

FRONT CASE

1. Install the front case assembly with a new gasket, and tighten the bolts to the specified torque.

Tightening torque

20 ~ 27 Nm (200 ~ 270 kg.cm, 15 ~ 20 lb.ft)


Length

A : 30 mm (1.18 in.)

B : 45 mm (1.77 in.)

C : 60 mm (2.36 in.)

D : 22 mm (0.89 in.)




G00334919

Fig. 156: Installing Front Case Assembly
Courtesy of HYUNDAI MOTOR CO.

OIL SEAL

1. Using the special tool, Crankshaft oil seal guide(09231-22100), install the oil seal.
2. Using the special tool, Crankshaft front oil seal installer (09231-22000), install the oil seal.




G00334920

Fig. 157: Installing Crankshaft Front Oil Seal
Courtesy of HYUNDAI MOTOR CO.

3. Install the oil screen.
4. Clean both gasket surfaces of the oil pan and the cylinder block.
5. Apply sealant into the groove of the oil pan flange as shown.

CAUTION:

- Apply sealant approx. 4mm (0.16 in.) in thickness.
- After application of sealant, do not exceed 15 minutes before installing the oil pan.



G00334921

Fig. 158: Applying Sealant Into Groove Of Oil Pan Flange
Courtesy of HYUNDAI MOTOR CO.

6. Install the oil pan and tighten the bolts to the specified torque.


Tightening torque

Oil pan bolt : 10 ~ 12 Nm (100 ~ 120 kg.cm, 7 ~ 9 lb.ft)

ENGINE BLOCK

ENGINE BLOCK

COMPONENTS




TORQUE : Nm (kgf.cm, lbf.ft)

G00334922

Fig. 159: Identifying Engine Block Components
Courtesy of HYUNDAI MOTOR CO.

DISASSEMBLY

1. Remove the timing belt, cylinder head, front case, flywheel, pistons and crankshaft.
2. Remove the oil pressure switch.



G00334923


Fig. 160: Removing Oil Pressure Switch
Courtesy of HYUNDAI MOTOR CO.

INSPECTION

1. Check the engine block for scores, rust and corrosion. Also check for cracks or any other defects. Replace the block if defective.
2. Using a straight edge and feeler gauge, check the top surface of the block for warpage. Make sure that the surface is free from gasket chips or other foreign material.

Standard : 0.03 mm (0.0012 in.) or less

Limit : 0.06 mm (0.0024 in.) or less




G00334924

Fig. 161: Checking Top Surface Of Block For Warpage
Courtesy of HYUNDAI MOTOR CO.

3. Measure the cylinder bore with a cylinder gauge at three levels in the direction of A and B. If the cylinder bores show more than the specified out-of-round or taper or if the cylinder walls are badly scuffed or scored, the cylinder block should be rebored and honed. Oversize pistons and rings must be fitted.

Cylinder I.D: 76.5 ~ 76.53 mm (3.0118 ~ 3.0130 in.)

Cylinder I.D taper : 0.01 mm (0.0004 in.) or less



G00334925

Fig. 162: Checking Cylinder Bores For Out-Of-Round Or Taper
Courtesy of HYUNDAI MOTOR CO.

4. If a cylinder ridge exists, cut away with a ridge reamer.
5. Oversize pistons are available in four sizes.

Piston service size and mark mm (in.)


0.25 (0.010) O.S. : 0.25

6. When boring the cylinder to the oversize, maintain the specified clearance between the oversize piston and the bore, and make sure that all pistons used are the same oversize.

The standard measurement of the piston's outside diameter is taken 39.35 mm (1.55 in.) from the top land of the piston.

Piston - to - cylinder clearance

0.025 ~ 0.045 mm (0.0010 ~ 0.0018 in.)



G00334926


Fig. 163: Measuring Piston Outside Diameter
Courtesy of HYUNDAI MOTOR CO.

ENGINE MOUNTS

COMPONENTS

2004 Hyundai Accent

2004 ENGINES 1.6L 4-Cylinder - Accent




TORQUE : Nm (kg-cm, lb-ft)

G00334927

Fig. 164: Identifying Engine Mounts & Components
Courtesy of HYUNDAI MOTOR CO.

REMOVAL

Attach an engine hoist to the engine hooks, and raise the engine just enough so that there is no pressure on the insulators.




G00334928

Fig. 165: Lifting Engine With Hoist
Courtesy of HYUNDAI MOTOR CO.

ENGINE MOUNTING

Remove the engine mounting support bracket from the engine.




G00334929

Fig. 166: Removing Engine Mounting Support Bracket From Engine
Courtesy of HYUNDAI MOTOR CO.

TRANSMISSION MOUNTING


1. Remove the air cleaner.



G00334930

Fig. 167: Removing Air Cleaner
Courtesy of HYUNDAI MOTOR CO.


2. Remove the transmission mounting bolt. (17 mm)



G00334931

Fig. 168: Removing Transmission Mounting Bolt
Courtesy of HYUNDAI MOTOR CO.

3. Detach the cap from inside the right fender shield. Remove the transmission mounting bolts. (14 mm)




G00334932

Fig. 169: Detaching Cap From Inside Right Fender Shield
Courtesy of HYUNDAI MOTOR CO.

4. Remove the transmission bracket.

FRONT ROLL STOPPER BRACKET

Remove the roll rod bracket from the cross member.




G00334933

Fig. 170: Removing Roll Rod Bracket From Cross Member
Courtesy of HYUNDAI MOTOR CO.

REAR ROLL STOPPER BRACKET

Remove the rear roll stopper bracket from the sub frame.




G00334934

Fig. 171: Removing Rear Roll Stopper Bracket From Sub Frame
Courtesy of HYUNDAI MOTOR CO.

INTAKE AND EXHAUST SYSTEM

EXHAUST MANIFOLD

COMPONENTS




TORQUE : Nm (kgf.cm, lbf.ft)

G00334935

Fig. 172: Identifying Exhaust System Components
Courtesy of HYUNDAI MOTOR CO.

DISASSEMBLY

1. Disconnect the oxygen sensor connect.



G00334936

Fig. 173: Locating Oxygen Sensor Connector
Courtesy of HYUNDAI MOTOR CO.

2. Remove the exhaust manifold heat protector.
3. Remove the exhaust manifold assembly from the cylinder head.
4. Remove the exhaust manifold gasket.

INSPECTION

EXHAUST MANIFOLD

1. Check for damage or cracking.
2. Check for damage or cracking of welding between exhaust manifold and converter.


REASSEMBLY

Install the exhaust manifold in the reverse order of removal.

CAUTION: Replace the exhaust manifold gasket and lock nut when reassembling.

INTAKE MANIFOLD

COMPONENTS




TORQUE : Nm (kg.cm, lb.ft)

G00334937

Fig. 174: Identifying Intake Manifold Components
Courtesy of HYUNDAI MOTOR CO.

REMOVAL


1. Disconnect the MAP, ISA and TPS connect.



G00334938

Fig. 175: Disconnecting MAP, ISA & TPS connectors
Courtesy of HYUNDAI MOTOR CO.


2. Remove the intake air hose connected to the throttle body.
3. Remove the accelerator cable.
4. Remove the PCV hose and brake booster vacuum hoses.



G00334939

Fig. 176: Removing PCV Hose & Brake Booster Vacuum Hoses
Courtesy of HYUNDAI MOTOR CO.


5. Disconnect the coolant hose connections front the throttle body.



G00334940

Fig. 177: Disconnecting Coolant Hose Connections Front Throttle Body
Courtesy of HYUNDAI MOTOR CO.


6. Disconnect the fuel injector harness connector.



G00334941

Fig. 178: Disconnecting Fuel Injector Harness Connector
Courtesy of HYUNDAI MOTOR CO.


7. Remove the delivery pipe with the fuel injectors.



G00334942

Fig. 179: Removing Delivery Pipe With Fuel Injectors
Courtesy of HYUNDAI MOTOR CO.

8. Remove the intake manifold stay.



G00334943

Fig. 180: Removing Intake Manifold Stay
Courtesy of HYUNDAI MOTOR CO.

9. Remove the intake manifold.
10. Remove the intake manifold assembly and gasket.

INSPECTION

INTAKE MANIFOLD

Check the parts for damage or cracking.


AIR HOSE

Check for damage or cracking of any part.

INSTALLATION

1. Replace the intake manifold gasket and install the intake manifold.
2. Install the intake manifold stay.
3. Install the delivery pipe with the fuel injectors.

CAUTION: Be careful not to drop the injectors when removing the delivery pipe.




G00334944

Fig. 181: Installing Delivery Pipe With Fuel Injectors
Courtesy of HYUNDAI MOTOR CO.

4. Connect the fuel injector harness connector.
5. Install the P.C.V. hose and brake booster vacuum hose.
6. Install the intake air hose to the throttle body.
7. Install the accelerator cable.
8. Connect the ISA and TPS wire harness connector.

MUFFLER

COMPONENTS



G00334945


Fig. 182: Identifying Muffler Components
Courtesy of HYUNDAI MOTOR CO.

REMOVAL

REAR MUFFLER

CAUTION: Before removing or inspecting the exhaust system, ensure that the exhaust system is cool.

1. Disconnect the rear muffler from the center muffler.
2. Remove the rubber hangers and remove the rear muffler.




G00334946

Fig. 183: Removing Rubber Hangers
Courtesy of HYUNDAI MOTOR CO.

CENTER MUFFLER

1. Remove the center muffler assembly from the rear muffler and front exhaust pipe.
2. Remove the rubber hanger, then remove the center muffler.




G00334947

Fig. 184: Removing Center Muffler Assembly From Rear Muffler & Front Exhaust Pipe
Courtesy of HYUNDAI MOTOR CO.

FRONT EXHAUST PIPE

1. Remove the front exhaust pipe clamp bolts, and remove the front exhaust pipe nuts from the catalytic converter.
2. Remove the front exhaust pipe and center muffler bolt.



G00334948


Fig. 185: Removing Front Exhaust Pipe & Center Muffler Bolt
Courtesy of HYUNDAI MOTOR CO.

INSTALLATION

1. Temporarily install the front exhaust pipe, the center exhaust pipe, and the rear muffler, in that order.
2. Tighten the parts securely. Make sure there is no interference with any body components.

AIR CLEANER (ACL)

COMPONENTS




TORQUE : Nm (kg.cm, lb.ft)

G00334949

Fig. 186: Identifying Air Cleaner Components
 Courtesy of HYUNDAI MOTOR CO.

REMOVAL

1. Remove the air duct connected to the air cleaner.
2. Remove the air intake hose at the air cleaner side.
3. Remove the air cleaner cover and filter.
4. Remove the air cleaner mounting bolts and remove the air cleaner.




G00334950

Fig. 187: Removing Air Cleaner Mounting Bolts & Air Cleaner
Courtesy of HYUNDAI MOTOR CO.

INSPECTION

1. Check the air cleaner body, cover or filter for distortion, corrosion or damage.
2. Check the air duct for damage.


3. Check the resonator for distortion or damage.



G00334951

Fig. 188: Checking Resonator For Distortion Or Damage
Courtesy of HYUNDAI MOTOR CO.

4. Check the air cleaner filter for restriction, contamination or damage. If the filter is slightly restricted, remove the dust and other contaminants by blowing compressed air from the upper side through the filter.



G00334952

Fig. 189: Removing Dust & Other Contaminants By Blowing Compressed Air From Upper Side Through Filter

Courtesy of HYUNDAI MOTOR CO.

5. Check the air cleaner housing for restrictions, contamination or damage.

INSTALLATION

Install the air cleaner assembly following the reverse order of removal.