


2005 ENGINE**Engine Mechanical - Grand Vitara & XL-7****GENERAL DESCRIPTION****ENGINE GENERAL INFORMATION**

The engine is a water-cooled, 60° V6 cylinders, 4 stroke cycle gasoline unit with its DOHC (Double overhead camshaft) valve mechanism arranged for "V" type valve configuration. The double overhead camshaft is mounted over the cylinder head; it is driven from crankshaft through timing chains, and no push rods are provided in the valve train system.



IYSQ01143001

Fig. 1: Identifying Engine

Courtesy of SUZUKI OF AMERICA CORP.

AIR CLEANER ELEMENT INTRODUCTION


This air cleaner element is of dry type. Note that it needs cleaning referring to "**AIR CLEANER ELEMENT INSPECTION AND CLEANING**".

DIAGNOSTIC INFORMATION AND PROCEDURES

COMPRESSION CHECK

Check compression pressure on all 6 cylinders as follows:

1. Warm up engine.
2. Stop engine after warming up.
3. Remove ignition coil covers and disconnect ignition coil harness couplers.
4. Remove all ignition coils (1) and spark plugs (2) referring to "SPARK PLUG REMOVAL AND INSTALLATION".



IYSQ01143002

Fig. 2: Removing Ignition Coils And Spark Plug
Courtesy of SUZUKI OF AMERICA CORP.


5. Remove surge tank cover.
6. Disconnect fuel injector wire harness at connector.
7. Install special tool (Compression gauge) into spark plug hole.

Special tool

(A): 09915-64510

(B): 09915-64530

(C): 09915-67010



IYSQ01143003

Fig. 3: Installing Special Tool (Compression Gauge) Into Spark Plug Hole
Courtesy of SUZUKI OF AMERICA CORP.

8. Disengage clutch (to lighten starting load on engine) for M/T vehicle, and depress accelerator pedal all the way to make throttle fully open.




Fig. 4: Depressing Accelerator Pedal All Way To Make Throttle Fully Open
Courtesy of SUZUKI OF AMERICA CORP.

9. Crank engine with fully charged battery, and read the highest pressure on compression gauge.

NOTE: For measuring compression pressure, crank engine at least 250 rpm by using fully charged battery.

Compression pressure

Standard: 1400 - 1600 kPa (14.0 - 16.0 kg/cm² , 199.0 - 227.5 psi)

Limit: 1300 kPa (13.0 kg/cm² , 185.0 psi)

Max. difference between any two cylinders: 100 kPa (1.0 kg/cm² ,14.2 psi)

10. Carry out steps 7), 8) and 9) on each cylinder to obtain 6 readings.

ENGINE VACUUM CHECK

The engine vacuum that develops in the intake line is a good indicator of the condition of the engine. The vacuum checking procedure is as follows:

1. Warm up engine to normal operating temperature and make sure that engine idle speed is within

specification.

2. Stop engine and disconnect vacuum hoses from fuel pressure regulator valve (1).
3. Connect special tools (Vacuum gauge and hose joint) and 3-way joint between vacuum hose and valve.


Special tool

(A): 09915-67311

(B): 09918-08210

(C): 09355-35754-600 (Hose, SUZUKI genuine parts)

(D): 09367-04002 (3-way joint, SUZUKI genuine parts)



14JA01140028

Fig. 5: Connecting Vacuum Gauge And Hose Joint And 3-Way Joint Between Vacuum Hose And Valve

Courtesy of SUZUKI OF AMERICA CORP.

4. Start engine and run engine at specified idle speed, and read vacuum gauge. Vacuum should be within specification.

Vacuum specifications (sea level)

59 - 79 kPa (450 - 600 mmHg, 17.7 - 23.7 in.Hg) at specified idle speed



5. After checking, remove, all special tools.
6. Connect vacuum hoses to fuel pressure regulator valve.

REPAIR INSTRUCTIONS

AIR CLEANER ELEMENT REMOVAL AND INSTALLATION

Removal

1. Remove air cleaner upper case (1).



I5JA01140001

[A]: H25 engine

[B]: H27 engine

Fig. 6: Removing Air Cleaner Upper Case
Courtesy of SUZUKI OF AMERICA CORP.

2. Remove air cleaner element.

Installation


1. Install element to air cleaner box.
2. Install air cleaner upper case.

AIR CLEANER ELEMENT INSPECTION AND CLEANING**Inspection**

Check element for dirt. Replace if element is excessively dirty.

Cleaning

When cleaning element, blow off dust by blowing compressed air from air outlet side of element (i.e., the side facing up when installed in air cleaner case).



IYSQ01143009

Fig. 7: Cleaning Air Cleaner Element
Courtesy of SUZUKI OF AMERICA CORP.

ACCELERATOR CABLE ADJUSTMENT

1. Warm up engine to normal operating temperature.

2. For H25 engine, check to make sure that fast idle control cam is off cam follower lever. If not, check fast idle control system referring to "**THROTTLE BODY REMOVAL AND INSTALLATION (H25 ENGINE)**".
3. With throttle valve closed, check accelerator pedal play "a" which should be within the following specification.

If measured value is out of specification, adjust accelerator cable (1) so as pedal play to be within specification with cable adjusting nut (2). Then tighten lock nut (3).

Accelerator pedal play

"a": 2 - 5 mm (0.08 - 0.20 in.)






Fig. 8: Adjusting Accelerator Cable Play
Courtesy of SUZUKI OF AMERICA CORP.

4. With accelerator pedal depressed fully, check clearance between throttle lever (2) and lever stopper (1) (throttle body) which should be within the following specification.

If measured value is out of specification, adjust it to specification by changing height of pedal stopper bolt (3).

Clearance between throttle lever and lever stopper (throttle body) (with accelerator pedal depressed fully)

"b": 0.5 - 2.0 mm (0.02 - 0.08 in.)



I5JA01140003

[A]: H25 engine

[B]: H27 engine

Fig. 9: Checking Clearance Between Throttle Lever And Lever Stopper With Accelerator Pedal Depressing
Courtesy of SUZUKI OF AMERICA CORP.


A/T THROTTLE CABLE ADJUSTMENT (H25 ENGINE WITH A/T ONLY)

1. Make sure that accelerator cable is adjusted as specified.
2. With throttle valve closed, check clearance "c" which should be within the following specification.

If it is out of specification, adjust A/T throttle cable (1) by turning cable adjusting nut (2).

A/T throttle cable adjustment clearance

"c": 0.8 - 1.5 mm (0.03 - 0.06 in.)



IYSQ01143174

Fig. 10: Checking A/T Throttle Cable Adjustment Clearance
Courtesy of SUZUKI OF AMERICA CORP.

THROTTLE BODY COMPONENTS





Fig. 11: Identifying Throttle Body Components
 Courtesy of SUZUKI OF AMERICA CORP.

THROTTLE BODY ON-VEHICLE INSPECTION

1. Check that throttle valve lever moves smoothly.
2. For H25 engine model, perform the following checks.
 - a. Measure plunger (1) protrusion "a" of fast idle control arm (2) at engine coolant temperature is 25 °C (77 °F).

Plunger protrusion

"a": 26.6 - 27.4 mm (1.047 - 1.079 in.)




IYSQ01143176

Fig. 12: Measuring Plunger Protrusion "a" Of Fast Idle Control Arm
Courtesy of SUZUKI OF AMERICA CORP.

- b. Warm up engine and check to make sure that fast control cam is off cam follower lever (1) at engine coolant temp, is 52 - 68 °C (126 - 154 °F).

If check result in Step a) or b) is out of specification, replace throttle body assembly.




IYSQ01143177

Fig. 13: Checking Fast Control Cam Is Off Cam Follower Lever
Courtesy of SUZUKI OF AMERICA CORP.

THROTTLE BODY REMOVAL AND INSTALLATION (H25 ENGINE)

Removal

1. Disconnect negative cable (-) at battery.
2. Drain engine coolant referring to "COOLANT DRAINING".
3. Detach fuse/relay box.
4. Remove strut tower bar.
5. Disconnect accelerator cable (1) and A/T throttle cable (2) (for A/T model) from throttle body.
6. Disconnect water hose (3) from throttle body.




IYSQ01143014

Fig. 14: Disconnecting Accelerator Cable And A/T Throttle Cable (For A/T Model) From Throttle Body

Courtesy of SUZUKI OF AMERICA CORP.


7. Remove surge tank cover.
8. Remove intake air pipe (1) and surge tank pipe (2).



IYSQ01143178

Fig. 15: Removing Intake Air Pipe And Surge Tank Pipe
Courtesy of SUZUKI OF AMERICA CORP.

9. Disconnect connector of injector wire.
10. Disconnect connectors of TP sensor (2), MAF sensor (1) and IAC valve (3).
11. Disconnect ground terminal (6) from intake manifold (5).
12. Remove clamp bracket (4) from intake collector.



IYSQ01143179

Fig. 16: Disconnecting Connectors Of TP Sensor, MAF Sensor And IAC Valve
Courtesy of SUZUKI OF AMERICA CORP.

13. Disconnect connectors of EVAP canister purge valve (1) and EGR valve (5).
14. Disconnect PCV hose (6), breather hose (3) and EVAP canister purge valve hose (2).
15. Remove EGR pipe (4) from exhaust manifold.





Fig. 17: Disconnecting PCV Hose, Breather Hose And EVAP Canister Purge Valve Hose
Courtesy of SUZUKI OF AMERICA CORP.

16. Remove throttle body (3) and intake collector (2) from intake manifold (1).
17. Disconnect hoses of IAC valve and PCV from throttle body.
18. Remove throttle body from intake collector.

NOTE:

- MAF sensor (4), TP sensor (5), or other components containing rubber must not be placed in a solvent or cleaner bath. A chemical reaction will cause these parts to swell, harden or get distorted.
- Don't put drills or wires into passages for cleaning. It causes damages in passages.




IYSQ01143181

Fig. 18: Removing Throttle Body From Intake Collector
Courtesy of SUZUKI OF AMERICA CORP.

Installation

1. Clean mating surfaces and install new throttle body gasket (2) to intake collector (1).




IYSQ01143182

Fig. 19: Installing Throttle Body Gasket
Courtesy of SUZUKI OF AMERICA CORP.

2. Install throttle body to intake collector and tighten bolts and nuts.
3. Connect IAC valve hose and PCV hose.
4. Install throttle body and intake collector to intake manifold with new intake collector gaskets.
5. Install EGR pipe with new gaskets.
6. Connect PCV hose, breather hose and EVAP canister purge valve hose.
7. Connect connectors of EVAP canister purge valve and EGR valve. Fix wire harness with clamps.
8. Install clamp bracket to intake collector.
9. Connect ground terminal to intake manifold.
10. Connect connectors of TP sensor, MAF sensor and IAC valve.
11. Connect connector of injector wire.
12. Install surge tank pipe to intake manifold with new gaskets and intake air pipe to throttle body.
13. Install surge tank cover.
14. Connect water hoses to throttle body.
15. Connect accelerator cable and A/T throttle cable (for A/T model).
16. Install strut tower bar (1) and tighten strut tower bar mounting bolts (2) to specified torque.

Tightening torque

Strut tower bar mounting bolts (a): 50 N.m (5.0 kg-m, 36.5 lb-ft)




I3JA01140011

Fig. 20: Installing Strut Tower Bar Mounting Bolts
Courtesy of SUZUKI OF AMERICA CORP.

17. Install fuse/relay box.
18. Refill cooling system referring to "**COOLING SYSTEM FLUSH AND REFILL**".
19. Connect negative (-) cable at battery.
20. Adjust accelerator cable and A/T throttle cable (for A/ T model) referring to "**ACCELERATOR CABLE ADJUSTMENT**" and to "**A/T THROTTLE CABLE ADJUSTMENT (H25 ENGINE WITH A/T ONLY)**".

THROTTLE BODY REMOVAL AND INSTALLATION (H27 ENGINE)**Removal**


1. Disconnect negative (-) cable at battery.
2. Drain engine coolant referring to "**COOLANT DRAINING**".
3. Detach fuse/relay box.
4. Remove strut tower bar.
5. Disconnect accelerator cable (1) from throttle body.



I4JA01140003

Fig. 21: Disconnecting Accelerator Cable From Throttle Body
Courtesy of SUZUKI OF AMERICA CORP.


6. Disconnect water hoses (2) from throttle body.



I4JA01140004

Fig. 22: Disconnecting Water Hoses From Throttle Body
Courtesy of SUZUKI OF AMERICA CORP.


7. Remove surge tank cover.
8. Remove intake air pipe (1), surge tank pipe (2) and intake control valve (3).



I4JA01140005

Fig. 23: Disconnecting Ground Terminal From Intake Manifold
Courtesy of SUZUKI OF AMERICA CORP.


9. Disconnect connectors of TP sensor (2) and IAC valve (3).
10. Disconnect ground terminal (5) from intake manifold (4).
11. Remove clamp bracket (1) and harness clamps from intake collector.



I3JA01140012

Fig. 24: Removing Clamp Bracket And Harness Clamps From Intake Collector
Courtesy of SUZUKI OF AMERICA CORP.

12. Disconnect connectors of EVAP canister purge valve (1) and EGR valve (5).
13. Disconnect PCV valve hose (6), ground terminal connector (7) and breather hose (3) from cylinder head and EVAP canister purge valve hose (2).
14. Detach EGR pipe (4) from exhaust manifold.



I4JA01140006


Fig. 25: Detaching EGR Pipe From Exhaust Manifold

Courtesy of SUZUKI OF AMERICA CORP.

15. Remove throttle body (3) and intake collector (2) from intake manifold (1).
16. Disconnect hoses of PCV from throttle body.
17. Remove throttle body from intake collector.

CAUTION:

- TP sensor (4), or other components containing rubber must not be placed in a solvent or cleaner bath. A chemical reaction will cause these parts to swell, harden or get distorted.
- Don't put drills or wires into passages for cleaning. It causes damages in passages.



I4JA01140007

Fig. 26: Removing Throttle Body From Intake Collector
Courtesy of SUZUKI OF AMERICA CORP.

Installation

1. Clean mating surfaces and install new throttle body gasket (2) to intake collector (1).




Fig. 27: Installing Throttle Body Gasket To Intake Collector
 Courtesy of SUZUKI OF AMERICA CORP.


2. Install throttle body to intake collector and tighten bolts and nuts.
3. Connect PCV hose to throttle body.
4. Install throttle body and intake collector to intake manifold with new intake collector gaskets.
5. Install EGR pipe with new gaskets.
6. Connect breather hose, EVAP canister purge valve hose and PCV valve hose.
7. Connect connectors of EVAP canister purge valve and EGR valve.

Fix wire harness with clamps.

8. Install clamp bracket to intake collector.
9. Connect ground wire connector.
10. Connect connectors of TP sensor and IAC valve.
11. Install surge tank pipe and intake control valve to intake manifold with new gaskets and intake air pipe to throttle body. Install surge tank cover.
12. Connect water hoses to throttle body.
13. Connect accelerator cable.
14. Install strut tower bar (1) and tighten strut tower bar mounting bolts (2) to specification.

Tightening torque

Strut tower bar mounting bolts (a): 50 N.m (5.0 kg-m, 36.5 lb-ft)



I3JA01140011

Fig. 28: Installing Strut Tower Bar Mounting Bolts
Courtesy of SUZUKI OF AMERICA CORP.

15. Install fuse/relay box.
16. Refill cooling system referring to "**COOLING SYSTEM FLUSH AND REFILL**".
17. Connect negative (-) cable at battery.
18. Adjust accelerator cable referring to "**ACCELERATOR CABLE ADJUSTMENT**".


THROTTLE BODY CLEANING

CAUTION:

- Do not blow compressed air through bypass air passage with IAC valve installed to throttle body. This will cause IAC valve to malfunction.
- TP sensor, idle air control valve or other components containing rubber must not be placed in a solvent or cleaner bath.

A chemical reaction will cause these parts to swell, harden or get distorted.

Clean throttle body bore and bypass air passages (1) by blowing compressed air.



I4JA01140009

Fig. 29: Cleaning Throttle Body Bore And Bypass Air Passages By Blowing Compressed Air
Courtesy of SUZUKI OF AMERICA CORP.

INTAKE CONTROL VALVE REMOVAL AND INSTALLATION FOR H27 ENGINE

Refer to "**THROTTLE BODY REMOVAL AND INSTALLATION (H27 ENGINE)**".

INTAKE CONTROL VALVE INSPECTION FOR H27 ENGINE

1. Connect special tool (A) to intake control valve (1).

Special tool

(A): 09917-47011




Fig. 30: Connecting Special Tool To Intake Control Valve
Courtesy of SUZUKI OF AMERICA CORP.

2. Apply vacuum to intake control valve (1) and verify that throttle (2) fully closes within the specified range. If intake control valve (1) fails the check, replace it.


CAUTION: Do not apply above 88 kPa of negative pressure. Damage may occur to intake control valve (1).

Valve operation pressure

1.3-34 kPa (9.8 - 255 mmHg)

3. Let the throttle (2) close for 15 seconds with no vacuum application and inspect throttle travel. If throttle travel decreases, replace intake air valve (1).

THROTTLE BODY AND INTAKE MANIFOLD COMPONENTS



14JA01140011

[A]: For H25 engine	3. Intake air pipe	7. Intake manifold gasket	11. Gasket	15. Throttle body nut
[B]: For H27 engine	4. Surge tank pipe	8. Throttle body assembly	12. IAT sensor	16. Throttle body bolt
1. Air cleaner box	5. Gasket	9. Throttle body gasket	13. MAF sensor	17. Intake control valve
2. Intake air hose	6. Intake manifold	10. Intake collector	14. MAP sensor	⊗ : Do not reuse.

Fig. 31: Exploded View Of Throttle Body And Intake Manifold Components
Courtesy of SUZUKI OF AMERICA CORP.


THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H25 ENGINE)

Removal

1. Release fuel pressure in fuel feed line by referring to "**FUEL PRESSURE RELIEF PROCEDURE**".

CAUTION: This work must not be done when engine is hot. If done so, it may cause adverse effect to catalyst.


2. Disconnect negative (-) cable at battery.
3. Drain coolant referring to "**COOLANT DRAINING**".
4. Detach fuse/relay box and remove strut tower bar.
5. Disconnect coupler from IAT sensor.
6. Remove surge tank cover (1).



IYSQ01143012

Fig. 32: Removing Surge Tank Cover
Courtesy of SUZUKI OF AMERICA CORP.

7. Remove air cleaner upper case, intake air hose, intake air pipe (1) and surge tank pipe (2) as one component. Do not disassemble them, when removing and reinstalling.




IYSQ01143013

Fig. 33: Removing Intake Air Pipe

Courtesy of SUZUKI OF AMERICA CORP.


8. Disconnect accelerator cable (1) and A/T throttle cable (for A/T model) (2) from throttle body.
9. Disconnect water hose (3) from throttle body.



IYSQ01143014

Fig. 34: Disconnecting Water Hose From Throttle Body
Courtesy of SUZUKI OF AMERICA CORP.


10. Disconnect injector wire (1) coupler.
11. Disconnect brake booster hose (2) and fuel pressure regulator vacuum hose (3) from intake manifold.



I4JA01140012

Fig. 35: Disconnecting Brake Booster Hose
Courtesy of SUZUKI OF AMERICA CORP.


12. Disconnect couplers of TP sensor (1), MAF sensor (2) and IAC valve (3).
13. Disconnect earth terminal (4) from intake collector.
14. Remove clamp bracket (5) from intake collector.



IYSQ01143016

Fig. 36: Disconnecting Couplers Of TP Sensor, MAF Sensor And IAC Valve
Courtesy of SUZUKI OF AMERICA CORP.

15. Disconnect couplers from MAP sensor, EVAP canister purge valve (1) and EGR valve (2).
16. Disconnect PCV hose (6) from cylinder head cover.
17. Disconnect breather hoses (8) from throttle body or cylinder head cover.
18. Disconnect EVAP canister purge valve hose (4), heater hose (5) and water hose (7).
19. Remove EGR pipe (3).




IYSQ01143017

Fig. 37: Removing EGR Pipe

Courtesy of SUZUKI OF AMERICA CORP.


20. Disconnect heater hose (1), EVAP canister hose (4), tank pressure control solenoid valve hose (5), fuel feed hose (2) and fuel return hose (3).



IYSQ01143018

Fig. 38: Disconnecting Heater Hose, EVAP Canister Hose, Tank Pressure Control Solenoid Valve Hose, Fuel Feed Hose And Fuel Return Hose
Courtesy of SUZUKI OF AMERICA CORP.


21. Remove throttle body (1) and intake collector (2) from intake manifold (3).



IYSQ01143019

Fig. 39: Removing Throttle Body And Intake Collector From Intake Manifold
Courtesy of SUZUKI OF AMERICA CORP.

22. Disconnect IAC valve hose (1) and EVAP canister purge valve hose from intake collector.
23. Remove throttle body (2) from intake collector.




IYSQ01143020

Fig. 40: Disconnecting IAC Valve Hose And EVAP Canister Purge Valve Hose From Intake Collector

Courtesy of SUZUKI OF AMERICA CORP.

24. Remove IAC valve, EGR valve and EVAP canister purge valve from intake collector.
25. Remove intake manifold bolts (8 pc.) and nuts (4 pc.).
26. Remove intake manifold.




IYSQ01143021

Fig. 41: Removing Intake Manifold Bolts And Nuts
Courtesy of SUZUKI OF AMERICA CORP.

Installation

1. Install new intake manifold gaskets (1) to cylinder heads.



IYSQ01143022

Fig. 42: Installing Intake Manifold Gaskets To Cylinder Heads
Courtesy of SUZUKI OF AMERICA CORP.

2. Install intake manifold and tighten bolts and nuts.




Fig. 43: Installing Intake Manifold And Bolts And Nuts
 Courtesy of SUZUKI OF AMERICA CORP.

3. Install throttle body (2) to intake collector (1) with new throttle body gasket.





Fig. 44: Installing Throttle Body To Intake Collector With Throttle Body Gasket

Courtesy of SUZUKI OF AMERICA CORP.

4. Install IAC valve (1), EGR valve (2), EVAP canister purge valve (3), MAP sensor, clamps and each hoses to intake collector and throttle body if removed.

NOTE: Use new gasket, when installing IAC valve and EGR valve.




IYSQ01143025

4. EVAP canister purge valve hose
5. IAC valve hose
6. Clamp

Fig. 45: Installing IAC Valve, EGR Valve, EVAP Canister Purge Valve, MAP Sensor, Clamps And Hoses To Intake Collector And Throttle Body
Courtesy of SUZUKI OF AMERICA CORP.


5. Install throttle body and intake collector assembly to intake manifold with new intake collector gaskets.
6. Connect heater hose (1), EVAP canister hose (4), tank pressure control solenoid valve hose (5), fuel feed hose (2) and fuel return hose (3).



IYSQ01143018

Fig. 46: Connecting Heater Hose, EVAP Canister Hose, Tank Pressure Control Solenoid Valve Hose, Fuel Feed Hose And Fuel Return Hose
Courtesy of SUZUKI OF AMERICA CORP.


7. Install EGR pipe (3) with new gaskets.
8. Connect EVAP canister purge valve hose (4) and heater hose (5).
9. Connect PCV hose (6), breather hose (8) and water hose (7).
10. Connect couplers of MAP sensor, EVAP canister purge valve (1) and EGR valve (2). Fix wire harness with clamps.



IYSQ01143017

Fig. 47: Connecting Couplers Of MAP Sensor, EVAP Canister Purge Valve And EGR Valve
Courtesy of SUZUKI OF AMERICA CORP.


11. Install clamp bracket (5) to intake collector.
12. Connect earth terminal (4) to intake collector.
13. Connect TP sensor coupler (1), MAF sensor coupler (2) and IAC valve coupler (3).



IYSQ01143016

Fig. 48: Connecting TP Sensor Coupler, MAF Sensor Coupler And IAC Valve Coupler
Courtesy of SUZUKI OF AMERICA CORP.


14. Connect brake booster hose (2) and fuel pressure regulator vacuum hose (3) to intake manifold.
15. Connect injector wire (1) coupler.



I4JA01140012

Fig. 49: Connecting Injector Wire Coupler
Courtesy of SUZUKI OF AMERICA CORP.


16. Connect water hoses (3) to throttle body.
17. Connect accelerator cable (1) and A/T throttle cable (for A/T model) (2) to throttle body, and adjust these cables referring to "**ACCELERATOR CABLE ADJUSTMENT**" and to "**A/T THROTTLE CABLE ADJUSTMENT (H25 ENGINE WITH A/T ONLY)**".



IYSQ01143014

Fig. 50: Connecting Water Hoses To Throttle Body
Courtesy of SUZUKI OF AMERICA CORP.


18. Install surge tank pipe (2) to intake manifold with new gaskets and intake air pipe (1) to throttle body.



IYSQ01143013

Fig. 51: Installing Surge Tank Pipe To Intake Manifold
Courtesy of SUZUKI OF AMERICA CORP.

19. Install surge tank cover (1).




IYSQ01143012

Fig. 52: Installing Surge Tank Cover
Courtesy of SUZUKI OF AMERICA CORP.

20. Install air cleaner upper case referring to "**AIR CLEANER ELEMENT REMOVAL AND INSTALLATION**".
21. Connect coupler to intake air temperature sensor.
22. Install strut tower bar (1) and tighten strut tower bar mounting bolts (2) to specification.

Tightening torque

Strut tower bar mounting bolts (a): 50 N.m (5.0 kg-m, 36.5 lb-ft)



I3JA01140013

Fig. 53: Installing Strut Tower Bar And Tighten Strut Tower Bar Mounting Bolts
Courtesy of SUZUKI OF AMERICA CORP.

23. Install fuse/relay box.
24. Check to ensure that all removed parts are back in place.


Reinstall any necessary parts which have not been reinstalled.

25. Refill cooling system referring to "**COOLING SYSTEM FLUSH AND REFILL**".
26. Connect negative (-) cable at battery.
27. Upon completion of installation, verify that there is no fuel leakage at each connection according to procedure described in "**FUEL LEAKAGE CHECK PROCEDURE**".

THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H27 ENGINE)

Removal


1. Release fuel pressure in fuel feed line by referring to "**FUEL PRESSURE RELIEF PROCEDURE**".
2. Disconnect negative (-) cable at battery.
3. Drain coolant referring to "**COOLANT DRAINING**".
4. Detach fuse/relay box and remove strut tower bar (2).
5. Disconnect coupler from IAT sensor and MAF sensor.
6. Remove surge tank cover (1).



I4JA01140013

Fig. 54: Removing Surge Tank Cover**Courtesy of SUZUKI OF AMERICA CORP.**


7. Remove air cleaner upper case, MAF sensor, intake air hose, intake air pipe (1) and surge tank pipe (2) as one component. Do not disassemble them, when removing and reinstalling.
8. Remove intake control valve (3).



I4JA01140014

Fig. 55: Removing Intake Control Valve
Courtesy of SUZUKI OF AMERICA CORP.


9. Disconnect accelerator cable (1) from throttle body.
10. Disconnect water hoses (2) from throttle body.



I4JA01140015

Fig. 56: Disconnecting Water Hoses From Throttle Body
Courtesy of SUZUKI OF AMERICA CORP.


11. Disconnect injector wire (1) coupler.
12. Disconnect brake booster hose (2), fuel pressure regulator vacuum hose (4) and intake control valve hose (3) from intake manifold.



I4JA01140016

Fig. 57: Disconnecting Brake Booster Hose, Fuel Pressure Regulator Vacuum Hose And Intake Control Valve Hose From Intake Manifold
 Courtesy of SUZUKI OF AMERICA CORP.

13. Disconnect couplers of TP sensor (1) and IAC valve (2).
14. Disconnect earth terminal (3) from intake collector.
15. Remove clamp bracket (4) from intake collector.



I1JA01140006

Fig. 58: Disconnecting Couplers Of TP Sensor And IAC Valve
Courtesy of SUZUKI OF AMERICA CORP.

16. Disconnect couplers from MAP sensor, EVAP canister purge valve (1), earth terminal (9) and EGR valve (2).
17. Disconnect PCV hose (6) from cylinder head cover.
18. Disconnect breather hoses (8) from throttle body or cylinder head cover.
19. Disconnect EVAP canister purge valve hose (4), heater hose (5) and water hose (7).
20. Remove EGR pipe (3) and wire harness clamps.





Fig. 59: Disconnecting Couplers From MAP Sensor, EVAP Canister Purge Valve, Earth Terminal And EGR Valve
Courtesy of SUZUKI OF AMERICA CORP.


21. Disconnect hoses of heater (1), EVAP canister purge (4), fuel feed (2) and fuel return (3).



I1JA01140008

Fig. 60: Disconnecting Hoses Of Heater, EVAP Canister Purge, Fuel Feed And Fuel Return
Courtesy of SUZUKI OF AMERICA CORP.

22. Remove throttle body (1) and intake collector (2) from intake manifold (3).



I1JA01140009

Fig. 61: Removing Throttle Body And Intake Collector From Intake Manifold
Courtesy of SUZUKI OF AMERICA CORP.

23. Disconnect hoses of PCV valve and EVAP canister purge valve from intake collector.
24. Remove throttle body (1) from intake collector.





Fig. 62: Removing Throttle Body From Intake Collector
Courtesy of SUZUKI OF AMERICA CORP.

25. Remove IAC valve from throttle body.
26. Remove EGR valve and EVAP canister purge valve from intake collector.
27. Remove intake manifold bolts (8 pcs.) and nuts (4 pcs.).




I1JA01140011

Fig. 63: Removing Intake Manifold Bolts And Nuts
Courtesy of SUZUKI OF AMERICA CORP.

28. Remove intake manifold.

Installation


1. Install new intake manifold gaskets (1) to cylinder heads.



IYSQ01143022

Fig. 64: Installing Intake Manifold Gaskets To Cylinder Heads
Courtesy of SUZUKI OF AMERICA CORP.


2. Install intake manifold (1), and tighten bolts (2) and nuts (3).



I4JA01140017

Fig. 65: Installing Intake Manifold Bolts And Nuts
Courtesy of SUZUKI OF AMERICA CORP.

3. Install throttle body (2) to intake collector (1) with new throttle body gasket.




I4JA01140018

Fig. 66: Installing Throttle Body To Intake Collector With Throttle Body Gasket
Courtesy of SUZUKI OF AMERICA CORP.

4. Install IAC valve, EGR valve (1), EVAP canister purge valve (2), MAP sensor and each hoses to intake collector and throttle body if removed.

NOTE: Use new gasket when installing IAC valve and EGR valve.




I1JA01140014

3. EVAP canister purge valve hose

Fig. 67: Installing IAC Valve, EGR Valve, EVAP Canister Purge Valve, MAP Sensor And Hoses To Intake Collector And Throttle Body
Courtesy of SUZUKI OF AMERICA CORP.

5. Install throttle body and intake collector assembly to intake manifold with new intake collector gaskets.
6. Connect hoses of heater (1), EVAP canister (4), fuel feed (2) and fuel return (3).



I1JA01140008

Fig. 68: Connecting Hoses Of Heater, EVAP Canister, Fuel Feed And Fuel Return
Courtesy of SUZUKI OF AMERICA CORP.

7. Install EGR pipe (3) with new gaskets.
8. Connect hoses of EVAP canister purge valve (4) and heater (5).
9. Connect hoses of PCV (6), breather (8) and water (7).
10. Connect couplers of manifold absolute pressure (MAP) sensor, EVAP canister purge valve (1), EGR valve (2) and earth terminal (9).

Fix wire harness with clamps.





Fig. 69: Connecting Couplers Of Manifold Absolute Pressure (MAP) Sensor, EVAP Canister Purge Valve, EGR Valve And Earth Terminal
Courtesy of SUZUKI OF AMERICA CORP.


11. Install clamp bracket (4) to intake collector.
12. Connect earth terminal (3) to intake collector.
13. Connect couplers of TP sensor (1) and IAC valve (2).



I1JA01140006

Fig. 70: Connecting Couplers Of TP Sensor And IAC Valve
Courtesy of SUZUKI OF AMERICA CORP.


14. Connect brake booster hose (2), fuel pressure regulator vacuum hose (4) and intake control valve hose (3) to intake manifold.
15. Connect injector wire (1) coupler.



I4JA01140019

Fig. 71: Connecting Brake Booster Hose, Fuel Pressure Regulator Vacuum Hose And Intake Control Valve Hose To Intake Manifold
Courtesy of SUZUKI OF AMERICA CORP.


16. Connect water hoses (2) to throttle body.



I4JA01140020

Fig. 72: Connecting Water Hoses To Throttle Body
Courtesy of SUZUKI OF AMERICA CORP.


17. Connect accelerator cable (1) to throttle body.
18. Install surge tank pipe (2) and intake control valve (3) to intake manifold with new gaskets and intake air pipe (1) to throttle body.



I4JA01140021

Fig. 73: Installing Surge Tank Pipe And Intake Control Valve To Intake Manifold With Gaskets
Courtesy of SUZUKI OF AMERICA CORP.

19. Install surge tank cover (1).




I4JA01140022

Fig. 74: Installing Surge Tank Cover
Courtesy of SUZUKI OF AMERICA CORP.

20. Install air cleaner upper case.
21. Connect coupler to intake air temp. sensor and MAF sensor.
22. Install strut tower bar (1) and tighten strut tower bar mounting bolts (2) to specification.

Tightening torque

Strut tower bar mounting bolts (a): 50 N.m (5.0 kg-m, 36.5 lb-ft)



I3JA01140013

Fig. 75: Installing Strut Tower Bar Mounting Bolts
Courtesy of SUZUKI OF AMERICA CORP.

23. Install fuse/relay box.
24. Check to ensure that all removed parts are back in place.

Reinstall any necessary parts which have not been reinstalled.

25. Refill cooling system referring to "**COOLING SYSTEM FLUSH AND REFILL**".
26. Connect negative cable (-) at battery.
27. Upon completion of installation, verify that there is no fuel leakage at each connection according to "**FUEL LEAKAGE CHECK PROCEDURE**".

CYLINDER HEAD COVERS REMOVAL AND INSTALLATION

Removal


1. Remove throttle body and intake manifold.

For H25 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H25 ENGINE)**".

For H27 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H27 ENGINE)**".

2. Remove ignition coil covers.

3. Disconnect ignition coil couplers and remove ignition coils referring to "**IGNITION COIL ASSEMBLY (IGNITER AND IGNITION COIL) REMOVAL AND INSTALLATION**".
4. Remove cylinder head covers (1).



I3JA01140031


2. Nut
3 Seal washer
4. Cylinder head cover gasket

Fig. 76: Removing Cylinder Head Covers
Courtesy of SUZUKI OF AMERICA CORP.

Installation

1. Clean sealing surfaces on cylinder heads and covers.
2. Remove oil, old sealant, and dust from sealing surfaces. After cleaning, apply sealant "A" to cylinder heads sealing surface area as shown in the figure.

"A": Water tight sealant 99000-31250



I5JA01140004


[A]: Left (No.1) cylinder
[B]: Right (No.2) cylinder

Fig. 77: Applying Sealant "a" To Cylinder Heads Sealing Surface Area
Courtesy of SUZUKI OF AMERICA CORP.

3. Install new cylinder head cover gaskets (4) to head covers (1).
4. Install cylinder head covers (1) to cylinder heads.
5. Using new seal washers (3), tighten nuts (2) to specified torque.

Tightening torque

Cylinder head cover nut (a): 10.5 N.m (1.1 kg-m, 7.5 lb-ft)



I3JA01140032


Fig. 78: Installing Seal Washers And Nuts
Courtesy of SUZUKI OF AMERICA CORP.

6. Install ignition coils and connect ignition coil couplers referring to "**IGNITION COIL ASSEMBLY (IGNITER AND IGNITION COIL) REMOVAL AND INSTALLATION**".
7. Install ignition coil covers.
8. Install intake manifold with throttle body.

For H25 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H25 ENGINE)**".

For H27 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H27 ENGINE)**".

TIMING CHAIN COVER COMPONENTS



I3JA01140033

1. Timing chain cover	7. Timing chain cover bolt
2. Crankshaft pulley	8. CKP sensor bolt
3. Crankshaft pulley bolt	: Tightening torque
4. Oil seal	: Do not reuse
5. O-ring	Apply engine oil
6. CKP sensor	

Fig. 79: Identifying Timing Chain Cover Components
 Courtesy of SUZUKI OF AMERICA CORP.

TIMING CHAIN COVER REMOVAL AND INSTALLATION

Removal

1. Disconnect negative (-) cable at battery.
2. Drain engine oil.
3. Drain coolant referring to "**COOLANT DRAINING**".
4. Remove throttle body and intake manifold.


For H25 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H25 ENGINE)**".

For H27 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H27 ENGINE)**".

5. Remove cylinder head covers. Refer to "CYLINDER HEAD COVERS REMOVAL AND INSTALLATION".
6. Remove P/S pump (A/C compressor) drive belt. Refer to "P/S PUMP DRIVE BELT INSPECTION AND ADJUSTMENT".
7. Remove cooling fan, fan clutch and water pump pulley. Refer to "COOLING FAN AND FAN CLUTCH REMOVAL AND INSTALLATION".
8. Remove radiator. Refer to "RADIATOR REMOVAL AND INSTALLATION".
9. Remove thermostat cap. Refer to "THERMOSTAT REMOVAL AND INSTALLATION".
10. Remove P/S pump and P/S pump bracket. Refer to "P/S PUMP REMOVAL AND INSTALLATION".
11. Raise vehicle.
12. Remove oil pan. Refer to "OIL PAN AND OIL PUMP STRAINER REMOVAL AND INSTALLATION".
13. Remove crankshaft pulley bolt (1). To lock crankshaft pulley, use special tool (camshaft pulley holder) as shown in the figure.

Special tool

(A): 09917-68221




IYSQ01143031

2. Bolt

3. Wrench

Fig. 80: Removing Crankshaft Pulley Bolt To Lock Crankshaft Pulley Using Special Tool
Courtesy of SUZUKI OF AMERICA CORP.

NOTE: Be sure to use the following bolt for fixing special tool to crankshaft pulley.
Bolt size: M8, P1.25 L=45 mm
Strength: 7T



IYSQ01143032

Fig. 81: Identifying Length Of Crankshaft Pulley Bolt
Courtesy of SUZUKI OF AMERICA CORP.

14. Remove crankshaft pulley (1).


If it is hard to remove, use special tools (Steering wheel remover, Bearing puller attachment) as shown in the figure.

If bolts of steering wheel remover are too long, replace them with those of suitable length.

Special tool

(B): 09944-36011

(C): 09926-58010



IYSQ01143033


Fig. 82: Removing Crankshaft Pulley Using Special Tool
Courtesy of SUZUKI OF AMERICA CORP.

15. Disconnect CKP sensor connector and remove CKP sensor if necessary.
16. Remove timing chain cover.

Installation

Reverse removal sequence to install timing chain cover noting the following points.

- Clean sealing surface on timing chain cover, crankcase, cylinder block and cylinder heads. Remove oil, old sealant, and dust from sealing surface.




IYSQ01143034

Fig. 83: Identifying Timing Chain
Courtesy of SUZUKI OF AMERICA CORP.

- Apply sealant "A" to timing chain cover sealing surface area as shown in the figure.

"A": Water tight sealant 99000-31250





I4JA01140023

"a": 3 mm (0.12 in)	1. Timing chain cover
"b": 2 mm (0.08 in)	2. Sealant "A"

Fig. 84: Identifying Timing Chain Cover Sealing Surface Area Applying Sealant
Courtesy of SUZUKI OF AMERICA CORP.

- Apply sealant "B" to mating surfaces of cylinder head and cylinder block as shown.

"B": Water tight sealant 99000-31140



I5JA01140005


[A]: View A	"a": 7 mm (0.28 in.)
1. Cylinder head	"b": 67 mm (2.64 in.)
2. Cylinder block	"c": 17 mm (0.67 in.)
3. Cylinder head gasket	"d": 18 mm (0.71 in)
4. Rub into	"e": 10 mm (0.39 in.)
5. Jig	"f": 34 mm (1.34 in.)
	"g": 50 mm (1.97 in)

Fig. 85: Identifying Mating Surfaces Of Cylinder Head And Cylinder Block Applying Sealant
 Courtesy of SUZUKI OF AMERICA CORP.

- Apply engine oil to new oil seal lip and water pump O-ring. Using special tool (bearing installer), install new oil seal (2) with its surface is flush with edge of timing chain cover (1).

Special tool

(D): 09913-75510



IYSQ01143037

Fig. 86: Installing Oil Seal Lip And Water Pump O-Ring Using Special Tool
Courtesy of SUZUKI OF AMERICA CORP.

- Install timing chain cover.

Tightening torque

Timing chain cover bolt: 11 N.m (1.1 kg-m, 8.0 lb-ft)

- Apply engine oil to O-ring of CKP sensor and install CKP sensor (4) to timing chain cover.

Tightening torque

CKP sensor bolt (b): 6 N.m (0.6 kg-m, 4.5 lb-ft)

- Install crankshaft pulley (1).


To lock crankshaft pulley, use special tool (camshaft pulley holder) with it at shown in the figure.

Special tool

(A): 09917-68221

Tightening torque

Crankshaft pulley bolt (a): 150 N.m (15 kg-m, 108.5 lb-ft)



I5JA01140006

2. Bolt

3. Wrench

Fig. 87: Installing Crankshaft Pulley Using Special Tool
Courtesy of SUZUKI OF AMERICA CORP.

NOTE: Be sure to use the following bolt for fixing special tool to crank pulley.
Bolt size: M8, P1.25 L=45 mm
Strength: 7T



**IYSQ01143032**

Fig. 88: Identifying Length Of Bolt
Courtesy of SUZUKI OF AMERICA CORP.

TIMING CHAIN COVER INSPECTION

Check oil seal lip for damages or deterioration. Replace as necessary.

LH (NO.1) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER COMPONENTS




I4JA01140030

1. LH bank 2nd timing chain	6. Timing chain guide No.4	11. Timing chain guide No. 4 bolt
2. Timing chain tensioner adjuster No.3	7. Timing chain guide No.5	: Apply engine oil to sliding surface of each point.
3. LH bank intake camshaft sprocket	8. Idler sprocket No.2	: Tightening torque
4. LH bank exhaust camshaft sprocket	9. Timing chain tensioner adjuster No. 3 bolt : Tighten 11 N-m (1.1 kg-m, 8.0 lb-ft) by the specified procedure	
5 Camshaft sprocket bolt	10. Timing chain tensioner adjuster No. 3 nut : Tighten 45 N-m (4.5 kg-m, 32.5 lb-ft) by the specified procedure	

Fig. 89: Identifying Bank 2nd Timing Chain And Chain Tensioner Components
Courtesy of SUZUKI OF AMERICA CORP.

LH (NO.1) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER REMOVAL


1. Disconnect negative (-) cable at battery.
2. Drain engine oil.
3. Drain coolant referring to "**COOLANT DRAINING**".
4. Remove timing chain cover. Refer to "**TIMING CHAIN COVER REMOVAL AND INSTALLATION**".
5. Turn crankshaft to meet the following condition.
 - Key (1) on crankshaft positions as shown.
 - Arrow mark on idler sprocket No.2 (2) points the center of crankshaft.
 - The marks on sprockets (3) match with marks on cylinder head.



IYSQ01143039

Fig. 90: Identifying Timing Chain And Match Marks
Courtesy of SUZUKI OF AMERICA CORP.

6. Remove timing chain tensioner adjuster No.3 (1). To remove it, slacken LH bank 2nd timing chain by turning intake camshaft (2) counterclockwise a little while pushing back pad.




IYSQ01143040

Fig. 91: Identifying Timing Chain Tensioner Adjuster And Intake Camshaft
Courtesy of SUZUKI OF AMERICA CORP.

7. Remove LH bank intake and exhaust camshaft sprocket bolts.

To remove it, fit a spanner to hexagonal part (3) at the center of camshaft to hold it stationary.




IYSQ01143041

- | |
|--------------------------------------|
| 1. LH bank intake camshaft sprocket |
| 2. LH bank exhaust camshaft sprocket |

Fig. 92: Removing LH Bank Intake And Exhaust Camshaft Sprocket Bolts
Courtesy of SUZUKI OF AMERICA CORP.

8. Remove LH bank exhaust camshaft sprocket (1).

CAUTION: Removing sprocket (1) from camshaft (2) may cause cam to turn, resulting in damage to valve and piston. To prevent this, when removing sprocket, hold camshaft stationary by using a spanner at its hexagonal part.



IYSQ01143042


Fig. 93: Removing Sprocket From Camshaft
Courtesy of SUZUKI OF AMERICA CORP.

9. Remove LH bank intake camshaft sprocket.
10. Remove LH bank 2nd timing chain.

LH (NO.1) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER INSPECTION

Timing Chain Guide No.4 and No.5

Check shoe (3) for wear or damage.



IYSQ01143043


1. Timing chain guide No.4

2. Timing chain guide No.5

Fig. 94: Checking Shoe For Wear Or Damage
Courtesy of SUZUKI OF AMERICA CORP.

Camshaft Sprocket

Check teeth of sprocket for wear or damage.




IYSQ01143044

Fig. 95: Checking Teeth Of Sprocket For Wear Or Damage
Courtesy of SUZUKI OF AMERICA CORP.

Timing Chain

Check timing chain for wear or damage.




IYSQ01143045

Fig. 96: Checking Timing Chain For Wear Or Damage
Courtesy of SUZUKI OF AMERICA CORP.

Tensioner Adjuster No.3


- Check shoe (1) for wear or damage.



IYSQ01143046

Fig. 97: Checking Shoe For Wear Or Damage
Courtesy of SUZUKI OF AMERICA CORP.

- Check that latch (1) and tooth surface (2) are free from damage and latch functions properly.




IYSQ01143047

Fig. 98: Checking Latch And Tooth Surface
Courtesy of SUZUKI OF AMERICA CORP.

LH (NO.1) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER INSTALLATION

1. Check timing mark on crankshaft as shown in the figure.




IYSQ01143048

1. Crank timing pulley key

2. Oil jet

Fig. 99: Checking Timing Mark On Crankshaft
Courtesy of SUZUKI OF AMERICA CORP.

2. Check timing mark on idler sprocket No.2 (1) as shown in the figure.



IYSQ01143049

2. Match mark of idler sprocket No.2


3. Crankshaft

Fig. 100: Checking Timing Mark On Idler Sprocket
Courtesy of SUZUKI OF AMERICA CORP.

3. Install timing chain guide No.4 (1).

Tightening torque

Timing chain guide No.4 bolt (a): 11 N.m (1.1 kg-m, 8.0 lb-ft)




IYSQ01143050

2. Bolts

Fig. 101: Installing Timing Chain Guide
Courtesy of SUZUKI OF AMERICA CORP.

4. Check that knock-pins of intake and exhaust camshafts are aligned with match marks on cylinder head as shown in the figure.




IYSQ01143051

1. Knock pin of LH bank intake camshaft	3. Match mark of intake side
2. Knock pin of LH bank exhaust camshaft	4. Match mark of exhaust side

Fig. 102: Checking Knock-Pins Of Intake And Exhaust Camshafts Aligned With Match Marks On Cylinder Head

Courtesy of SUZUKI OF AMERICA CORP.

5. Install by aligning match marks (2) on yellow plate (1) of LH bank 2nd timing chain and idler sprocket No.2.



IYSQ01143052

Fig. 103: Aligning Match Marks On Yellow Plate Of LH Bank 2nd Timing Chain And Idler Sprocket

Courtesy of SUZUKI OF AMERICA CORP.

6. Install sprockets to intake and exhaust camshafts by aligning silver plate (1) of LH bank 2nd timing chain, match marks on intake sprocket and exhaust sprocket respectively.


CAUTION: Do not turn camshaft more than necessary. If turned excessively, valve and piston may get damaged.

7. Install LH bank intake and exhaust camshaft timing sprockets.

To install it, fit a spanner to hexagonal part at the center of camshaft to hold stationary.

Tightening torque

Camshaft timing sprocket bolt (b): 80 N.m (8.0 kg-m, 58.0 lb-ft)




2.	Arrow mark on intake camshaft timing sprocket
3.	Arrow mark on exhaust camshaft timing sprocket
4.	Sprocket bolt

Fig. 104: Aligning Silver Plate Of LH Bank 2nd Timing Chain, Match Marks On Intake Sprocket And Exhaust Sprocket

Courtesy of SUZUKI OF AMERICA CORP.

8. With latch (2) of tensioner adjuster No.3 returned and plunger (1) pushed back into body, insert stopper (pin) (4) into set hole (3).

After inserting it, check to make sure that plunger will not come out.



IYSQ01143054

Fig. 105: Inserting Stopper (Pin) Into Set Hole
Courtesy of SUZUKI OF AMERICA CORP.

9. Install timing chain tensioner adjuster No.3 (1) in tightening order below.

Tightening torque

Timing chain tensioner adjuster No.3 bolt (c):

Tighten 11 N m (1.1 kg-m, 7.5 lb-ft) by the specified procedure


Timing chain tensioner adjuster No.3 nut (d):

Tighten 55 N m (5.5 kg-m, 40.0 lb-ft) by the specified procedure

Tightening order for tensioner bolt and nuts

"1" --> "2" --> "3"


10. Pull out stopper (pin) (2) from set hole.



IYSQ01143055

Fig. 106: Pulling Out Stopper (Pin) From Set Hole
Courtesy of SUZUKI OF AMERICA CORP.

11. Turn crankshaft two rotations clockwise then align timing mark on crankshaft and timing mark on cylinder block as shown in figure. Check each other timing marks that align them shown in the figure.



IYSQ01143056

1. Crank timing pulley key	5. Timing mark of LH bank 2nd timing chain intake sprocket	9. Timing mark of RH bank 2nd timing chain intake sprocket
2. Oil jet	6. Timing mark of LH bank 2nd timing chain	10. Timing mark of RH bank 2nd timing chain exhaust sprocket
3. Timing mark of RH bank 1st timing chain sprocket	7. Timing mark of LH bank 2nd timing chain exhaust sprocket	
4. Timing mark of RH bank 1st timing chain	8. Timing mark of LH bank 2nd timing chain	

Fig. 107: Aligning Timing Mark On Crankshaft And Timing Mark On Cylinder Block
Courtesy of SUZUKI OF AMERICA CORP.


12. Apply oil to timing chains, tensioner adjusters sprockets and guides.
13. Install timing chain cover referring to "**TIMING CHAIN COVER REMOVAL AND INSTALLATION**".
14. Install oil pan referring to "**OIL PAN AND OIL PUMP STRAINER REMOVAL AND INSTALLATION**".
15. Install front differential referring to "**FRONT DIFFERENTIAL DISMOUNTING AND REMOUNTING**" and "**FRONT DIFFERENTIAL DISMOUNTING AND REMOUNTING**".
16. Install P/S system referring to "**P/S PUMP REMOVAL AND INSTALLATION**".
17. Install cooling system referring to "**COOLING FAN AND FAN CLUTCH REMOVAL AND INSTALLATION**" and "**RADIATOR REMOVAL AND INSTALLATION**".
18. Install intake manifold with throttle body.

For H25 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H25 ENGINE)**".

For H27 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H27 ENGINE)**".

19. Refill coolant referring to "**COOLING SYSTEM FLUSH AND REFILL**".
20. Refill engine oil referring to "**ENGINE OIL AND FILTER CHANGE**".
21. Refill P/S fluid and bleed air in P/S system referring to "**P/S SYSTEM AIR BLEEDING PROCEDURE**".
22. Check wheel alignment referring to "**FRONT ALIGNMENT INSPECTION AND ADJUSTMENT**".
23. Verify that there is no fuel leakage, water leakage and oil leakage at each connection.

1ST TIMING CHAIN AND CHAIN TENSIONER COMPONENTS



I3JA01140039


1. 1st timing chain	8. Shaft	15. Timing chain tensioner nut
2. Timing chain tensioner adjuster No.1	9. Washer	16. Idler sprocket No.1 bolt
3. RH bank 1st timing chain intake camshaft sprocket	10. Timing chain tensioner	17. Timing tensioner adjuster No.1 bolt
4. 1st timing chain crankshaft sprocket	11. Timing chain guide No.1	18. Timing chain guide No.1 bolt
5. Idler sprocket No.2	12. Timing chain guide No.2	19. Timing chain guide No.2 bolt
6. Shaft	13. Camshaft sprocket bolt	⌘ : Tightening torque
7. Idler sprocket No.1	14. Spacer	⌘ : Apply engine oil to sliding parts.

Fig. 108: Identifying 1st Timing Chain And Chain Tensioner Components
Courtesy of SUZUKI OF AMERICA CORP.

1ST TIMING CHAIN AND CHAIN TENSIONER REMOVAL

1. Disconnect negative cable at battery.
2. Drain engine oil.

3. Drain coolant referring to "COOLANT DRAINING".
4. Remove timing chain cover. Refer to "TIMING CHAIN COVER REMOVAL AND INSTALLATION".
5. For reinstallation of timing chain, align 8 timing marks as shown in the figure by turning crankshaft.




IYSQ01143058

Fig. 109: Locating Timing Marks

Courtesy of SUZUKI OF AMERICA CORP.

6. Remove LH bank 2nd timing chain. Refer to "LH (NO.1) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER REMOVAL".
7. Remove the following parts referring to "1ST TIMING CHAIN AND CHAIN TENSIONER COMPONENTS".
 - Timing chain guide No.1 and No.2.
 - Timing chain tensioner.
 - Timing chain tensioner adjuster.

- Idler sprocket No.1 and 1st timing chain.
 - Idler sprocket No.2 and sprocket shaft.
8. Remove RH bank 1st timing chain intake camshaft sprocket bolt. To remove it, fit a spanner to hexagonal part (3) at the center of camshaft (2) to hold it stationary.
 9. Remove RH bank 1 st timing chain intake camshaft sprocket (1).



IYSQ01143059


Fig. 110: Removing RH Bank 1st Timing Chain Intake Camshaft Sprocket Bolt
Courtesy of SUZUKI OF AMERICA CORP.

10. Remove 1st timing chain crankshaft sprocket.

1ST TIMING CHAIN AND CHAIN TENSIONER INSPECTION

Timing Chain Guides No.1 and No.2

Check shoe for excessive wear or damage. If any malfunction is found, replace it.



IYSQ01143060

1. Timing chain guide No.1
2. Timing chain guide No.2

Fig. 111: Checking Shoe For Excessive Wear Or Damage
Courtesy of SUZUKI OF AMERICA CORP.

Timing Chain Tensioner

Check shoe (1) for wear or damage.

If any malfunction is found, replace it.




IYSQ01143061

Fig. 112: Checking Shoe For Wear Or Damage
Courtesy of SUZUKI OF AMERICA CORP.

1st Timing Chain Crankshaft Sprocket

Check teeth of sprocket for wear or damage.

If any malfunction is found, replace it.



IYSQ01143062

Fig. 113: Checking Teeth Of Sprocket For Wear Or Damage
Courtesy of SUZUKI OF AMERICA CORP.

RH Bank 1st Timing Chain Intake Camshaft Sprocket

Check teeth of sprocket for wear or damage.

If any malfunction is found, replace it.



**IYSQ01143063**

Fig. 114: Checking RH Bank 1st Teeth Of Sprocket For Wear Or Damage
Courtesy of SUZUKI OF AMERICA CORP.

Idler Sprocket No.1

Check teeth of sprocket for wear or damage.

If any malfunction is found, replace it.



IYSQ01143064


1. Bearing

Fig. 115: Checking Teeth Of Sprocket For Wear Or Damage (Idler Sprocket No.1)
Courtesy of SUZUKI OF AMERICA CORP.

Idler Sprocket No.2

Check teeth of sprocket for wear or damage.

If any malfunction is found, replace it.



IYSQ01143065


1. Bush

Fig. 116: Checking Teeth Of Sprocket For Wear Or Damage (Idler Sprocket No.2)
Courtesy of SUZUKI OF AMERICA CORP.

1st Timing Chain

Check timing chain for wear or damage.

If any malfunction is found, replace it.



IYSQ01143066

Fig. 117: Checking Timing Chain For Wear Or Damage
Courtesy of SUZUKI OF AMERICA CORP.

Timing Chain Tensioner Adjuster No.1

Check that latch (1) and tooth surface (2) are free from damage and latch functions properly.

If any malfunction is found, replace it.



**IYSQ01143067**

Fig. 118: Checking Latch And Tooth Surface
Courtesy of SUZUKI OF AMERICA CORP.

1ST TIMING CHAIN AND CHAIN TENSIONER INSTALLATION

1. Check timing mark on crankshaft as shown in the figure.




IYSQ01143048

1. Crank timing pulley key
2. Oil jet

Fig. 119: Checking Timing Mark On Crankshaft
Courtesy of SUZUKI OF AMERICA CORP.

2. Install 1st timing chain crankshaft sprocket (2) to crankshaft (1) as shown in the figure. Confirm that tooth for CKP sensor are free from metal particles and damage.



IYSQ01143068

3. Lower crankcase

Fig. 120: Installing 1st Timing Chain Crankshaft Sprocket To Crankshaft
Courtesy of SUZUKI OF AMERICA CORP.

3. Check timing mark on RH bank intake camshaft as shown in the figure.





Fig. 121: Checking Timing Mark On RH Bank Intake Camshaft
Courtesy of SUZUKI OF AMERICA CORP.

4. Install RH bank 1st timing chain intake camshaft sprocket (1) noting the following points.
- The sprocket should be set in such way that its RH mark (4) can be seen.
 - Camshaft (2) should be held stationary by using a spanner at its hexagonal parts (3) as shown in the figure.

Tightening torque

RH bank 1st timing chain intake camshaft sprocket bolt (a): 80 N.m (8.0 kg-m, 58.0 lb-ft)



IYSQ01143070

Fig. 122: Installing RH Bank 1st Timing Chain Intake Camshaft Sprocket
Courtesy of SUZUKI OF AMERICA CORP.

5. Install timing chain tensioner (1) as shown in the figure.

Tightening torque

Timing chain tensioner nut (b): 27 N.m (2.7 kg-m, 19.5 lb-ft)





Fig. 123: Installing Timing Chain Tensioner
Courtesy of SUZUKI OF AMERICA CORP.

6. Install 1st timing chain by aligning match marks (2) on RH silver plate (1) of 1st timing chain and RH bank 1st timing chain intake camshaft sprocket.




IYSQ01143072

3. RH bank cylinder head

Fig. 124: Aligning Match Marks On RH Silver Plate
Courtesy of SUZUKI OF AMERICA CORP.

7. Apply oil to bush of idler sprocket No.2.
8. Install idler sprocket No.2 and sprocket shaft.
9. Install idler sprocket No.2 by aligning match marks (2) on LH silver plate (1) of 1st timing chain.



IYSQ01143073


3. RH bank cylinder head

Fig. 125: Aligning Match Marks On LH Silver Plate
Courtesy of SUZUKI OF AMERICA CORP.

10. Install crankshaft sprocket by aligning match marks (2) on yellow plate (1) of 1st timing chain and crankshaft timing sprocket.

To install it, fit a spanner to hexagonal part at the center of RH bank intake camshaft to turn a little.

CAUTION: Do not turn camshaft more than necessary. If turned excessively, valve and piston may get damaged.



IYSQ01143074


3. Crankshaft

Fig. 126: Aligning Match Marks On Yellow Plate
Courtesy of SUZUKI OF AMERICA CORP.

11. Apply oil to bearing of idler sprocket No.1.
12. Install idler sprocket No.1.

Tightening torque

Idler sprocket No.1 bolt (c): 45 N.m (4.5 kg-m, 32.5 lb-ft)



IYSQ01143075

Fig. 127: Identifying Idler Sprocket No.1 Bolt
Courtesy of SUZUKI OF AMERICA CORP.

13. With latch of tensioner adjuster No.1 returned and plunger (1) pushed back into body, insert stopper (3) into latch (2) and body.

After inserting it, check to make sure that plunger (1) will not come out.





Fig. 128: Inserting Stopper Into Latch And Body
 Courtesy of SUZUKI OF AMERICA CORP.

14. Install timing chain tensioner adjuster No.1 (1).

Tightening torque

Timing chain tensioner adjuster No.1 bolt (d): 11 Nm(1.1 kg-m, 8.0 lb-ft)

15. Pull out stopper (3) from adjuster No.1 (1).



IYSQ01143077


2. Timing chain tensioner

Fig. 129: Installing Timing Chain Tensioner Adjuster
Courtesy of SUZUKI OF AMERICA CORP.

16. Install timing chain guide No.1 (2) and No.2 (1).

Tightening torque

Timing chain guide No.1 and No.2 bolt (e): 9 N.m (0.9 kg-m, 6.5 lb-ft)



IYSQ01143078

3. Guide bolts

Fig. 130: Installing Timing Chain Guide
Courtesy of SUZUKI OF AMERICA CORP.

17. Check each aligned timing marks as shown in the figure.




Fig. 131: Checking Aligned Timing Marks
Courtesy of SUZUKI OF AMERICA CORP.


18. Install LH bank 2nd timing chain. Refer to "**LH (NO.1) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER INSTALLATION**".
19. Install timing chain cover. Refer to "**TIMING CHAIN COVER REMOVAL AND INSTALLATION**".
20. Install oil pan referring to "**OIL PAN AND OIL PUMP STRAINER REMOVAL AND INSTALLATION**".
21. Install front differential housing referring to "**FRONT DIFFERENTIAL DISMOUNTING AND REMOUNTING**" and "**FRONT DIFFERENTIAL DISMOUNTING AND REMOUNTING**".
22. Install P/S system referring to "**P/S PUMP REMOVAL AND INSTALLATION**".
23. Install cooling system referring to "**COOLING FAN AND FAN CLUTCH REMOVAL AND INSTALLATION**" and "**RADIATOR REMOVAL AND INSTALLATION**".
24. Install intake manifold with throttle body.

For H25 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H25 ENGINE)**".

For H27 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H27 ENGINE)**".

25. Refill cooling system with coolant, front differential with gear oil, P/S system with specified fluid and engine with engine oil.
26. Check wheel alignment referring to "**FRONT ALIGNMENT INSPECTION AND ADJUSTMENT**".
27. Verify that there is no fuel leakage, water leakage and oil leakage at each connection.

RH (NO.2) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER COMPONENTS




14JA01140031

1. RH bank 2nd timing chain	6. RH bank intake camshaft	11. Timing chain tensioner adjuster No.2 bolt
2. Timing chain tensioner adjuster No.2	7. RH bank exhaust camshaft housing	12. Camshaft housing bolt Tighten 12 N·m (1.2 kg·m, 9.0 lb-ft) by the specified procedure
3. RH bank exhaust camshaft sprocket	8. RH bank intake camshaft housing	11: Apply engine oil to sliding surface of each part.
4. RH bank 2nd timing chain intake camshaft sprocket	9. Timing chain guide No.3	12: Tightening torque
5. RH bank exhaust camshaft	10. Timing chain guide No.3 bolt	

Fig. 132: Identifying RH (No.2) Bank 2nd Timing Chain And Chain Tensioner Components
Courtesy of SUZUKI OF AMERICA CORP.

RH (NO.2) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER REMOVAL

1. For reinstallation of timing chain, align 12 timing marks as shown in the figure by turning crankshaft.




IYSQ01143081

Fig. 133: Aligning Timing Marks By Turning Crankshaft
Courtesy of SUZUKI OF AMERICA CORP.

2. Remove LH bank 2nd timing chain. Refer to "**LH (NO.1) BANK 2ND TIMING CHAIN AND CHAIN**"

TENSIONER REMOVAL.

3. Remove 1st timing chain. Refer to "**1ST TIMING CHAIN AND CHAIN TENSIONER REMOVAL**".
4. Remove timing chain guide No.3 referring to "**RH (NO.2) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER COMPONENTS**".
5. Loosen camshaft housing bolts in such order ("1" - "17") as indicated in the figure and remove them.
6. Remove camshaft housings.



IYSQ01143082


Fig. 134: Identifying Camshaft Housings
 Courtesy of SUZUKI OF AMERICA CORP.

7. Remove RH bank intake camshaft, RH bank exhaust camshaft, and RH bank 2nd timing chain as a set referring to "**RH (NO.2) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER COMPONENTS**".
8. Remove timing chain tensioner adjuster No.2, referring to "**RH (NO.2) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER COMPONENTS**".

RH (NO.2) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER INSPECTION**Timing Chain Guide No.3**

Check shoe (1) for excessive wear or damage.

If any malfunction is found, replace it.




IYSQ01143083

Fig. 135: Checking Shoe For Excessive Wear Or Damage
Courtesy of SUZUKI OF AMERICA CORP.

RH Bank 2nd Timing Chain Sprockets

Check teeth of sprocket for wear or damage.




IYSQ01143084

Fig. 136: Checking Teeth Of Sprocket For Wear Or Damage
Courtesy of SUZUKI OF AMERICA CORP.

RH Bank 2nd Timing Chain

Check timing chain for wear or damage.




IYSQ01143085

Fig. 137: Check Timing Chain For Wear Or Damage
Courtesy of SUZUKI OF AMERICA CORP.

Timing Chain Tensioner Adjuster No.2

- Check shoe (1) for wear or damage.
- Check that plunger slides smoothly.




IYSQ01143086

Fig. 138: Checking Shoe For Wear Or Damage
Courtesy of SUZUKI OF AMERICA CORP.

RH (NO.2) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER INSTALLATION

1. Check timing mark on crankshaft as shown in the figure.



IYSQ01143048

1. Crank timing pulley key


2. Oil jet

Fig. 139: Checking Timing Mark On Crankshaft
Courtesy of SUZUKI OF AMERICA CORP.

2. Apply oil to timing chain tensioner adjuster No.2 (1).
3. Install timing chain tensioner adjuster No.2 (1).

Tightening torque

Timing chain tensioner adjuster No.2 bolt (a): 11 N.m(1.1 kg-m, 8.0 lb-ft)




IYSQ01143087

2. Water pump
3. Engine front side

Fig. 140: Identifying Timing Chain Tensioner Adjuster Bolt
Courtesy of SUZUKI OF AMERICA CORP.

4. Apply oil to sliding surface of each camshafts and camshaft journals.
5. Install RH bank 2nd timing chain by aligning match marks on yellow or silver plates (1) of RH bank 2nd timing chain, RH bank 2nd timing chain intake camshaft sprocket and RH bank 2nd timing chain exhaust camshaft sprocket as shown in the figure.




IYSQ01143088

- | |
|---|
| 2. Match mark of RH bank 2nd timing chain exhaust camshaft sprocket |
| 3. Match mark of RH bank 2nd timing chain intake camshaft sprocket |

Fig. 141: Aligning Match Marks On Yellow Or Silver Plates
Courtesy of SUZUKI OF AMERICA CORP.

6. Install camshaft housing pins (3) as shown in the figure.




IYSQ01143089

- | |
|-----------------------------|
| 1. RH bank intake camshaft |
| 2. RH bank exhaust camshaft |

Fig. 142: Installing Camshaft Housing Pins
Courtesy of SUZUKI OF AMERICA CORP.

7. Check position of camshaft housings.

Embossed marks are provided on each camshaft housing, indicating position and direction for installation. Install housings as indicated by these marks.



IYSQ01143090

1. I: Intake side, E: Exhaust side
2. Position from timing chain side
3. Timing chain side

Fig. 143: Checking Position Of Camshaft Housings


Courtesy of SUZUKI OF AMERICA CORP.

8. After applying oil to housing bolts, tighten them temporarily first.

Then tighten them by following sequence ("1" - "17") as indicated in the figure. Tighten a little at a time and evenly among bolts and repeat tightening sequence 2 or 3 times before they are tightened to specified torque below.

Tightening torque

Camshaft housing bolt: Tighten 12 N.m (1.2 kg-m, 9.0 lb-ft) by the specified procedure




IYSQ01143091

Fig. 144: Identifying Tighten Sequence Of Camshaft Housing Bolt
Courtesy of SUZUKI OF AMERICA CORP.

9. Install timing chain guide No.3 (1).

Tightening torque

Timing chain guide No.3 bolt (c): 11 N.m (1.1 kg-m, 8.0 lb-ft)



IYSQ01143092

Fig. 145: Installing Timing Chain Guide
Courtesy of SUZUKI OF AMERICA CORP.

10. Install 1st timing chain. Refer to "**1ST TIMING CHAIN AND CHAIN TENSIONER INSTALLATION**".
11. Install LH bank 2nd timing chain. Refer to "**LH (NO.1) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER INSTALLATION**".
12. Install timing chain cover. Refer to "**TIMING CHAIN COVER REMOVAL AND INSTALLATION**".
13. Install oil pan referring to "**OIL PAN AND OIL PUMP STRAINER REMOVAL AND INSTALLATION**".
14. Install front differential housing referring to "**FRONT DIFFERENTIAL DISMOUNTING AND REMOUNTING**" and "**FRONT DIFFERENTIAL DISMOUNTING AND REMOUNTING**".
15. Install P/S system referring to "**P/S PUMP REMOVAL AND INSTALLATION**".
16. Install cooling system referring to "**RADIATOR REMOVAL AND INSTALLATION**".
17. Install intake manifold with throttle body.

For H25 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H25 ENGINE)**".


For H27 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H27 ENGINE)**".

18. Refill cooling system with coolant, front differential with gear oil, P/S system with specified fluid and

engine with engine oil.

19. Check wheel alignment referring to "**FRONT ALIGNMENT INSPECTION AND ADJUSTMENT**".
20. Verify that there is no fuel leakage, water leakage and oil leakage at each connection.

CAMSHAFTS AND VALVE LASH ADJUSTERS COMPONENTS



I4JA01140032

1. RH bank 2nd timing chain	6. LH bank intake camshaft	11. Timing chain guide No.5
2. RH bank exhaust camshaft	7. LH bank exhaust camshaft	12. Valve lash adjuster
3. RH bank intake camshaft	8. LH bank intake camshaft housing	13. Camshaft housing bolt : Tighten 12 N·m (1.2 kg-m, 9.0 lb-ft) by the specified procedure
4. RH bank exhaust camshaft housing	9. LH bank exhaust camshaft housing	: Tightening torque
5. RH bank intake camshaft housing	10. LH bank camshaft housing	: Apply engine oil to sliding surface of each part.

Fig. 146: Identifying Camshafts And Valve Lash Adjusters Components
 Courtesy of SUZUKI OF AMERICA CORP.

CAMSHAFTS AND VALVE LASH ADJUSTERS REMOVAL AND INSTALLATION


Removal

1. Disconnect negative (-) cable at battery.
2. Drain engine oil.
3. Drain coolant referring to "**COOLANT DRAINING**".
4. Remove timing chain cover. Refer to "**TIMING CHAIN COVER REMOVAL AND INSTALLATION**".
5. Remove LH bank 2nd timing chain. Refer to "**LH (NO.1) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER REMOVAL**".
6. Remove 1st timing chain. Refer to "**1ST TIMING CHAIN AND CHAIN TENSIONER INSTALLATION**".
7. Remove RH bank camshafts. Refer to "**RH (NO.2) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER REMOVAL**".
8. Remove CMP sensor.

For H25 engine model, refer to "**CAMSHAFT POSITION (CMP) SENSOR REMOVAL AND INSTALLATION**".

For H27 engine model, refer to "**CAMSHAFT POSITION (CMP) SENSOR REMOVAL AND INSTALLATION**".

9. Loosen LH bank camshaft housing bolts in such order ("1" - "19") as indicated in the figure and remove them.



IYSQ01143094


[A]: LH bank

Fig. 147: Loosening LH Bank Camshaft Housing Bolts
Courtesy of SUZUKI OF AMERICA CORP.

10. Remove LH bank camshaft housings.
11. Remove LH bank camshafts.
12. Remove valve lash adjuster.

CAUTION:


- Never disassemble hydraulic valve lash adjuster.
- Don't apply force (1) to body of adjuster, oil in high pressure chamber in adjuster will leak.



IYSQ01143095

Fig. 148: Identifying Valve Lash Adjuster
Courtesy of SUZUKI OF AMERICA CORP.

NOTE: Immerse removed adjuster (2) in clean engine oil (1) and keep it there till reinstalling it so as to prevent oil leakage. If it is left in air, place it with its bucket body facing down. Don't place on its side or with bucket body facing up.



IYSQ01143096

Fig. 149: Immersing Removed Adjuster In Cleaning Engine Oil
Courtesy of SUZUKI OF AMERICA CORP.

Installation


CAUTION:

- Don't turn camshafts or start engine (i.e., valves should not be operated) for about half an hour after reinstalling hydraulic valve lash adjusters and camshafts. As it takes time for valves to settle in place, operating engine within half an hour after their installation may cause interference to occur between valves themselves or valves and piston.
- If air is trapped in valve lash adjuster, valve may make tapping sound when engine is operated after valve lash adjuster is installed. In such a case, run engine for about half an hour at about 2000 to 3000 rpm, and then air will be purged and tapping sound will cease. Should tapping sound not cease, it is possible that valve lash adjuster is defective. Replace it if defective.
- If defective adjuster can't be located by hearing among 24 of them, check as follows.
 - Stop engine and remove cylinder head cover.
 - Push adjuster downward by hand (with less than 200 N (20 kg, 44 lbs) of force) when cam crest is not on adjuster to be checked and check if clearance exists between cam and adjuster. If it does, adjuster is defective and needs replacement.

1. Before installing valve lash adjuster to cylinder head, fill oil passage of cylinder head (1) with engine oil according to the following procedure.

Pour engine oil through oil holes (2) and check that oil comes out from oil holes (2) in sliding part of valve lash adjuster.

Perform this check on both intake and exhaust sides.




IYSQ01143097

Fig. 150: Pouring Engine Oil In Holes And Checking Oil Coming From Oil Holes In Sliding Part Of Valve Lash Adjuster

Courtesy of SUZUKI OF AMERICA CORP.


2. Apply engine oil around valve lash adjuster and then install it to cylinder head.



IYSQ01143098

Fig. 151: Applying Engine Oil Around Valve Lash Adjuster
Courtesy of SUZUKI OF AMERICA CORP.

3. Check timing mark on crankshaft as shown in the figure.



IYSQ01143048

1. Crank timing pulley key

2. Oil jet

Fig. 152: Checking Timing Mark On Crankshaft
Courtesy of SUZUKI OF AMERICA CORP.

4. Install RH bank camshafts referring to "**RH (NO.2) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER INSTALLATION**".
5. Install LH bank camshafts.

Apply oil to sliding surface of each camshaft and camshaft journal then install them by aligning match marks (4) on cylinder head (3) and LH bank camshafts as shown in the figure.





Fig. 153: Aligning Match Marks On Cylinder Head And LH Bank Camshafts
Courtesy of SUZUKI OF AMERICA CORP.

6. Install LH bank camshaft housing pins as shown in the figure.
7. Apply sealant "A" to LH bank exhaust camshaft housing No.5 sealing surface area as shown in the figure.

"A": Water tight sealant 99000-31250




IYSQ01143100

1. LH bank intake camshaft
2. LH bank exhaust camshaft
3. Pin installation position

Fig. 154: Installing LH Bank Camshaft Housing Pins
Courtesy of SUZUKI OF AMERICA CORP.

8. Check position of LH bank camshaft housings. Embossed marks are provided on each camshaft housing, indicating position and direction for installation. Install housings as indicated by these marks.



IYSQ01143101

1. I: Intake side, E: Exhaust side
2. Position from timing chain side
3. Timing chain side


Fig. 155: Checking Position Of LH Bank Camshaft Housings With Embossed Marks
Courtesy of SUZUKI OF AMERICA CORP.

9. After applying oil to housing bolts, tighten them temporarily first.

Then tighten them by following sequence ("1" - "19") as indicated in the figure. Tighten a little at a time and evenly among bolts and repeat tightening sequence 2 or 3 times before they are tightened to specified torque below.

Tightening torque

Camshaft housing bolt: Tighten 12 N.m (1.2 kg-m, 9.0 lb-ft) by the specified procedure

[A]

IYSQ01143102

[A]: LH bank

Fig. 156: Identifying Tightening Sequence Of Camshaft Housing Bolt
Courtesy of SUZUKI OF AMERICA CORP.

10. Install 1st timing chain. Refer to "**1ST TIMING CHAIN AND CHAIN TENSIONER INSPECTION**".
11. Install LH bank 2nd timing chain. Refer to "**LH (NO.1) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER INSTALLATION**".
12. Install timing chain cover. Refer to "**TIMING CHAIN COVER REMOVAL AND INSTALLATION**".
13. Install oil pan referring to "**OIL PAN AND OIL PUMP STRAINER REMOVAL AND INSTALLATION**".
14. Install front differential housing referring to "**FRONT DIFFERENTIAL DISMOUNTING AND REMOUNTING**" and "**FRONT DIFFERENTIAL DISMOUNTING AND REMOUNTING**".
15. Install P/S system referring to "**P/S PUMP REMOVAL AND INSTALLATION**".
16. Install cooling system referring to "**COOLING FAN AND FAN CLUTCH REMOVAL AND INSTALLATION**" and "**RADIATOR REMOVAL AND INSTALLATION**".
17. Install intake manifold with throttle body.

For H25 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H25 ENGINE)**".

For H27 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H27 ENGINE)**".

18. Install CMP sensor.

For H25 engine model, refer to "**CAMSHAFT POSITION (CMP) SENSOR REMOVAL AND INSTALLATION**".

For H27 engine model, refer to "**CAMSHAFT POSITION (CMP) SENSOR REMOVAL AND INSTALLATION**".

19. Refill cooling system with coolant, front differential with gear oil, P/S system with specified fluid and engine with engine oil.
20. Check wheel alignment referring to "**FRONT ALIGNMENT INSPECTION AND ADJUSTMENT**".
21. Verify that there is no fuel leakage, water leakage and oil leakage at each connection.
22. Check ignition timing, referring to "**IGNITION TIMING CHECK AND ADJUSTMENT**".

CAMSHAFTS AND CAMSHAFT HOUSINGS INSPECTION


Cam Wear

Using a micrometer, measure cam height "a". If measured height is below its limit, replace camshaft.

Cam height specifications

CAM HEIGHT SPECIFICATIONS

		Intake cam	Exhaust cam
H25 engine model	Standard	39.445 - 39.605 mm (1.5530-1.5593 in.)	39.428 - 39.588 mm (1.5523-1.586 in.)
	Limit	39.400 mm (1.5512 in.)	39.400 mm (1.5512 in.)
H27 engine model	Standard	40.402 - 40.562 mm (1.5906-1.5969 in.)	39.428 - 39.588 mm (1.5523-1.586 in.)
	Limit	40.300 mm (1.3581 in.)	39.400 mm (1.5512 in.)



IYSQ01143103

Fig. 157: Measuring Cam Height Using Micrometer
Courtesy of SUZUKI OF AMERICA CORP.

Camshaft Runout


Set camshaft between two "V" blocks, and measure its runout by using a dial gauge.

If measured runout exceeds specified limit, replace camshaft.

Camshaft runout limit

For H25 engine model: 0.10 mm (0.004 in.)

For H27 engine model: 0.04 mm (0.002 in.)




IYSQ01143104

Fig. 158: Measuring Camshaft Runout Using Dial Gauge
Courtesy of SUZUKI OF AMERICA CORP.

Camshaft Journal Wear

Check camshaft journals and camshaft housings for pitting, scratches, wear or damage.

If any malfunction is found, replace camshaft or cylinder head with housing. Never replace cylinder head without replacing housings.



IYSQ01143105

Fig. 159: Checking Camshaft Journal Wear
Courtesy of SUZUKI OF AMERICA CORP.

Check clearance by using gauging plastic. The procedure is as follows.

1. Clean housings and camshaft journals.
2. Make sure that all valve lash adjusters are removed and install camshaft to cylinder head.
3. Place a piece of gauging plastic the full width of journal of camshaft (parallel to camshaft).
4. Install camshaft housing.
5. Tighten camshaft housing bolts in such order ([A]: "1" --> "17", [B]: "1" --> "19") as shown in the figure a little at a time till they are tightened to specified torque.

NOTE: **Do not rotate camshaft while gauging plastic is installed.**





Fig. 160: Tightening Camshaft Housing Bolts In Order
 Courtesy of SUZUKI OF AMERICA CORP.

6. Remove housing, and using scale (2) on gauging plastic (1) envelop, measure gauging plastic (1) width at its widest point.

Camshaft journal clearance

Standard: 0.020 - 0.074 mm (0.0008 - 0.0029 in.)

Limit: 0.12 mm (0.0047 in.)



IYSQ01143107

Fig. 161: Measuring Camshaft Journal Clearance
Courtesy of SUZUKI OF AMERICA CORP.


If measured camshaft journal clearance exceeds limit, measure journal (housing) bore and outside diameter of camshaft journal. Replace camshaft or cylinder head assembly whichever the difference from specification is greater.

Camshaft journal bore via. (IN and EX)

Standard: 26.000 - 26.033 mm (1.0236 - 1.0249 in.)

Camshaft journal O.D. (IN and EX)

Standard: 25.959 - 25.980 mm (1.0220 - 1.0228 in.)



I5JA01140009

Fig. 162: Measuring Journal (Housing) Bore And Outside Diameter Of Camshaft Journal Using Micrometer

Courtesy of SUZUKI OF AMERICA CORP.

VALVE LASH ADJUSTERS INSPECTION

Check adjuster for pitting, scratches, or damage.

If any malcondition is found, replace.




Fig. 163: Checking Valve Lash Adjusters
Courtesy of SUZUKI OF AMERICA CORP.

Measure cylinder head bore and adjuster outside diameter to determine cylinder head-to-adjuster clearance. If clearance exceeds limit, replace adjuster or cylinder head.

Hydraulic valve lash adjuster O.D.

Standard: 30.959 - 30.975 mm (1.2188 - 1.2194 in.)


Cylinder head bore

Standard: 31.000 - 31.025 mm (1.2205-1.2214 in.)

Cylinder head to adjuster clearance

Standard: 0.025 - 0.066 mm (0.0010 - 0.0025 in.)

Limit: 0.15 mm (0.0059 in.)



I5JA01140010

Fig. 164: Measuring Cylinder Head Bore And Adjuster Outside Diameter
 Courtesy of SUZUKI OF AMERICA CORP.

VALVE LASH ADJUSTERS NOISE INSPECTION

In case of the followings, valve lash adjuster noise may be caused by air trapped into valve lash adjusters.

- Vehicle is left for 24 hours or more.
- Engine oil is changed.
- Hydraulic lash adjuster is replaced or reinstalled.
- Engine is overhauled.

If noise from valve lash adjusters is suspected, perform the following checks.


1. Check engine oil for the followings.

- Oil level in oil pan - If oil level is low, add oil up to full level hole on oil level gauge.
 - Oil quality - If oil is discolored, or deteriorated, change it. For particular oil to be used, refer to "**ENGINE OIL AND FILTER CHANGE**".
 - Oil leaks - If leak is found, repair it.
 - Oil pressure (refer to "**OIL PRESSURE CHECK**".) - If defective pressure is found, repair it.
2. Run engine for about half an hour at about 2000 to 3000 rpm, and then air will be purge and tapping sound will cease.
 3. Should tapping sound not cease, it is possible that hydraulic valve lash adjuster is defective.

Replace it if defective. If defective adjuster can't be located by hearing among 16 of them, check as follows.

- a. Stop engine and remove cylinder head cover.
- b. Push adjuster downward by hard (with less than 200 N (20 kg, 44 lbs) of force) when cam crest is not on adjuster to be check if clearance exists between cam and adjuster. If it does, adjuster is defective and needs replacement.

VALVES AND CYLINDER HEADS COMPONENTS



14JA01140033


1. Cylinder block	8. Valve spring seat	15. Cylinder head bolt : Tighten 53 N-m (5.3 kg-m, 38.5 lb-ft), 84 N-m (8.4 kg-m, 61.0 lb-ft), 0 N-m (0 kg-m, 0 lb-ft), 53 N-m (5.3 kg-m, 38.5 lb-ft) and 105 N-m (10.5 kg-m, 76.0 lb-ft) by the specified procedure.
2. RH bank cylinder head	9. Outer valve spring: Be sure to position spring in place with its bottom end (small-pitch end) facing the bottom (valve spring seat side).	16. Cylinder head bolt (hex hole bolt)
3. LH bank cylinder head	10. Inner valve spring: Be sure to position spring in place with its bottom end (small-pitch end) facing the bottom (valve spring seat side)	: Tightening torque
4. RH bank cylinder head gasket: Carved lot number on cylinder head gasket should face up (toward cylinder head side).	11. Valve stem oil seal	: Do not reuse.
5. LH bank cylinder head gasket: Carved lot number on cylinder head gasket should face up (toward cylinder head side).	12. Valve spring retainer	: Apply engine oil.
6. Exhaust valve	13. Valve cotter	
7. Intake valve	14. Valve guide	

Fig. 165: Identifying Valves And Cylinder Heads Components
Courtesy of SUZUKI OF AMERICA CORP.

VALVES AND CYLINDER HEADS REMOVAL AND INSTALLATION**Removal**

1. Relieve fuel pressure according to "**FUEL PRESSURE RELIEF PROCEDURE**".
2. Disconnect negative (-) cable at battery.
3. Drain engine oil.
4. Drain coolant referring to "**COOLANT DRAINING**".
5. Remove CMP sensor, camshaft and valve lash adjuster. Refer to "**CAMSHAFT POSITION (CMP) SENSOR REMOVAL AND INSTALLATION**" or "**CAMSHAFT POSITION (CMP) SENSOR REMOVAL AND INSTALLATION**" for CMP sensor removal and "**CAMSHAFTS AND VALVE LASH ADJUSTERS REMOVAL AND INSTALLATION**" for camshaft and valve lash adjuster removal.
6. Remove exhaust manifold referring to "**EXHAUST MANIFOLD REMOVAL AND INSTALLATION**".
7. Remove water outlet cap.
8. Loosen cylinder head bolts in such order ("1" --> "8") as shown in the figure and remove them.

NOTE: **Be sure to remove 2 hex bolts (1) shown in the figure.**



[A]: RH bank	2. Timing chain side
[B]: LH bank	3. Flywheel side

Fig. 166: Removing/Installing Valves And Cylinder Heads
 Courtesy of SUZUKI OF AMERICA CORP.

9. Remove cylinder heads.

Installation


1. Clean mating surface on cylinder head and cylinder block. Remove oil, old gasket and dust from mating surface.
2. Install knock pin (4) to cylinder block.
3. For H25 engine model, apply sealant "A" to cylinder head gasket (1) as shown in the figure.

"A": Water tight sealant 99000-31250

Sealant amount

Width "w": 4 mm (0.158 in.)

4. Install new cylinder head gasket (1) to cylinder block as shown in the figure. Carved lot number (5) on cylinder head gasket (1) should face up (toward cylinder head side).



I5JA01140012

[A]: RH (No.2) bank	2. Crankshaft pulley side
[B]: LH (No.1) bank	3. Flywheel side

Fig. 167: Installing Cylinder Head Gasket
 Courtesy of SUZUKI OF AMERICA CORP.

5. Install cylinder head to block.

After applying oil to cylinder head bolts, tighten them gradually as follows.

- a. Tighten cylinder head bolts (except hex hole bolt) to 53 N.m (5.3 kg-m, 38.5 lb-ft) according to numerical order in the figure.
- b. In the same manner as Step a), tighten them to 84 N.m (8.4 kg-m, 61.0 lb-ft).
- c. Loosen all bolts until tightening torque is reduced to 0 in reverse order of tightening.
- d. In the same manner as Step a), tighten them to 53 N.m (5.3 kg-m, 38.5 lb-ft).
- e. In the same manner as Step a) again, tighten them to specified torque.
- f. Tighten cylinder head bolts (hex hole bolt) to specified torque.

Tightening torque

Cylinder head bolt (a): Tighten 53 N.m (5.3 kg-m, 38.5 lb-ft), 84 N.m (8.4 kg-m, 61.0 lb-ft), 0 N.m (0 kg-m, 0 lb-ft), 53 N.m (5.3 kg-m, 38.5 lb-ft) and 105 N.m (10.5 kg-m, 76.0 lb-ft) by the specified procedure

Cylinder head bolt (hex hole bolt) (b):

Tighten 11 N.m (1.1 kg-m, 7.5 lb-ft) by the specified procedure

NOTE: Be sure to install hex hole bolts (1) as shown in the figure.





Fig. 168: Tightening Cylinder Head Bolts
 Courtesy of SUZUKI OF AMERICA CORP.

6. Install water outlet cap.
7. Check timing mark on crankshaft as shown in the figure.



IYSQ01143048

1	Crank timing pulley key
2.	Oil jet

Fig. 169: Checking Timing Mark On Crankshaft
 Courtesy of SUZUKI OF AMERICA CORP.

8. Install valve lash adjuster, camshaft, CMP sensor and RH bank 2nd timing chain.

Refer to "[CAMSHAFTS AND VALVE LASH ADJUSTERS REMOVAL AND INSTALLATION](#)" and to "[RH \(NO.2\) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER INSTALLATION](#)". For CMP sensor, refer to "[CAMSHAFT POSITION \(CMP\) SENSOR REMOVAL AND INSTALLATION](#)" or "[CAMSHAFT POSITION \(CMP\) SENSOR REMOVAL AND INSTALLATION](#)".

9. Install 1st timing chain referring to "[1ST TIMING CHAIN AND CHAIN TENSIONER INSTALLATION](#)".
10. Install LH bank 2nd timing chain referring to "[LH \(NO.1\) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER INSTALLATION](#)".
11. Install timing chain cover referring to "[TIMING CHAIN COVER REMOVAL AND INSTALLATION](#)".
12. Install oil pan and oil pump strainer referring to "[OIL PAN AND OIL PUMP STRAINER REMOVAL AND INSTALLATION](#)".

13. Install cylinder head cover referring to "**CYLINDER HEAD COVERS REMOVAL AND INSTALLATION**".
14. Install exhaust manifold referring to "**EXHAUST MANIFOLD REMOVAL AND INSTALLATION**".
15. Install radiator outlet pipe, radiator, cooling fan and water hose.

Refer to "**COOLING WATER PIPES OR HOSES REMOVAL AND INSTALLATION**", "**RADIATOR REMOVAL AND INSTALLATION**" and "**COOLING FAN AND FAN CLUTCH REMOVAL AND INSTALLATION**".

16. Install intake manifold with throttle body.

For H25 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H25 ENGINE)**".

For H27 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H27 ENGINE)**".

17. Adjust water pump drive belt tension.

Refer to "**COOLING FAN / GENERATOR BELT TENSION CHECK AND ADJUSTMENT**".

18. Adjust power steering pump drive belt tension referring to "**P/S PUMP DRIVE BELT INSPECTION AND ADJUSTMENT**".
19. Adjust accelerator cable play and A/T throttle cable play. Refer to "**ACCELERATOR CABLE ADJUSTMENT**" and "**A/T THROTTLE CABLE ADJUSTMENT (H25 ENGINE WITH A/T ONLY)**".
20. Check to ensure that all removed parts are back in place. Reinstall any necessary parts which have not been reinstalled.
21. Refill engine with engine oil referring to "**ENGINE OIL AND FILTER CHANGE**".
22. Refill cooling system referring to "**COOLING SYSTEM FLUSH AND REFILL**".
23. Refill front differential housing with gear oil if drained. For H25 engine model, refer to "**FRONT DIFFERENTIAL GEAR OIL INSPECTION AND CHANGE**".

For H27 engine model, refer to "**FRONT DIFFERENTIAL GEAR OIL INSPECTION AND CHANGE**".


24. Connect negative (-) cable at battery.
25. Check ignition timing and adjust as necessary referring to "**IGNITION TIMING CHECK AND ADJUSTMENT**".
26. Verify that there is no fuel leakage, water leakage, oil leakage and exhaust gas leakage at each connection.
27. Check wheel alignment referring to "**FRONT ALIGNMENT INSPECTION AND ADJUSTMENT**".

VALVES AND CYLINDER HEADS DISASSEMBLY AND ASSEMBLY

Disassembly

1. Using special tools (A), (B) and (C), compress valve springs and then remove valve cotters (1) by using special tool (D).
2. Release special tool, and remove spring retainer and valve spring.

Special tool**(A): 09916-14510****(B): 09916-14910****(C): 09919-28610****(D): 09916-84511**




I5JA01140014

Fig. 170: Compressing Valve Springs Using Special Tools
Courtesy of SUZUKI OF AMERICA CORP.

3. Remove valve from combustion chamber side.
4. Remove valve stem seal (1) from valve guide, and then valve spring seat (2).

NOTE: Do not reuse seal once disassembled. Be sure to use new seal when assembling.



IYSQ01143116


Fig. 171: Removing Valve Stem Seal From Valve Guide
Courtesy of SUZUKI OF AMERICA CORP.

5. Using special tool (E) (Valve guide remover), drive valve guide out from combustion chamber side to valve spring side.

Special tool

(E): 09916-44910

NOTE: Do not reuse valve guide once disassembled. Be sure to use new valve guide (Oversize) when assembling.



IYSQ01143117

Fig. 172: Using Special Tool For Valve Guide
Courtesy of SUZUKI OF AMERICA CORP.

6. Place disassembled parts except valve stem seal and valve guide in order so that they can be installed in their original positions.

Assembly

1. Before installing valve guide into cylinder head, ream guide hole with special tool (11 mm reamer) so as to remove burrs and make it truly round.

Special tool

(E): 09916-34542

(F): 09916-38210

2. Install valve guide to cylinder head.

Heat cylinder head uniformly at a temperature of 80 to 100 °C (176 to 212 °F) so that head will not be distorted, and drive new valve guide into hole with special tools. Drive in new valve guide until special tool (Valve guide installer) contacts cylinder head. After installing, make sure that valve guide protrusions (1) by specified height from cylinder head.

Special tool

(G): 09916-58210

(H): 09917-87810

NOTE:


- **Do not reuse valve guide once disassembled. Install new valve guide (Oversize).**
- **Intake and exhaust valve guides are identical.**

Width of oversized valve guide

11.088 - 11.103 mm (0.4365 - 0.4371 in.)

Valve guide protrusion (In and Ex)

13.5 mm (0.53 in.)



I5JA01140015


Fig. 173: Installing Valve Guide To Cylinder Head
Courtesy of SUZUKI OF AMERICA CORP.

3. Ream valve guide bore with special tool (6.0 mm reamer). After reaming, clean bore.

Special tool

(E): 09916-34542

(I): 09916-37810



IYSQ01143119

Fig. 174: Reaming Valve Guide Bore With Special Tool
Courtesy of SUZUKI OF AMERICA CORP.

4. Install valve spring seat to cylinder head.
5. Install new valve stem seal (1) to valve guide.

After applying engine oil to seal and spindle of special tool (Valve guide installer handle), fit oil seal to spindle, and then install seal to valve guide by pushing special tool by hand.

After installing, check to be sure that seal is properly fixed to valve guide.

Special tool


(J): 09917-98221

(K): 09916-58210

NOTE:

- Do not reuse seal once disassembled. Be sure to install new seal.

- When installing, never tap or hit special tool with a hammer or else. Install seal to guide only by pushing special tool by hand. Tapping or hitting special tool may cause damage to seal.




IYSQ01143120

Fig. 175: Installing Valve Spring Seat To Cylinder Head
Courtesy of SUZUKI OF AMERICA CORP.

6. Install valve (1) to valve guide.

Before installing valve to valve guide, apply engine oil to stem seal, valve guide bore, and valve stem.




IYSQ01141092

Fig. 176: Installing Valve To Valve Guide
Courtesy of SUZUKI OF AMERICA CORP.

7. Install valve springs (inner and outer) and spring retainer.

Each valve spring has top end (large-pitch end (1)) and bottom end (small-pitch end (2)). Be sure to position spring in place with its bottom end (valve spring retainer side (3)) facing the bottom (valve spring seat side (4)).



IYSQ01141093

Fig. 177: Installing Valve Springs (Inner And Outer) And Spring Retainer
Courtesy of SUZUKI OF AMERICA CORP.

8. Using special tool (Valve lifter), compress valve spring and fit 2 valve cotters (1) into groove in valve stem.


Special tool

(A): 09916-14510

(B): 09916-14910

(C): 09916-84511

(D): 09919-28610



IYSQ01143121

Fig. 178: Compressing Valve Spring And Fit Valve Cotters Into Groove In Valve Stem Using Special Tool

Courtesy of SUZUKI OF AMERICA CORP.

VALVES AND VALVE GUIDES INSPECTION

Valve Guides

Using a micrometer and bore gauge, take diameter readings on valve stems and guides to check stem-to-guide clearance. Be sure to take reading at more than one place along the length of each stem and guide. If clearance exceeds limit, replace valve and valve guide.

VALVE STEM-TO-GUIDE CLEARANCE SPECIFICATIONS

Item		Standard	Limit
Valve stem diameter	Intake	5.965 - 5.980 mm (0.2348 - 0.2354 in.)	-
	Exhaust	5.940 - 5.955 mm (0.2339 - 0.2344 in.)	-
Valve guide I.D.	In and Ex	6.000-6.012 mm (0.2362 - 0.2367 in.)	-
Stem-to-guide clearance	Intake	0.020 - 0.047 mm (0.0008 - 0.0019 in.)	0.07 mm (0.0028 in.)
	Exhaust	0.045 - 0.072 mm (0.0018-0.0028 in.)	0.09 mm (0.0035 in.)





Fig. 179: Checking Stem-To-Guide Clearance Using Micrometer
Courtesy of SUZUKI OF AMERICA CORP.

Valves

- Remove all carbon from valves.
- Inspect each valve for wear, burn or distortion at its face and stem and, as necessary, replace it.
- Measure thickness of valve head. If measured thickness exceeds limit, replace valve.

VALVE SPECIFICATIONS

Item	Standard	Limit
Intake	1.0 mm (0.039 in.)	0.6 mm (0.024 in.)
Exhaust	1.2 mm (0.047 in.)	0.7 mm (0.028 in.)



IYSQ01141097

1. Valve head thickness

2. 45°

Fig. 180: Measuring Thickness Of Valve Head
Courtesy of SUZUKI OF AMERICA CORP.

- Inspect valve stem end face for pitting and wear. If pitting or wear is found, valve stem end may be resurfaced. But do not grind its taper excessively. When valve is excessively worn out too much or its taper is gone, replace it.

**IYSQ01141098**


Fig. 181: Inspecting Valve Stem End Face For Pitting And Wear
Courtesy of SUZUKI OF AMERICA CORP.

- Check each valve for radial runout with a dial gauge and "V" block.

To check runout, rotate valve slowly. If runout exceeds its limit, replace valve.

Valve head radial runout

Limit: 0.08 mm (0.003 in.)



IYSQ01143123

Fig. 182: Checking Radial Runout With Dial Gauge
Courtesy of SUZUKI OF AMERICA CORP.


- Seating contact width

Create contact pattern on each valve in the usual manner, i.e., by giving uniform coat of marking compound to valve seat and by rotating tapping seat with valve head. Valve lapper (tool used in valve lapping) must be used.

Pattern produced on seating face of valve must be a continuous ring without any break, and the width of pattern must be within specified range.

Standard seating width revealed by contact pattern on valve face

Intake and Exhaust: 1.1-1.3 mm (0.0433 - 0.0512 in.)



IYSQ01141099

Fig. 183: Merging Thickness Of Valve
Courtesy of SUZUKI OF AMERICA CORP.

- Valve seat repair

A valve seat not producing a uniform contact with its valve or showing width of seating contact that is out of specified range must be repaired by regrinding or by cutting and regrinding and finished by lapping.

- a. **Exhaust valve seat**

Use valve seat cutters (1) to make two cuts as illustrated in the figure. Two cutters must be used: the 1st for making 15° angle, and the 2nd for making 45° angle. The 2nd cut must be made to produce desired seat width.

Seat width for exhaust valve seat

1.1 - 1.3 mm (0.0433 - 0.0512 in.)


- b. **Intake valve seat**

Use valve seat cutters (1) to make three cuts as illustrated in figure. Three cutters must be used: the 1st for making 15° angle, the 2nd for making 60° angle, and the 3rd for making 45°

angle. The 3rd cut (45°) must be made to produce desired seat width.

Seat width for intake valve seat

1.1 - 1.3 mm (0.0433 - 0.0512 in.)



IYSQ01141100

Fig. 184: Using Valve Seat Cutters
Courtesy of SUZUKI OF AMERICA CORP.

c. Valve lapping

Lap valve on seat in two steps, first with coarse size lapping compound applied to face and the second with fine-size compound, each time using valve lapper according to usual lapping method.





Fig. 185: Lapping Valve On Seat In Two Steps
Courtesy of SUZUKI OF AMERICA CORP.

CYLINDER HEAD INSPECTION

- Remove all carbon from combustion chambers.

NOTE: Do not use any sharp-edged tool to scrape off carbon. Be careful not to scuff or nick metal surfaces when decarboning. The same applies to valves and valve seats, too.



IYSQ01141102


Fig. 186: Removing All Carbon From Combustion Chambers
Courtesy of SUZUKI OF AMERICA CORP.

- Check cylinder head for cracks on intake and exhaust ports, combustion chambers, and head surface. Using straightedge (1) and thickness gauge (2), check flatness of gasketed surface at a total of 6 locations. If distortion limit, given below, is exceeded, correct gasketed surface with a surface plate and abrasive paper of about #400 (Waterproof silicon carbide abrasive paper): Place abrasive paper on and over surface plate, and rub gasketed surface against paper to grind off high spots. Should this fail to reduce thickness gauge readings to within limit, replace cylinder head.

Leakage of combustion gases from this gasketed joint is often due to warped gasketed surface: such leakage results in reduced power output.

Cylinder head gasketed surface distortion

Limit: 0.05 mm (0.002 in.)



I5JA01140016


Fig. 187: Checking Cylinder Head For Cracks On Intake And Exhaust Ports, Combustion Chambers, And Head Surface Using Straightedge
Courtesy of SUZUKI OF AMERICA CORP.

- Distortion of manifold seating faces

Check seating faces of cylinder head for manifolds, using a straightedge (1) and thickness gauge (2), in order to determine whether these faces should be corrected or cylinder head replaced.

Manifold seating surface distortion

Limit: 0.10 mm (0.004 in.)



I5JA01140017

Fig. 188: Checking Seating Faces Of Cylinder Head For Manifolds Using Straightedge
Courtesy of SUZUKI OF AMERICA CORP.

VALVE SPRINGS INSPECTION

- Referring to data given below, check to be sure that each spring is in sound condition, free of any evidence of breakage or weakening. Remember, weakened valve springs can cause chatter, not to mention possibility of reducing power output due to gas leakage caused by decreased seating pressure.




Fig. 189: Inspecting Valve Springs
 Courtesy of SUZUKI OF AMERICA CORP.

VALVE SPRING FREE LENGTH SPECIFICATIONS

Item	Standard	Limit
Inner	36.08 mm (1.4205 in.)	35.00 mm (1.3780 in.)
Outer	40.44 mm (1.5921 in.)	39.22 mm (1.5441 in.)

VALVE SPRING PRELOAD SPECIFICATIONS

Item	Standard	Limit
Inner	6.9 - 7.9 kg for 27.5 mm (15.2-17.4 lb/1.08 in.)	5.9 kg for 27.5 mm (13.0 lb/1.08 in.)
Outer	15.4-17.8 kg for 31.7 mm (34.0 -39.2 lb/1.25 in.)	13.3 kg for 31.7 mm (29.3 lb/1.25 in.)


- Spring squareness

Use a square and surface plate to check each spring for squareness in terms of clearance between end of valve spring and square. Valve springs found to exhibit a larger clearance than limit given below must be replaced.

Valve spring squareness limit

Inner spring: 1.6 mm (0.063 in.)


Outer spring: 1.8 mm (0.071 in.)



IYSQ01141106

Fig. 190: Checking Spring For Squareness Use Square And Surface Plate
Courtesy of SUZUKI OF AMERICA CORP.

PISTONS, PISTON RINGS, CONNECTING RODS AND CYLINDERS COMPONENTS



11JA01140020

1. Top ring	6. Connecting rod bearing cap: Clean bearing installing surface when install.	11. Bearing cap nut
2. 2nd ring	7. Connecting rod bearing: Apply engine oil to inner surface. Clean outer surface when install	Tightening torque
3. Oil ring	8. Piston pin	Do not reuse.
4. Piston	9. Piston pin circlip	Apply engine oil.
5. Connecting rod: Clean bearing installing surface when install.	10. Cylinder block	


Fig. 191: Identifying Pistons, Piston Rings, Connecting Rods And Cylinders Components
Courtesy of SUZUKI OF AMERICA CORP.

PISTONS, PISTON RINGS, CONNECTING RODS AND CYLINDERS REMOVAL AND INSTALLATION

Removal

1. Disconnect negative (-) cable at battery.
2. Drain engine oil.

3. Drain coolant referring to "COOLANT DRAINING".
4. Remove cylinder heads. Refer to "VALVES AND CYLINDER HEADS REMOVAL AND INSTALLATION".
5. Remove oil pump. Refer to "OIL PUMP REMOVAL AND INSTALLATION".
6. Mark cylinder number on all pistons, connecting rods and connecting rod caps.
7. Remove rod bearing caps.
8. Install guide hose (1) over threads of rod bolts. This prevents damage to bearing journal and rod bolt threads when removing connecting rod.



IYSQ01143127

Fig. 192: Removing Rod Bearing Caps
Courtesy of SUZUKI OF AMERICA CORP.

9. Clean carbon from top of cylinder bore before removing piston from cylinder.
10. Push piston and connecting rod assembly out through the top of cylinder bore.

Installation

1. Apply engine oil to pistons, rings, cylinder walls, connecting rod bearings and crank pins.

NOTE: Do not apply oil between connecting rod and bearing or between bearing cap and bearing.

2. Install guide hoses (1) over connecting rod bolts. These guide hoses (1) protect crank pin and threads of rod bolt from damage during installation of connecting rod and piston assembly.



**(YSQ01141109**

Fig. 193: Identifying Connecting Rod
Courtesy of SUZUKI OF AMERICA CORP.

3. When installing piston and connecting rod assembly into cylinder bore, point mark (1) on piston head to crankshaft pulley side (2).



IYSQ01143128


Fig. 194: Identifying Point Mark On Piston Head To Crankshaft Pulley Side While Installing Piston And Connecting Rod Into Cylinder Bore
Courtesy of SUZUKI OF AMERICA CORP.

4. Install piston and connecting rod assembly into cylinder bore. Use special tool (Piston ring compressor) to compress rings. Guide connecting rod into place on crankshaft.

Using a hammer handle, tap piston head to install piston into bore. Hold ring compressor firmly against cylinder block until all piston rings have entered cylinder bore.

Special tool

(A): 09916-77310



IYSQ01141111


Fig. 195: Installing Piston And Connecting Rod Assembly Into Cylinder Bore Using Special Tool
Courtesy of SUZUKI OF AMERICA CORP.

5. Install bearing cap

Point mark (1) on cap to crankshaft pulley side (2). Tighten cap nuts to specification.

Tightening torque

Connecting rod bearing cap nut (a): 45 N.m (4.5 kg-m, 32.5 lb-ft)



IYSQ01143129

Fig. 196: Locating Point Mark On Cap To Crankshaft Pulley Side
 Courtesy of SUZUKI OF AMERICA CORP.

6. Install cylinder heads to cylinder block referring to "VALVES AND CYLINDER HEADS REMOVAL AND INSTALLATION".
7. Install oil pump to cylinder block referring to "OIL PUMP REMOVAL AND INSTALLATION".
8. Install valve lash adjusters and camshafts referring to "CAMSHAFTS AND VALVE LASH ADJUSTERS REMOVAL AND INSTALLATION".
9. Install RH bank 2nd timing chain referring to "RH (NO.2) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER INSTALLATION".
10. Install 1st timing chain. Refer to "1ST TIMING CHAIN AND CHAIN TENSIONER INSTALLATION".
11. Install LH bank 2nd timing chain. Refer to "LH (NO.1) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER INSTALLATION".
12. Install timing chain cover. Refer to "TIMING CHAIN COVER REMOVAL AND INSTALLATION".
13. Install oil pan and pump strainer. Refer to "OIL PAN AND OIL PUMP STRAINER REMOVAL AND INSTALLATION".
14. Install cylinder head cover. Refer to "CYLINDER HEAD COVERS REMOVAL AND INSTALLATION".
15. Install exhaust manifold. Refer to "EXHAUST MANIFOLD REMOVAL AND INSTALLATION".
16. Install radiator outlet pipe, radiator, cooling fan and water hose.

Refer to "**COOLING WATER PIPES OR HOSES REMOVAL AND INSTALLATION** ", "**RADIATOR REMOVAL AND INSTALLATION** " and "**COOLING FAN AND FAN CLUTCH REMOVAL AND INSTALLATION** ".

17. Install intake manifold with throttle body.

For H25 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H25 ENGINE)**".


For H27 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H27 ENGINE)**".

18. Adjust water pump drive belt tension. Refer to "**COOLING FAN / GENERATOR BELT TENSION CHECK AND ADJUSTMENT** ".
19. Adjust power steering pump drive belt tension. Refer to "**DRIVE BELT INSPECTION AND ADJUSTMENT** ".
20. Adjust accelerator cable play and A/T throttle cable play. Refer to "**ACCELERATOR CABLE ADJUSTMENT**" and to "**A/T THROTTLE CABLE ADJUSTMENT (H25 ENGINE WITH A/T ONLY)**".
21. Check to ensure that all removed parts are back in place. Reinstall any necessary parts which have not been reinstalled.
22. Refill engine with engine oil referring to "**ENGINE OIL AND FILTER CHANGE** ".
23. Refill cooling system referring to "**COOLING SYSTEM FLUSH AND REFILL** ".
24. Refill front differential housing with gear oil if drained, referring to "**FRONT DIFFERENTIAL GEAR OIL INSPECTION AND CHANGE** ".
25. Connect negative cable at battery.
26. Check ignition timing and adjust as necessary, referring to "**IGNITION TIMING CHECK AND ADJUSTMENT** ".
27. Verify that there is no fuel leakage, water leakage, oil leakage and exhaust gas leakage at each connection.
28. Check wheel alignment referring to "**FRONT ALIGNMENT INSPECTION AND ADJUSTMENT** ".

PISTONS, PISTON RINGS, CONNECTING RODS AND CYLINDERS DISASSEMBLY AND ASSEMBLY

Disassembly


1. Using piston ring expander, remove two compression rings (Top and 2nd) and oil ring from piston.
2. Remove piston pin from connecting rod.
 - a. Ease out piston pin circlips (1) as shown in the figure.



IYSQ01141113

Fig. 197: Removing Piston Pin From Connecting Rod
Courtesy of SUZUKI OF AMERICA CORP.

- b. Force piston pin out.



IYSQ01141114

Fig. 198: Forcing Piston Pin Out
Courtesy of SUZUKI OF AMERICA CORP.

Assembly

1. 2 sizes of piston are available as standard size spare part so as to ensure proper piston-to-cylinder clearance. When installing a standard size piston, make sure to match piston with cylinder as follows.
 - a. Each piston has stamped number (1 or 2) on its piston head. It represents outer diameter of piston.
 - b. There are also stamped numbers of 1 and 2 on the cylinder block as shown in the figure.
 - c. Stamped number on piston and cylinder block must correspond. That is, install number "2" stamped piston to cylinder which is stamped also number "2" and a number "1" piston to cylinder with number "1".

For H25 engine model, a letter A or B is stamped on piston head but ordinarily it is not necessary to distinguish each piston by this letter.

PISTON OUTER DIAMETER SPECIFICATIONS


	Number at the top (mark)	Outer diameter
For H27 engine model	1	87.98 - 87.99 mm (3.4638 - 3.4642 in.)
	2	87.97 - 87.98 mm (3.4634 - 3.4638 in.)
For H25 engine model	1	83.98 - 83.99 mm (3.3063 - 3.3067 in.)
	2	83.97 - 83.98 mm (3.3059 - 3.3063 in.)

CYLINDER OUTER DIAMETER SPECIFICATIONS

	Number on cylinder block (mark)	Outer diameter
For H27 engine model	1	88.01 - 88.02 mm (3.4650 - 3.4653 in.)
	2	88.00-88.01 mm (3.4646 - 3.4650 in.)
For H25 engine model	1	84.01 - 84.02 mm (3.3075 - 3.3079 in.)
	2	84.00 - 84.01 mm (3.3071 - 3.3075 in.)

Piston-to-cylinder clearance

0.02 - 0.04 mm (0.0008 - 0.0016 in.)



IYSQ01143130


[1]: No.1 cylinder	[4]: No.4 cylinder	[A]: Crankshaft pulley side
[2]: No.2 cylinder	[5]: No.5 cylinder	
[3]: No.3 cylinder	[6]: No.6 cylinder	

Fig. 199: Identifying Piston Stamped Number On Piston Head
 Courtesy of SUZUKI OF AMERICA CORP.

2. Install piston pin to piston and connecting rod:

After applying engine oil to piston pin and piston pin holes in piston (1) and connecting rod (3), fit connecting rod to piston as shown in the figure and insert piston pin to piston and connecting rod, and install piston pin circlips.

NOTE: "86F" mark on connecting rod must face toward crankshaft pulley side.




IYSQ01142152

2 Arrow mark

Fig. 200: Installing Piston Pin To Piston And Connecting Rod
Courtesy of SUZUKI OF AMERICA CORP.

NOTE:

- Install circlip with its cut part facing as shown in the figure.
- Install so that circlip end gap comes within such range as indicated by arrow "A".



I3JA01140053

1. Piston	4. Oil hole
2. Arrow mark	5. Crankshaft pulley side
3. Connecting rod	6. Circlip

Fig. 201: Identifying End Gap As Indicated By Arrow "A"

Courtesy of SUZUKI OF AMERICA CORP.

3. Install piston rings to piston:

- As shown in the figure, 1st (1) and 2nd rings (2) have "RN" or "R" mark respectively. When installing these piston rings to piston, direct marked side of each ring toward top of piston.
- 1st rings differs from 2nd ring in thickness, shape and color of surface contacting cylinder wall. Distinguish 1st ring from 2nd ring by referring to the figure.
- When installing oil ring (3), install spacer first and then 2 rails.





Fig. 202: Identifying Piston Rings
Courtesy of SUZUKI OF AMERICA CORP.

4. After installing three rings (1st, 2nd and oil rings), distribute their end gaps as shown in the figure.



IYSQ01141119

1. Mark
2. 1st ring end gap
3. 2nd ring end gap and oil ring spacer gap
4. Oil ring upper rail gap
5. Oil ring lower rail gap
6. Intake side
7. Exhaust side

Fig. 203: Identifying End Gaps Of Piston Rings
 Courtesy of SUZUKI OF AMERICA CORP.

CYLINDERS, PISTONS AND PISTON RINGS INSPECTION

NOTE: Before the following inspection, clean carbon from piston head and ring grooves, using a suitable tool.

Cylinders

- Inspect cylinder walls for scratches, roughness, or ridges which indicate excessive wear. If cylinder bore is very rough or deeply scratched, or ridged, rebore cylinder and use over size piston.
- Using a cylinder gauge, measure cylinder bore in thrust and axial directions at 2 positions (1, 2) as shown in the figure. If any of the following condition is noted, rebore cylinder.
 - Cylinder bore via. exceeds limit.

- Difference of measurements at 2 positions exceeds taper limit.
- Difference between thrust and axial measurements exceeds out-of-round limit.

Cylinder bore dia. limit

For H25 engine: 84.050 mm (3.3091 in.)

For H27 engine: 88.050 mm (3.4665 in.)

Taper and out-of-round

Limit: 0.10 mm (0.004 in.)

NOTE: If any one of six cylinders has to be rebored, rebore all six to the same oversize. This is necessary for the sake of uniformity and balance.




Fig. 204: Measuring Cylinder Bore In Thrust And Axial Directions At 2 Positions Using Cylinder Gauge

Courtesy of SUZUKI OF AMERICA CORP.


Pistons

- Inspect piston for faults, cracks or other damages. Damaged or faulty piston should be replaced.
- Piston diameter:

As shown in the figure, piston diameter should be measured at a position 26.5 mm (1.04 in.) ("a") from piston skirt end in the direction perpendicular to piston pin.

PISTON DIAMETER SPECIFICATIONS

	Standard	Oversize 0.50 mm (0.0196 in.)
For H25 Engine	83.970 - 83.990 mm (3.3059 - 3.3067 in.)	84.470 - 84.490 mm (3.3256 - 3.3264 in.)
For H27 engine	87.970 - 87.990 mm (3.4634 - 3.4642 in.)	88.470 - 88.490 mm (3.4831 - 3.4839 in.)



IYSQ01141121

"a": 26.5 mm (1.04 in.)

Fig. 205: Measuring Piston Diameter
Courtesy of SUZUKI OF AMERICA CORP.

- Piston clearance:

Measure cylinder bore diameter and piston diameter to find their difference which is piston clearance. Piston clearance should be within specification as given below. If it is out of specification, rebore cylinder and use oversize piston.

Piston-to-cylinder clearance

0.02 - 0.04 mm (0.0008 - 0.0015 in.)

NOTE: Cylinder bore diameter should be measured in 2 places 90 degrees apart.




Fig. 206: Measuring Cylinder Bore Diameter And Piston Diameter
Courtesy of SUZUKI OF AMERICA CORP.

- Ring groove clearance:


Before checking, piston grooves must be clean, dry and free of carbon.

Fit new piston ring (1) into piston groove, and measure clearance between ring and ring land by using thickness gauge (2). If clearance is out of specification, replace piston.

Ring groove clearance

Top: 0.03 - 0.07 mm (0.0012 - 0.0027 in.)

2nd: 0.02 - 0.06 mm (0.0008 - 0.0023 in.)



IYSQ01141123

Fig. 207: Measuring Ring Groove Clearance Using Thickness Gauge
 Courtesy of SUZUKI OF AMERICA CORP.


Piston Rings

To measure end gap, insert piston ring into cylinder bore and then measure the gap by using thickness gauge. If measure gap is out of specification, replace ring.

NOTE: Clean carbon and any other dirt from top of cylinder bore before inserting piston ring.

PISTON RING END GAP SPECIFICATIONS

Engine Type	Item	Standard	Limit
H27 engine	Top ring	0.20 - 0.35 mm (0.0079-0.0138 in.)	0.7 mm (0.0276 in.)
	2nd ring	0.35 - 0.47 mm (0.0138-0.0197 in.)	0.7 mm (0.0276 in.)
	Oil ring	0.20 - 0.70 mm (0.0079 - 0.0276 in.)	1.8 mm (0.0709 in.)
H25 engine	Top ring	0.20 - 0.35 mm (0.0079-0.0138 in.)	0.7 mm (0.0276 in.)
	2nd ring	0.35 - 0.50 mm (0.0138-0.0197 in.)	0.7 mm (0.0276 in.)
	Oil ring	0.20 - 0.70 mm (0.0079 - 0.0276 in.)	1.8 mm (0.0709 in.)



IYSQ01141124

1. Cylinder block	3. Piston ring
2. Feeler gauge	4. 120 mm (4.72 in.)

Fig. 208: Measuring End Gap, Insert Piston Ring Into Cylinder Bore Using Thickness Gauge
Courtesy of SUZUKI OF AMERICA CORP.

PISTON PINS AND CONNECTING RODS INSPECTION

Piston Pins

- Check piston pin, connecting rod small end bore and piston bore for wear or damage, paying particular attention to condition of small end bore bush. If pin, connecting rod small end bore or piston bore is badly worn or damaged, replace pin, connecting rod or piston.
- Piston pin clearance:

Check piston pin clearance in small end. Replace connecting rod if its small end is badly worn or

damaged or if measured clearance exceeds limit.

Piston pin clearance in small end


0.003 - 0.014 mm (0.0001 - 0.0006 in.)

Small-end bore

21.003 - 21.011 mm (0.8269 - 0.8272 in.)

Piston pin diameter

20.997 - 21.000 mm (0.8267 - 0.8268 in.)



ISJA01140020

Fig. 209: Checking Piston Pin Clearance In Small End
Courtesy of SUZUKI OF AMERICA CORP.

Connecting Rods


- Big-end side clearance:

Check big-end of connecting rod for side clearance, with rod fitted and connected to its crank pin in the normal manner. If measured clearance is found to exceed its limit, replace connecting rod.

Big-end side clearance

Standard: 0.25 - 0.35 mm (0.0098 - 0.0138 in.)

Limit: 0.45 mm (0.0177 in.)



IYSQ01143135

Fig. 210: Checking Big-End Side Clearance
Courtesy of SUZUKI OF AMERICA CORP.

- Connecting rod alignment:

Mount connecting rod on aligner to check it for bow and twist. If limit is exceeded, replace it.

Connecting rod alignment

Limit on bow: 0.05 mm (0.0020 in.)

Limit on twist: 0.10 mm (0.0039 in.)

CRANK PINS AND CONNECTING ROD BEARINGS INSPECTION

- Inspect crank pin for uneven wear or damage. Measure crank pin for out-of-round or taper with a

micrometer. If crank pin is damaged, or out-of-round or taper is out of limit, replace crankshaft or regrind crank pin then inspect rod bearing clearance referring to "Rod bearing clearance".

CRANK PIN DIAMETER SPECIFICATIONS

Connecting rod bearing size	Crank pin diameter
Standard	49.982 - 50.000 mm (1.9678-1.9685 in.)
0.25 mm (0.0098 in.) undersize	49.732 - 49.750 mm (1.9580-1.9587 in.)

Crank pin out-of-round (a - b)

Limit: 0.01 mm (0.0004 in.)

Crank pin taper (c - d)

Limit: 0.01 mm (0.0004 in.)





Fig. 211: Measuring Crank Pin For Out-Of-Round Or Taper With Micrometer
Courtesy of SUZUKI OF AMERICA CORP.

- **Connecting rod bearing general information:**

Service connecting rod bearings are available in standard size and 0.25 mm (0.0098 in.) undersize, and standard size bearing has 5 kinds of bearings differing in tolerance. For identification of undersize bearing, it is painted red at the position as indicated in figure, undersize bearing thickness is 1.605 -1.615 mm (0.0632 - 0.0635 in.) at the center of it.



IYSQ01141169

1. Painting


Fig. 212: Identifying Connecting Rod Bearings
Courtesy of SUZUKI OF AMERICA CORP.

- **Connecting rod bearing visual inspection:**

Inspect bearing shells for signs of fusion, pitting, burn or flaking and observe contact pattern. Bearing shells found in defective condition must be replaced.

- **Connecting rod bearing clearance:**

- a. Before checking bearing clearance, clean bearing and crank pin.
- b. install bearing in connecting rod and bearing cap.
- c. Place a piece of gaging plastic (1) to full width of crank pin as contacted by bearing (parallel to crankshaft), avoiding oil hole.



IYSQ01143137

Fig. 213: Identifying Crank Pin

Courtesy of SUZUKI OF AMERICA CORP.


- d. Install rod bearing cap to connecting rod.

When installing cap, be sure to point arrow mark on cap to crankshaft pulley side, as shown in the figure. After applying engine oil to rod bolts, tighten cap nuts to specified torque.

Tightening torque

Connecting rod bearing cap nut (a): 45 N.m (4.5 kg-m, 32.5 lb-ft)

NOTE: DO NOT turn crankshaft with gaging plastic installed.



I3JA01140064

Fig. 214: Installing Rod Bearing Cap To Connecting Rod
Courtesy of SUZUKI OF AMERICA CORP.


- e. Remove cap and using a scale (2) on gaging plastic (1) envelope, measure gaging plastic (1) width at the widest point (clearance). If clearance exceed its limit, use a new standard size bearing referring to "Selection of Connecting Rod Bearings" in this section.

After selecting new bearing, recheck clearance.

Bearing clearance

Standard: 0.045 - 0.063 mm (0.0018 - 0.0024 in.)

Limit: 0.08 mm (0.0031 in.)



I3JA01140065

Fig. 215: Measuring Gaging Plastic Width At Widest Point
 Courtesy of SUZUKI OF AMERICA CORP.

- f. If clearance can not be brought to within its limit even by using a new standard size bearing, regrind crankpin to undersize and use 0.25 mm undersize bearing as follows.
 - i. Install 0.25 mm undersize bearing to connecting rod big end.
 - ii. Measure bore diameter of connecting rod big end.
 - iii. Regrind crank pin to following finished diameter:

Measured big end

Finished crank pin dia. = Measured big end bore dia. (including - under-size bearing) - 0.054 mm (0.0021 in.)

- iv. Confirm that bearing clearance is within above standard value.

• **Selection of connecting rod bearings:**

NOTE:

- If bearing is in malcondition, or bearing clearance is out of

specification, select a new standard bearing according to the following procedure and install it.

- **When replacing crankshaft or connecting rod and its bearing due to any reason, select new standard bearings to be installed by referring to numbers stamped on connecting rod and its cap and/or alphabets stamped on crank web No.3.**


- a. Check stamped numbers on connecting rod and its cap as shown.

Three kinds of numbers ("1", "2" and "3") represent the following connecting rod big end inside diameters.

For example, stamped number "1" indicates that corresponding connecting rod big end inside diameter is 53.0000 - 53.0060 mm (2.0867 - 2.0868 in.).

CONNECTING ROD BIG END INSIDE DIAMETER SPECIFICATIONS

Stamped numbers	connecting rod big end inside diameter
1	53.0000 - 53.0060 mm (2.0867 - 2.0868 in.)
2	53.0061 - 53.0120 mm (2.0869 - 2.0870 in.)
3	53.0121 - 53.0180 mm (2.0871 - 2.0873 in.)



[A]: Weight indication mark

[B]: Connecting rod big end inside diameter number

Fig. 216: Checking Stamped Numbers On Connecting Rod
Courtesy of SUZUKI OF AMERICA CORP.

- b. Next, check crankshaft pin diameter. On crank web No.3, six alphabets are stamped as shown in figure.


Three kinds of alphabet ("A", "B" and "C") represent the following crankshaft pin diameter respectively.

For example, stamped "A" indicates that corresponding crankshaft pin diameter is 49.9940 -

50.0000 mm (1.9683 -1.9685 in.).

CRANKSHAFT PIN DIAMETER SPECIFICATIONS

Stamped alphabet	Crankshaft pin diameter
A	49.9940 - 50.0000 mm (1.9683-1.9685 in.)
B	49.9880 - 49.9939 mm (1.9681 -1.9682 in.)
C	49.9820 - 49.9879 mm (1.9677-1.9680 in.)



I3JA01140067

[A]:	Crankshaft pin diameter for No.1 cylinder
[B]:	Crankshaft pin diameter for No.2 cylinder
[C]:	Crankshaft pin diameter for No.3 cylinder
[D]:	Crankshaft pin diameter for No.4 cylinder
[E]:	Crankshaft pin diameter for No.5 cylinder
[F]:	Crankshaft pin diameter for No.6 cylinder
[G]:	Crank main shaft outside diameter tolerance mark

Fig. 217: Checking Crankshaft Pin Diameter On Crank Web
 Courtesy of SUZUKI OF AMERICA CORP.


- c. There are five kinds of standard bearings differing in thickness. To distinguish them, they are painted in the following colors at the position as indicated in figure.

Each color indicated the following thickness at the center of bearing.

Standard size of connecting rod bearing thickness

STANDARD SIZE OF CONNECTING ROD BEARING THICKNESS SPECIFICATIONS

Color painted	Bearing thickness
Blue	1.494-1.497 mm (0.05882 - 0.05893 in.)
Yellow	1.491 -1.494 mm (0.05871 - 0.05881 in.)
Nothing	1.488-1.491 mm (0.05859 - 0.05870 in.)
Black	1.485-1.488 mm (0.05847 - 0.05858 in.)
Green	1.482 -1.485 mm (0.05835 - 0.05846 in.)



IYSQ01141169

1. Paint

Fig. 218: Identifying Big And Bearing Lip
 Courtesy of SUZUKI OF AMERICA CORP.

- d. From number stamped on connecting rod and its cap and alphabets stamped on crank web No.3, determine new standard bearing to be installed to connecting rod big end inside, by referring to table.

For example, if number stamped on connecting rod and its cap is "1" and alphabet stamped on crank web No.3 is "B", install a new standard bearing painted in "Black" to its connecting rod big end inside.

NEW STANDARD CONNECTING ROD BEARING SIZE SPECIFICATION

		Number stamped on connecting rod and its cap (connecting rod big end inside diameter)		
		1	2	3
Alphabet stamped on crank web No.3 (Crankshaft pin outer diameter)	A	Green	Black	Nothing
	B	Black	Nothing	Yellow
	C	Nothing	Yellow	Blue
		New standard bearing to be installed.		

- e. Check bearing clearance with newly selected standard bearing referring to "Selection of Connecting Rod Bearing" in this section.


If clearance still exceeds its limit, use next thicker bearing and recheck clearance.

ENGINE ASSEMBLY REMOVAL AND INSTALLATION


Removal

1. Release fuel pressure in fuel feed line referring to "**FUEL PRESSURE RELIEF PROCEDURE**".
2. Disconnect negative (-) cable at battery.
3. Remove engine hood.
4. Drain engine oil.
5. Drain coolant referring to "**COOLANT DRAINING**".
6. Remove radiator, radiator fan shroud, cooling fan and radiator reservoir. Refer to "**COOLING FAN AND FAN CLUTCH REMOVAL AND INSTALLATION**" and "**RADIATOR REMOVAL AND INSTALLATION**".
7. Disconnect accelerator cable (1) and A/T throttle cable (2) (for H25 Engine with A/T) from throttle body.

[A]



[B]



I5JA01140021

[A]: H25 engine

[B]: H27 engine


Fig. 219: Disconnecting Accelerator Cable And A/T Throttle Cable From Throttle Body
Courtesy of SUZUKI OF AMERICA CORP.

8. Detach fuse/relay box, then remove strut tower bar and surge tank cover.
9. Disconnect IAT sensor coupler and MAF sensor coupler (for H27 engine) then remove air cleaner upper


case, intake air hose, intake air pipe and surge tank pipe as a component.

10. Remove intake control valve (for H27 engine), referring to "**THROTTLE BODY REMOVAL AND INSTALLATION (H27 ENGINE)**".
11. Remove engine oil level gauge guide and A/T fluid level gauge guide (for A/T vehicle).
12. Remove ignition coil covers.
13. Disconnect the following electric lead wires:
 - Injector wire coupler
 - CMP sensor coupler
 - Ignition coil couplers
 - CKP sensor coupler
 - MAP sensor coupler
 - MAF sensor (8) coupler for H25 engine
 - TP sensor (1) coupler
 - IAC valve (2) coupler
 - Earth wire (3) from surge tank
 - EVAP canister purge valve (5) coupler
 - EGR valve (6) coupler
 - Oxygen sensor-1 and -2 couplers (Refer to "**EXHAUST MANIFOLD REMOVAL AND INSTALLATION**".)
 - Coolant temperature sensor coupler
 - Knock sensor coupler for H27 engine
 - Generator wires
 - Starter wires
 - Oil pressure wire
 - P/S pump wire
 - Earth wire from generator bracket
 - Engine block heater (if equipped)
14. Remove clamps and brackets (4).
15. Disconnect the following hoses:
 - Heater hose (7) from heater water pipe and water outlet cap
 - Tank pressure control solenoid valve hose from intake manifold
 - EVAP canister hose from canister purge pipe
 - Brake booster vacuum hose
16. Remove EVAP canister purge valve (5).
17. For H25 engine, remove IAC valve (2).

[A]



[B]



15JA01140022


[A]: H25 engine

[B]: H27 engine

Fig. 220: Identifying Couplers, Sensors, Wires And Hoses
 Courtesy of SUZUKI OF AMERICA CORP.

18. Disconnect the following hoses at the location shown in the figure:
 - Fuel feed hose (1) from fuel feed pipe

- Fuel return hose (2) from fuel return pipe



IYSQ01143141


Fig. 221: Disconnecting Fuel Feed Hose And Fuel Return Hose
Courtesy of SUZUKI OF AMERICA CORP.

19. Remove P/S pump assembly referring to "**P/S PUMP REMOVAL AND INSTALLATION**".
20. Remove A/C compressor assembly.

For H25 engine model, refer to "**COMPRESSOR ASSEMBLY REMOVAL AND INSTALLATION FOR H25 ENGINE MODEL**". For H27 engine model, refer to "**COMPRESSOR ASSEMBLY REMOVAL AND INSTALLATION FOR H27 ENGINE MODEL**".

21. Remove steering shaft lower assembly referring to "**STEERING LOWER SHAFT ASSEMBLY REMOVAL AND INSTALLATION**".
22. Raise vehicle.
23. Remove front differential housing with differential from chassis if equipped. Refer to "**FRONT DIFFERENTIAL DISMOUNTING AND REMOUNTING**" and "**FRONT DIFFERENTIAL DISMOUNTING AND REMOUNTING**".
24. Remove exhaust No.1 pipe referring to "**EXHAUST MANIFOLD REMOVAL AND INSTALLATION**".
25. Remove exhaust manifold stiffener from transmission.

26. Remove A/T fluid hose clamps (1) from engine mounting bracket (2). (for A/T vehicle)




IYSQ01143142

Fig. 222: Removing A/T Fluid Hose Clamps From Engine Mounting Bracket
Courtesy of SUZUKI OF AMERICA CORP.

- 27. Remove clutch housing lower plate.
- 28. Remove torque converter bolts (for A/T vehicle).
- 29. Remove starter motor.
- 30. Lower vehicle.
- 31. Support transmission.

CAUTION: Do not support A/T by placing a jacking equipment under oil pan. If may damage to A/T.


- 32. Remove bolts and nuts fastening cylinder block and transmission.



IYSQ01143143

Fig. 223: Removing Bolts And Nuts Fastening Cylinder Block And Transmission
Courtesy of SUZUKI OF AMERICA CORP.

33. Install lifting device.
34. Disconnect engine side mounting brackets (1) from engine mountings (2) by removing nuts (3).



I3JA01140056

Fig. 224: Identifying Engine Side Mounting Brackets From Engine Mountings By Removing Nuts
Courtesy of SUZUKI OF AMERICA CORP.

35. Before lifting engine, check to ensure all hoses, wires and cables are disconnected from engine.
36. Remove engine assembly from chassis and transmission by sliding toward front, and then, carefully hoist engine assembly.

Installation

Reverse removal procedure for installation noting the following points.

- Tighten engine side mounting bracket nuts to specified torque.

Tightening torque

Engine side mounting bracket nut (a): 55 N.m (5.5 kg-m, 40.0 lb-ft)





Fig. 225: Tightening Engine Side Mounting Bracket Nuts
Courtesy of SUZUKI OF AMERICA CORP.

- Tighten transmission case bolts and nuts to specified torque.

Tightening torque

Transmission case bolt and nut (b): 85 N.m (8.5 kg-m, 61.5 lb-ft) (for M/T vehicle)

Transmission case bolt and nut (b): 80 N.m (8.0 kg-m, 58.0 lb-ft) (for A/T vehicle)



IYSQ01143146


1. Bolt (short)
2. Bolt (Long)

Fig. 226: Installing Transmission Case Bolts And Nuts
Courtesy of SUZUKI OF AMERICA CORP.

- Tighten torque converter bolts to specified torque (for A/T vehicle).

Tightening torque

Torque converter bolt (c): 65 N.m (6.5 kg-m, 47.0 lb-ft)




IYSQ01143147

Fig. 227: Tightening Torque Converter Bolts
Courtesy of SUZUKI OF AMERICA CORP.

- Tighten bolts and nuts of exhaust No.1 pipe (1) to specified torque.

Tightening torque

Exhaust No.1 pipe bolt and nut (d): 50 N.m (5.0 kg-m, 36.5 lb-ft)



I5JA01140023

Fig. 228: Tightening Exhaust Pipe Bolt And Nut
Courtesy of SUZUKI OF AMERICA CORP.

- Install front differential housing with differential to chassis referring to "**FRONT DIFFERENTIAL DISMOUNTING AND REMOUNTING**" and "**FRONT DIFFERENTIAL DISMOUNTING AND REMOUNTING**", if necessary.


- Install steering shaft lower assembly referring to "**STEERING LOWER SHAFT ASSEMBLY REMOVAL AND INSTALLATION**".
- Install A/C compressor assembly.

For H25 engine model, refer to "**COMPRESSOR ASSEMBLY REMOVAL AND INSTALLATION FOR H25 ENGINE MODEL**".

For H25 engine model, refer to "**COMPRESSOR ASSEMBLY REMOVAL AND INSTALLATION FOR H27 ENGINE MODEL**".

- Install P/S pump assembly referring to "**P/S PUMP REMOVAL AND INSTALLATION**".
- Adjust accelerator cable play and A/T throttle cable play (for H25 engine with A/T) referring to "**ACCELERATOR CABLE ADJUSTMENT**" and to "**A/T THROTTLE CABLE ADJUSTMENT (H25 ENGINE WITH A/T ONLY)**".
- Refill engine with engine oil referring to "**ENGINE OIL AND FILTER CHANGE**".
- Refill cooling system referring to "**COOLING SYSTEM FLUSH AND REFILL**".
- Check to ensure that all fasteners and clamps are tightened.
- Upon completion of installation, verify that there is no fuel leakage, coolant leakage, P/S fluid leakage or exhaust gas leakage at each connection.

MAIN BEARINGS, CRANKSHAFT AND CYLINDER BLOCK COMPONENTS



I4JA01140025

1. Cylinder block	8. Water pump	[A]: Sealant application amount
2. Lower crankcase: Apply sealant 99000-31250 to lower crankcase mating surface.	9. O-ring	*a*: Width 3 mm (0.12 in.)
3. Crankshaft: Apply engine oil to crankshaft journals.	10. Timing chain oil jet	*b*: Height 2 mm (0.08 in.)
4. Main bearing: Apply engine oil to bearing inside surfaces.	11. O-ring	Tightening torque
5. Thrust bearing: Set bearing facing grooved side to crank weds. Apply engine oil.	12. Clutch housing plate	Do not reuse.
6. Rear oil seal: Apply engine oil to contact part of crankshaft with oil seal lip.	13. Crankcase bolt (10 mm (0.39 in.) thread diameter): Tighten 42 N-m (4.2 kg-m, 30.5 lb-ft), 0 N-m (0 kg-m, 0 lb-ft), 42 N-m (4.2 kg-m, 30.5 lb-ft) and 60 N-m (6.0 kg-m, 43.5 lb-ft) by the specified procedure.	Apply engine oil.
7. Flywheel (M/T), Drive plate (A/T)	14. Crankcase bolt (8 mm (0.31 in.) thread diameter): Tighten 27 N-m (2.7 kg-m, 19.5 lb-ft) by the specified procedure.	

Fig. 229: Identifying Main Bearings, Crankshaft And Cylinder Block Components
Courtesy of SUZUKI OF AMERICA CORP.


MAIN BEARINGS, CRANKSHAFT AND CYLINDER BLOCK REMOVAL AND INSTALLATION**Removal**

1. Remove engine assembly from vehicle referring to "**ENGINE ASSEMBLY REMOVAL AND INSTALLATION**".
2. Remove clutch and flywheel (for M/T vehicle) or drive plate (for A/T vehicle). For clutch removal, refer to "**CLUTCH COVER, CLUTCH DISC AND FLYWHEEL REMOVAL AND INSTALLATION**".

Using special tool (flywheel holder), remove flywheel (M/T vehicle) or drive plate (A/T vehicle).

Special tool

(A): 09924-17811



IYSQ01143150


1. Flywheel bolt

Fig. 230: Removing Flywheel (M/T Vehicle) Or Drive Plate (A/T Vehicle) Using Special Tool
Courtesy of SUZUKI OF AMERICA CORP.

3. Remove throttle body with intake manifold and exhaust manifold referring to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H25 ENGINE)**" or "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H27 ENGINE)**" and "**EXHAUST MANIFOLD REMOVAL AND INSTALLATION**".

4. Remove oil pans (lower and upper) and oil pump strainer. Refer to "**OIL PAN AND OIL PUMP STRAINER REMOVAL AND INSTALLATION**".
5. Remove cylinder head cover referring to "**CYLINDER HEAD COVERS REMOVAL AND INSTALLATION**".
6. Remove timing chain cover. Refer to "**TIMING CHAIN COVER REMOVAL AND INSTALLATION**".
7. Remove LH bank 2nd timing chain and tensioner referring to "**LH (NO.1) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER REMOVAL**".
8. Remove 1st timing chain and tensioner referring to "**1ST TIMING CHAIN AND CHAIN TENSIONER REMOVAL**".
9. Remove RH bank 2nd timing chain and tensioner referring to "**RH (NO.2) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER REMOVAL**".
10. Remove cylinder head assembly referring to "**VALVES AND CYLINDER HEADS REMOVAL AND INSTALLATION**".
11. Remove pistons and connecting rods referring to "Pistons, Piston Rings, Connecting Rods and Cylinders Removal and Installation:".
12. Remove oil pump referring to "**OIL PUMP REMOVAL AND INSTALLATION**".
13. Remove oil pump chain referring to "**OIL PUMP CHAIN REMOVAL AND INSTALLATION**".
14. Loosen crankcase bolts, following sequence in figure and remove them.

NOTE: Loosen 8 mm (0.31 in.) thread diameter bolts first, then loosen 10 mm (0.39 in.) thread diameter bolts following the order shown in the figure.



IYSQ01143151

1. Lower crankcase
2. Bolt (10 mm (0.39 in.) thread diameter)
3. Bolt (8 mm (0.31 in.) thread diameter)

Fig. 231: Identifying Crankcase Bolts

Courtesy of SUZUKI OF AMERICA CORP.

15. Remove crankshaft from cylinder block.


Installation**NOTE:**

- All parts to be installed must be perfectly clean.
- Be sure to oil crankshaft journals, journal bearings, thrust bearings, crank pins, connecting rod bearings, pistons, piston rings and cylinder bores.
- Journal bearings, crankcase (bearings caps), connecting rods, rod bearings, rod bearing caps, pistons and piston rings are in combination sets. Do not disturb combination and try to see that each part goes back to where it came from, when installing.
- Clean mating surface of cylinder block and crankcase, remove oil, old sealant and dust from mating surface.

1. Fit main bearings (4) to cylinder block (1).

One of two halves of main bearing, has oil groove (3). Install this half with oil groove to cylinder block, and another half without oil groove to crankcase. Make sure that two halves are painted in the same color.

2. Install O-ring (2) to cylinder block.




I2JA01143002

5. Knock pin

Fig. 232: Installing O-Ring And Main Bearings To Cylinder Block
Courtesy of SUZUKI OF AMERICA CORP.

3. Fit thrust bearings (1) to cylinder block between No.2 and No.3 cylinders.

Face oil groove (2) sides to crank webs.




IYSQ01143153

Fig. 233: Fitting Thrust Bearings To Cylinder Block Between No.2 And No.3 Cylinders
Courtesy of SUZUKI OF AMERICA CORP.

4. Put crankshaft to cylinder block.
5. Apply sealant "A" to crankcase mating surface area as shown in the figure.

"A": Water tight sealant 99000-31250



I4JA01140026

[A]. Sealant application amount	1. Lower crankcase
"a": 2 mm (0.08 in.)	2. Bearing
"b": 3 mm (0.12 in.)	

Fig. 234: Applying Sealant "A" To Crankcase Mating Surface Area
 Courtesy of SUZUKI OF AMERICA CORP.

6. Install crankcase to cylinder block. Apply oil to crankcase bolts before installing them. Tighten crankcase bolts gradually as follows.
 - a. Tighten crankcase bolts (10 mm (0.39 in.) thread diameter) to 42 N.m (4.2 kg-m, 30.5 lb-ft) according to numerical order in figure.
 - b. Loosen all bolts until tightening torque is reduced to 0 in reverse order of tightening.
 - c. In the same manner as Step a), tighten them to 42 N.m (4.2 kg-m, 30.5 lb-ft).
 - d. In the same manner as Step a) again, tighten them to specified torque.
 - e. Tighten crankcase bolts (8 mm (0.31 in.) thread diameter) to specified torque.


NOTE: Tighten 10 mm (0.39 in.) thread diameter bolts first (the following the order shown in figure), then tighten 8 mm (0.31 in.) thread diameter bolts.

Tightening torque

Crankcase bolt (a): Tighten 42 N.m (4.2 kg-m, 30.5 lb-ft), 0 N.m (0 kg-m, 0 lb-ft), 42 N.m (4.2 kg-m, 30.5 lb-ft) and 60 N.m (6.0 kg-m, 43.5 lb-ft) by the specified procedure (10 mm (0.39 in.) thread diameter)

Crankcase bolt (b): Tighten 27 N.m (2.7 kg-m, 19.5 lb-ft) by the specified procedure (8 mm (0.31 in.) thread diameter)

NOTE: After tightening crankcase bolts, check to be sure that crankshaft rotates smoothly when turned by hand.



IYSQ01143155

1. Lower crankcase	3. Bolt (8 mm (0.31 in.) thread diameter)
2. Bolt (10 mm (0.39 in.) thread diameter)	4. Long bolt (8 mm (0.31 in.) thread diameter)

Fig. 235: Identifying Crankcase Bolts
Courtesy of SUZUKI OF AMERICA CORP.

7. Using special tools (Oil seal installer and oil seal guide), install rear oil seal (1).

Special tool

(A): 09911-97710

(B): 09911-97811




Fig. 236: Installing Rear Oil Seal Using Special Tools
 Courtesy of SUZUKI OF AMERICA CORP.

8. Install flywheel (M/T vehicle) or drive plate (A/T vehicle). Using special tool, lock flywheel or drive plate, and tighten flywheel or drive plate bolts to specification.

"A": Sealant 99000-31110

Special tool

(A): 09924-17811

Tightening torque

Flywheel (or drive plate) bolt (c): 70 N.m (7.0 kg-m, 51.0 lb-ft)




Fig. 237: Installing Flywheel Or Drive Plate Bolts
 Courtesy of SUZUKI OF AMERICA CORP.

9. Install oil pump referring to "**OIL PUMP REMOVAL AND INSTALLATION**".
10. Install pistons and connecting rods referring to "**PISTONS, PISTON RINGS, CONNECTING RODS AND CYLINDERS REMOVAL AND INSTALLATION**".
11. Install oil pump strainer and oil pan referring to "**OIL PAN AND OIL PUMP STRAINER REMOVAL AND INSTALLATION**".
12. Install cylinder heads assembly to cylinder block referring to "**VALVES AND CYLINDER HEADS REMOVAL AND INSTALLATION**".
13. Install oil pump chain referring to "**OIL PUMP CHAIN REMOVAL AND INSTALLATION**".
14. Install RH bank 2nd timing chain and tensioner referring to "**RH (NO.2) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER INSTALLATION**".
15. Install 1st timing chain and tensioner referring to "**1ST TIMING CHAIN AND CHAIN TENSIONER INSTALLATION**".
16. Install LH bank 2nd timing chain and tensioner referring to "**LH (NO.1) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER INSTALLATION**".
17. Install timing chain cover and crankshaft pulley referring to "**TIMING CHAIN COVER REMOVAL AND INSTALLATION**".

18. Install cylinder head covers referring to "**CYLINDER HEAD COVERS REMOVAL AND INSTALLATION**".
19. Install exhaust manifold referring to "**EXHAUST MANIFOLD REMOVAL AND INSTALLATION**".
20. Install intake manifold with throttle body.

For H25 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H25 ENGINE)**".

For H27 engine model, refer to "**THROTTLE BODY AND INTAKE MANIFOLD REMOVAL AND INSTALLATION (H27 ENGINE)**".

21. Install clutch to flywheel (for M/T vehicle). For clutch installation, refer to "**CLUTCH COVER, CLUTCH DISC AND FLYWHEEL REMOVAL AND INSTALLATION**".
22. Install engine assembly to vehicle referring to "**ENGINE ASSEMBLY REMOVAL AND INSTALLATION**".


CRANKSHAFT INSPECTION

Crankshaft Runout

Using a dial gauge, measure runout at center journal. Rotate crankshaft slowly. If runout exceeds its limit, replace crankshaft.

Crankshaft runout

Limit: 0.06 mm (0.0023 in.)



IYSQ01143158

Fig. 238: Measuring Runout At Center Journal Using Dial Gauge
Courtesy of SUZUKI OF AMERICA CORP.

Crankshaft Thrust Play

Measure this play with crankshaft set in cylinder block in the normal manner, that is, with thrust bearing and journal bearing caps installed. Tighten crankcase bolts gradually as follows.

1. Tighten crankcase bolts (10 mm (0.39 in.) thread diameter) to 42 N.m (4.2 kg-m, 30.5 lb-ft) according to numerical order in figure.
2. Loosen all bolts until tightening torque is reduced to 0 in reverse order of tightening.
3. In the same manner as Step a), tighten them to 42 N.m (4.2 kg-m, 30.5 lb-ft).
4. In the same manner as Step a) again tighten them to specified torque.
5. Tighten crankcase bolts (8 mm (0.31 in.) thread diameter) to specified torque.


NOTE: Tighten 10 mm (0.394 in.) thread diameter bolts first (following the order shown in figure), then tighten 8 mm (0.315 in.) thread diameter bolts.

Tightening torque

Crankcase bolt (a): Tighten 42 N.m (4.2 kg-m, 30.5 lb-ft), 0 N.m (0 kg-m, 0 lb-ft), 42 N.m (4.2 kg-m, 30.5 lb-ft) and 60 N.m (6.0 kg-m, 43.5 lb-ft) by the specified procedure (10 mm (0.39 in.) thread diameter)

Crankcase bolt (b): Tighten 27 N.m (2.7 kg-m, 19.5 lb-ft) by the specified procedure (8 mm (0.31

in.) thread diameter)



IYSQ01143159

1. Lower crankcase	3. Bolt (8 mm (0.31 in.) thread diameter)
2. Bolt (10 mm (0.39 in.) thread diameter)	4. Long bolt (8 mm (0.31 in.) thread diameter)

Fig. 239: Identifying Crankcase Bolts

Courtesy of SUZUKI OF AMERICA CORP.


Use a dial gauge to read displacement in axial (thrust) direction of crankshaft.

If its limit is exceeded, replace thrust bearing with new standard one or oversize one to obtain standard thrust play.

Crankshaft thrust play

Standard: 0.1 - 0.35 mm (0.0039 - 0.0138 in.)

Limit: 0.38 mm (0.0150 in.)




IYSQ01143160

Fig. 240: Using Dial Gauge To Read Displacement In Axial (Thrust) Direction Of Crankshaft
Courtesy of SUZUKI OF AMERICA CORP.

Thickness of crankshaft thrust bearing

Standard: 2.500 mm (0.984 in.)

Oversize (0.125 mm (0.0049 in.)): 2.563 mm (0.1009 in.)



IYSQ01143153

1. Thrust bearing
2. Oil groove

Fig. 241: Measuring Thickness Of Crankshaft Thrust Bearing**Courtesy of SUZUKI OF AMERICA CORP.****Out-of-Round and Taper (Uneven Wear) of Journals**

An unevenly worn crankshaft journal shows up as a difference in diameter at a cross section or along its length (or both). This difference, if any, is determined by taking micrometer readings. If any one of journals is badly damaged or if amount of uneven wear in the sense explained above exceeds its limit, regrind or replace crankshaft.

Crank journal out-of-round (a - b) and taper (c - d)**Limit: 0.01 mm (0.0004 in.)**





Fig. 242: Measuring Difference Between Crank Journal Out-Of-Round (A - B) And Taper (C - D)
Courtesy of SUZUKI OF AMERICA CORP.

MAIN BEARINGS INSPECTION

NOTE: Before inspecting main bearings, note the following points.

- Service main bearings are available in standard size and 0.25 mm (0.0098 in.) undersize, and each of them has 5 kinds of bearings differing in tolerance.
- Upper half of bearing (1) has oil groove (2) as shown in the figure. Install this half with oil groove toward cylinder block.



IYSQ01143162

Fig. 243: Identifying Upper Half Of Bearing
Courtesy of SUZUKI OF AMERICA CORP.

- Lower half of bearing does not have oil groove.


Visual Inspection

Check bearings for pitting, scratches, wear or damage. If any malcondition is found, replace both upper and lower halves. Never replace either half without replacing the other half.

Main Bearing Clearance

Check clearance by using gauging plastic (1) according to the following procedure.

1. Remove crankcase.
2. Clean bearings and main journals.
3. Place a piece of gauging plastic (1) to full width of bearing (parallel to crankshaft) on journal, avoiding oil hole.



IYSQ01143163

Fig. 244: Checking Main Bearing Clearance By Using Gauging Plastic
 Courtesy of SUZUKI OF AMERICA CORP.

4. Install crankcase to cylinder block.

Tighten crankcase bolts, gradually as follows.

- a. Tighten crankcase bolts (10 mm (0.39 in.) thread diameter) to 42 N.m (4.2 kg-m, 30.5 lb-ft) according to numerical order in figure.
- b. Loosen all bolts until tightening torque is reduced to 0 in reverse order of tightening.
- c. In the same manner as Step a), tighten them to 42 N.m (4.2 kg-m, 30.5 lb-ft).
- d. In the same manner as Step a) again, tighten them to specified torque.
- e. Tighten crankcase bolts (8 mm (0.31 in.) thread diameter) to specified torque.


NOTE: Tighten 10 mm (0.394 in.) thread diameter bolts first (following the order shown in the figure) then tighten 8 mm (0.315 in.) thread diameter bolts.

Tightening torque

Crankcase bolt (a): Tighten 42 N.m (4.2 kg-m, 30.5 lb-ft), 0 N.m (0 kg-m, 0 lb-ft), 42 N.m (4.2 kg-m, 30.5 lb-ft) and 60 N.m (6.0 kg-m, 43.5 lb-ft) by the specified procedure (10 mm (0.39 in.) thread diameter)

Crankcase bolt (b): Tighten 27 N.m (2.7 kg-m, 19.5 lb-ft) by the specified procedure (8 mm (0.31 in.) thread diameter)

NOTE: Do not rotate crankshaft while gauging plastic is installed.



IYSQ01143159

1. Lower crankcase	3. Bolt (8 mm (0.31 in.) thread diameter)
2. Bolt (10 mm (0.39 in.) thread diameter)	4. Long bolt (8 mm (0.31 in.) thread diameter)

Fig. 245: Identifying Crankcase Bolt

Courtesy of SUZUKI OF AMERICA CORP.

- Remove crankcase and using scale (2) on gauging plastic (1) envelop, measure gauging plastic (1) width at its widest point. If clearance exceeds its limit, replace bearing. Always replace both upper and lower inserts as a unit.


A new standard bearing may produce proper clearance. If not, it will be necessary to regrind crankshaft journal for use of 0.25 mm undersize bearing.

After selecting new bearing, recheck clearance.

Main bearing clearance

Standard: 0.024 - 0.042 mm (0.0010 - 0.0016 in.)

Limit: 0.060 mm (0.0023 in.)



IYSQ01143164

Fig. 246: Removing Crankcase And Using Scale On Gauging Plastic
Courtesy of SUZUKI OF AMERICA CORP.

Selection of Main Bearings

Standard bearing


If bearing is in malcondition, or bearing clearance is out of specification, select a new standard bearing according to the following procedure and install it.

1. First check journal diameter. As shown in the figure, crank web has stamped numbers and alphabet at the center.

Three kinds of numbers ("1", "2" and "3") represent the following journal diameters.

JOURNAL DIAMETER SPECIFICATIONS

Stamped numbers	Journal diameter
1	65.0000 - 65.0060 mm (2.5591 - 2.5593 in.)
2	64.9940 - 64.9999 mm (2.5588 - 2.5591 in.)
3	64.9880 - 64.9939 mm (2.5586 - 2.5588 in.)



IYSQ01143165

- | |
|---------------|
| 1. Crankshaft |
| 2 Crank web |

Fig. 247: Checking Journal Diameter
 Courtesy of SUZUKI OF AMERICA CORP.


2. Next, check crankcase (bearing cap) bore diameter without bearing.

On lower surface of lower crankcase 4 alphabets are stamped as shown in the figure.

Three kinds of alphabets (A, B and C) represent the following cap bore diameters.

MAIN BEARING CAP BORE DIAMETER SPECIFICATIONS

Stamped alphabet	Bearing cap bore diameter (without bearing)
A	70.0000 - 70.0060 mm (2.7559 - 2.7561 in.)
B	70.0061-70.0120 mm (2.7561 - 2.7564 in.)
C	70.0121-70.0180 mm (2.7564 - 2.7566 in.)



IYSQ01143166

1. Crankshaft pulley side	4. No.2 bearing
2. Stamped alphabets	5. No.3 bearing
3. No.1 bearing	6. No.4 bearing


Fig. 248: Checking Crankcase (Bearing Cap) Bore Diameter Without Bearing
 Courtesy of SUZUKI OF AMERICA CORP.

- There are 5 kinds of standard bearings differing in thickness. To distinguish them, they are painted in the following colors at the position as indicated in the figure.

Each color indicates the following thickness at the center of bearing.

STANDARD SIZE MAIN BEARING THICKNESS

Color painted	Bearing thickness
Black	2.497 - 2.500 mm (0.0983 - 0.0984 in.)
Colorless (no paint)	2.500 - 2.503 mm (0.0984 - 0.0985 in.)
Yellow	2.503 - 2.506 mm (0.0985 - 0.0986 in.)
Blue	2.506 - 2.509 mm (0.0986 - 0.0987 in.)
Pink	2.509-2.512 mm (0.0987 - 0.0989 in.)



IYSQ01141169

1. Paint

Fig. 249: Checking Main Bearing Thickness
 Courtesy of SUZUKI OF AMERICA CORP.

4. From number stamped on crank webs at its center and alphabets stamped on crankcase lower side, determine new standard bearing to be installed to journal referring to the table shown below.

For example, if number stamped on crank webs is "1" and alphabet stamped on crankcase is "A", install a new standard bearing painted in "Black" to its journal.

NEW STANDARD SIZE BEARING SPECIFICATIONS

		Number stamped on crank web (Journal diameter)		
		1	2	3
Alphabet stamped on lower crankcase (Cap bore diameter)	A	Black	Colorless	Yellow
	B	Colorless	Yellow	Blue
	C	Yellow	Blue	Pink

5. Using gauging plastic, check bearing clearance with newly selected standard bearing.

If clearance still exceeds its limit, use next thicker bearing and recheck clearance.

6. When replacing crankshaft or cylinder block and crankcase due to any reason, select new standard bearings to be installed by referring to number stamped on new crankshaft or alphabets stamped on new crankcase lower side.

Undersize bearing (0.25 mm (0.0098 in.))

0.25 mm (0.0098 in.) undersize bearing is available, in five kinds varying in thickness.


To distinguish them, each bearing is painted in following colors at such position as indicated in the figure.

Each color represents the following thickness at the center of bearing.

If necessary, regrind crankshaft journal and select undersize bearing to use with it as follows.

UNDERSIZE MAIN BEARING THICKNESS SPECIFICATIONS

Color painted	Bearing thickness
Black & Red	2.622 - 2.625 mm (0.1032-0.1033 in.)
Red only	2.625 - 2.628 mm (0.1033-0.1034 in.)
Yellow & Red	2.628 - 2.630 mm (0.1034-0.1035 in.)
Blue & Red	2.630 - 2.634 mm (0.1035-0.1037 in.)
Pink & Red	2.634 - 2.637 mm (0.1037-0.1038 in.)



IYSQ01141171

1. Paint

Fig. 250: Checking Under Size Main Bearing Thickness
 Courtesy of SUZUKI OF AMERICA CORP.


1. Regrind journal to the following finished diameter.

Finished journal diameter

64.738 - 64.756 mm (2.5487 - 2.5494 in.)

2. Using micrometer, measure reground journal diameter.

Measurement should be taken in two directions perpendicular to each other in order to check for out-of-round.



IYSQ01143167

Fig. 251: Measuring Reground Journal Diameter Using Micrometer
 Courtesy of SUZUKI OF AMERICA CORP.

3. Using journal diameter measured above and alphabets stamped on lower crankcase, select an undersize bearing referring to table given below. Check bearing clearance with newly selected undersize bearing.

UNDERSIZE BEARING SPECIFICATIONS


	Measured journal diameter		
	64.7500 -64.7560 mm (2.5492 -2.5494 in.)	64.7440 -64.7499 mm (2.5489 -2.5492 in.)	64.7380 -64.7439 mm (2.5487 -2.5489 in.)

Alphabets stamped on lower crankcase	A	Black & Red	Red only	Yellow & Red
	B	Red only	Yellow & Red	Blue & Red
	C	Yellow & Red	Blue & Red	Pink & Red

REAR OIL SEAL AND FLYWHEEL INSPECTION

Rear Oil Seal

Carefully inspect oil seal for wear or damage. If lip portion is worn or damaged, replace oil seal.



IYSQ01143168

Fig. 252: Identifying Rear Oil Seal


Courtesy of SUZUKI OF AMERICA CORP.

Flywheel

- If ring gear is damaged, cracked or worn, replace flywheel.
- If the surface contacting clutch disc is damaged, or excessively worn, replace flywheel.
- Check flywheel for face runout with a dial gauge. If runout exceeds its limit, replace flywheel.

Flywheel runout

Limit: 0.2 mm (0.0078 in.)



IYSQ01143169

Fig. 253: Checking Flywheel For Face Runout With Dial Gauge
Courtesy of SUZUKI OF AMERICA CORP.


CYLINDER BLOCK INSPECTION

Distortion of Gasketed Surface

Using straightedge and thickness gauge, check gasketed surface for distortion. If flatness exceeds its limit, correct or replace it.

Gasketed surface flatness

Limit: 0.06 mm (0.0024 in.)



IYSQ01143170

Fig. 254: Checking Gasketed Surface For Distortion Using Straightedge And Thickness Gauge
 Courtesy of SUZUKI OF AMERICA CORP.


Honing or reboring cylinders

1. When any cylinder needs reboring, all other cylinders must also be rebored at the same time.
2. Select oversized piston according to amount of cylinder wear.

OVERSIZE PISTON DIAMETER SPECIFICATIONS

Engine Type	Standard	Oversize 0.50
For H25 engine	83.970 - 83.990 mm (3.3059 - 3.3067 in.)	84.470 - 84.490 mm (3.3256 - 3.3264 in.)
For H27 engine	87.970 - 87.990 mm (3.4634 - 3.4642 in.)	88.470 - 88.490 mm (3.4831 - 3.4839 in.)

3. Using micrometer, measure piston diameter.



I5JA01140018

Fig. 255: Measuring Piston Diameter Using Micrometer
Courtesy of SUZUKI OF AMERICA CORP.

4. Calculate cylinder bore diameter to be rebored as follows.

$$D = A + B - C$$

D: Cylinder bore diameter to be rebored

A: Piston diameter as measured

B: Piston clearance = 0.02 - 0.04 mm (0.0008 - 0.0015 in.)

C: Allowance for honing = 0.02 mm (0.0008 in.)

5. Rebore and hone cylinder to calculated dimension.

NOTE: Before reboring, install all main bearing caps in place and tighten to


specification to avoid distortion of bearing bores.

6. Measure piston clearance after honing.

ENGINE BLOCK HEATER (IF EQUIPPED) REMOVAL AND INSTALLATION

Removal

1. Disconnect negative (-) cable at battery.
2. Drain engine coolant referring to "**COOLANT DRAINING**".
3. Remove strut tower bar, if equipped. Refer to "**STRUT DAMPER REMOVAL AND INSTALLATION**".
4. Remove right side exhaust manifold. Refer to "**EXHAUST MANIFOLD REMOVAL AND INSTALLATION**".
5. Disconnect engine block heater and remove engine block heater (1).




I2JA01160005

Fig. 256: Removing Right Side Exhaust Manifold
Courtesy of SUZUKI OF AMERICA CORP.

Installation

Reverse removal procedure for installation, noting the followings.

- Install engine block heater (1) in the direction as shown in the figure.



I1JA01160006

Fig. 257: Installing Engine Block Heater
Courtesy of SUZUKI OF AMERICA CORP.


- Tighten engine block heater mounting bolt to specified torque.
 - a. Apply thread lock cement to block heater bolt (1).

"A": Thread lock cement 99000-32020

- b. Tighten engine block heater mounting bolt to specified torque.

Tightening torque

Engine block heater mounting bolt (a): 11 N.m (1.1 kg-m, 8.0 lb-ft)




I1SQ01162002

Fig. 258: Applying Thread Lock Cement To Block Heater Bolt
 Courtesy of SUZUKI OF AMERICA CORP.

- Use new exhaust manifold gasket.
- Tighten exhaust manifold mounting bolts and nuts to specified torque referring to "**EXHAUST MANIFOLD REMOVAL AND INSTALLATION**".
- Refill coolant referring to "**COOLING SYSTEM FLUSH AND REFILL**".
- Refill P/S fluid and bleed air in P/S system referring to "**P/S SYSTEM AIR BLEEDING PROCEDURE**".
- Refill engine oil referring to "**ENGINE OIL AND FILTER CHANGE**".
- Refill front differential gear oil referring to "**FRONT DIFFERENTIAL GEAR OIL INSPECTION AND CHANGE**" and "**FRONT DIFFERENTIAL GEAR OIL INSPECTION AND CHANGE**".
- Finally, start engine and check for engine coolant leaks and exhaust gas leakage.

ENGINE BLOCK HEATER (IF EQUIPPED) INSPECTION

- Check continuity between terminal "a" and "c". If there is no continuity, replace it.
- Check that there is no continuity between terminal "a" or "b" and "c". If there is continuity, replace it.
- Check continuity between terminal "c" and engine block heater body. If there is no continuity, replace it.



I1SQ01162003

Fig. 259: Checking Continuity Between Terminal "a" And "c" For Engine Block Heater
 Courtesy of SUZUKI OF AMERICA CORP.

SPECIFICATIONS

TIGHTENING TORQUE SPECIFICATIONS

TIGHTENING TORQUE SPECIFICATIONS

Fastening part	Tightening torque			Note
	N.m	kg-m	lb-ft	
Strut tower bar mounting bolts	50	5.0	36.5	///
Cylinder head cover nut	10.5	1.1	7.5	
Timing chain cover bolt	11	1.1	8.0	
CKP sensor bolt	6	0.6	4.5	
Crankshaft pulley bolt	150	15	108.5	
Timing chain guide No.4 bolt	11	1.1	8.0	
Camshaft timing sprocket bolt	80	8.0	58.0	
Timing chain tensioner adjuster No.3 bolt	Tighten 11 N.m (1.1 kg-m, 7.5 lb-ft) by the specified procedure			
Timing chain tensioner adjuster No.3 nut	Tighten 55 N.m (5.5 kg-m, 40.0 lb-ft) by the specified procedure			

2005 Suzuki Grand Vitara EX

2005 ENGINE Engine Mechanical - Grand Vitara & XL-7

RH bank 1st timing chain intake camshaft sprocket bolt	80	8.0	58.0	
Timing chain tensioner nut	27	2.7	19.5	
Idler sprocket No.1 bolt	45	4.5	32.5	
Timing chain tensioner adjuster No.1 bolt	11	1.1	8.0	
Timing chain guide No.1 and No.2 bolt	9	0.9	6.5	
Timing chain tensioner adjuster No.2 bolt	11	1.1	8.0	
Camshaft housing bolt	Tighten 12 N.m (1.2 kg-m, 9.0 lb-ft) by the specified procedure			/
Timing chain guide No.3 bolt	11	1.1	8.0	
Cylinder head bolt	Tighten 53 N.m (5.3 kg-m, 38.5 lb-ft), 84 N.m (8.4 kg-m, 61.0 lb-ft), 0 N.m (0 kg-m, 0 lb-ft), 53 N.m (5.3 kg-m, 38.5 lb-ft) and 105 N.m (10.5 kg-m, 76.0 lb-ft) by the specified procedure			
Cylinder head bolt (hex hole bolt)	Tighten 11 N.m (1.1 kg-m, 7.5 lb-ft) by the specified procedure			
Connecting rod bearing cap nut	45	4.5	32.5	
Engine side mounting bracket nut	55	5.5	40.0	
Transmission case bolt and nut	85	8.5	61.5	(for M/T vehicle)
Transmission case bolt and nut	80	8.0	58.0	(for A/T vehicle)
Torque converter bolt	65	6.5	47.0	
Exhaust No.1 pipe bolt and nut	50	5.0	36.5	
Crankcase bolt	Tighten 42 N.m (4.2 kg-m, 30.5 lb-ft), 0 N.m (0 kg-m, 0 lb-ft), 42 N.m (4.2 kg-m, 30.5 lb-ft) and 60 N.m (6.0 kg-m, 43.5 lb-ft) by the specified procedure			(10 mm (0.39 in.) thread diameter) / /
Crankcase bolt	Tighten 27 N.m (2.7 kg-m, 19.5 lb-ft) by the specified procedure			(8 mm (0.31 in.) thread diameter) / /
Flywheel (or drive plate) bolt	70	7.0	51.0	
Engine block heater mounting bolt	11	1.1	8.0	

NOTE: The specified tightening torque is also described in the following.

- "TIMING CHAIN COVER COMPONENTS"**
- "LH (NO.1) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER COMPONENTS"**
- "1ST TIMING CHAIN AND CHAIN TENSIONER COMPONENTS"**
- "RH (NO.2) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER COMPONENTS"**
- "CAMSHAFTS AND VALVE LASH ADJUSTERS COMPONENTS"**
- "VALVES AND CYLINDER HEADS COMPONENTS"**
- "PISTONS, PISTON RINGS, CONNECTING RODS AND CYLINDERS COMPONENTS"**
- "MAIN BEARINGS, CRANKSHAFT AND CYLINDER BLOCK COMPONENTS"**

Reference:

For the tightening torque of fastener not specified in this article, refer to **"FASTENER INFORMATION"**.

SPECIAL TOOLS AND EQUIPMENT

RECOMMENDED SERVICE MATERIAL

RECOMMENDED SERVICE MATERIAL CHART

Material	SUZUKI recommended product or Specification	
Sealant	SUZUKI Bond No.1215	P/No.: 99000-31110
Thread lock cement	Thread Lock Cement Super 1333B	P/No.: 99000-32020
Water tight sealant	SUZUKI Bond No.1207B	P/No.: 99000-31140
	SUZUKI Bond NO.1207F	P/No.: 99000-31250

NOTE: Required service material is also described in the following.

TIMING CHAIN COVER COMPONENTS

"LH (NO.1) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER COMPONENTS"

"1ST TIMING CHAIN AND CHAIN TENSIONER COMPONENTS"

"RH (NO.2) BANK 2ND TIMING CHAIN AND CHAIN TENSIONER COMPONENTS"

"CAMSHAFTS AND VALVE LASH ADJUSTERS COMPONENTS"

"VALVES AND CYLINDER HEADS COMPONENTS"

"PISTONS, PISTON RINGS, CONNECTING RODS AND CYLINDERS COMPONENTS"

"MAIN BEARINGS, CRANKSHAFT AND CYLINDER BLOCK COMPONENTS"


SPECIAL TOOL

SPECIAL TOOL


09355-35754-600
Hose




09367-04002
3-way joint




09911-97710
Oil seal guide




09911-97811
Oil seal installer



09913-75510
Bearing installer



09915-64510
Compression gauge
set (0-20 kg/cm2,
M14)











09915-64530
Compression gauge hose

09915-67010
Compression gauge

2005 Suzuki Grand Vitara EX


2005 ENGINE Engine Mechanical - Grand Vitara & XL-7

		attachment (C)	
09915-67311 Vacuum gauge		09916-14510 Valve lifter /	
09916-14910 Valve spring compressor attachment /		09916-34542 Reamer handle /	
09916-37810 Valve guide reamer (6 mm)		09916-38210 Valve guide reamer (11 mm)	


2005 Suzuki Grand Vitara EX

2005 ENGINE Engine Mechanical - Grand Vitara & XL-7


09916-44910
Valve guide installer &
remover




09916-58210
Valve guide installer
handle
/




09916-77310
Piston ring compressor
(50-125 mm)




09916-84511
Forceps
/



09917-47011
Vacuum pump gauge



09917-68221
Camshaft pulley
holder
/




09917-87810
Valve guide installer
attachment (protrusion:
13.5 mm)


09917-98221
Valve guide stem
attachment

2005 Suzuki Grand Vitara EX


2005 ENGINE Engine Mechanical - Grand Vitara & XL-7




09918-08210
Vacuum gauge hose joint




09919-28610
Protector sleeve



09924-17811
Flywheel holder



09926-58010
Bearing remover
attachment



09944-36011
Steering wheel remover

