

2004 ENGINE**Engine Mechanical - I35****PRECAUTIONS****PARTS REQUIRING ANGULAR TIGHTENING**

- Use an angle wrench [SST: KV10112100] for the final tightening of the following engine parts:
 - a. Cylinder head bolts
 - b. Main bearing cap bolts
 - c. Connecting rod cap nuts
 - d. Crankshaft pulley bolt
- Do not use a torque value for final tightening.
- The torque value for these parts are for a preliminary step.
- Ensure thread and seat surfaces are clean and coated with engine oil.

LIQUID GASKET APPLICATION PROCEDURE

1. Use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves. Also, completely clean any oil from these areas.
2. Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine RTV silicone sealant or equivalent. Refer to **RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS** .)
 - Be sure liquid gasket diameter is as specified in this manual.





Fig. 1: Applying Liquid Gasket Around Inner Side Of Bolt Holes
Courtesy of NISSAN MOTOR CO., U.S.A.

3. Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
4. Assembly should be done within 5 minutes after coating.
5. Wait at least 30 minutes before refilling engine oil and engine coolant.









G00787647

Fig. 2: Applying Liquid Gasket Around Inner Side Of Bolt Holes
Courtesy of NISSAN MOTOR CO., U.S.A.

PREPARATION

SPECIAL SERVICE TOOLS

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.






Tool number (Kent-Moore No.) Tool name	Description
ST0501S000 (—) Engine stand assembly 1 ST05011000 (—) Engine stand 2 ST05012000 (—) Base	Disassembling and assembling 
KV10106500 (—) Engine stand shaft	
KV10117000 (J41262) Engine sub-attachment	 KV10117000 has been replaced with KV10117001 (KV10117000 is no longer in production, but it is usable).
KV10117001 (—) Engine sub-attachment	Installing on the cylinder block 
ST10120000 (J24239-01) Cylinder head bolt wrench	Loosening and tightening cylinder head bolt a: 13 (0.51) dia. b: 12 (0.47) c: 10 (0.39) Unit: mm (in) 
KV10116200 (J26336-A) Valve spring compressor 1 KV10115900 (J26336-20) Attachment	Disassembling valve mechanism 

G00787648

Fig. 3: Identifying Special Service Tools (1 Of 2)
Courtesy of NISSAN MOTOR CO., U.S.A.

2004 Infiniti I35





2004 ENGINE Engine Mechanical - I35

Tool number (Kent-Moore No.) Tool name	Description
(J39386) Valve oil seal drift	Installing valve oil seal 
EM03470000 (J8037) Piston ring compressor	Installing piston assembly into cylinder bore 
ST16610001 (J23907) Pilot bushing puller	Removing crankshaft pilot bushing 
KV10111100 (J37228) Seal cutter	Removing steel oil pan and rear timing chain case 
WS39930000 (—) Tube presser	Pressing the tube of liquid gasket 
KV10112100 (BT8653-A) Angle wrench	Tightening bolts for bearing cap, cylinder head, etc. 
KV10117100 (J3647-A) Heated oxygen sensor wrench	Loosening or tightening heated oxygen sensor For 22 mm (0.87 in) hexagon nut 

G00787649

Fig. 4: Identifying Special Service Tools (2 Of 2)
Courtesy of NISSAN MOTOR CO., U.S.A.


COMMERCIAL SERVICE TOOLS

Tool number (Kent-Moore No.) Tool name	Description
Spark plug wrench	 16 mm (0.63 in) Removing and installing spark plug
Valve seat cutter set	 Finishing valve seat dimensions
Piston ring expander	 Removing and installing piston ring
Valve guide drift	 Removing and installing valve guide Intake & Exhaust: a = 9.5 mm (0.374 in) dia. b = 5.5 mm (0.217 in) dia.
Valve guide reamer	 Reaming valve guide 1 or hole for oversize valve guide 2 Intake & Exhaust: d₁ = 6.0 mm (0.236 in) dia. d₂ = 10.2 mm (0.402 in) dia.
(J-43897-18) (J-43897-12) Oxygen sensor thread cleaner	 Reconditioning the exhaust system threads before installing a new heated oxygen sensor (Use with anti-seize lubricant shown below.) a = J-43897-18 (18 mm dia.) for zirconia heated oxygen sensor b = J-43897-12 (12 mm dia.) for titania heated oxygen sensor
Anti-seize lubricant (Permatex 133AR or equivalent meeting MIL specification MIL-A-907)	 Lubricating heated oxygen sensor thread cleaning tool when reconditioning exhaust system threads

G00787650

Fig. 5: Identifying Commercial Service Tools
 Courtesy of NISSAN MOTOR CO., U.S.A.

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING



G00787651

Fig. 6: Identifying Engine Components
 Courtesy of NISSAN MOTOR CO., U.S.A.

NVH TROUBLESHOOTING - ENGINE NOISE

Location of noise	Type of noise	Operating condition of engine						Source of noise	Check item
		Before warm-up	After warm-up	When starting	When idling	When racing	While driving		
Top of engine Rocker cover Cylinder head	Ticking or clicking	C	A	—	A	B	—	Tappet noise	Valve clearance
	Rattle	C	A	—	A	B	C	Camshaft bearing noise	Camshaft journal clearance Camshaft runout
Crankshaft pulley Cylinder block (Side of engine) Oil pan	Slap or knock	—	A	—	B	B	—	Piston pin noise	Piston and piston pin clearance Connecting rod bushing clearance
	Slap or rap	A	—	—	B	B	A	Piston slap noise	Piston-to-bore clearance Piston ring side clearance Piston ring end gap Connecting rod bend and torsion
	Knock	A	B	C	B	B	B	Connecting rod bearing noise	Connecting rod bushing clearance (Small end) Connecting rod bearing clearance (Big end)
	Knock	A	B	—	A	B	C	Main bearing noise	Main bearing oil clearance Crankshaft runout
Front of engine Timing chain cover	Tapping or ticking	A	A	—	B	B	B	Timing chain and chain tensioner noise	Timing chain cracks and wear Timing chain tensioner operation
Front of engine	Squeaking or fizzing	A	B	—	B	—	C	Drive belts (Sticking or slipping)	Drive belts deflection
	Creaking	A	B	A	B	A	B	Drive belts (Slipping)	Idler pulley bearing operation
	Squall Creak	A	B	—	B	A	B	Water pump noise	Water pump operation

A: Closely related B: Related C: Sometimes related —: Not related

G00787652

Fig. 7: Troubleshooting - Engine Noise Chart
Courtesy of NISSAN MOTOR CO., U.S.A.

Use the chart below to help you find the cause of the symptom.

1. Locate the area where noise occurs.
2. Confirm the type of noise.
3. Specify the operating condition of engine.
4. Check specified noise source.

If necessary, repair or replace these parts.

OUTER COMPONENT PARTS

REMOVAL AND INSTALLATION





Fig. 9: Removing Engine Components
Courtesy of NISSAN MOTOR CO., U.S.A.

TIGHTENING PROCEDURES

Intake Manifold

- Loosen in reverse order shown in the figure.
- Tighten in numerical order shown in the figure.
 1. Tighten all bolts and nuts to 4.9 to 9.8 N.m (0.50 to 0.99 kg-m, 4 to 7 ft-lb).
 2. Finally tighten all bolts and nuts to 26.5 to 31.4 N.m (2.7 to 3.2 kg-m, 20 to 23 ft-lb).
- Tighten all bolts and nuts to the final torque, evenly dividing the tightening into at least three steps.




G00787655

Fig. 10: Removing Intake Manifold
Courtesy of NISSAN MOTOR CO., U.S.A.

Fuel Tube

- Tighten in numerical order shown in the figure.
 1. Tighten all bolts to 9.3 to 10.8 N.m (0.95 to 1.1 kg-m, 6.9 to 7.9 ft-lb).
 2. Then tighten all bolts to 20.6 to 26.5 N.m (2.1 to 2.7 kg-m, 16 to 19 ft-lb).



G00787656


Fig. 11: Removing Fuel Tube

Courtesy of NISSAN MOTOR CO., U.S.A.

Fuel Damper

Tighten fuel damper to 2.9 to 3.8 N.m (0.3 to 0.39 kg-m, 26.0 to 33.9 in-lb).

- Tighten screws evenly several times to have the fuel damper tightened at the specified torque.
- Always replace O-ring with new ones.
- Lubricate O-ring with new engine oil.



G00787657

Fig. 12: Installing Fuel Damper
Courtesy of NISSAN MOTOR CO., U.S.A.

Electronic Control Throttle Actuator

- Tighten in numerical order shown in the figure.

Tighten all bolts to 7.2 to 9.6 N.m (0.74 to 0.97 kg-m, 64 to 84 in lb).


CAUTION:

- Perform "Throttle Valve Closed Position Learning" when harness connector of electronic throttle control actuator is disconnected.

Refer to **BASIC SERVICE PROCEDURE** .

- Perform "Idle Air Volume Learning" when electronic throttle control actuator is replaced.

Refer to **BASIC SERVICE PROCEDURE** .



G00787658


Fig. 13: Installing Electronic Control Throttle Actuator

Courtesy of NISSAN MOTOR CO., U.S.A.

Intake Manifold Upper Collector

- Loosen in reverse order and tighten in numerical order shown in the figure.

Tighten all bolts to 17.6 to 21.6 N.m (1.8 to 2.2 kg-m, 13 to 15 ft-lb).




G00787659

Fig. 14: Installing Intake Manifold Upper Collector Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.

Intake Manifold Lower Collector

- Loosen in reverse order shown in the figure.
- Tighten in numerical order shown in the figure.

Tighten bolts and nuts to 17.6 to 21.6 N.m (1.8 to 2.2 kg-m, 13 to 15 ft-lb).




G00787660

Fig. 15: Installing Intake Manifold Lower Collector
Courtesy of NISSAN MOTOR CO., U.S.A.

Power Valve

- Tighten in numerical order shown in the figure.

Tighten all bolts to 17.6 to 21.6 N.m (1.8 to 2.2 kg-m, 13 to 15 ft-lb).




G00787661

Fig. 16: Tightening Power Valve Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.

Exhaust Manifold

- Loosen in reverse order shown in the figure.
- Tighten in numerical order shown in the figure.

Tighten nuts to 28.4 to 33.3 N.m (2.9 to 3.3 kg-m, 21 to 24 ft-lb).

RH bank


➡ Engine front

G00787662

Fig. 17: Tightening Exhaust Manifold Nuts (RH Bank)

Courtesy of NISSAN MOTOR CO., U.S.A.

LH bank



G00787663

Fig. 18: Tightening Exhaust Manifold Nuts (LH Bank)


Courtesy of NISSAN MOTOR CO., U.S.A.

MEASUREMENT OF COMPRESSION PRESSURE

1. Warm up engine.
2. Turn ignition switch OFF.
3. Release fuel pressure.

Refer to **FUEL PRESSURE RELEASE** .

4. Disconnect ignition coil with power transistor harness connectors, then remove ignition coils.
5. Remove all spark plugs.
6. Remove fuse for fuel injector.



G00787664

Fig. 19: Identifying fuel Injector Fuse

Courtesy of NISSAN MOTOR CO., U.S.A.


7. Attach a compression tester to No. 1 cylinder.
8. Depress accelerator pedal fully to keep throttle valve wide open.
9. Crank engine and record highest gauge indication.
10. Repeat the measurement on each cylinder as shown above.
 - **Always use a fully-charged battery to obtain specified engine speed.**

Unit: kPa (kg/cm², psi)/rpm

Standard	Minimum	Difference limit between cylinders
1,275 (13.0, 185)/300	981 (10.0, 142)/300	98 (1.0, 14)/300

G00787665

Fig. 20: Attaching Compression Tester
Courtesy of NISSAN MOTOR CO., U.S.A.




G00787666

Fig. 21: Cylinders Compression Specification Chart
Courtesy of NISSAN MOTOR CO., U.S.A.

11. If compression in one or more cylinders is low:
 - a. Pour a small amount of engine oil into cylinders through spark plug holes.
 - b. Retest compression.
 - If adding oil helps compression, piston rings may be worn or damaged. If so, replace

piston rings after checking piston.

- If pressure stays low, a valve may be sticking or seating improperly. Inspect and repair valve and valve seat. (Refer to SDS, VALVE and VALVE SEAT.) If valve or valve seat is damaged excessively, replace them.
- If compression stays low in two cylinders that are next to each other:
 - a. The cylinder head gasket may be leaking, or
 - b. Both cylinders may have valve component damage. Inspect and repair as necessary.



20 mm (0.79 in) dia.

Use compressor tester whose end (rubber portion) is less than 20 mm (0.79 in) dia. Otherwise, it may be caught by cylinder head during removal.


G00787667

Fig. 22: Identifying Compression Tester
Courtesy of NISSAN MOTOR CO., U.S.A.

OIL PAN

COMPONENTS

SEC. 110•150•221•251




G00787668

Fig. 23: Exploded View Of Oil Pan
 Courtesy of NISSAN MOTOR CO., U.S.A.

REMOVAL

CAUTION: When removing the aluminum oil pan from engine, first remove the crankshaft position sensor (POS) from the assembly.
 Be careful not to damage sensor edges and signal plate teeth.

1. Remove engine undercover.
2. Drain engine oil.
 - To avoid the danger of being scalded, never drain the engine oil when the engine is hot.
3. Loosen steel oil pan bolts in reverse order shown in the figure.




G00787669

Fig. 24: Removing Oil Pan Bolts

Courtesy of NISSAN MOTOR CO., U.S.A.


4. Remove steel oil pan.
 - a. Insert seal cutter between aluminum oil pan and steel oil pan.
 - Be careful not to damage aluminum mating surface.
 - Do not insert screwdriver, or oil pan flange will be deformed.



G00787670

Fig. 25: Inserting Seal Cutter Between Aluminum Oil Pan And Steel Oil Pan
Courtesy of NISSAN MOTOR CO., U.S.A.


- b. Slide seal cutter by tapping on the side of it with a hammer.
- c. Remove steel oil pan.



G00787671

Fig. 26: Removing Steel Oil Pan
Courtesy of NISSAN MOTOR CO., U.S.A.

5. Remove oil strainer.




G00787672

Fig. 27: Removing Oil Strainer

Courtesy of NISSAN MOTOR CO., U.S.A.

6. Remove front exhaust tube and its support.


Refer to **REMOVAL AND INSTALLATION**.



G00787673

Fig. 28: Removing Front Exhaust Tube
Courtesy of NISSAN MOTOR CO., U.S.A.

7. Set a suitable transmission jack under transaxle and hoist engine with engine slinger.
8. Remove crankshaft position sensor (POS) from oil pan.
9. Loosen front and rear engine mounting nuts and bolts.
10. Remove center member.




G00787674

Fig. 29: Removing Engine Mounting Nuts And Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.

11. Remove drive belts.
12. Remove air conditioner compressor.

Refer to **COMPRESSOR** .

13. Remove rear cover plate.



G00787675

Fig. 30: Removing Rear Cover Plate
Courtesy of NISSAN MOTOR CO., U.S.A.

14. Remove oil filter, oil cooler fixing bolt and water hoses or pipes as follows.
 - a. Remove oil filter.
 - b. Disconnect water hoses from oil cooler, pinching hose to prevent coolant spill.
 - c. Remove oil cooler.





Fig. 31: Removing Oil Cooler
Courtesy of NISSAN MOTOR CO., U.S.A.

15. Loosen aluminum oil pan bolts in numerical order.




G00787677

Fig. 32: Removing Oil Pan Bolts

Courtesy of NISSAN MOTOR CO., U.S.A.


16. Loosen four engine-to-transaxle bolts.



G00787678

Fig. 33: Removing Engine-To-Transaxle Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.


17. Remove aluminum oil pan.
 - a. Insert an appropriate size tool into the notch of aluminum oil pan as shown in the figure.
 - **Be careful not to damage aluminum mating surface.**
 - **Do not insert screwdriver, or oil pan flange will be deformed.**
 - b. Pry off aluminum oil pan by moving the tool up and down.
 - c. Remove aluminum oil pan.



G00787679

Fig. 34: Removing Oil Pan Using Tool
Courtesy of NISSAN MOTOR CO., U.S.A.

18. Remove O-rings from cylinder block and oil pump body.



G00787680

Fig. 35: Removing O-Rings From Cylinder Block And Oil Pump Body
Courtesy of NISSAN MOTOR CO., U.S.A.

INSTALLATION

1. Install aluminum oil pan.
 - a. Use a scraper to remove old liquid gasket from mating surfaces.
 - Also remove old liquid gasket from mating surface of cylinder block, front cover and steel oil pan.
 - Remove old liquid gasket from the bolt hole and thread.



**G00787681**

Fig. 36: Removing Old Liquid Gasket From Mating Surfaces
Courtesy of NISSAN MOTOR CO., U.S.A.


- b. Apply sealant to front cover gasket and rear oil seal retainer gasket.



G00787682

Fig. 37: Applying Sealant To Front Cover Gasket
 Courtesy of NISSAN MOTOR CO., U.S.A.


- c. Apply a continuous bead of liquid gasket to mating surface of aluminum oil pan.
 - Use Genuine RTV silicone sealant or equivalent. Refer to **RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS**.
- d. Apply liquid gasket to inner sealing surface as shown in figure.
 - Be sure liquid gasket is 4.0 to 5.0 mm (0.157 to 0.197 in) or 4.5 to 5.5 mm (0.177 to 0.217 in) wide as shown in the figure.
 - Apply a bead of 4.5 to 5.5 mm (0.177 to 0.217 in) in diameter to area "A".
 - For bolt holes with * marks (5 locations), apply liquid gasket outside the holes.
 - Assembly should be done within 5 minutes after coating.



G00787683

Fig. 38: Applying Liquid Gasket To Inner Sealing Surface
Courtesy of NISSAN MOTOR CO., U.S.A.


- e. Install O-rings, cylinder block and oil pump body.



G00787684

Fig. 39: Installing O-Rings, Cylinder Block And Oil Pump Body
Courtesy of NISSAN MOTOR CO., U.S.A.


- f. Tighten aluminum oil pan.
 - Tighten bolts in numerical order.
 - **Wait at least 30 minutes before refilling engine oil.**
- g. Install oil cooler, water hoses and pipes.
 - For tightening torque of the oil cooler fixing bolt, refer to **SERVICE DATA AND SPECIFICATIONS (SDS)** .



G00787685

Fig. 40: Tightening Engine-To-Transaxle Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.

2. Install the four engine-to-transaxle bolts. For tightening torque, refer to **SERVICE DATA AND SPECIFICATIONS (SDS)** .



G00787686

Fig. 41: Installing Engine-To-Transaxle Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.

3. Install rear cover plate.





Fig. 42: Installing Rear Cover Plate

Courtesy of NISSAN MOTOR CO., U.S.A.

4. Install air conditioner compressor and bracket.

Refer to **COMPRESSOR** .


5. Install drive belts.
6. Install center member.
7. Tighten front and rear engine mounting insulator nuts and bolts.
8. Install crankshaft position sensor (POS) with new rubber seal, and heated oxygen sensor 1 (bank 2) harness clamp.
 - **Make sure that crankshaft position sensor (POS) and heated oxygen sensor 1 (bank 2) harness clamp are installed correctly as shown in figure.**
9. Install front exhaust tube and its support.
10. Install oil strainer.



G00787688

Fig. 43: Installing Crankshaft Position Sensor
Courtesy of NISSAN MOTOR CO., U.S.A.

11. Install steel oil pan.
 - a. Use a scraper to remove old liquid gasket from mating surfaces.
 - Also remove old liquid gasket from mating surface of aluminum oil pan.



G00787689

Fig. 44: Removing Old Liquid Gasket
Courtesy of NISSAN MOTOR CO., U.S.A.

- b. Apply a continuous bead of liquid gasket to mating surface of steel oil pan.
 - Use Genuine RTV silicone sealant or equivalent. Refer to **RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS**.





Fig. 45: Applying Liquid Gasket

Courtesy of NISSAN MOTOR CO., U.S.A.


- Be sure liquid gasket is 4.5 to 5.5 mm (0.177 to 0.217 in) wide.
- Assembly should be done within 5 minutes after coating.



G00787691

Fig. 46: Applying Continuous Mating Surface Of Steel Oil Pan
Courtesy of NISSAN MOTOR CO., U.S.A.

- c. Install steel oil pan.
- Tighten in numerical order shown in the figure.
 - Wait at least 30 minutes before refilling engine oil.



G00787692

Fig. 47: Installing Steel Oil Pan
 Courtesy of NISSAN MOTOR CO., U.S.A.

12. Install in the reverse order for steps remain.
 - Check oil level after refilling engine oil.
 - Warm engine up and check for oil leakage.

FRONT TIMING CHAIN CASE

REMOVAL


NOTE:

- This section describes removal/installation procedure of front timing chain case and timing-chain-related parts without removing oil pan (upper) on vehicle.
- When oil pan (upper) needs to be removed or installed, or when rear timing chain case is removed or installed, remove oil pans (upper and lower) first. Then remove front timing chain case, timing-chain-related parts, and rear timing chain case in this order, and install in reverse order

of removal. Refer to **TIMING CHAIN**.

- Refer to **TIMING CHAIN** for component parts location.


1. Drain engine oil.
 - To avoid the danger of being scalded, never drain the engine oil when the engine is hot.
2. Drain coolant by removing cylinder block drain plugs. Refer to **ENGINE COOLING SYSTEM**.
 - When secondary timing chain is not removed/installed, the steps from 2 to 10 are not required.
3. Remove ornament cover.
4. Remove air duct to intake manifold, collector, PCV hose, vacuum hoses, fuel hoses, harness, connectors and so on.
5. Remove the following.
 - Water hoses
 - EVAP canister purge hose
6. Remove intake manifold upper collectors loosening bolts and nuts in reverse order shown in the figure.



G00787693

Fig. 48: Removing Intake Manifold Upper Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.


7. Remove intake manifold lower collectors loosening bolts in reverse order shown in the figure.



G00787694

Fig. 49: Removing Intake Manifold Lower Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.

8. Remove RH and LH ignition coils.




G00787695

Fig. 50: Removing Ignition Coils (RH And LH)

Courtesy of NISSAN MOTOR CO., U.S.A.


9. Remove RH and LH intake valve timing control solenoid valves.



G00787696

Fig. 51: Removing Valve Timing Control Solenoid Valves Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.


10. Remove RH and LH rocker covers from cylinder head.
 - Loosen bolts in numerical order shown in the figure.



G00787697

Fig. 52: Removing Rocker Covers From Cylinder Head Bolts (RH And LH)
Courtesy of NISSAN MOTOR CO., U.S.A.

11. Remove engine undercover.
12. Remove front RH wheel and engine side cover.
13. Remove drive belts and idler pulley bracket.
14. Remove power steering oil pump assembly. Refer to STEERING SYSTEM.
15. Remove alternator. Refer to GENERATOR.



G00787698

Fig. 53: Aligning Piston TDC On Compression Stroke
Courtesy of NISSAN MOTOR CO., U.S.A.

16. Set No. 1 piston at TDC on the compression stroke by rotating crankshaft.
 - Disregard this step when timing chain removal is not necessary.
 - Check that intake and exhaust cam nose on NO. 1 cylinder are located as shown.

If not, turn the crankshaft one revolution (360°) and align as shown.

When only primary timing chain is removed, rocker cover does not need to be removed. To confirm that No. 1 cylinder is at its compression TDC, remove front timing chain case first. Then check mating marks on camshaft sprockets. Refer to "**INSTALLATION**".





Fig. 54: Aligning Intake And Exhaust Cam Nose
Courtesy of NISSAN MOTOR CO., U.S.A.


17. Loosen crankshaft pulley bolt. (At this time remove oil pan rear cover plate and set a suitable tool to ring gear so that crankshaft cannot rotate.)
 - Be careful not to damage the signal plate teeth.



G00787700

Fig. 55: Removing Crankshaft Pulley Bolt
Courtesy of NISSAN MOTOR CO., U.S.A.

18. Remove crankshaft pulley with a suitable puller.
19. Remove steel oil pan. Refer to "**REMOVAL**".



G00787701

Fig. 56: Removing Crankshaft Pulley Using Suitable Puller
Courtesy of NISSAN MOTOR CO., U.S.A.

20. Loosen bolts in reverse order shown in figure, and remove installation bolts at the front of aluminum oil pan.
21. Install steel oil pan temporarily.
22. Support steel oil pan bottom with a transmission jack.
 - Perform following operations with engine front-side supported with jack.





Fig. 57: Removing Oil Pan Bolts


Courtesy of NISSAN MOTOR CO., U.S.A.

23. Remove center member assembly.
24. Remove intake valve timing control covers.
 - **Loosen bolts in reverse order shown in the figure.**
 - In the cover, the shaft is engaged with the center hole of the intake camshaft sprocket. Remove it straight out until the engagement comes off.
25. Remove right side engine mounting, mounting bracket and nuts. Refer to "**REMOVAL AND INSTALLATION**".
26. Raise engine front-side with jack. (This secures workspace to remove front timing chain case.)

Right



Left




G00787703

Fig. 58: Identifying Dowel Hole

Courtesy of NISSAN MOTOR CO., U.S.A.

27. Loosen front timing chain case bolts in reverse order shown in the figure.



G00787704

Fig. 59: Removing Front Timing Chain Case Bolts

Courtesy of NISSAN MOTOR CO., U.S.A.


28. Remove front timing chain case.
 - a. Insert the appropriate size tool into the notch at the top of the front timing chain case as shown (1).
 - b. Pry off the case by moving the tool as shown (2).
 - Use seal cutter (special service tool) or an equivalent tool to cut liquid gasket for removal.

CAUTION:

- Do not use screwdrivers or something similar.
- After removal, handle it carefully so it does not tilt, cant, or warp under a load.

29. Remove water pump cover and timing chain tensioner cover from front timing chain case.
 - Use seal cutter (special service tool) or an equivalent tool to cut liquid gasket for removal.
30. Remove front oil seal from front timing chain case. Refer to "**FRONT OIL SEAL**".

31. Remove timing chain and related parts. Refer to "**TIMING CHAIN**".



G00787705

Fig. 60: Inserting Tool Into Front Timing Chain Case
Courtesy of NISSAN MOTOR CO., U.S.A.

INSTALLATION

1. Install timing chain and related parts. Refer to "**TIMING CHAIN**".
2. Remove residual gasket from front timing chain case and liquid-gasket mating surface.

CAUTION: Be careful not to allow gasket fragments to enter oil pan.

3. Hammer dowel pins (right and left) into front timing chain case up to a point close to taper in order to shorten protrusion length.





Fig. 61: Installing Dowel Pins (Right And Left) Into Front Timing Chain Case
Courtesy of NISSAN MOTOR CO., U.S.A.

4. Install the front oil seal on the front timing chain case. Apply new engine oil to the oil seal edges.
 - Install it so that each seal lip is oriented as shown in figure.




G00787707

Fig. 62: Installing Seal Lip

Courtesy of NISSAN MOTOR CO., U.S.A.

- Using a suitable drift, press-fit oil seal until it becomes flush with front timing chain case end face.
- Make sure the garter spring is in position and seal lip is not inverted.




G00787708

Fig. 63: Pressing Oil Seal

Courtesy of NISSAN MOTOR CO., U.S.A.

5. Install the water pump cover and the chain tensioner cover to front timing chain case cover.
 - Apply RTV Silicone Sealant or equivalent. Refer to **RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS** and **INSTALLATION** .




G00787709

Fig. 64: Applying Silicone Sealant To Water Pump Cover
Courtesy of NISSAN MOTOR CO., U.S.A.

6. Install front timing chain case as follows:
 - a. Apply liquid gasket to front timing chain case back side as shown.
 - b. Install dowel pin on the rear timing chain case into dowel pin hole on front timing chain case.

Front timing chain case




Sealant protrusion away from bolt hole

 : Apply liquid gasket (Use Genuine RTV silicone sealant or equivalent. Refer to GI section.)

G00787710

Fig. 65: Applying Liquid Gasket To Front Timing Chain Case
Courtesy of NISSAN MOTOR CO., U.S.A.

7. Apply liquid gasket to top surface of oil pan (upper) as shown in figure.
 - Use Genuine RTV Silicone Sealant or equivalent. Refer to **RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS**.




G00787711

Fig. 66: Applying Liquid Gasket To Oil Pan (Upper)
Courtesy of NISSAN MOTOR CO., U.S.A.

8. As shown in figure, assemble front timing chain case.
 - a. Fit lower end of front timing chain case tightly onto top face of oil pan (upper). From the fitting point, make entire front timing chain case contact rear timing chain case completely.


CAUTION: Be careful that oil pan gasket is in place.



G00787712

Fig. 67: Installing Front Timing Chain Case
Courtesy of NISSAN MOTOR CO., U.S.A.

- b. While pressing front timing chain case from its front and top as shown in figure, install bolts and temporarily tighten them. For bolt length and positions, refer to 9.
- c. Hammer dowel pin until the outer end becomes flush with surface.



G00787713


Fig. 68: Pressing Front Timing Chain Case
Courtesy of NISSAN MOTOR CO., U.S.A.

9. Tighten bolts to the specified torque in order shown in the figure.

8 mm (0.31 in) dia. bolts: 1, 2

6 mm (0.24 in) dia. bolts: Except the above

- After tightening, retighten them to specified torque in numerical order shown in figure.



G00787714

Fig. 69: Tightening Front Timing Chain Case Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.

10. Tighten two mounting bolts in front of oil pan (upper) in numerical order shown in figure.

: 15.7 - 18.6 N.m (1.6 - 1.9 Kg-m, 12 - 13 ft-lb)





Fig. 70: Tightening Front Of Oil Pan Bolts (Upper)
Courtesy of NISSAN MOTOR CO., U.S.A.

11. Install RH and LH intake valve timing control covers as follows:
 - a. Install seal rings in shaft grooves.
 - b. Apply liquid gasket to the intake valve timing control covers.
 - Use Genuine RTV Silicone Sealant or equivalent. Refer to **RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS**

2.1 - 3.1 mm (0.083 - 0.122 in) dia.



G00787716

Fig. 71: Installing Seal Rings On Intake Valve Timing Control Covers
Courtesy of NISSAN MOTOR CO., U.S.A.

- c. Install collared O-ring in front timing chain case oil hole (LH and RH sides).




Fig. 72: Installing Collared O-Ring In Front Timing Chain Case
Courtesy of NISSAN MOTOR CO., U.S.A.

- d. Being careful not to move the seal ring from the installation groove, align the dowel pins on the chain case with the holes to install the intake valve timing control covers.
- e. Tighten bolts in the numerical order as shown.





Fig. 73: Aligning Dowel Pins On Chain Case
Courtesy of NISSAN MOTOR CO., U.S.A.

12. Install crankshaft pulley as follows:
 - a. Fix crankshaft using a suitable tool.
 - b. Install crankshaft pulley, taking care not to damage front oil seal.
 - When press-fitting crankshaft pulley with a plastic hammer, tap on its center portion (not circumference).
 - c. Tighten bolt to 39.2 to 49.0 N.m (4.0 to 5.0 kg-m, 29 to 36 ft-lb).
 - d. Put a paint mark on crankshaft pulley aligning with angle mark on crankshaft pulley bolt. Then, further retighten bolt by 60 to 66 degrees [Target: 60 degrees (equivalent to one graduation)].



G00787719

Fig. 74: Aligning Angle Mark On Crankshaft Pulley Bolt
Courtesy of NISSAN MOTOR CO., U.S.A.

13. Rotate crankshaft pulley in normal direction (clockwise when viewed from front) to confirm it turns smoothly.
14. For the following operations, perform steps in the reverse order of removal.
 - If hydraulic pressure inside chain tensioner drops after removal/installation, slack in the guide may generate a pounding noise during and just after engine start. However, this does not indicate an unusualness. Noise will stop after hydraulic pressure rises.

TIMING CHAIN

COMPONENTS

[illegible]

- G00787720


POSITION FOR APPLYING LIQUID GASKET

- **Before installation, wipe off the protruding sealant.**

2.6 - 3.6
(0.102 - 0.142)

A

B




Sealant protrusion away from bolt hole

Diagram illustrating the assembly of the cylinder head, showing various components and dimensions:


- 2.6 - 3.6 (0.102 - 0.142)**: Dimension for the distance between the camshaft axis area and the center line of the liquid gasket.
- D**: Dimension for the distance between the camshaft axis area and the center line of the liquid gasket.
- C**: Dimension for the distance between the camshaft axis area and the center line of the liquid gasket.
- E**: Dimension for the distance between the camshaft axis area and the center line of the liquid gasket.
- F**: Dimension for the distance between the camshaft axis area and the center line of the liquid gasket.
- G**: Dimension for the distance between the camshaft axis area and the center line of the liquid gasket.
- Do not**: Instruction to not overlap the gasket.
- in this**: Instruction to not overlap the gasket.
- 2.6 - 3.6 (0.102 - 0.142)**: Dimension for the distance between the camshaft axis area and the center line of the liquid gasket.
- Center chain c**: Label for the center chain cover.
- Camshaft axis area**: Label for the camshaft axis area.
- Center line of liquid gasket**: Label for the center line of the liquid gasket.
- 1**: Dimension for the distance between the camshaft axis area and the center line of the liquid gasket.
- 5 (0.20)**: Dimension for the distance between the camshaft axis area and the center line of the liquid gasket.
- 2 (0.08)**: Dimension for the distance between the camshaft axis area and the center line of the liquid gasket.
- D**: Dimension for the distance between the camshaft axis area and the center line of the liquid gasket.
- Cross both ends as shown and be sure to minimize the overlapped area.**: Instruction to cross both ends as shown and minimize the overlapped area.

Protrusions at beginning
and end of liquid gasket

*1: Apply liquid gasket to the chamfered surface between
camshaft bracket and cylinder head.




Rocker cover



*2: Remove the protruding sealant from front face.
(Remove the hardened sealant from surface only.)

Unit: mm (in)

G00787721



martes, 12 de octubre de 2021 12:57:39 p. m.


CAUTION:

- After removing timing chain, do not turn crankshaft and camshaft separately, or valves will strike piston heads.
- When installing camshafts, chain tensioners, oil seals, & other sliding parts, lubricate contacting surfaces with new engine oil.
- Apply new engine oil to bolt threads and seat surfaces when installing cylinder head, camshaft sprockets, crankshaft pulley and camshaft brackets.
- Before disconnecting fuel hose, release fuel pressure. Refer to FUEL PRESSURE RELEASE .
- When removing the oil pans, oil pump assembly and timing chain from engine, first remove the crankshaft position sensor (POS) from the assembly. Be careful not to damage sensor edges.
- Do not spill engine coolant on drive belts.

REMOVAL**NOTE:**

- This section describes removal and installation procedure for front timing chain, timing-chain-related parts, and rear timing chain case when oil pan (upper) needs to be removed/installed for engine overhaul, etc.
- Refer to "FRONT TIMING CHAIN CASE" to remove and install front timing chain case, timing chain and its related parts without removing oil pan (upper).


1. Drain engine oil.
 - To avoid the danger of being scalded, never drain the engine oil when the engine is hot.
2. Drain coolant by removing cylinder block drain plugs.
3. Remove ornament cover.
4. Remove air duct to intake manifold, collector, PCV hose, vacuum hoses, fuel hoses, wires, harness, connectors and so on.
5. Remove the following.
 - Water hoses
 - EVAP canister purge hose
6. Remove intake manifold upper collectors loosening bolts and nuts in reverse order shown in the figure.



G00787722


Fig. 77: Removing Intake Manifold Upper Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.

7. Remove intake manifold lower collectors loosening bolts in reverse order shown in the figure.



G00787723


Fig. 78: Removing Intake Manifold Lower Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787724

Fig. 79: Installing Ignition Coils (RH And LH)
Courtesy of NISSAN MOTOR CO., U.S.A.


8. Remove RH and LH ignition coils.



G00787725

Fig. 80: Installing Intake Valve Timing Control Solenoid Valves
Courtesy of NISSAN MOTOR CO., U.S.A.

9. Remove RH and LH intake valve timing control solenoid valves.




G00787726

Fig. 81: Installing Rocker Covers From Cylinder Head (RH And LH)
 Courtesy of NISSAN MOTOR CO., U.S.A.

10. Remove RH and LH rocker covers from cylinder head.
 - Loosen bolts in numerical order shown in the figure.
11. Remove engine undercover.
12. Remove from RH wheel and engine side cover.
13. Remove drive belts and idler pulley bracket.
14. Remove power steering oil pump assembly.

Refer to **STEERING SYSTEM** .

15. Remove alternator. Refer to **GENERATOR** .
16. Remove crankshaft position sensor (POS).



Crankshaft position
sensor (POS)

G00787727

Fig. 82: Removing Crankshaft Position Sensor (POS)
Courtesy of NISSAN MOTOR CO., U.S.A.



**G00787728**

Fig. 83: Aligning Crankshaft Pulley Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.



17. Set No. 1 piston at TDC on the compression stroke by rotating crankshaft.



G00787729

Fig. 84: Aligning Intake And Exhaust Cam Nose
Courtesy of NISSAN MOTOR CO., U.S.A.


- Check that intake and exhaust cam nose on No. 1 cylinder are installed as shown.
- If not, turn the crankshaft one revolution (360°) and align as shown.



G00787730

Fig. 85: Removing Crankshaft Pulley Bolt
Courtesy of NISSAN MOTOR CO., U.S.A.


18. Loosen crankshaft pulley bolt. (At this time remove oil pan rear cover plate and set a suitable tool to ring gear so that crankshaft cannot rotate.)
 - **Be careful not to damage the signal plate teeth.**
19. Remove crankshaft pulley with a suitable puller.




G00787731

Fig. 86: Removing Crankshaft Pulley Using Suitable Puller
Courtesy of NISSAN MOTOR CO., U.S.A.

Right



Left




G00787732

Fig. 87: Identifying Dowel Hole

Courtesy of NISSAN MOTOR CO., U.S.A.


20. Remove intake valve timing control covers.
 - Loosen bolts in reverse order shown in the figure.
 - In the cover, the shaft is engaged with the center hole of the intake camshaft sprocket. Remove it straight out until the engagement comes off.
21. Remove air conditioner compressor. Refer to **COMPRESSOR** .
22. Remove front exhaust tube and its support. Refer to **REMOVAL AND INSTALLATION** .
23. Hang engine at right and left side engine slingers with a suitable hoist. Refer to "**REMOVAL AND INSTALLATION**".
24. Remove right side engine mounting, mounting bracket and nuts. Refer to "**REMOVAL AND INSTALLATION**".
25. Remove center member assembly.
26. Remove upper and lower oil pans. Refer to "**REMOVAL**".



G00787733

Fig. 88: Removing Front Timing Chain Case Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.

27. Loosen front timing chain case bolts in reverse order shown in the figure.




G00787734

Fig. 89: Inserting Tool Into Front Timing Chain Case
Courtesy of NISSAN MOTOR CO., U.S.A.

28. Remove front timing chain case.
- Insert the appropriate size tool into the notch at the top of the front timing chain case as shown (1).
 - Pry off the case by moving the tool as shown (2).
 - Use seal cutter (special service tool) or an equivalent tool to cut liquid gasket for removal.

CAUTION:

- Do not use screwdrivers or something similar.
- After removal, handle it carefully so it does not tilt or warp under a load.




G00787735

Fig. 90: Removing Timing Chain Tensioner And Slack Side Chain Guide
Courtesy of NISSAN MOTOR CO., U.S.A.

- c. Remove water pump cover and timing chain tensioner cover from front timing chain case.
- d. Remove front oil seal from front timing chain case.

Refer to "**FRONT OIL SEAL**".


- e. Remove internal chain guide.
- f. Remove timing chain tensioner and slack side chain guide.



G00787736

Fig. 91: Inserting Stopper Pin Into Tensioner Body Hole
Courtesy of NISSAN MOTOR CO., U.S.A.


- Remove chain tensioner as follows.
 - a. Pull lever down, and release plunger stopper tab.
 - Plunger stopper tab can be pushed up to release (coaxial structure with lever).
 - Insert stopper pin into tensioner body hole to fix lever, and keep the tab released.
 - Insert plunger into tensioner body by pressing slack guide.
 - Keep slack guide pressed, and fix it by pushing stopper pin through lever hole and body hole.
 - Loosen mounting bolts, and remove chain tensioner.
 - g. Remove primary timing chain and crankshaft sprocket.



G00787737


Fig. 92: Removing Chain Tensioner
Courtesy of NISSAN MOTOR CO., U.S.A.

- h. Attach a suitable stopper pin to RH and LH camshaft chain tensioners. (For secondary timing chains)




G00787738

Fig. 93: Removing Camshaft Chain Tensioners Using Suitable Stopper Pin
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787739


Fig. 94: Removing Intake And Exhaust Camshaft Sprocket Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787740


Fig. 95: Removing Cam Sprocket And Secondary Timing Chain With Timing Chain Floated From Guide Groove

Courtesy of NISSAN MOTOR CO., U.S.A.



G00787741

Fig. 96: Identifying Bolt Location
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787742

Fig. 97: Removing Rear Timing Chain Case
 Courtesy of NISSAN MOTOR CO., U.S.A.

- i. Loosen intake and exhaust camshaft sprocket bolts.
 - **Secure the hexagonal portion of the camshaft using a spanner to loosen mounting bolts.**
- j. Remove secondary timing chains with camshaft sprockets.
 - a. Rotate camshaft lightly, and slacken timing chain of timing chain tensioner-side.
 - b. Insert metal or resin plate [thickness: 0.5 mm (0.020 in)] into guide between timing chain and chain tensioner plunger.

Remove cam sprocket and secondary timing chain with timing chain floated from guide groove.


CAUTION: Chain tensioner plunger may move, while fixed stopper pin and plunger both come off when timing chain is removed. Use caution during removal.

- Intake camshaft sprocket is two-for-one structure of primary and secondary sprockets.
- Handle intake camshaft sprocket, taking care of the following.

- CAUTION:**
- Avoid impact.
 - Do not disassemble (Never loosen bolts A and B).


- k. Remove chain tension guide.
- l. Remove rear timing chain case as follows.
 - a. Loosen mounting bolts in reverse order shown in figure, and remove them.
 - b. Disconnect liquid gasket applied portion using seal cutter (special service tool: KV10111100) or an equivalent tool. Then remove rear timing chain case.

- CAUTION:**
- Do not remove plate metal cover of oil passage.
 - After removing chain case, do not apply any load which affects flatness.



G00787743

Fig. 98: Identifying Plate Metal Cover
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787744

Fig. 99: Removing O-Rings From Cylinder Block
Courtesy of NISSAN MOTOR CO., U.S.A.

- m. Remove O-rings from cylinder block.
- n. Remove RH and LH camshaft chain tensioners from cylinder head as follows, if necessary.
 - a. Remove No. 1 camshaft brackets. Refer to "**REMOVAL**".
 - b. Remove chain tensioners with stopper pin attached.



**G00787745**

Fig. 100: Removing Liquid Gasket From Front Timing Chain Cases
Courtesy of NISSAN MOTOR CO., U.S.A.

- o. Use a scraper to remove all traces of liquid gasket from front and rear timing chain cases, and opposite mating surfaces.



G00787746

Fig. 101: Removing Old Liquid Gasket From Bolt Hole
Courtesy of NISSAN MOTOR CO., U.S.A.

- Remove old liquid gasket from the bolt hole and thread.





Fig. 102: Removing Liquid Gasket From Water Pump Cover
Courtesy of NISSAN MOTOR CO., U.S.A.

- p. Use a scraper to remove all traces of liquid gasket from water pump cover, chain tensioner cover and intake valve timing control covers.




G00787748

Fig. 103: Checking Timing Chain Roller Links
Courtesy of NISSAN MOTOR CO., U.S.A.

INSPECTION

Check for cracks and excessive wear at roller links. Replace chain if necessary.




G00787749

Fig. 104: Installing Chain Tensioners
Courtesy of NISSAN MOTOR CO., U.S.A.

INSTALLATION


1. Install RH and LH camshaft chain tensioners to cylinder head as follows, if removed.
 - a. Install chain tensioners with stopper pin attached and new O-ring, if removed.
 - b. Install No. 1 camshaft brackets.



G00787750

Fig. 105: Installing O-Rings Onto Cylinder Block
Courtesy of NISSAN MOTOR CO., U.S.A.

2. Install O-rings onto cylinder block.



G00787751

Fig. 106: Installing O-Rings To Cylinder Head
 Courtesy of NISSAN MOTOR CO., U.S.A.

3. Install O-rings to cylinder head.
4. Apply liquid gasket to rear timing chain case. Refer to "**POSITION FOR APPLYING LIQUID GASKET**".
5. Align rear timing chain case and water pump assembly with dowel pins (RH and LH) on cylinder block. Then install it.
 - Do not allow O-ring to drop.
 - a. Tighten mounting bolts in order as shown in the figure.
 - Install two types of mounting bolts, referring to the following instructions and figure.


Bolt length:

20 mm (0.79 in) (1, 2, 3, 6, 7, 8, 9, and 10 in the figure)

16 mm (0.63 in) (other than the above)

12 - 13 N.m (1.2 - 1.4 kg-m, 9 - 10 ft-lb)

- b. After all bolts are temporarily tightened, retighten them to specified torque in **Fig. 107**.



G00787752

Fig. 107: Tightening Rear Timing Chain Case Bolts

Courtesy of NISSAN MOTOR CO., U.S.A.

6. After installing rear timing chain case, check surface height difference between following parts on oil pan mounting surface.


Standard

Rear timing chain case to cylinder block:

-0.24 to 0.14 mm (-0.0094 to 0.0055 in)

- If not within standard, repeat above installation procedure.

7. Install chain tension guide.



G00787753

Fig. 108: Identifying Crankshaft Key
Courtesy of NISSAN MOTOR CO., U.S.A.

8. Make sure that camshaft and crankshaft are at TDC position of No. 1 cylinder.
 - Make sure that dowel pin hole, dowel pin and crankshaft key are located as shown in the figure.


Camshaft dowel pin hole (intake-side): At cylinder head upper face side in each bank

Camshaft dowel pin (exhaust-side): At cylinder head upper face side in each bank

Crankshaft key: At cylinder head side of RH bank

CAUTION: Hole on small diameter side must be used for intake camshaft sprocket dowel pin. Do not misidentify (Ignore big diameter side).

9. Install secondary timing chain and camshaft sprocket.




G00787754

Fig. 109: Identifying Stopper Pin

Courtesy of NISSAN MOTOR CO., U.S.A.

CAUTION: Matching marks between timing chain, intake and exhaust camshaft sprockets slip easily. Confirm all matching mark positions repeatedly during the installation process.

- Push sleeve of secondary chain tensioner, and keep it pressed with stopper pin.
- a. Align matching marks on secondary timing chain (gold link) with the ones on intake and exhaust sprockets (stamped). Then install them.
 - Matching marks of intake sprocket are on back side of secondary sprocket.

Example: Right bank side (Rear view)

G00787755

Fig. 110: Aligning Dowel Pin And Pin Hole On Camshaft With Groove And Dowel Pin On Sprocket


Courtesy of NISSAN MOTOR CO., U.S.A.

- There are two types of matching marks: round and oval types. They should be used for RH/LH banks respectively.

RH bank: Use round type.

LH bank: Use oval type.


- b. Align dowel pin and pin hole on camshaft with groove and dowel pin on sprocket. Then install them.
- On intake side, align pin hole on small diameter side of camshaft front end with dowel pin on back side of camshaft sprocket. Then install them.
 - On exhaust side, align dowel pin on camshaft front end with pin groove on camshaft sprocket. Then install them.
 - Mounting bolts for camshaft sprockets must be tightened in step 10. Tightening them by hand is enough to prevent dislocation of dowel pins.



G00787756

Fig. 111: Identifying Mating Mark On Top Of Sprocket Teeth
Courtesy of NISSAN MOTOR CO., U.S.A.


- It may be difficult to visually check the dislocation of mating marks during and after installation. To make the matching easier, make a mating mark on the top of sprocket teeth and its extended line in advance with paint.



G00787757


Fig. 112: Securing Camshaft Hexagonal Portion Using Spanner To Tightening Mounting Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.

10. After confirming the mating marks are aligned, tighten the camshaft sprocket mounting bolts.
 - Secure the camshaft hexagonal portion using a spanner to tighten mounting bolts.
11. Pull out the stopper pin from the secondary timing chain tensioner.



G00787758


Fig. 113: Pulling Out Stopper Pin From Secondary Timing Chain Tensioner
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787759

Fig. 114: Identifying Matching Mark To Crankshaft Sprocket
Courtesy of NISSAN MOTOR CO., U.S.A.

12. Install primary timing chain.
 - Install crankshaft sprocket, with matching mark to timing chain facing front to engine.



G00787760

Fig. 115: Aligning Mating Marks Of Primary Timing Chain Sprocket
Courtesy of NISSAN MOTOR CO., U.S.A.

- Install primary timing chain so that mating mark (punched) on camshaft sprocket is aligned with

that (yellow link) on the timing chain, and mating mark (notched) on crankshaft sprocket is aligned with that orange link on the timing chain, respectively.

- When it is difficult to align mating marks of the primary timing chain with each sprocket, gradually turn the camshaft hexagonal portion using a spanner so it is aligned with the mating mark.

13. Install internal chain guide.





Fig. 116: Installing Internal Chain Guide

Courtesy of NISSAN MOTOR CO., U.S.A.

14. Install slack guide.




G00787762

Fig. 117: Identifying Mounting Bolts

Courtesy of NISSAN MOTOR CO., U.S.A.


- Take care not to over tighten mounting bolts for slack guide. It is normal for a gap to exist under bolt seats when mounting bolts are tightened to specified torque.



G00787763

Fig. 118: Installing Chain Tensioner For Slack Guide
Courtesy of NISSAN MOTOR CO., U.S.A.


15. Install chain tensioner for slack guide.
 - When installing chain tensioner, push in sleeve and keep it pressed with stopper pin.
 - Remove dirt and foreign materials completely from back and mounting surfaces of chain tensioner.
 - After installing, pull out stopper pin by pressing slack guide.
16. Confirm again that matching marks on sprockets and timing chain have not slipped.



G00787764


Fig. 119: Installing Front Oil Seal To Front Timing Chain Case
Courtesy of NISSAN MOTOR CO., U.S.A.

17. Install front oil seal to front timing chain case. Refer to "**FRONT OIL SEAL**".




G00787765

Fig. 120: Applying Liquid Gasket To Water Pump Cover And Chain Tensioner Cover
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787766

Fig. 121: Installing O-Rings On Rear Timing Chain Case
Courtesy of NISSAN MOTOR CO., U.S.A.



**① - ② 8 mm (0.31 in) dia. bolts
25.5 - 31.3 N·m**


(2.6 - 3.1 kg-m, 19 - 23 ft-lb)

**③ - ②② 6 mm (0.24 in) dia. bolts
11.7 - 13.7 N·m**

(1.2 - 1.4 kg-m, 9 - 10 ft-lb)

G00787767

Fig. 122: Tightening Front Timing Chain Case Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787768

Fig. 123: Checking Surface Height Difference Between On Oil Pan Mounting Surface
Courtesy of NISSAN MOTOR CO., U.S.A.

18. Apply liquid gasket to water pump cover and chain tensioner cover. Refer to **INSTALLATION**.
 - Use Genuine RTV Silicone Sealant or equivalent. Refer to **RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS**.
 - Before installation, wipe off the protruding sealant.
19. Install water pump cover and chain tensioner cover.
20. Install O-rings on rear timing chain case.
21. Apply liquid gasket to front timing chain case.
 - Refer to **"POSITION FOR APPLYING LIQUID GASKET"**, .
 - Before installation, wipe off the protruding sealant.
22. Install front timing chain case.
 - Align dowel pin on rear timing chain case with hole on front timing chain case.
23. Tighten bolts to the specified torque in order shown in the figure.
24. After installing front timing chain case, check surface height difference between following parts on oil pan mounting surface.

Standard**Front timing chain case to rear timing chain case:****-0.14 to 0.14 mm (-0.0055 to 0.0055 in)**

- If not within standard, repeat above installation procedure.



**G00787769**


Fig. 124: Installing Seal Ring On Intake Valve Timing Control Cover
Courtesy of NISSAN MOTOR CO., U.S.A.




G00787770

Fig. 125: Installing O-Ring In Front Timing Chain Case
Courtesy of NISSAN MOTOR CO., U.S.A.

Right




Left




G00787771

Fig. 126: Aligning Dowel Pins On Chain Case
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787772

Fig. 127: Installing Rocker Covers
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787773

Fig. 128: Tightening Rocker Covers Bolts

Courtesy of NISSAN MOTOR CO., U.S.A.


25. Install LH and RH intake valve timing control covers.
 - a. Install new seal ring at intake valve timing control cover with new engine oil applied on it.
 - b. Apply liquid gasket to intake valve timing control covers.
 - Use genuine RTV silicone sealant or equivalent. Refer to **RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS**.
 - c. Install collared O-ring in front timing chain case oil hole (LH and RH sides).
 - d. Being careful not to move the seal ring from the installation groove, align the dowel pins on the chain case with the holes to install the intake valve timing control cover.
 - e. Tighten in numerical order as shown in the figure.
26. Install RH and LH rocker covers.
 - Check spark plug hole oil seal for cracks and damage on sealing portion. Replace rocker cover if necessary.
 - Apply liquid gasket to RH and LH rocker covers. Refer to "**POSITION FOR APPLYING LIQUID GASKET**".
 - Use Genuine RTV Silicone Sealant or equivalent. Refer to **RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS**.

Rocker cover tightening procedure:

- **Tighten in numerical order as shown in the figure.**

- a. Tighten bolts 1 to 10 in that order to 0.96 to 2.96 N.m (0.10 to 0.30 kg-m, 9 to 26 in-lb).
- b. Then tighten bolts 1 to 10 as indicated in figure to 7.33 to 9.33 N.m (0.75 to 0.95 kg-m, 65 to 82 in-lb).

27. Install RH and LH intake valve timing control solenoid valves.




G00787774

Fig. 129: Installing Intake Valve Timing Control Solenoid Valves
Courtesy of NISSAN MOTOR CO., U.S.A.

28. Install RH and LH ignition coils.
29. Install intake manifold collector gasket.
30. Install intake manifold upper and lower collectors.


Refer to **TIGHTENING PROCEDURES**.



G00787775

Fig. 130: Tightening Crankshaft Pulley To Crankshaft Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.


31. Install crankshaft pulley to crankshaft.
 - a. Tighten to 39.2 to 49.0 N.m (4.0 to 5.0 kg-m, 29 to 36 ft-lb).
 - b. Put a paint mark on the crankshaft pulley.



G00787776

Fig. 131: Aligning Crankshaft Pulley
Courtesy of NISSAN MOTOR CO., U.S.A.

- c. Again tighten by turning 60° to 66° [Target: 60 degrees (equivalent to one graduation)].



G00787777

Fig. 132: Installing Heated Oxygen Sensor Harness Clamp
Courtesy of NISSAN MOTOR CO., U.S.A.

32. Reinstall removed parts in reverse order of removal.

- **Make sure that crankshaft position sensor (POS) and heated oxygen sensor 1 (bank 2) harness clamp are installed correctly as shown in figure.**
- When installing fuel tube assembly. Refer to **FUEL PRESSURE CHECK** .
- Check oil level after refilling engine oil.
- **After starting engine, keep idling for three minutes. Then rev engine up to 3,000 RPM under no load to purge air from the high-pressure chamber of the chain tensioners. The engine may produce a rattling noise. This indicates that air still remains in the chamber and is not a matter of concern.**

OIL SEAL


REPLACEMENT

CAUTION: When removing the oil pans, oil pump assembly and timing chain from engine, first remove the crankshaft position sensor (POS) from the assembly.

Be careful not to damage sensor edges.

VALVE OIL SEAL

1. Remove ornament cover.
2. Remove intake manifold upper collector and intake manifold lower collector. Refer to "**TIGHTENING PROCEDURES**".
3. Remove RH and LH ignition coils.
4. Remove RH and LH rocker covers from cylinder head. Refer to "**REMOVAL**".
5. Remove crankshaft position sensor (POS). Refer to "**COMPONENTS**".
6. Remove oil pan. Refer to "**REMOVAL**".
7. Remove timing chain. Refer to "**REMOVAL**".
8. Remove camshaft brackets and camshaft. Refer to "**REMOVAL**".
9. Remove valve lifters. Refer to "**REMOVAL**".
10. Remove valve spring with Tool.




G00787778

Fig. 133: Removing Valve Spring Using Tool
Courtesy of NISSAN MOTOR CO., U.S.A.

Before removing valve spring, fix valve as follows.

Piston concerned should be set at TDC to prevent valve from falling.




G00787779

Fig. 134: Applying Air Pressure To Hold Valves In Place

Courtesy of NISSAN MOTOR CO., U.S.A.

Remove spark plug, then install air hose adapter into spark plug hole and apply air pressure to hold valves in place. Apply a pressure of 490 kPa (5 kg/cm², 71 psi).



G00787780

Fig. 135: Removing Valve Oil Seal
Courtesy of NISSAN MOTOR CO., U.S.A.

11. Remove valve oil seal.
12. Apply engine oil to new valve oil seal and install it with Tool.





Fig. 136: Installing Valve Oil Seal
Courtesy of NISSAN MOTOR CO., U.S.A.

13. Reinstall any parts removed in reverse order of removal.

FRONT OIL SEAL

1. Remove the following parts:
 - Engine undercover
 - Front RH wheel and engine side cover
 - Drive belts.
 - Crankshaft pulley. Refer to "**REMOVAL**".

Be careful not to damage sensor edge.




G00787782

Fig. 137: Removing Front Oil Seal Using Suitable Tool
Courtesy of NISSAN MOTOR CO., U.S.A.

2. Remove front oil seal using a suitable tool.

Be careful not to scratch front cover.

3. Apply engine oil to new oil seal and install it using a suitable tool.




G00787783

Fig. 138: Installing Oil Seal

Courtesy of NISSAN MOTOR CO., U.S.A.

- Install new oil seal in the direction shown in the figure.



G00787784

Fig. 139: Removing Rear Oil Seal
Courtesy of NISSAN MOTOR CO., U.S.A.

REAR OIL SEAL

1. Remove transaxle. Refer to **AUTOMATIC TRANSAXLE** .
2. Remove drive plate. Refer to "**COMPONENTS**".
3. Remove oil pan. Refer to **OIL PAN**.
4. Remove rear oil seal retainer.
 - Use seal cutter (SST) or an equivalent tool to cut liquid gasket for removal.
5. Remove old liquid gasket on mating surface of cylinder block and oil pan using scraper.
 - **Remove old liquid gasket from the bolt hole and thread.**





Fig. 140: Applying Liquid Gasket To Rear Oil Seal Retainer
Courtesy of NISSAN MOTOR CO., U.S.A.

6. Apply liquid gasket to rear oil seal retainer.
 - Use Genuine RTV Silicone Sealant or equivalent. Refer to **RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS**.
 - Assembly should be done within 5 minutes after coating.
 - Wait at least 30 minutes before refilling engine oil and engine coolant.

CYLINDER HEAD

COMPONENTS


SEC. 111•118•130•140•220



- | | | |
|---|--------------------------------------|---------------------------|
| 1. Oil filler cap | 8. Spring | 15. Valve spring seat |
| 2. Oil catcher | 9. Chain tensioner | 16. Valve spring |
| 3. Rocker cover | 10. Valve | 17. Valve spring retainer |
| 4. PCV hose | 11. Cylinder head | 18. Valve collet |
| 5. Intake valve timing control solenoid valve | 12. Camshaft position sensor (PHASE) | 19. Valve lifter |
| 6. PCV valve | 13. Spark plug tube | 20. Camshaft (Exhaust) |
| 7. Tensioner sleeve | 14. Spark plug | 21. Camshaft (Intake) |
| | | 22. Camshaft bracket |


G00787786

Fig. 141: Exploded View Of Upper Engine
 Courtesy of NISSAN MOTOR CO., U.S.A.



G00787787

Fig. 142: Front Exhaust Components
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787788


Fig. 143: Removing Front And Rear Engine Mounting Nuts And Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.

CAUTION:

- When installing camshafts, chain tensioners, oil seals, or other sliding parts, lubricate contacting surfaces with new engine oil.
- Apply new engine oil to threads and seat surfaces when installing cylinder head, camshaft sprocket, crankshaft pulley, and camshaft bracket.
- Attach tags to valve lifters so as not to mix them up.


REMOVAL

1. Remove engine undercover.
2. Drain engine oil.
 - To avoid the danger of being scalded, never drain the engine oil when the engine is hot.
3. Drain engine coolant from radiator.
4. Remove radiator. Refer to **RADIATOR**.
5. Remove front exhaust tube and its support. Refer to **REMOVAL AND INSTALLATION**.
6. Set a suitable transmission jack under transaxle and hoist engine with engine slinger.
7. Remove crankshaft position sensor (POS) from oil pan.
8. Loosen front and rear engine mounting nuts and bolts.
9. Remove center member.
10. Remove aluminum oil pan. Refer to **"REMOVAL"**.
11. Remove exhaust manifolds. Refer to **"EXHAUST MANIFOLD"**.
12. Install center member to support engine temporarily.
13. Tighten front and rear engine mounting nuts and bolts.
14. Remove transmission jack and hoist that were supporting engine.
15. Remove timing chain. Refer to **"REMOVAL"**.




G00787789

Fig. 144: Removing Bolts And Intake Manifold
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787790

Fig. 145: Identifying Dowel Pin Hole
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787791

Fig. 146: Removing Rear Timing Chain Case
Courtesy of NISSAN MOTOR CO., U.S.A.




Right bank**Left bank****G00787792**


Fig. 147: Removing O-Rings From Cylinder Head
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787793


Fig. 148: Removing O-Rings From Cylinder Block
Courtesy of NISSAN MOTOR CO., U.S.A.

16. Remove intake manifold in reverse order of illustration.
17. Remove water outlet.
18. Loosen rear timing chain case bolts in reverse order as shown in the figure.
19. Remove rear timing chain case.
 - Use seal cutter (SST) or an equivalent tool to cut liquid gasket for removal.
20. Remove O-rings from cylinder head.
21. Remove O-rings from cylinder block.
22. Remove intake valve timing control solenoid valves.



G00787794


Fig. 149: Removing Intake Valve Timing Control Solenoid Valves
 Courtesy of NISSAN MOTOR CO., U.S.A.



Loosen in numerical order.


G00787795

Fig. 150: Removing (LH) Intake And Exhaust Camshafts And Camshaft Brackets
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787796

Fig. 151: Removing (RH) Intake And Exhaust Camshafts And Camshaft Brackets
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787797


Fig. 152: Removing Chain Tensioner Using Stopper Pin

Courtesy of NISSAN MOTOR CO., U.S.A.

23. Remove intake and exhaust camshafts and camshaft brackets.
- Equally loosen camshaft bracket bolts in several steps in the numerical order shown in the figure.


For reinstallation, be sure to put marks on camshaft bracket before removal.

24. Remove valve lifters.
- Identify installation positions, and store them without mixing them up.
25. Remove RH and LH camshaft chain tensioners from cylinder head.
- Remove chain tensioner with its stopper pin attached.
 - Stopper pin was attached when secondary timing chain was removed.



G00787798


Fig. 153: Removing Cylinder Head Bolts (RH)
Courtesy of NISSAN MOTOR CO., U.S.A.



Loosen in numerical order.

G00787799

Fig. 154: Removing Cylinder Head Bolts (LH)
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787800

Fig. 155: Removing Cylinder Head

Courtesy of NISSAN MOTOR CO., U.S.A.

26. Loosen cylinder head bolts.
 - Cylinder head bolts should be loosened in two or three steps.
 - A warped or cracked cylinder head could result from removing in incorrect order.
27. Remove cylinder head.

DISASSEMBLY


1. Remove spark plug with spark plug wrench (Commercial service tool).
2. Remove valve component parts.

Refer to "VALVE OIL SEAL".

- Check the clearance before removing the valve guide. Refer to "VALVE GUIDE CLEARANCE".
3. Remove spark plug tube, as necessary.
 - Using a pair of pliers, pull spark plug tube out of cylinder head.

CAUTION:

- Take care not to damage cylinder head.
- Once removed, a spark plug tube will be deformed and cannot be reused. Do not remove it unless absolutely necessary.

INSPECTION**CYLINDER HEAD DISTORTION**

G00787801

Fig. 156: Checking Cylinder Head Surface
Courtesy of NISSAN MOTOR CO., U.S.A.

Clean surface of cylinder head.

Use a reliable straightedge and feeler gauge to check the flatness of cylinder head surface.

Check along six positions shown in the figure.

Head surface flatness: Limit 0.1 mm (0.004 in)

If beyond the specified limit, resurface or replace it.

The limit for cylinder head resurfacing is determined by the cylinder block resurfacing.

Resurfacing limit:

Amount of cylinder head resurfacing is "A".

Amount of cylinder block resurfacing is "B".

The maximum limit: $A+B=0.2$ mm (0.008 in)

After resurfacing cylinder head, check that camshaft rotates freely by hand. If resistance is felt, cylinder head must be replaced.

Nominal cylinder head height:

126.3 - 126.5 mm (4.972 - 4.980 in)


**G00787802**

Fig. 157: Measuring Camshaft Runout Using Dial Gauge
Courtesy of NISSAN MOTOR CO., U.S.A.

CAMSHAFT VISUAL CHECK

Check camshaft for scratches, seizure and wear.

CAMSHAFT RUNOUT

1. Put V block on precise flat bed, and support No. 2 and No. 4 journal of camshaft.

2. Set dial gauge vertically to No. 3 Journal.
3. Turn camshaft to one direction with hands, and measure camshaft runout on dial gauge. (total indicator reading).

Runout:**Limit (Total indicator reading) 0.05 mm (0.0020 in)**


4. If it exceeds the limit, replace camshaft.

CAMSHAFT CAM HEIGHT

1. Measure camshaft cam height.

Standard cam height:**Intake and exhaust****44.865 - 45.055 mm (1.7763 - 1.7738 in)****Cam wear limit:****0.2 mm (0.008 in)**

2. If wear is beyond the limit, replace camshaft.



G00787803

Fig. 158: Measuring Camshaft Cam Height
Courtesy of NISSAN MOTOR CO., U.S.A.


CAMSHAFT JOURNAL CLEARANCE

1. Install camshaft bracket and tighten bolts to the specified torque.
2. Measure inner diameter "A" of camshaft bearing.

Standard inner diameter:


No. 1: 26.000 - 26.021 mm (1.0236 - 1.0244 in)

No. 2, 3, 4: 23.500 - 23.521 mm (0.9252 - 0.9260 in)



G00787804

Fig. 159: Measuring Inner Diameter Of Camshaft Bearing
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787805

Fig. 160: Measuring Outer Diameter Of Camshaft Journal
Courtesy of NISSAN MOTOR CO., U.S.A.

3. Measure outer diameter of camshaft journal.

Standard outer diameter:

No. 1: 25.935 - 25.955 mm (1.0211 - 1.0218 in)

No. 2, 3, 4: 23.445 - 23.465 mm (0.9230 - 0.9238 in)

4. If clearance exceeds the limit, replace camshaft and/or cylinder head.

Camshaft journal clearance:

Standard

NO. 1: 0.045 - 0.086 mm (0.0018 - 0.0034 in)


NO. 2, 3, 4: 0.035 - 0.076 mm (0.0014 - 0.0030 in)

Limit

0.15 mm (0.0059 in)

CAMSHAFT END PLAY

1. Install camshaft in cylinder head. Then install dial gauge in thrust direction on front end of camshaft.
2. Measure and play of dial gauge when camshaft is moved forward/backward (in direction to axis).



G00787806

Fig. 161: Measuring And Play Of Camshaft Using Dial Gauge
Courtesy of NISSAN MOTOR CO., U.S.A.

Camshaft end play:

Standard

0.115 - 0.188 mm (0.0045 - 0.0074 in)

Limit

0.24 mm (0.0094 in)

- When out of the limit, replace with new camshaft and measure again.
- When out of the limit again, replace with new cylinder head.


CAMSHAFT SPROCKET RUNOUT

1. Put V block on precise flat bed, and support No. 2 and No. 4 journal of camshaft.
2. Install sprocket on camshaft.
3. Measure camshaft sprocket runout.

Runout (Total indicator reading):

Less than 0.15 mm (0.0059 in)

4. If it exceeds the limit, replace camshaft sprocket.



G00787807

Fig. 162: Measuring Camshaft Sprocket Runout
Courtesy of NISSAN MOTOR CO., U.S.A.




Fig. 163: Measuring Valve Guide Clearance
Courtesy of NISSAN MOTOR CO., U.S.A.

VALVE GUIDE CLEARANCE

1. Measure valve deflection as shown in the figure. (Valve and valve guide mostly wear in this direction.)

Valve deflection limit (Dial gauge reading):

Intake 0.24 mm (0.0094 in)

Exhaust 0.28 mm (0.0110 in)




Fig. 164: Measuring Valve Stem Diameter And Valve Guide Inner Diameter
Courtesy of NISSAN MOTOR CO., U.S.A.


2. If it exceeds the limit, check valve to valve guide clearance.
 - a. Measure valve stem diameter and valve guide inner diameter.
 - b. Check that clearance is within specification.

Valve to valve guide clearance limit:

Intake 0.08 mm (0.0031 in)

Exhaust 0.1 mm (0.004 in)

- c. If it exceeds the limit, replace valve or valve guide.



G00787810

Fig. 165: Heating Cylinder Head To By Soaking In Heated Oil
Courtesy of NISSAN MOTOR CO., U.S.A.

VALVE GUIDE REPLACEMENT

1. To remove valve guide, heat cylinder head to 110 to 130°C (230 to 266°F) by soaking in heated oil.


**G00787811**

Fig. 166: Removing Valve Guide Using Hammer And Suitable Tool
Courtesy of NISSAN MOTOR CO., U.S.A.


2. Drive out valve guide with a press [under a 20 kN (2 ton, 2.2 US ton, 2.0 Imp ton) pressure] or hammer and suitable tool.

CAUTION: Cylinder head contains heat. When working, wear protective equipment to avoid getting burned.

3. Ream cylinder head valve guide hole.


Valve guide hole diameter (for service parts):

10.175 - 10.196 mm (0.4006 - 0.4014 in)



G00787812

Fig. 167: Reaming Valve Guide Hole On Cylinder Head
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787813

Fig. 168: Measuring Service Valve Guide Onto Cylinder Head

Courtesy of NISSAN MOTOR CO., U.S.A.


4. Heat cylinder head to 110 to 130°C (230 to 266°F) and press service valve guide onto cylinder head.

Projection "L":**12.6 - 12.8 mm (0.496 - 0.504 in)**

CAUTION: Cylinder head contains heat. When working, wear protective equipment to avoid getting burned.

5. Ream valve guide.

Finished size:**6.000 - 6.018 mm (0.2362 - 0.2369 in)**




G00787814

Fig. 169: Reaming Valve Guide Seats
Courtesy of NISSAN MOTOR CO., U.S.A.

VALVE SEATS

Check valve seats for any evidence of pitting at valve contact surface, and reseal or replace if it has worn out excessively.

- **Before repairing valve seats, check valve and valve guide for wear. If they have worn, replace them. Then correct valve seat.**
- **Use both hands to cut uniformly.**



G00787815

Fig. 170: Measuring Valve Seat Recess Diameter
Courtesy of NISSAN MOTOR CO., U.S.A.

REPLACING VALVE SEAT FOR SERVICE PARTS

1. Bore out old seat until it collapses. Boring should not continue beyond the bottom face of the seat recess in cylinder head. Set the machine depth stop to ensure this.
2. Ream cylinder head recess for service valve seat.


Oversize [0.5 mm (0.020 in)]:

Intake 38.500 - 38.516 mm (1.5157 - 1.5164 in)

Exhaust 32.700 - 32.716 mm (1.2874 - 1.2880 in)

Be sure to ream in circles concentric to the valve guide center.

This will enable valve seat to fit correctly.



G00787816

Fig. 171: Checking Valve Seating Condition

Courtesy of NISSAN MOTOR CO., U.S.A.

3. Heat cylinder head to 110 to 130°C (230 to 266°F) by soaking in heated oil.
4. Press fit valve seat until it seats on the bottom.

CAUTION: Cylinder head contains heat. When working, wear protective equipment to avoid getting burned.

5. Cut or grind valve seat using suitable tool to the specified dimensions as shown in SDS (EM-91).
6. After cutting, lap valve seat with abrasive compound.
7. Check valve seating condition.

Seat face angle "alpha": 45°15' - 45°45'

Contacting width "W":**Intake 1.09 - 1.31 mm (0.0429 - 0.0516 in)****Exhaust 1.29 - 1.51 mm (0.0508 - 0.0594 in)**

8. Use a depth gauge to measure the distance between the mounting surface of the cylinder head spring seat and the valve stem end. If the distance is shorter than specified, repeat step 5 above to adjust it. If it is longer, replace the valve seat with a new one.


Valve seat resurface limit "L":**Intake 41.07 - 41.67 mm (1.6169 - 1.6405 in)****Exhaust 41.00 - 41.60 mm (1.6142 - 1.6378 in)****G00787817**

Fig. 172: Measuring Distance Between Mounting Surface Of Cylinder Head
Courtesy of NISSAN MOTOR CO., U.S.A.


VALVE DIMENSIONS

Check dimensions of each valve. For dimensions, refer to SDS (**VALVE**).

When valve head has been worn down to 0.5 mm (0.020 in) in margin thickness, replace valve.

Grinding allowance for valve stem tip is 0.2 mm (0.008 in) or less.

T (Margin thickness)



G00787818

Fig. 173: Measuring Valve Dimensions
Courtesy of NISSAN MOTOR CO., U.S.A.

VALVE SPRING


Squareness

1. Measure dimension "S".

Out-of-square "S":

Less than 2.0 mm (0.079 in)

2. If it exceeds the limit, replace spring.



G00787819

Fig. 174: Measuring Valve Spring
Courtesy of NISSAN MOTOR CO., U.S.A.

Pressure

Check valve spring pressure at specified spring height.

Pressure:


Installation

196 N (20.0 kg, 44.1 lb) at height 37.0 mm (1.457 in)

Valve open

More than 433 N (44.2 Kg, 97.3 lb) at height 27.8 mm (1.094 in)

If it exceeds the limit, replace spring.




G00787820

Fig. 175: Checking Valve Spring Pressure
Courtesy of NISSAN MOTOR CO., U.S.A.

VALVE LIFTER

1. Check contact and sliding surfaces for wear or scratches.




G00787821

Fig. 176: Identifying Valve Lifter

Courtesy of NISSAN MOTOR CO., U.S.A.

2. Check diameter of valve lifter and valve lifter guide bore.

Valve lifter outer diameter:**33.977 - 33.987 mm (1.3377 - 1.3381 in)**




G00787822

Fig. 177: Measuring Valve Lifter Diameter
Courtesy of NISSAN MOTOR CO., U.S.A.

Lifter guide bore diameter:

34.000 - 34.016 mm (1.3386 - 1.3392 in)

- When out of specified range, refer to each specification of outer and inner diameter. Then replace either or both valve lifter and cylinder head.



G00787823

Fig. 178: Measuring Outer And Inner Diameter
Courtesy of NISSAN MOTOR CO., U.S.A.

ASSEMBLY

1. Install spark plug tube.


**G00787824**

Fig. 179: Locating Applying Liquid Gasket To Area
Courtesy of NISSAN MOTOR CO., U.S.A.

- Press-fit spark plug tube following procedure below.
 - a. Remove old liquid gasket adhering to cylinder-head mounting hole.
 - b. Apply liquid gasket to area within approximately 12 mm (0.47 in) from edge of spark plug tube press-fit side.
 - Use Genuine Liquid Gasket or equivalent.
 - c. Using a drift, press-fit spark plug tube so that its height "H" is as specified in the figure.

Standard press-fit height "H":


: 38.55 - 38.65 mm (1.5177 - 1.5217 in)

CAUTION:

- When press-fitting, take care not to deform spark plug tube.
- After press-fitting, wipe off liquid gasket protruding onto cylinder-head upper face.

2. Install valve component parts.


- Always use new valve oil seal. Refer to VALVE OIL SEAL.
- Before installing valve oil seal, install valve spring seat.
- Install valve spring (uneven pitch type) with its narrow pitch side toward cylinder head side (paint mark).
- After installing valve component parts, tap valve stem tip with plastic hammer to assure a proper fit.



Cylinder head side

G00787825

Fig. 180: Measuring Valve Spring
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787826

Fig. 181: Removing Old Liquid Gasket From Mating Surface Using Scraper
Courtesy of NISSAN MOTOR CO., U.S.A.

3. Install spark plug.

INSTALLATION

1. Before installing rear timing chain case, remove old liquid gasket from mating surface using a scraper.
 - Also remove old liquid gasket from mating surface of cylinder block.
 - **Remove old liquid gasket from the bolt hole and thread.**



**G00787827**

Fig. 182: Removing Old Liquid Gasket From Bolt Hole And Thread
Courtesy of NISSAN MOTOR CO., U.S.A.

2. Before installing cam bracket, remove old liquid gasket from mating surface using a scraper.




G00787828

Fig. 183: Removing Old Liquid Gasket Using Scraper
Courtesy of NISSAN MOTOR CO., U.S.A.

3. Before installing the cylinder head gasket, be sure that No. 1 cylinder is at TDC.

Right bank side




G00787829


Fig. 184: Identifying Crankshaft Key
Courtesy of NISSAN MOTOR CO., U.S.A.

- At this time, the crankshaft key should face toward the right bank.
4. Install cylinder heads with new gaskets.

RH cylinder head gasket




LH cylinder head gasket



G00787830


Fig. 185: Identifying cylinder heads gaskets
Courtesy of NISSAN MOTOR CO., U.S.A.

Cylinder head bolt




G00787831

Fig. 186: Measuring Cylinder Head Bolt Outer Diameter
Courtesy of NISSAN MOTOR CO., U.S.A.




G00787832

Fig. 187: Tightening Cylinder Head Outside Bolts (RH)
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787833

Fig. 188: Tightening Cylinder Head Outside Bolts (LH)
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787834

Fig. 189: Tightening Torque Graph

Courtesy of NISSAN MOTOR CO., U.S.A.

- Do not rotate crankshaft and camshaft separately, o valves will strike piston heads.

CAUTION: Cylinder head bolts are tightened by plastic zone tightening method. Whenever the size difference between d1 and d2 exceeds the limit, replace them with new ones.

Limit (d1 - d2):

0.11 mm (0.0043 in)


- If reduction of outer diameter appears in a position other than d2, use it as d2 point.
- Lubricate threads and seat surfaces of the bolts with new engine oil.

5. Tighten cylinder head outside bolts.

- Tightening procedure:


- Tighten all bolts to 98 N.m (10 kg-m, 72 ft-lb).
- Completely loosen all bolts.

- c. Tighten all bolts to 34.3 to 44.1 N.m (3.5 to 4.4 kg-m, 26 to 32 ft-lb).
 - d. Turn all bolts 90 to 95 degrees clockwise [target: 90 degrees (angle tightening)].
 - e. Turn all bolts 90 to 95 degrees clockwise again [target: 90 degrees (angle tightening)].
 - Tighten in numerical order shown in the figure.
6. Install camshaft chain tensioners on both sides of cylinder head.



G00787835

Fig. 190: Installing Camshaft Chain Tensioners On Both Sides Of Cylinder Head
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787836

Fig. 191: Installing Dowel Pin On Camshaft Sprocket
 Courtesy of NISSAN MOTOR CO., U.S.A.

Bank	INT/EXH	ID mark	Paint mark	
			M1	M2
RH	INT	RE	Yes	No
	EXH	RE	No	Yes
LH	INT	LH	Yes	No
	EXH	LH	No	Yes

G00787837

Fig. 192: Camshafts Pint Mark Chart

Courtesy of NISSAN MOTOR CO., U.S.A.





Fig. 193: Identifying Mark On Camshafts
Courtesy of NISSAN MOTOR CO., U.S.A.

7. Install exhaust and intake camshafts and camshaft brackets.
 - Exhaust camshaft has a dowel pin on camshaft sprocket mounting flange. Install it on the exhaust side.
 - Identification marks are present on camshafts.



G00787839


Fig. 194: Identifying Dowel Pin

Courtesy of NISSAN MOTOR CO., U.S.A.

- **Position camshaft**

RH exhaust camshaft dowel pin at about 10 o'clock**LH exhaust camshaft dowel pin at about 2 o'clock**

8. Before installing camshaft brackets, apply sealant to mating surface of No. 1 camshaft bracket.




G00787840

Fig. 195: Identifying Stamp Mark
Courtesy of NISSAN MOTOR CO., U.S.A.


RH camshaft brackets

Exhaust side



LH camshaft brackets

Intake side




G00787841

Fig. 196: Identifying Camshaft Bering Cap
 Courtesy of NISSAN MOTOR CO., U.S.A.

Step	Tightening torque	Tightening order
1	1.96 N·m (0.2 kg-m, 17 in-lb)	Tighten in the order of 7 to 10, then tighten 1 to 6.
2	5.88 N·m (0.6 kg-m, 52 in-lb)	Tighten in the numerical order.
3	9.02 - 11.8 N·m (0.92 - 1.20 kg-m, 79.9 - 104.2 in-lb)	Tighten in the order of 1 to 6.
	8.3 - 10.3 N·m (0.9 - 1.0 kg-m, 74 - 91 in-lb)	Tighten in the order of 7 to 10.

G00787842


Fig. 197: Tightening Torque Specification Chart
 Courtesy of NISSAN MOTOR CO., U.S.A.



G00787843

Fig. 198: Tightening Camshaft Bering Cap (RH)

Courtesy of NISSAN MOTOR CO., U.S.A.



G00787844

Fig. 199: Tightening Camshaft Bering Cap (LH)

Courtesy of NISSAN MOTOR CO., U.S.A.

- Refer to "POSITION FOR APPLYING LIQUID GASKET", .
- Use Genuine RTV silicone sealant or equivalent. Refer to RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS .
- Install camshaft brackets in their original positions. Align stamp mark as shown in the figure.
- If any part of valve assembly or camshaft is replaced, check valve clearance according to reference data.

After completing assembly check valve clearance. Refer to "Checking" and "Adjusting", Valve CLEARANCE and ADJUSTING.

Reference data valve clearance (Cold):


Intake

0.26 - 0.34 mm (0.010 - 0.013 in)

Exhaust

0.29 - 0.37 mm (0.011 - 0.015 in)


- Lubricate threads and seat surfaces of camshaft bracket bolts with new engine oil before installing them.
- Tighten the camshaft brackets in the following steps.



G00787845

Fig. 200: Installing Intake Valve Timing Control Solenoid Valves
Courtesy of NISSAN MOTOR CO., U.S.A.


9. Install intake valve timing control solenoid valves.



G00787846

Fig. 201: Installing O-Rings To Cylinder Block
Courtesy of NISSAN MOTOR CO., U.S.A.


10. Install O-rings to cylinder block.



G00787847

Fig. 202: Installing O-Rings To Cylinder Head
Courtesy of NISSAN MOTOR CO., U.S.A.

11. Install O-rings to cylinder head.
12. Apply sealant to the hatched portion of rear timing chain case. Refer to "**POSITION FOR APPLYING LIQUID GASKET**", .
 - Apply continuous bead of liquid gasket to mating surface of rear timing chain case.
 - **Before installation, wipe off the protruding sealant.**



G00787848

Fig. 203: Tightening Rear Chain Case Bolts
 Courtesy of NISSAN MOTOR CO., U.S.A.

13. Align rear timing chain case with dowel pins, then install on cylinder head and block.
14. Tighten rear chain case bolts.
 - a. Tighten bolts in numerical order shown in the figure with smaller torque than specified.
 - b. Tighten bolts to the specified torque repeating above step a.
15. Reinstall all removed parts in reverse order of removal.


VALVE CLEARANCE

CHECKING

Check valve clearance while engine is cold and not running.

1. Remove ornament cover.
2. Remove air duct with air cleaner case, collectors, hoses, wires, harnesses, connectors and so on.
3. Remove intake manifold collectors. Refer to "**TIGHTENING PROCEDURES**".

4. Remove ignition coils and spark plugs.
5. Remove RH and LH rocker cover. Refer to "**REMOVAL**".
6. Set No. 1 cylinder at TDC on its compression stroke.
 - Align pointer with TDC mark on crankshaft pulley.



G00787849

Fig. 204: Aligning Crankshaft Pulley Mark
Courtesy of NISSAN MOTOR CO., U.S.A.




Fig. 205: Aligning Valve Lifters

Courtesy of NISSAN MOTOR CO., U.S.A.

- Check that valve lifters on No. 1 cylinder are loose and valve lifters on No. 4 are tight.

If not, turn crankshaft one revolution (360°) and align as shown.


Measuring position (RH bank)		No. 1 CYL	No. 3 CYL	No. 5 CYL
No. 1 cylinder at TDC	EXH		X	
	INT	X		
Measuring position (LH bank)		No. 2 CYL	No. 4 CYL	No. 6 CYL
No. 1 cylinder at TDC	INT			X
	EXH	X		

G00787851


Fig. 206: Cylinder Positioning Chart
Courtesy of NISSAN MOTOR CO., U.S.A.

7. Check only those valves shown in the figure.

RH cylinder head




Engine front



LH cylinder head

G00787852

Fig. 207: Tightening Crankshaft Bering Cap
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787853

Fig. 208: Measuring Clearance Between Valve Lifter And Camshaft
Courtesy of NISSAN MOTOR CO., U.S.A.

- Using a feeler gauge, measure clearance between valve lifter and camshaft.
- Record any valve clearance measurements which are out of specification. They will be used later to determine the required replacement valve lifter.

Valve clearance for checking (Cold):

Intake

0.26 - 0.34 mm (0.010 - 0.013 in)

Exhaust

0.29 - 0.37 mm (0.011 - 0.015 in)


8. Turn crankshaft 240° and align as above.
9. Set No. 3 cylinder at TDC on its compression stroke.
10. Check only those valves shown in the figure.

Measuring position (RH bank)		No. 1 CYL	No. 3 CYL	No. 5 CYL
No. 3 cylinder at TDC	EXH			X
	INT		X	
Measuring position (LH bank)		No. 2 CYL	No. 4 CYL	No. 6 CYL
No. 3 cylinder at TDC	INT	X		
	EXH		X	


G00787854

Fig. 209: Cylinder Position Chart (RH BANK)
 Courtesy of NISSAN MOTOR CO., U.S.A.

RH cylinder head



←
Engine front



LH cylinder head

G00787855

Fig. 210: Tightening Crankshaft Bering Cap
 Courtesy of NISSAN MOTOR CO., U.S.A.

11. Turn crankshaft 240° and align as above.
12. Set No. 5 cylinder at TDC on its compression stroke.
13. Check only those valves shown in the figure.


Measuring position (RH bank)		No. 1 CYL	No. 3 CYL	No. 5 CYL
No. 5 cylinder at TDC	EXH	X		
	INT			X
Measuring position (LH bank)		No. 2 CYL	No. 4 CYL	No. 6 CYL
No. 5 cylinder at TDC	INT		X	
	EXH			X

G00787856


Fig. 211: Cylinder Position Chart (RH BANK)
 Courtesy of NISSAN MOTOR CO., U.S.A.

14. If all valve clearances are within specification, install the following parts. If they are out of specification, adjust the valve clearances.
 - Intake manifold collectors
 - RH and LH rocker covers
 - All spark plugs
 - All ignition coils

RH cylinder head



Engine front



LH cylinder head

G00787857


Fig. 212: Tightening Crankshaft Bearing Cap
Courtesy of NISSAN MOTOR CO., U.S.A.

ADJUSTING

Adjust valve clearance while engine is cold.

Perform adjustment by selecting head thickness of valve lifter (Adjusting shims are not used).

1. Remove camshaft.
2. Remove valve lifter at location where measured value is outside standard.



G00787858

Fig. 213: Measuring Center Thickness Of Valve Lifter Using Micrometer
Courtesy of NISSAN MOTOR CO., U.S.A.

3. Measure center thickness of removed valve lifter with micrometer.

4. Use equation below to calculate valve lifter thickness for replacement.

Valve lifter thickness calculation: $t = t1 + (C1 - C2)$

t = Thickness of replacement valve lifter

t1 = Thickness of removed valve lifter

C1 = Measured valve clearance

C2 = Standard valve clearance:

Intake: 0.30 mm (0.012 in)

Exhaust: 0.33 mm (0.013 in)

Unit: mm (in)


Stamp mark	Thickness of valve lifter
Starting: 788U or 788R	7.88 (0.3102)
Ending: 840U or 840R	8.40 (0.3307)

G00787859

Fig. 214: Valve Lifter Thickness Chart

Courtesy of NISSAN MOTOR CO., U.S.A.

- Thickness of new valve lifter can be identified by stamp mark on reverse side (inside cylinder).



G00787860

Fig. 215: Identifying Stamp Mark

Courtesy of NISSAN MOTOR CO., U.S.A.

- Available thickness of valve lifter (Factory setting): 7.88 - 8.40 mm (0.3102 - 0.3307 in) [in 0.02 mm (0.0008 in) step] in 27 sizes (Intake/Exhaust)

5. Install selected valve lifter.

6. Install camshaft.
7. Rotate crankshaft a few turns by hand.
8. Confirm that valve clearance is within standard.
9. After repair, confirm that valve clearance is within standard with engine warmed-up.

Valve clearance:

Unit: mm (in)

	Cold	Hot* (reference data)
Intake	0.26 - 0.34 (0.010 - 0.013)	0.304 - 0.416 (0.012 - 0.016)
Exhaust	0.29 - 0.37 (0.011 - 0.015)	0.308 - 0.432 (0.012 - 0.017)

*: Approximately 80°C (176°F)

G00787861

Fig. 216: Valve Clearance Chart

Courtesy of NISSAN MOTOR CO., U.S.A.

ENGINE ASSEMBLY**REMOVAL AND INSTALLATION**

SEC. 112




Fig. 217: Removing Engine Components
Courtesy of NISSAN MOTOR CO., U.S.A.


WARNING:

- Situate vehicle on a flat and solid surface.
- Place chocks at front and back of rear wheels.
- Do not remove engine until exhaust system has completely cooled off. Otherwise, you may burn yourself and/or fire may break out in fuel line.

- For safety during subsequent steps, the tension of wires should be slackened against the engine.
- Before disconnecting fuel hose, release fuel pressure from fuel line.
- Refer to **FUEL PRESSURE RELEASE** .
- Before removing front axle from transaxle, place safety stands under designated front supporting points.
- Be sure to hoist engine and transaxle in a safe manner.
- For engines not equipped with engine slingers, attach proper slingers and bolts described in **PARTS CATALOG**.

CAUTION:

- When lifting engine, be careful not to strike adjacent parts, especially the following: Accelerator wire casing, brake lines, and brake master cylinder.
- In hoisting the engine, always use engine slingers in a safe manner.
- In removing drive shaft, be careful not to damage grease seal of transaxle.
- Before separating engine and transaxle, remove the crankshaft position sensor (POS) from the assembly.
- Always pay extra attention not to damage edge of crankshaft position sensor (POS) or ring gear teeth.



G00787863

Fig. 218: Identifying Engine Mounting Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.


REMOVAL

1. Remove engine undercover and hood.
2. Drain engine coolant from both cylinder block and radiator.
3. Remove vacuum hoses, fuel hoses, wires, harnesses, connectors and so on.
4. Remove front exhaust tubes, ball joints and drive shafts. Refer to **REMOVAL AND INSTALLATION & AXLE SHAFTS**.
5. Remove radiator and fans. Refer to **RADIATOR**.
6. Remove drive belts.
7. Remove alternator, compressor and power steering oil pump from engine. Refer to **GENERATOR, COMPRESSOR & STEERING SYSTEM**.

Vehicle front

**24.5 - 31.4 N•m
(2.5 - 3.2 kg-m,
18 - 23 ft-lb)**


Engine front



G00787864

Fig. 219: Removing Engine Rear Slinger
Courtesy of NISSAN MOTOR CO., U.S.A.

8. Set a suitable transmission jack under transaxle. Hoist engine with engine slinger.
9. Remove LH engine mounting.





Fig. 220: Removing Engine Front Lower Slinger
 Courtesy of NISSAN MOTOR CO., U.S.A.


10. Disconnect control cable from transaxle. Refer to CONTROL CABLE.



G00787866

Fig. 221: Removing LH Engine Mounting
Courtesy of NISSAN MOTOR CO., U.S.A.


11. Remove RH engine mounting.



G00787867

Fig. 222: Removing Center Member Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.


12. Remove center member and then slowly lower transmission jack.



G00787868

Fig. 223: Lifting Engine With Transaxle
Courtesy of NISSAN MOTOR CO., U.S.A.

13. Remove engine with transaxle as shown.



G00787869

Fig. 224: Identifying Actuator Harness

Courtesy of NISSAN MOTOR CO., U.S.A.

INSTALLATION

Installation is in the reverse order of removal.

Install the electronically-controlled engine mount harness to match the following values.

Front (A - B):

170 mm (6.69 in)

Rear (C - D):

130 mm (5.12 in)


CYLINDER BLOCK

COMPONENTS

[illegible]

- G00787870


martes, 12 de octubre de 2021 12:57:42 p. m.



G00787871

Fig. 226: Removing Components


Courtesy of NISSAN MOTOR CO., U.S.A.



G00787872


Fig. 227: Removing Oil Pan

Courtesy of NISSAN MOTOR CO., U.S.A.




G00787873

Fig. 228: Heating Pistons And Connecting Rods
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787874

Fig. 229: Removing Bearing Beam And Bearing Cap
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787875

Fig. 230: Removing Oil Jets

Courtesy of NISSAN MOTOR CO., U.S.A.

REMOVAL AND INSTALLATION**CAUTION:**

- When installing bearings, pistons, or other sliding parts, lubricate contacting surfaces with new engine oil.
- Place removed parts such as bearings and bearing caps in their proper order and direction.
- When installing connecting rod nuts, and main bearing cap bolts, apply new engine oil to threads and seating surfaces.

- Do not allow any magnetic materials to contact the signal plate teeth of flywheel or drive plate.

DISASSEMBLY

PISTON, CRANKSHAFT AND OIL JET

1. Remove engine. Refer to "**REMOVAL AND INSTALLATION**", .
2. Place engine on a work stand.
3. Drain coolant and oil.
4. Remove oil pan. Refer to "**REMOVAL**", .
5. Remove timing chain. Refer to "**REMOVAL**", .
6. Remove cylinder head. Refer to "**REMOVAL**", .
7. Remove pistons with connecting rods.
 - When disassembling piston and connecting rod, remove snap ring first, then heat piston to 60 to 70° C (140 to 158°F).
8. Remove rear oil seal retainer.

CAUTION:

- When piston rings are not replaced, make sure that piston rings are mounted in their original positions.
- When replacing piston rings, if there is no punchmark, install with either side up.

9. Loosen bolts in numerical order as shown and remove main bearing beam, bearing cap and crankshaft.
 - Before removing bearing beam and bearing cap, measure crankshaft end play. Refer to **OIL JET**.
 - Bolts should be loosened in two or three steps.
10. Remove knock sensor.

CAUTION:


- Carefully handle the sensor and avoid impacts.

11. Remove oil jets.

INSPECTION


PISTON AND PISTON PIN CLEARANCE

1. Measure inner diameter of piston pin hole "dp".



G00787876


Fig. 231: Measuring Inner Diameter Of Piston Pin Hole
Courtesy of NISSAN MOTOR CO., U.S.A.



Micrometer

G00787877

Fig. 232: Measuring Outer Diameter Of Piston Pin
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787878

Fig. 233: Measuring Piston Ring Side Clearance

Courtesy of NISSAN MOTOR CO., U.S.A.

Standard diameter "dp".**Grade No. 0****21.993 - 21.999 mm (0.8659 - 0.8661 in)****Grade No. 1****21.999 - 22.005 mm (0.8661 - 0.8663 in)**

2. Measure outer diameter of piston pin "Dp".

Standard diameter "Dp":**Grade No. 0**

21.989 - 21.995 mm (0.8657 - 0.8659 in)

Grade No. 1

21.995 - 22.001 mm (0.8659 - 0.8662 in)

3. Calculate interference fit of piston pin to piston.

Dp - dp = 0.002 - 0.006 mm (0.0001 - 0.0002 in)

If it exceeds the above value, replace piston assembly with pin.

PISTON RING SIDE CLEARANCE

Side clearance:

Top ring

0.045 - 0.080 mm (0.0018 - 0.0031 in)

2nd ring

0.030 - 0.070 mm (0.0012 - 0.0028 in)

Oil ring


0.065 - 0.135 mm (0.0026 - 0.0053 in)

Max. limit of side clearance:

Top ring 0.11 mm (0.0043 in)

2nd ring 0.1 mm (0.004 in)

If out of specification, replace piston ring. If clearance exceeds maximum limit with new ring, replace piston.



G00787879

Fig. 234: Measuring Piston Ring End Gap
Courtesy of NISSAN MOTOR CO., U.S.A.

PISTON RING END GAP

End gap:

Top ring 0.23 - 0.33 mm (0.0091 - 0.0130 in)

2nd ring 0.33 - 0.48 mm (0.0130- 0.0189 in)

Oil ring 0.20 - 0.60 mm (0.0079 - 0.0236 in)

Max. limit of ring gap:

Top ring 0.54 mm (0.0213 in)


2nd ring 0.80 mm (0.0315 in)

Oil ring 0.95 mm (0.0374 in)

If out of specification, replace piston ring. If gap still exceeds the limit even with a new ring, do the following. Rebore cylinder and use oversized piston and piston rings.


Refer to SDS (**PISTON, PISTON RING AND PISTON PIN**).

- When replacing the piston, check the cylinder block surface for scratches or seizure. If scratches or seizure is found, hone or replace the cylinder block.




G00787880

Fig. 235: Checking Connecting Rod Bend And Torsion (1 Of 2)
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787881

Fig. 236: Checking Connecting Rod Bend And Torsion (2 Of 2)
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787882

Fig. 237: Checking Cylinder Block Surface
Courtesy of NISSAN MOTOR CO., U.S.A.

CONNECTING ROD BEND AND TORSION

Bend:

Limit 0.15 mm (0.0059 in)

per 100 mm (3.94 in) length

Torsion:

Limit 0.30 mm (0.0118 in)

per 100 mm (3.94 in) length

If it exceeds the limit, replace connecting rod assembly.

CYLINDER BLOCK DISTORTION AND WEAR

- Clean upper surface of cylinder block.

Use a reliable straightedge and feeler gauge to check the flatness of cylinder block surface.

Check along six positions shown in the figure.

Distortion limit: 0.10 mm (0.0039 in)

- If out of specification, resurface it. The limit for cylinder block resurfacing is determined by cylinder head resurfacing in engine.

Resurfacing limit:

Amount of cylinder head resurfacing is "A".

Amount of cylinder block resurfacing is "B".

The maximum limit is as follows:

A + B = 0.2 mm (0.008 in)

Nominal cylinder block height from crankshaft center:

214.95 - 215.05 mm (8.4626 - 8.4665 in)


Refer to SDS (CYLINDER BLOCK).

- If necessary, replace cylinder block.

Grade No.	Standard inner diameter	Wear limit
No. 1	95.500 - 95.510 mm (3.7598 - 3.7602 in)	0.20 mm (0.0079 in)
No. 2	95.510 - 95.520 mm (3.7602 - 3.7606 in)	
No. 3	95.520 - 95.530 mm (3.7606 - 3.7610 in)	


G00787883

Fig. 238: Measuring Cylinder Bore Diameter Chart
Courtesy of NISSAN MOTOR CO., U.S.A.




G00787884

Fig. 239: Measuring Cylinder Bore
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787885

Fig. 240: Measuring Cylinder Bore Out Diameter
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787886


Fig. 241: Identifying Cylinder Bore Grade Number

Courtesy of NISSAN MOTOR CO., U.S.A.

PISTON-TO-BORE CLEARANCE

1. Using a bore gauge, measure cylinder bore for wear, out-of-round and taper.

Cylinder bore inner diameter



G00787887

Fig. 242: Measuring Piston Skirt Diameter
Courtesy of NISSAN MOTOR CO., U.S.A.

If it exceeds the limit, rebore all cylinders. Replace cylinder block if necessary.

Out-of-round (Difference between X and Y):

Limit 0.015 mm (0.0006 in)

Taper (Difference between A and C):

Limit 0.015 mm (0.0006 in)

2. Check for scratches and seizure. If seizure is found, hone it.

- If both cylinder block and piston are replaced with new ones, select piston of the same grade number punched on cylinder block rear position. These numbers are punched in either Arabic or Roman numerals.

3. Measure piston skirt diameter.

Piston diameter "A": Refer to SDS (PISTON, PISTON RING AND PISTON PIN).

Measuring point "a" (Distance from the top):

41.0 mm (1.61 in)

4. Check that piston-to-bore clearance is within specification.

Piston-to-bore clearance "B":

0.010 - 0.030 mm (0.0004 - 0.0012 in)

5. Determine piston oversize according to amount of cylinder wear.

Oversize pistons are available for service.

Refer to SDS (PISTON, PISTON RING AND PISTON PIN).

- **If oversize piston is used, use it for all cylinders with oversize piston rings.**

6. Cylinder bore size is determined by adding piston-to-bore clearance to piston diameter "A".

Rebored size calculation: $D = A + B - C$ where,

D: Bored diameter


A: Piston diameter as measured

B: Piston-to-bore clearance

C: Honing allowance 0.02 mm (0.0008 in)

7. Install main bearing caps, and tighten to the specified torque. Otherwise, cylinder bores may be distorted in final assembly.
8. Cut cylinder bores.
 - **When any cylinder needs boring, all other cylinders must also be bored.**
 - **Do not cut too much out of cylinder bore at a time. Cut only 0.05 mm (0.0020 in) or so in diameter at a time.**
9. Hone cylinders to obtain specified piston-to-bore clearance.
10. Measure finished cylinder bore for out-of-round and taper.
 - **Measurement should be done after cylinder bore cools down.**

CRANKSHAFT



G00787888

Fig. 243: Measuring Journals For Taper And Out-Of-Round
Courtesy of NISSAN MOTOR CO., U.S.A.

1. Check crankshaft main and pin journals for score, wear or cracks.
2. With a micrometer, measure journals for taper and out-of-round.

Out-of-round (X - Y):


Standard

0.002 mm (0.0001 in)

Taper (A - B):

Standard

0.002 mm (0.0001 in)



G00787889

Fig. 244: Measuring Crankshaft Runout
Courtesy of NISSAN MOTOR CO., U.S.A.

3. Measure crankshaft runout.


- Place a V-block on a precise flat table to support the journals on the both end of the crankshaft.
- Place a dial gauge straight up on the No. 3 journal.
- While rotating the crankshaft, read the movement of the pointer on the dial gauge. (Total indicator reading)

Runout (Total indicator reading):

Limit 0.10 mm (0.0039 in)

If it exceeds the limit, replace crankshaft.

BEARING CLEARANCE



G00787890


Fig. 245: Identifying Bearing Clearance

Courtesy of NISSAN MOTOR CO., U.S.A.

- Use either of the following two methods, however, method "A" gives more reliable results and is preferable.


Method A (Using bore gauge & micrometer)**Main bearing**

1. Set main bearings in their proper positions on cylinder block and main bearing cap.




G00787891

Fig. 246: Measuring Inner Diameters Of Main Bearing
Courtesy of NISSAN MOTOR CO., U.S.A.




G00787892

Fig. 247: Measuring Outer Diameters Of Each Crankshaft Main Journal
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787893

Fig. 248: Measuring Crankshaft Main Journal Diameters
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787894

Fig. 249: Identifying Cylinder Bore Grade Number
Courtesy of NISSAN MOTOR CO., U.S.A.




Fig. 250: Identifying Crankshaft Journal Diameters Grade Number
 Courtesy of NISSAN MOTOR CO., U.S.A.

2. Install main bearing cap and bearing beam to cylinder block.

Tighten all bolts in correct order.

3. Measure inner diameters "A" of each main bearing.
4. Measure outer diameters "Dm" of each crankshaft main journal.
5. Calculate main bearing clearance.

Main bearing clearance = A - Dm

Standard: 0.035 - 0.045 mm (0.0014 - 0.0018 in)

Limit: 0.065 mm (0.0026 in)

- If it exceeds the limit, replace bearing.
- If clearance cannot be adjusted using any standard bearing grade, grind crankshaft journal and use undersized bearing.

- a. When grinding crankshaft journal, confirm that "L" dimension in fillet roll is more than the specified limit.

"L": 0.1 mm (0.004 in)

- b. Refer to SDS for grinding crankshaft and available service parts.

6. If crankshaft or cylinder block is replaced with a new one, select thickness of main bearings as follows:

- a. Grade number of each cylinder block main journal is punched on the respective cylinder block. These numbers are punched in either Arabic or Alphabet. Refer to SDS, **CYLINDER BLOCK**.

If measured diameter is out of grade punched, decide suitable grade using table in SDS.

- b. Grade number of each crankshaft main journal is punched on the respective crankshaft. These numbers are punched in either Arabic or Alphabet. Refer to SDS, **CRANKSHAFT**.

If measured diameter is out of grade punched, decide suitable grade using table in SDS.


- c. Select main bearing with suitable thickness according to the following table.

Refer to "SDS", for **AVAILABLE MAIN BEARINGS**.

Cylinder block bearing housing inner diameter Unit: mm (in) Crankshaft main journal diameter Unit: mm (in)		Mark	Hole diameter																											
		A	B	C	D	E	F	G	H	J	K	L	M	N	P	R	S	T	U	V	W	X	Y	4	7					
Mark	Axle diameter	63.993 - 63.994 (2.5194 - 2.5194)	63.994 - 63.995 (2.5194 - 2.5195)	63.995 - 63.996 (2.5195 - 2.5195)	63.996 - 63.997 (2.5195 - 2.5196)	63.997 - 63.998 (2.5196 - 2.5196)	63.998 - 63.999 (2.5196 - 2.5196)	63.999 - 64.000 (2.5196 - 2.5197)	64.000 - 64.001 (2.5197 - 2.5197)	64.001 - 64.002 (2.5197 - 2.5198)	64.002 - 64.003 (2.5198 - 2.5198)	64.003 - 64.004 (2.5198 - 2.5198)	64.004 - 64.005 (2.5198 - 2.5199)	64.005 - 64.006 (2.5199 - 2.5199)	64.006 - 64.007 (2.5199 - 2.5200)	64.007 - 64.008 (2.5200 - 2.5200)	64.008 - 64.009 (2.5200 - 2.5200)	64.009 - 64.010 (2.5200 - 2.5201)	64.010 - 64.011 (2.5201 - 2.5201)	64.011 - 64.012 (2.5201 - 2.5202)	64.012 - 64.013 (2.5202 - 2.5202)	64.013 - 64.014 (2.5202 - 2.5202)	64.014 - 64.015 (2.5202 - 2.5203)	64.015 - 64.016 (2.5203 - 2.5203)	64.016 - 64.017 (2.5203 - 2.5203)					
A	59.975 - 59.974 (2.3612 - 2.3612)	0	0	0	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	34				
B	59.974 - 59.973 (2.3612 - 2.3611)	0	0	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4					
C	59.973 - 59.972 (2.3611 - 2.3611)	0	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4					
D	59.972 - 59.971 (2.3611 - 2.3611)	01	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4					
E	59.971 - 59.970 (2.3611 - 2.3610)	01	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45					
F	59.970 - 59.969 (2.3610 - 2.3610)	01	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45					
G	59.969 - 59.968 (2.3610 - 2.3609)	1	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45					
H	59.968 - 59.967 (2.3609 - 2.3609)	1	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5					
J	59.967 - 59.966 (2.3609 - 2.3609)	1	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5					
K	59.966 - 59.965 (2.3609 - 2.3608)	12	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5					
L	59.965 - 59.964 (2.3608 - 2.3608)	12	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56					
M	59.964 - 59.963 (2.3608 - 2.3607)	12	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56					
N	59.963 - 59.962 (2.3607 - 2.3607)	2	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56					
P	59.962 - 59.961 (2.3607 - 2.3607)	2	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6					
R	59.961 - 59.960 (2.3607 - 2.3606)	2	23	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6					
S	59.960 - 59.959 (2.3606 - 2.3606)	23	23	3	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6					
T	59.959 - 59.958 (2.3606 - 2.3605)	23	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	67					
U	59.958 - 59.957 (2.3605 - 2.3605)	23	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	67	67					
V	59.957 - 59.956 (2.3605 - 2.3605)	3	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	67	67	67					
W	59.956 - 59.955 (2.3605 - 2.3604)	3	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	67	67	67	7					
X	59.955 - 59.954 (2.3604 - 2.3604)	3	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	67	67	67	7	7					
Y	59.954 - 59.953 (2.3604 - 2.3603)	34	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	67	67	67	7	7	7					
4	59.953 - 59.952 (2.3603 - 2.3603)	34	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	67	67	67	7	7	7	7					
7	59.952 - 59.951 (2.3603 - 2.3603)	34	4	4	4	45	45	45	5	5	5	56	56	56	6	6	6	67	67	67	7	7	7	7	7					

G00787896

Fig. 251: Cylinder Block Specification Chart
 Courtesy of NISSAN MOTOR CO., U.S.A.



G00787897


Fig. 252: Measuring Inner Diameter Of Connecting Rod
Courtesy of NISSAN MOTOR CO., U.S.A.

Connecting Rod Bearing (Big end)

1. Install connecting rod bearing to connecting rod and cap.
2. Install connecting rod cap to connecting rod.

Tighten bolts to the specified torque.

3. Measure inner diameter "C" of connecting rod.
4. Measure outer diameter "Dp" of each crankshaft pin journal.



G00787898

Fig. 253: Measuring Outer Diameter Of Each Crankshaft Pin Journal
 Courtesy of NISSAN MOTOR CO., U.S.A.

Crankshaft pin journal grade number	Connecting rod bearing grade number
0	0 (Black)
1	1 (Brown)
2	2 (Green)

G00787899

Fig. 254: Connecting Rod Bearing Grade Number Chart
 Courtesy of NISSAN MOTOR CO., U.S.A.






Fig. 255: Identifying Crankshaft Journal Diameters Grade Number
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787901

Fig. 256: Identifying Plastigage
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787902

Fig. 257: Measuring Inner Diameter Of Bushing
Courtesy of NISSAN MOTOR CO., U.S.A.

5. Calculate connecting rod bearing clearance.

Connecting rod bearing clearance = $C - D_p$

Standard: 0.034 - 0.059 mm (0.0013 - 0.0023 in)

Limit: 0.070 mm (0.0028 in)


6. If it exceeds the limit, replace bearing.
7. If clearance cannot be adjusted within the standard of any bearing, grind crankshaft journal and use undersized bearing.

Refer to "**BEARING CLEARANCE - MAIN BEARING**", .

8. If crankshaft is replaced with a new one, select connecting rod bearing according to the following table.

Connecting rod bearing grade number (Identification color):

These numbers are punched in either Arabic or Roman numerals.



G00787903

Fig. 258: Aligning Oil Holes

Courtesy of NISSAN MOTOR CO., U.S.A.

Method B (Using plastigage)

CAUTION:

- Do not turn crankshaft or connecting rod while plastigage is being inserted.
- When bearing clearance exceeds the specified limit, ensure that the proper bearing has been installed. If incorrect bearing clearance exists, use a thicker or undersized main bearing to

ensure specified clearance.

CONNECTING ROD BUSHING CLEARANCE (SMALL END)

1. Measure inner diameter "C" of bushing.
2. Measure outer diameter "Dp" of piston pin.
3. Calculate connecting rod bushing clearance.

Connecting rod bushing clearance = C - Dp

Standard: 0.005 - 0.017 mm (0.0002 - 0.0007 in)

Limit: 0.030 mm (0.0012 in)

If it exceeds the limit, replace connecting rod assembly or connecting rod bushing and/or piston set with pin.


REPLACEMENT OF CONNECTING ROD BUSHING (SMALL END)

1. Drive in small end bushing until it is flush with end surface of rod.

Be sure to align the oil holes.


2. After driving in small end bushing, ream the bushing. This is to ensure the clearance between connecting rod bushing and piston pin is the specified value.

Clearance between connecting rod bushing and piston pin: 0.005 - 0.017 mm (0.0002 - 0.0007 in)



G00787904

Fig. 259: Measuring Drive Plate Runout
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787905

Fig. 260: Identifying Drive Plate

Courtesy of NISSAN MOTOR CO., U.S.A.





Fig. 261: Aligning Direction Of Piston And Connecting Rod
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787907

Fig. 262: Locating Piston Ring Gap
Courtesy of NISSAN MOTOR CO., U.S.A.




Fig. 263: Aligning Piston Rings

Courtesy of NISSAN MOTOR CO., U.S.A.

DRIVE PLATE RUNOUT

Runout (Total indicator reading):

Drive plate

Less than 0.15 mm (0.0059 in)

CAUTION:

- The signal plate is built into the drive plate assembly. Be careful not to damage the signal plate, especially the teeth.
- Check the drive plate and signal plate for deformation or cracks.
- Keep any magnetized objects away from the signal plate.
- Do not allow any magnetic materials to contact the signal plate teeth.


ASSEMBLY

PISTON

1. Install new snap ring on one side of piston pin hole.
2. Heat piston to 60 to 70°C (140 to 158°F) and assemble piston piston pin, connecting rod and new snap ring.
 - **Align the direction of piston and connecting rod.**
 - **Numbers stamped on connecting rod and cap correspond to each cylinder.**
 - **After assembly, make sure connecting rod swings smoothly.**
3. Set piston rings as shown.

CAUTION:


- **When piston rings are not replaced, make sure that piston rings are mounted in their original positions.**
- **When replacing piston rings, those without punchmarks present can be mounted with either side up.**
- **Align piston rings so that end gaps are positioned as shown in the figure.**



G00787909


Fig. 264: Installing Oil Jets

Courtesy of NISSAN MOTOR CO., U.S.A.



G00787910

Fig. 265: Identifying Crankshaft Bearings
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787911

Fig. 266: Measuring Bolts Diameters

Courtesy of NISSAN MOTOR CO., U.S.A.





Fig. 267: Aligning Crankshaft, Main Bearing Cap Sequence
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787913

Fig. 268: Tightening Crankshaft, Main Bearing Cap Bolts
 Courtesy of NISSAN MOTOR CO., U.S.A.

OIL JET

1. Install oil jets.
 - Insert oil jet knock pin into the cylinder block knock pin hole, and tighten the mounting bolts.

CRANKSHAFT


1. Set main bearings in their proper positions on cylinder block and main bearing beam.
 - **Confirm that correct main bearings are used. Refer to "INSPECTION" of this section.**
2. Instructions for re-use of main bearing cap bolts.
 - **A plastic zone tightening method is used for tightening main bearing cap bolts. Measure d1 and d2 as shown in the figure.**

d2: Select minimum diameter in the measuring area.

If the difference between d1 and d2 exceeds the limit, replace the bolts with new ones.


Limit (d1 - d2): 0.11 mm (0.0043 in)

3. After installing crankshaft, main bearing cap, main bearing beam and bearing cap bolts, tighten bearing cap bolts in numerical order as shown.
 - **Make sure that the front mark on the main bearing beam faces the front of the engine.**
 - **Tightening procedure**
 - a. **Tighten all bolts to 32 to 38 N.m (3.3 to 3.9 kg-m, 24 to 28 ft-lb) in several different steps.**
 - b. **Turn all bolts 90 to 95 degrees clockwise with angle wrench.**
 - **Prior to tightening bearing cap bolts, place bearing beam in its proper position by shifting crankshaft in the axial direction.**
 - After securing bearing cap bolts, make sure crankshaft turns smoothly by hand.
 - Lubricate threads and seat surfaces of the bolts with new engine oil.




G00787914

Fig. 269: Measuring Crankshaft End Play
Courtesy of NISSAN MOTOR CO., U.S.A.




G00787915

Fig. 270: Positioning Connecting Rod Bearings
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787916

Fig. 271: Installing Pistons With Connecting Rods
Courtesy of NISSAN MOTOR CO., U.S.A.



G00787917

Fig. 272: Identifying Connecting Rod Caps
 Courtesy of NISSAN MOTOR CO., U.S.A.

4. Measure crankshaft end play.

Crankshaft end play:

Standard

0.10 - 0.25 mm (0.0039 - 0.0098 in)


Limit

0.30 mm (0.0118 in)

If the measured value exceeds the limit, replace the thrust bearings and measure again.

If it still exceeds the limit, replace the crankshaft also.

5. Install connecting rod bearings in connecting rods and connecting rod caps.
 - **Confirm that correct bearings are used. Refer to "CONNECTING ROD BEARING (BIG END)".**
 - a. When installing the connecting rod bearings, apply engine oil to the bearing surface (inside). Do not apply oil to the back surface, but thoroughly clean it.
 - b. When installing, align the connecting rod bearing stopper protrusion with the cutout of the connecting rod to install.
 - c. Check the oil hole on the connecting rod and that on the corresponding bearing are aligned.
6. Install pistons with connecting rods.
 - a. Install them into corresponding cylinders with Tool.
 - **Be careful not to scratch cylinder wall with the connecting rod.**
 - **Arrange so that front mark on piston head faces toward engine front.**
 - b. Install connecting rod caps.
 - **Lubricate threads and seat surfaces with new engine oil.**
 - Install so that the cylinder number stamped on the connecting rod agrees with that stamped on cap side.
 - Make sure that front mark on the connecting rod cap faces the front of the engine.



Unit: mm (in)

G00787918

Fig. 273: Measuring Bolt Outer Diameter
Courtesy of NISSAN MOTOR CO., U.S.A.

- c. Re-use connecting rod cap bolts as follows.
- Make sure that the bolts can be smoothly screwed-in to the end manually.
 - If not, measure the outer diameter "d" shown in the figure.

Outer diameter "d" of connecting rod cap bolt:

Standard

7.90 - 8.00 mm (0.3110 - 0.3150 in)

Limit

7.75 mm (0.3051 in)

- d. Tighten connecting rod cap bolts to the specified torque.

Connecting rod cap bolt:

1. Tighten nuts to 19 to 21 N.m (1.9 to 2.1 kg-m, 14 to 15 ft-lb).
2. Turn nuts 90 to 95 degrees clockwise with angle wrench.


**G00787919**

Fig. 274: Tightening Connecting Rod Cap Bolts
Courtesy of NISSAN MOTOR CO., U.S.A.




Fig. 275: Measuring Connecting Rod Side Clearance
Courtesy of NISSAN MOTOR CO., U.S.A.

7. Measure connecting rod side clearance.

Connecting rod side clearance:

Standard

0.20 - 0.35 mm (0.0079 - 0.0138 in)

Limit

0.40 mm (0.0157 in)

If the measured valve exceeds the limit, replace the connecting rod and measure again. If it still exceeds the limit, replace the crankshaft also.

8. Install rear oil seal retainer.




Fig. 276: Installing Knock Sensor
Courtesy of NISSAN MOTOR CO., U.S.A.

KNOCK SENSOR

1. Install knock sensor.
 - Make sure that there is no foreign material on the cylinder block mating surface and the back surface of the knock sensor.
 - Install knock sensor so that connector faces rear of engine.
 - Do not tighten the mounting bolts while holding the connector.
 - Make sure that the knock sensor does not interfere with other parts.

CAUTION: If any impact by dropping is applied to the knock sensor, replace it with new one.

- After installing knock sensor, connect sub-harness, and lay it out to rear of engine.





Fig. 277: Removing Pilot Converter Using Suitable Tool
Courtesy of NISSAN MOTOR CO., U.S.A.

REPLACEMENT OF PILOT CONVERTER

1. Remove pilot converter using tool or suitable tool.



G00787923

Fig. 278: Installing Pilot Converter

Courtesy of NISSAN MOTOR CO., U.S.A.

2. Install pilot converter as shown.




Fig. 279: Installing Drive Plate
Courtesy of NISSAN MOTOR CO., U.S.A.

DRIVE PLATE

Install drive plate.

- Install the drive plate and reinforce plate in the direction shown in the figure.
- Align dowel pin of crankshaft rear end with pin holes of each parts.
- Secure the crankshaft using a ring gear stopper.
- Tighten the installation bolts crosswise over several times.

SERVICE DATA AND SPECIFICATIONS (SDS)

GENERAL SPECIFICATIONS


2004 Infiniti I35

2004 ENGINE Engine Mechanical - I35

General Specifications Chart

Cylinder arrangement		V-6
Displacement cm ³ (cu in)		3,498 (213.45)
Bore and stroke mm (in)		95.5 x 81.4 (3.760 x 3.205)
Valve arrangement		DOHC
Firing order		1-2-3-4-5-6
Number of piston rings	Compression	2
	Oil	1
Number of main bearings		4
Compression ratio		10.3

COMPRESSION PRESSURE

Unit: kPa (kg/cm ² , psi)/300 rpm		
Compression pressure	Standard	1,275 (13.0, 185)
	Minimum	981 (10.0, 142)
	Differential limit between cylinders	98 (1.0, 14)
Cylinder number		


G00787926

Fig. 280: Identifying Cylinder Numbers & Pressures
Courtesy of NISSAN MOTOR CO., U.S.A.

CYLINDER HEAD

Unit: mm (in)

	Standard	Limit
Head surface distortion	Less than 0.03 (0.0012)	0.1 (0.004)



Nominal cylinder head height:
H = 126.3 - 126.5 mm (4.972 - 4.980 in)


G00787927

Fig. 281: Cylinder Head Height Specifications Chart
Courtesy of NISSAN MOTOR CO., U.S.A.

VALVE

VALVE

Unit: mm (in)



Valve head diameter "D"	Intake	37.0 - 37.3 (1.4567 - 1.4685)
	Exhaust	31.2 - 31.5 (1.228 - 1.240)
Valve length "L"	Intake	96.12 - 96.62 (3.7842 - 3.8039)
	Exhaust	93.65 - 94.15 (3.6870 - 3.7067)
Valve stem diameter "d"	Intake	5.965 - 5.980 (0.2348 - 0.2354)
	Exhaust	5.955 - 5.970 (0.2344 - 0.2350)
Valve seat angle "α"	Intake	45°15' - 45°45'
	Exhaust	
Valve margin "T"	Intake	1.1 (0.043)
	Exhaust	1.3 (0.051)
Valve margin "T" limit		More than 0.5 (0.020)
Valve stem end surface grinding limit		Less than 0.2 (0.008)

G00787928

Fig. 282: Measuring Valve Diameter Specifications Chart

Courtesy of NISSAN MOTOR CO., U.S.A.

VALVE CLEARANCE

Unit: mm (in)

	Cold	Hot* (reference data)
Intake	0.26 - 0.34 (0.010 - 0.013)	0.304 - 0.416 (0.012 - 0.016)
Exhaust	0.29 - 0.37 (0.011 - 0.015)	0.308 - 0.432 (0.012 - 0.017)

*: Approximately 80°C (176°F)

G00787929

Fig. 283: Valve Clearances Specifications Chart

Courtesy of NISSAN MOTOR CO., U.S.A.

VALVE SPRING

Free height	mm (in)	45.62 (1.7961)
Pressure	N (kg, lb) at height mm (in)	196 (20.0, 44.1) at 37.0 (1.457)
	Valve open	433 (44.2, 97.3) at 27.8 (1.094)
Out-of-square	mm (in)	Less than 2.0 (0.079)

G00787930

Fig. 284: Valve Spring Specifications Chart

Courtesy of NISSAN MOTOR CO., U.S.A.

VALVE LIFTER

Unit: mm (in)


Valve lifter outer diameter	33.977 - 33.987 (1.3377 - 1.3381)
Lifter guide inner diameter	34.000 - 34.016 (1.3386 - 1.3392)
Clearance between lifter and lifter guide	0.013 - 0.039 (0.0005 - 0.0015)

G00787931

Fig. 285: Valve Lifter Specifications Chart

Courtesy of NISSAN MOTOR CO., U.S.A.

Identification mark	Thickness mm (in)
788U or 788R	7.88 (0.3102)
790U or 790R	7.90 (0.3110)
792U or 792R	7.92 (0.3118)
794U or 794R	7.94 (0.3126)
796U or 796R	7.96 (0.3134)
798U or 798R	7.98 (0.3142)
800U or 800R	8.00 (0.3150)
802U or 802R	8.02 (0.3157)
804U or 804R	8.04 (0.3165)
806U or 806R	8.06 (0.3173)
808U or 808R	8.08 (0.3181)
810U or 810R	8.10 (0.3189)
812U or 812R	8.12 (0.3197)
814U or 814R	8.14 (0.3205)
816U or 816R	8.16 (0.3213)
818U or 818R	8.18 (0.3220)
820U or 820R	8.20 (0.3228)
822U or 822R	8.22 (0.3236)
824U or 824R	8.24 (0.3244)
826U or 826R	8.26 (0.3252)
828U or 828R	8.28 (0.3260)
830U or 830R	8.30 (0.3268)
832U or 832R	8.32 (0.3276)
834U or 834R	8.34 (0.3283)
836U or 836R	8.36 (0.3291)
838U or 838R	8.38 (0.3299)
840U or 840R	8.40 (0.3307)




G00787932

Fig. 286: Measuring Valve Lifter Thickness
 Courtesy of NISSAN MOTOR CO., U.S.A.

VALVE GUIDE

Unit: mm (in)





		Standard	Service
Valve guide	Outer diameter	10.023 - 10.034 (0.3946 - 0.3950)	10.223 - 10.234 (0.4025 - 0.4029)
Valve guide	Inner diameter (Finished size)	6.000 - 6.018 (0.2362 - 0.2369)	
Cylinder head valve guide hole diameter		9.975 - 9.996 (0.3927 - 0.3935)	10.175 - 10.196 (0.4006 - 0.4014)
Interference fit of valve guide		0.027 - 0.059 (0.0011 - 0.0023)	
		Standard	Max. tolerance
Stem to guide clearance	Intake	0.020 - 0.053 (0.0008 - 0.0021)	0.08 (0.0031)
	Exhaust	0.030 - 0.063 (0.0012 - 0.0025)	0.09 (0.0035)
Valve deflection limit	Intake	—	0.24 (0.0094)
	Exhaust	—	0.28 (0.0110)
Projection length "L"		12.6 - 12.8 (0.496 - 0.504)	

G00787933

Fig. 287: Measuring Valve Guide
 Courtesy of NISSAN MOTOR CO., U.S.A.

VALVE SEAT

Unit: mm (in)



		Standard	Service
Cylinder head seat recess diameter (D)	Intake	38.000 - 38.016 (1.4961 - 1.4967)	38.500 - 38.516 (1.5157 - 1.5164)
	Exhaust	32.200 - 32.216 (1.2677 - 1.2683)	32.700 - 32.716 (1.2874 - 1.2880)
Valve seat interference fit	Intake	0.081 - 0.113 (0.0032 - 0.0044)	
	Exhaust	0.064 - 0.096 (0.0025 - 0.0038)	
Valve seat outer diameter (d)	Intake	38.097 - 38.113 (1.4999 - 1.5005)	38.597 - 38.613 (1.5196 - 1.5202)
	Exhaust	32.280 - 32.296 (1.2709 - 1.2715)	32.780 - 32.796 (1.2905 - 1.2912)
Height (h)	Intake	5.9 - 6.0 (0.232 - 0.236)	5.05 - 5.15 (0.1988 - 0.2028)
	Exhaust	5.9 - 6.0 (0.232 - 0.236)	4.95 - 5.05 (0.1949 - 0.1988)
Depth (H)		5.9 - 6.1 (0.232 - 0.240)	
Depth (L)	Intake	41.07 - 41.67 (1.6169 - 1.6405)	
	Exhaust	41.00 - 41.60 (1.6142 - 1.6378)	

G00787934

Fig. 288: Identifying Valve Seat Dimension
Courtesy of NISSAN MOTOR CO., U.S.A.

CAMSHAFT AND CAMSHAFT BEARING


Unit: mm (in)

	Standard	Limit
Camshaft journal to bearing clearance	No. 1 0.045 - 0.086 (0.0018 - 0.0034) No. 2, 3, 4 0.035 - 0.076 (0.0014 - 0.0030)	0.15 (0.0059)
Inner diameter of camshaft bearing	No. 1 26.000 - 26.021 (1.0236 - 1.0244) No. 2, 3, 4 23.500 - 23.521 (0.9252 - 0.9260)	—
Outer diameter of camshaft journal	No. 1 25.935 - 25.955 (1.0211 - 1.0218) No. 2, 3, 4 23.445 - 23.465 (0.9230 - 0.9238)	—
Camshaft runout [TIR*]	Less than 0.02 (0.0008)	0.05 (0.0020)
Camshaft sprocket runout [TIR*]	Less than 0.15 (0.0059)	—
Camshaft end play	0.115 - 0.188 (0.0045 - 0.0074)	0.24 (0.0094)

*: Total indicator reading


G00787935

Fig. 289: Camshaft And Camshaft Bearing Specifications Chart
Courtesy of NISSAN MOTOR CO., U.S.A.



Cam height "A"	Intake and exhaust	44.865 - 45.055 (1.7663 - 1.7738)
Wear limit of cam height		0.2 (0.008)

Valve timing



Unit: degree


		a	b	c	d	e	f
Intake valve timing control	OFF	240	238	-6	84	8	52

G00787936

Fig. 290: Measuring Cam Height
Courtesy of NISSAN MOTOR CO., U.S.A.

CYLINDER BLOCK

Unit: mm (in)



Surface flatness	Standard			Less than 0.03 (0.0012)
	Limit			0.10 (0.0039)
Cylinder bore	Inner diameter	Standard	Grade No. 1	95.500 - 95.510 (3.7598 - 3.7602)
			Grade No. 2	95.510 - 95.520 (3.7602 - 3.7606)
			Grade No. 3	95.520 - 95.530 (3.7606 - 3.7610)
		Wear limit		0.20 (0.0079)
Out-of-round (Difference between X and Y)				Less than 0.015 (0.0006)
Taper (Difference between A and C)				Less than 0.015 (0.0006)
Main journal inner diameter grade (Without bearing)	Grade No. A			63.993 - 63.994 (2.5194 - 2.5194)
	Grade No. B			63.994 - 63.995 (2.5194 - 2.5195)
	Grade No. C			63.995 - 63.996 (2.5195 - 2.5195)
	Grade No. D			63.996 - 63.997 (2.5195 - 2.5196)
	Grade No. E			63.997 - 63.998 (2.5196 - 2.5196)
	Grade No. F			63.998 - 63.999 (2.5196 - 2.5196)
	Grade No. G			63.999 - 64.000 (2.5196 - 2.5197)
	Grade No. H			64.000 - 64.001 (2.5197 - 2.5197)
	Grade No. J			64.001 - 64.002 (2.5197 - 2.5198)
	Grade No. K			64.002 - 64.003 (2.5198 - 2.5198)
	Grade No. L			64.003 - 64.004 (2.5198 - 2.5198)
	Grade No. M			64.004 - 64.005 (2.5198 - 2.5199)
	Grade No. N			64.005 - 64.006 (2.5199 - 2.5199)
	Grade No. P			64.006 - 64.007 (2.5199 - 2.5200)
	Grade No. R			64.007 - 64.008 (2.5200 - 2.5200)
	Grade No. S			64.008 - 64.009 (2.5200 - 2.5200)
	Grade No. T			64.009 - 64.010 (2.5200 - 2.5201)
	Grade No. U			64.010 - 64.011 (2.5201 - 2.5201)
	Grade No. V			64.011 - 64.012 (2.5201 - 2.5202)
	Grade No. W			64.012 - 64.013 (2.5202 - 2.5202)
	Grade No. X			64.013 - 64.014 (2.5202 - 2.5202)
	Grade No. Y			64.014 - 64.015 (2.5202 - 2.5203)
	Grade No. 4			64.015 - 64.016 (2.5203 - 2.5203)
	Grade No. 7			64.016 - 64.017 (2.5203 - 2.5203)
Difference in inner diameter between cylinders	Standard			Less than 0.03 (0.0012)

G00787937


Fig. 291: Measuring Cylinder Block Inner Diameter

Courtesy of NISSAN MOTOR CO., U.S.A.

PISTON, PISTON RING AND PISTON PIN

AVAILABLE PISTON

Unit: mm (in)



Piston skirt diameter "A"	Standard	Grade No. 1	95.480 - 95.490 (3.7590 - 3.7594)
		Grade No. 2	95.490 - 95.500 (3.7594 - 3.7598)
		Grade No. 3	95.500 - 95.510 (3.7598 - 3.7602)
		0.20 (0.0079) oversize (Service)	95.680 - 95.710 (3.7669 - 3.7681)
"a" dimension		41.0 (1.614)	
Piston pin hole diameter		Grade No. 0	21.993 - 21.999 (0.8659 - 0.8661)
		Grade No. 1	21.999 - 22.005 (0.8661 - 0.8663)
Piston clearance to cylinder block			0.010 - 0.030 (0.0004 - 0.0012)

G00787938

Fig. 292: Measuring Piston Skirt Diameter
Courtesy of NISSAN MOTOR CO., U.S.A.

PISTON RING

Unit: mm (in)

		Standard	Limit
Side clearance	Top	0.045 - 0.080 (0.0018 - 0.0031)	0.11 (0.0043)
	2nd	0.030 - 0.070 (0.0012 - 0.0028)	0.1 (0.004)
	Oil ring	0.065 - 0.135 (0.0026 - 0.0053)	—
End gap	Top	0.23 - 0.33 (0.0091 - 0.0130)	0.54 (0.0213)
	2nd	0.33 - 0.48 (0.0130 - 0.0189)	0.80 (0.0315)
	Oil (rail ring)	0.20 - 0.60 (0.0079 - 0.0236)	0.95 (0.0374)

G00787939

Fig. 293: Piston Ring Specifications Chart
Courtesy of NISSAN MOTOR CO., U.S.A.

PISTON PIN

2004 Infiniti I35

2004 ENGINE Engine Mechanical - I35

Unit: mm (in)

Piston pin outer diameter	Grade No. 0	21.989 - 21.995 (0.8657 - 0.8659)
	Grade No. 1	21.995 - 22.001 (0.8659 - 0.8662)
Interference fit of piston pin to piston		0.002 - 0.006 (0.0001 - 0.0002)
Piston pin to connecting rod bushing clearance	Standard	0.005 - 0.017 (0.0002 - 0.0007)
	Limit	0.030 (0.0012)

*: Values measured at ambient temperature of 20°C (68°F)

G00787940

Fig. 294: Piston Ring Specifications Chart
Courtesy of NISSAN MOTOR CO., U.S.A.

CONNECTING ROD

Unit: mm (in)

Center distance		144.15 - 144.25 (5.6752 - 5.6791)
Bend [per 100 (3.94)]	Limit	0.15 (0.0059)
Torsion [per 100 (3.94)]	Limit	0.30 (0.0118)
Connecting rod small end inner diameter		23.980 - 24.000 (0.9441 - 0.9449)
Piston pin bushing inner diameter*	Grade No. 0	22.000 - 22.006 (0.8661 - 0.8664)
	Grade No. 1	22.006 - 22.012 (0.8664 - 0.8666)
Connecting rod big end inner diameter		55.000 - 55.013 (2.1654 - 2.1659)
Side clearance	Standard	0.20 - 0.35 (0.0079 - 0.0138)
	Limit	0.40 (0.0157)

*: After installing in connecting rod

G00787941

Fig. 295: Connecting Rod Specifications Chart
Courtesy of NISSAN MOTOR CO., U.S.A.

CRANKSHAFT

Unit: mm (in)


Main journal dia. "Dm" grade	Grade No. A	59.975 - 59.974 (2.3612 - 2.3612)
	Grade No. B	59.974 - 59.973 (2.3612 - 2.3611)
	Grade No. C	59.973 - 59.972 (2.3611 - 2.3611)
	Grade No. D	59.972 - 59.971 (2.3611 - 2.3611)
	Grade No. E	59.971 - 59.970 (2.3611 - 2.3610)
	Grade No. F	59.970 - 59.969 (2.3610 - 2.3610)
	Grade No. G	59.969 - 59.968 (2.3610 - 2.3609)
	Grade No. H	59.968 - 59.967 (2.3609 - 2.3609)
	Grade No. J	59.967 - 59.966 (2.3609 - 2.3609)
	Grade No. K	59.966 - 59.965 (2.3609 - 2.3608)
	Grade No. L	59.965 - 59.964 (2.3608 - 2.3608)
	Grade No. M	59.964 - 59.963 (2.3608 - 2.3607)
	Grade No. N	59.963 - 59.962 (2.3607 - 2.3607)
	Grade No. P	59.962 - 59.961 (2.3607 - 2.3607)
	Grade No. R	59.961 - 59.960 (2.3607 - 2.3606)
	Grade No. S	59.960 - 59.959 (2.3606 - 2.3606)
	Grade No. T	59.959 - 59.958 (2.3606 - 2.3605)
	Grade No. U	59.958 - 59.957 (2.3605 - 2.3605)
	Grade No. V	59.957 - 59.956 (2.3605 - 2.3605)
	Grade No. W	59.956 - 59.955 (2.3605 - 2.3604)
	Grade No. X	59.955 - 59.954 (2.3604 - 2.3604)
Pin journal dia. "Dp"	Grade No. 0	51.968 - 51.974 (2.0460 - 2.0462)
	Grade No. 1	51.962 - 51.968 (2.0457 - 2.0460)
	Grade No. 2	51.956 - 51.962 (2.0445 - 2.0457)
Center distance "r"		40.36 - 40.44 (1.5890 - 1.5921)
Out-of-round (X - Y)	Standard	Less than 0.002 (0.0001)
Taper (A - B)	Standard	Less than 0.002 (0.0001)
Runout [TIR*]	Limit	Less than 0.10 (0.0039)
Free end play	Standard	0.10 - 0.25 (0.0039 - 0.0098)
	Limit	0.30 (0.0118)
		Out-of-round (X) - (Y) Taper (A) - (B)

*: Total indicator reading

G00787942

Fig. 296: Crankshaft Specifications Chart
 Courtesy of NISSAN MOTOR CO., U.S.A.

AVAILABLE MAIN BEARING



Grade number		Thickness "T" mm (in)	Width "W" mm (in)	Identification color (UPR/LWR)	Remarks
0		2.000 - 2.003 (0.0787 - 0.0789)	19.9 - 20.1 (0.783 - 0.791)	Black	Grade is the same for upper and lower bearings.
1		2.003 - 2.006 (0.0789 - 0.0790)		Brown	
2		2.006 - 2.009 (0.0790 - 0.0791)		Green	
3		2.009 - 2.012 (0.0791 - 0.0792)		Yellow	
4		2.012 - 2.015 (0.0792 - 0.0793)		Blue	
5		2.015 - 2.018 (0.0793 - 0.0794)		Pink	
6		2.018 - 2.021 (0.0794 - 0.0796)		Purple	
7		2.021 - 2.024 (0.0796 - 0.0797)		White	
01	UPP	2.003 - 2.006 (0.0789 - 0.0790)		Brown/Black	Grade is different for upper and lower bearings.
	LWR	2.000 - 2.003 (0.0787 - 0.0789)			
12	UPR	2.006 - 2.009 (0.0790 - 0.0791)		Green/Brown	
	LWR	2.003 - 2.006 (0.0789 - 0.0790)			
23	UPR	2.009 - 2.012 (0.0791 - 0.0792)		Yellow/Green	
	LWR	2.006 - 2.009 (0.0790 - 0.0791)			
34	UPR	2.012 - 2.015 (0.0792 - 0.0793)		Blue/Yellow	
	LWR	2.009 - 2.012 (0.0791 - 0.0792)			
45	UPR	2.015 - 2.018 (0.0793 - 0.0794)		Pink/Blue	
	LWR	2.012 - 2.015 (0.0792 - 0.0793)			
56	UPR	2.018 - 2.021 (0.0794 - 0.0796)		Purple/Pink	
	LWR	2.015 - 2.018 (0.0793 - 0.0794)			
67	UPR	2.021 - 2.024 (0.0796 - 0.0797)		White/Purple	
	LWR	2.018 - 2.021 (0.0794 - 0.0796)			

G00787943

Fig. 297: Main Bearing Specifications Chart
 Courtesy of NISSAN MOTOR CO., U.S.A.

UNDERSIZE

Unit: mm (in)

	Thickness	Main journal diameter "Dm"
0.25 (0.0098)	2.132 - 2.140 (0.0839 - 0.0843)	Grind so that bearing clearance is the specified value.

G00787944

Fig. 298: Undersize Specifications Chart

Courtesy of NISSAN MOTOR CO., U.S.A.

AVAILABLE CONNECTING ROD BEARING

CONNECTING ROD BEARING

Grade number	Thickness "T" mm (in)	Identification color (mark)
0	1.500 - 1.503 (0.0591 - 0.0592)	Black
1	1.503 - 1.506 (0.0592 - 0.0593)	Brown
2	1.506 - 1.509 (0.0593 - 0.0594)	Green

G00787945

Fig. 299: Connecting Rod Bearing Specifications Chart

Courtesy of NISSAN MOTOR CO., U.S.A.

UNDERSIZE

Unit: mm (in)

	Thickness	Crank pin journal diameter "Dp"
0.25 (0.0098)	1.626 - 1.634 (0.0640 - 0.0643)	Grind so that bearing clearance is the specified value.

G00787946

Fig. 300: Undersize Specifications Chart

Courtesy of NISSAN MOTOR CO., U.S.A.

MISCELLANEOUS COMPONENTS

Unit: mm (in)

Drive plate runout [TIR]*	Less than 0.15 (0.0059)
---------------------------	-------------------------

*: Total indicator reading

G00787947

Fig. 301: Miscellaneous Components Specifications Chart

Courtesy of NISSAN MOTOR CO., U.S.A.

BEARING CLEARANCE

2004 Infiniti I35

2004 ENGINE Engine Mechanical - I35

Unit: mm (in)

Main bearing clearance	Standard	0.035 - 0.045 (0.0014 - 0.0018)
	Limit	0.065 (0.0026)
Connecting rod bearing clearance	Standard	0.034 - 0.059 (0.0013 - 0.0023)
	Limit	0.070 (0.0028)

G00787948

Fig. 302: Bearing Clearance Specifications Chart
Courtesy of NISSAN MOTOR CO., U.S.A.