

2012 ENGINE**Engine Mechanical (Service Information) - xD****ENGINE****ON-VEHICLE INSPECTION****ON-VEHICLE INSPECTION**

1. **INSPECT ENGINE COOLANT** . Refer to **ON-VEHICLE INSPECTION - Step 3**
2. **INSPECT ENGINE OIL** . Refer to **ON-VEHICLE INSPECTION - Step 2**
3. **INSPECT BATTERY** . Refer to **ON-VEHICLE INSPECTION - Step 1**
4. **INSPECT AIR CLEANER FILTER ELEMENT SUB-ASSEMBLY**
 - a. Remove the air cleaner filter element sub-assembly.
 - b. Visually check that there is no dirt, blockage, or damage to the air cleaner filter element.

HINT:

- If there is any dirt or a blockage in the air cleaner filter element, clean it with compressed air.
- If any dirt or a blockage remains even after cleaning the air cleaner filter element with compressed air, replace it.

5. **INSPECT SPARK PLUGS** . Refer to **ON-VEHICLE INSPECTION - Step 2**
6. **INSPECT IGNITION TIMING**
 - a. When using a Techstream:
 1. Warm up and stop the engine.
 2. Connect the Techstream to the DLC3.
 3. Turn the ignition switch ON.
 4. Select the following menu items:

Powertrain / Engine and ECT / Active Test /Connect the TC and TE1 / ON.

HINT:

Refer to the Techstream operator's manual for further details.

5. Inspect the ignition timing during idling.

Ignition timing

8 to 12 degrees BTDC

NOTE:

- **Turn all the electrical systems and the A/C OFF.**

- **Inspect the ignition timing with the cooling fan OFF.**
 - **When checking the ignition timing, shift the transmission to the neutral position.**
6. Select the following menu items: Connect the TC and TE1 / OFF
 7. Turn the ignition switch OFF.
 8. Disconnect the Techstream from the DLC3.
- b. When not using a Techstream:
1. Remove No. 2 cylinder head cover. Refer to **REMOVAL - Step 1** .
 2. Pull out the wire harness (brown) shown in the illustration.




Fig. 1: Connecting Clip Of Timing Light To Wire Harness
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: After checking, wrap the wire harness with tape.

3. Warm up and stop the engine.
4. Connect the clip of the timing light to the wire harness.

NOTE: Use a timing light that detects the first signal.

5. Turn the ignition switch ON.
6. Using SST, connect terminals 13 (TC) and 4 (CG) of the DLC3.

DLC3




Fig. 2: Identifying DLC3 Connector Terminals
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09843-18040

NOTE: Examine the terminal numbers before connecting them.
Connecting the wrong terminals can damage the engine.

7. Inspect the ignition timing during idling.

Ignition timing

8 to 12 degrees BTDC

NOTE:

- Turn all the electrical systems and the A/C OFF.
- Inspect the ignition timing with the cooling fan OFF.
- When checking the ignition timing, shift the transmission to the neutral position.

8. Disconnect terminals 13 (TC) and 4 (CG) of the DLC3.
9. Turn the ignition switch OFF.
10. Remove the timing light.
11. Install No. 2 cylinder head cover. Refer to **INSTALLATION - Step 3**.

7. INSPECT ENGINE IDLING SPEED

- a. When using a Techstream:

1. Warm up and stop the engine.
2. Connect the Techstream to the DLC3.
3. Turn the ignition switch on (IG).
4. Select the following menu items: Powertrain / Engine and ECT / Data List / Av Engine Speed of All Cyl.

HINT:

Refer to the Techstream operator's manual for further details.

5. Inspect the engine idling speed.

Idling speed

650 to 750 rpm for manual transaxle

650 to 750 rpm for automatic transaxle

NOTE:

- Turn all the electrical systems and the A/C OFF.
- Inspect the idling speed with the cooling fan OFF.
- When checking the idling speed, shift the transmission to either the neutral position or the parking position.

6. Turn the ignition switch off.
 7. Disconnect the Techstream from the DCL3.
- b. When not using a Techstream.
1. Warm up and stop the engine.
 2. Install SST to terminal 9 (TAC) of the DLC3, then connect a tachometer.

DLC3




Fig. 3: Identifying DLC3 Connector Terminals
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09843-18040

NOTE: Examine the terminal numbers before connecting them.
Connecting the wrong terminals can damage the engine.

3. Turn the ignition switch ON.
4. Inspect the engine idling speed.

Idling speed

650 to 750 rpm for manual transaxle

650 to 750 rpm for automatic transaxle

5. Turn the ignition switch OFF.
6. Disconnect the tachometer.
7. Remove SST from terminal 9 (TAC).

8. INSPECT COMPRESSION

- a. Warm up and stop the engine.
- b. Remove No. 2 cylinder head cover. Refer to **REMOVAL - Step 1**.
- c. Remove the 4 ignition coils. Refer to **REMOVAL - Step 2**.
- d. Remove the 4 spark plugs.

- e. Disconnect the 4 fuel injector connectors.
- f. Inspect the cylinder compression pressure.




Fig. 4: Inspecting Cylinder Compression Pressure
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

1. Insert a compression gauge into the spark plug hole.
2. Fully open the throttle.
3. While cranking the engine, measure the compression pressure.

Compression

1471 kPa (15.0 kgf/cm² , 213 psi)

Minimum pressure

1079 kPa (11.0 kgf/cm² , 156 psi)

Difference between each cylinder

98 kPa (1.0 kgf/cm² , 14 psi) or less

NOTE:

- Use a fully-charged battery so the engine speed can be increased to 250 rpm or more.
- Inspect the other cylinders in the same way.

- **Measure the compression in as short a time as possible.**

4. If the cylinder compression is low, pour a light coat of engine oil into the cylinder through the spark plug hole, then inspect it again.

HINT:

- If adding oil increases the compression, the piston rings and/or cylinder bore may be worn or damaged.
 - If the pressure stays low, the valve may be stuck or seated improperly, or there may be leakage from the gasket.
- g. Connect the 4 fuel injector connectors.
 - h. Install the 4 spark plugs.

Torque: 20 N*m (204 kgf*cm, 15 ft.*lbf)

- i. Install the 4 ignition coils. Refer to **INSTALLATION - Step 2**.
- j. Install No. 2 cylinder head cover. Refer to **INSTALLATION - Step 3**.

9. INSPECT CO/HC

- a. Start the engine.
- b. Run the engine at 2500 rpm for approximately 180 seconds.
- c. Insert the CO/HC meter testing probe at least 40 cm (1.3 ft) into the tailpipe while idling.
- d. Check the CO/HC concentration during idling and when running at 2500 rpm.

HINT:

When doing the 2 mode (with the engine idling/running at 2500 rpm) test, the measuring procedures are determined by applicable local regulations.

If the CO/HC concentration does not comply with the regulations, troubleshoot in the order given below.

1. Check the heated oxygen sensor operation. Refer to **INSPECTION**.
2. See the table below for possible causes, then inspect the applicable parts and repair them if necessary.

CO	HC	Problems	Possible Causes
			a. Faulty ignition: • Incorrect timing • Fouled, shorted or improperly

2012 Scion xD


2012 ENGINE Engine Mechanical (Service Information) - xD

Normal	High	Rough idling	gapped plugs b. Incorrect valve clearance c. Leakage from intake and exhaust valves d. Leakage from cylinders
Low	High	Rough idling (Fluctuating HC reading)	a. Vacuum leaks: • PCV hoses • Intake manifold • Throttle body • Brake booster line b. Lean mixture causing misfire
High	High	Rough idling (Black smoke from exhaust)	a. Restricted air cleaner filter element b. Plugged PCV valve c. Faulty EFI systems: • Faulty pressure regulator • Faulty engine coolant temperature sensor • Faulty mass air flow meter • Faulty ECM • Faulty injectors • Throttle body

DRIVE BELT

COMPONENTS

ILLUSTRATION




N*m (kgf*cm, ft*lbf) : Specified torque



Fig. 5: Identifying Drive Belt Replacement Components With Torque Specifications (1 Of 2)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



N*m (kgf*cm, ft*lb) : Specified torque


P

Fig. 6: Identifying Drive Belt Replacement Components With Torque Specifications (2 Of 2)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ON-VEHICLE INSPECTION

ON-VEHICLE INSPECTION

1. INSPECT FAN & GENERATOR V BELT



B00543

Fig. 7: Inspecting Fan And Generator V Belt
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- a. Visually check the belt for excessive wear, frayed cords etc. If any defects are found, replace the belt.


HINT:

- If any defects are found, replace the belt.
- If the belt has pieces missing from the ribs, it should be replaced.

REMOVAL

REMOVAL

1. **REMOVE ENGINE UNDER COVER RH**
2. **REMOVE NO. 2 CYLINDER HEAD COVER** . Refer to **REMOVAL - Step 1**
3. **REMOVE FAN & GENERATOR V BELT**
 - a. Loosen bolts A and B.

**P****Fig. 8: Locating Generator Bolts****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

- b. Turn adjusting bolt C to release the tension and remove the V belt from the pulleys.
- c. Remove the fan and generator V belt.

INSTALLATION

INSTALLATION


1. INSTALL FAN & GENERATOR V BELT

- a. Provisionally install the fan and generator V belt onto each pulley.

NOTE: **Make sure that the V belt is securely fitted into the rib groove of the pulley.**

2. ADJUST FAN & GENERATOR V BELT

- a. Turn adjusting bolt C and adjust the tension of the V belt.

**P****Fig. 9: Locating Generator Bolts**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Check that bolt D is tightened to the specified torque of 19 N*m (189 kgf*cm, 14 ft.*lbf).

- b. Tighten fixing bolts A and B.

Torque: 19 N*m (189 kgf*cm, 14 ft.*lbf)

for bolt A


Torque: 43 N*m (438 kgf*cm, 32 ft.*lbf)

for bolt B

3. INSPECT FAN & GENERATOR V BELT

- a. Check the V belt deflection and tension.

w/ Air Conditioning System:



w/o Air Conditioning System:


**P**

Fig. 10: View Of Drive Belt And Pulley

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Deflection



Item	Specified Condition
New belt	7.5 to 8.6 mm (0.296 to 0.338 in.)
Used belt	8.0 to 10.0 mm (0.315 to 0.397 in.)

Tension

Item	Specified Condition
New belt	637 to 735 N (65 to 75 kg, 143 to 165 ld)
Used belt	392 to 588 N (40 to 60 kg, 88 to 132 ld)

If the belt deflection is not as specified, adjust it.

HINT:

- When inspecting the V belt deflection, apply 98 N (10 kgf) tensile force to it.
- After installing a new belt, run the engine for approximately 5 minutes and then re-adjust the tension to (new belt) specifications.
- Check the V-ribbed belt deflection and tension at the specified point.
- V-ribbed belt tension and deflection should be checked after 2 revolutions of the engine.
- V-ribbed belt tension and deflection should be checked at TDC crank angle and cold condition.
- When adjusting a belt, adjust its deflection and tension to the intermediate values of the specification.
- When reinstalling a belt which has been used for over 5 minutes, adjust its deflection and tension to the used belt specification.
- When using a belt tension gauge, confirm its accuracy by using a master gauge first.
- If use a sonic tension meter.

Input Data for Sonic Tension Meter

Weight

15 g/rib*m

Width

6 ribs

Span

188 mm (w/ A/C)

282 mm (w/o A/C)


4. INSTALL ENGINE UNDER COVER RH

5. INSTALL NO. 2 CYLINDER HEAD COVER . Refer to INSTALLATION - Step 3

CAMSHAFT

COMPONENTS

ILLUSTRATION



N*m (kgf*cm, ft*lbf) : Specified torque

Y

Fig. 11: Identifying Camshaft Replacement Components With Torque Specifications (1 Of 4)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION





Fig. 12: Identifying Camshaft Replacement Components With Torque Specifications (2 Of 4)
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

sábado, 16 de octubre de 2021 01:00:10 a. m.




[N*m (kgf*cm, ft.*lbf)]: Specified torque

● Non-reusable part

c

Fig. 13: Identifying Camshaft Replacement Components With Torque Specifications (3 Of 4)
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



* For use with SST

c

Fig. 14: Identifying Camshaft Replacement Components With Torque Specifications (4 Of 4)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

REMOVAL

REMOVAL

1. REMOVE FRONT WIPER ARM HEAD CAP . Refer to **REMOVAL - Step 1**

2. **REMOVE FRONT WIPER ARM AND BLADE ASSEMBLY LH** . Refer to **REMOVAL - Step 2**
3. **REMOVE FRONT WIPER ARM AND BLADE ASSEMBLY RH** . Refer to **REMOVAL - Step 3**
4. **REMOVE HOOD TO COWL TOP SEAL** . Refer to **REMOVAL - Step 4**
5. **REMOVE COWL TOP VENTILATOR LOUVER SUB-ASSEMBLY** . Refer to **REMOVAL - Step 5**
6. **REMOVE COWL TOP VENTILATOR LOUVER LH** . Refer to **REMOVAL - Step 6**
7. **REMOVE FRONT WIPER MOTOR AND LINK** . Refer to **REMOVAL - Step 7**
8. **REMOVE FRONT AIR SHUTTER SEAL RH** See step 17
9. **REMOVE OUTER COWL TOP PANEL** See step 18
10. **REMOVE NO. 2 CYLINDER HEAD COVER** . Refer to **REMOVAL - Step 1**
11. **REMOVE IGNITION COIL ASSEMBLY** See step 1
12. **REMOVE RADIO SETTING CONDENSER** See step 2
13. **DISCONNECT NO. 2 VENTILATION HOSE**
 - a. Disconnect the No. 2 ventilation hose.




Fig. 15: Locating No. 2 Ventilation Hose
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

14. **DISCONNECT ENGINE WIRE**
 - a. Remove the 2 bolts, 5 connectors, 5 clamps and disconnect the engine wire.




Fig. 16: Locating Engine Wire Fasteners
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

15. REMOVE AIR TUBE ASSEMBLY

- a. Remove the 2 bolts, 4 hoses and air tube assembly.






Fig. 17: Remove/Install Air Tube Assembly Bolts And Hoses

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

16. **REMOVE CYLINDER HEAD COVER SUB-ASSEMBLY** See step 7
17. **REMOVE CYLINDER HEAD COVER GASKET** See step 8
18. **SET NO. 1 CYLINDER TO TDC / COMPRESSION**
 - a. Turn the crankshaft pulley until its timing notch (groove) and the timing mark "0" of the timing chain cover are aligned.



Matchmark



Timing Notch


T

Fig. 18: View Of Camshaft Timing Matchmark And Timing Notch
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Check that each matchmark of the camshaft timing gear and camshaft timing exhaust gear are aligned with each matchmark located as shown in the illustration. If not, turn the crankshaft 1

revolution (360°) to align the timing marks as shown in the illustration.

- c. Place paint marks on the chain in alignment with the timing marks on the camshaft timing gear and camshaft timing exhaust gear.



C

Fig. 19: Identifying Paint Marks On Camshaft Timing Gear
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

19. REMOVE SERVICE COVER

- a. Remove the 5 bolts and service cover.




Fig. 20: Identifying Service Cover Bolts

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Using a screwdriver with its tip taped, pry at the areas shown in the illustration and remove the service cover.




Fig. 21: Removing Service Cover

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Do not damage the service cover or the contact surfaces of the timing chain cover.

20. REMOVE NO. 2 CHAIN VIBRATION DAMPER

- a. Remove the 2 bolts and No. 2 chain vibration damper from the camshaft bearing cap.




Fig. 22: Identifying Chain Vibration Damper & Bolts
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

21. REMOVE NO. 1 CHAIN TENSIONER ASSEMBLY See step 11

22. REMOVE CAMSHAFT TIMING EXHAUST GEAR ASSEMBLY

- a. While holding the hexagonal portion of the camshaft with a wrench, remove the camshaft timing exhaust gear bolt.




Fig. 23: Removing Camshaft Timing Exhaust Gear Bolt

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Be sure not to remove the other 4 bolts. If any of them is removed, replace the camshaft timing exhaust gear assembly.

- b. Hold the hexagonal portion of the intake camshaft with a wrench and turn it slightly counterclockwise to release the chain.

NOTE: Do not turn the intake camshaft more than necessary.

HINT:

Be sure to loosen the chain because the camshaft timing exhaust gear assembly cannot be removed with the chain tensioned.

- c. Remove the camshaft timing exhaust gear assembly.

NOTE: Keep the camshaft timing exhaust gear assembly horizontal while removing it from the camshaft.

23. INSPECT CAMSHAFT TIMING EXHAUST GEAR ASSEMBLY

- a. Temporarily install the camshaft timing exhaust gear assembly.




Fig. 24: Aligning Knock Pin & Pin Hole

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

1. Align the knock pin on the No. 2 camshaft with the pin hole in the camshaft timing exhaust gear assembly and temporarily install the camshaft timing exhaust gear assembly to the No. 2 camshaft with the bolt.

NOTE:

- Do not install the chain onto the gear at this step.
- Do not allow the chain to interfere with the gear when installing the gear assembly.

- b. Inspect the camshaft timing exhaust gear lock.
 1. Check that the camshaft timing exhaust gear is locked.
- c. Inspect camshaft timing exhaust gear operation.





Fig. 25: Sealing Oil Hole

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

1. After cleaning and degreasing the exhaust side VVT oil hole on the No. 1 camshaft bearing cap, completely seal the oil hole with adhesive tape or equivalent as shown in the illustration to prevent air from leaking.

NOTE: Be sure to seal the oil hole completely because air leaks due to insufficient sealing will prevent the lock pin from being released.

2. Make a hole in the adhesive tape covering the oil hole as shown in the illustration. (Procedure B)
3. Apply approximately 200 kPa (2.0 kgf/cm², 28 psi.) of air pressure to the hole made in procedure B to release the lock pin.

**Fig. 26: Releasing Lock Pin**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:

- If air leaks out, reattach the adhesive tape.
- Cover the oil hole with a piece of cloth when applying air pressure to prevent oil from spraying.

4. Using a screwdriver with its tip taped, forcibly turn the camshaft timing exhaust gear in the retard direction (clockwise).

NOTE:

- Be sure to keep the camshaft timing exhaust gear in the retard direction. If the gear is released, it will return to the advanced position automatically due to the force from the spring.
- Do not damage the camshaft timing exhaust gear.

HINT:

Depending on the air pressure applied, the camshaft timing exhaust gear may turn in the retard direction without assistance by hand.

5. Using a screwdriver with its tip taped, turn the camshaft timing exhaust gear within its movable range (20°) 2 or 3 times without turning it to the most advanced position. Check that the camshaft timing gear turns smoothly.




Fig. 27: Turning Camshaft Timing Exhaust Gear
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


6. Lock the camshaft timing exhaust gear.

NOTE: Check that the camshaft timing exhaust gear assembly locks at the most advanced position (the most advanced position of its movable range) and cannot be rotated any further.

7. Remove the adhesive tape from the No. 1 camshaft bearing cap.
- d. Remove the camshaft timing exhaust gear assembly.
1. Remove the temporarily installed camshaft timing exhaust gear assembly.

24. INSPECT CAMSHAFT TIMING GEAR ASSEMBLY

- a. Inspect the camshaft timing gear lock.
 1. Check that the camshaft timing gear is locked.
- b. Inspect camshaft timing gear operation.


**C****Fig. 28: Sealing Oil Hole**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

1. After cleaning and degreasing the intake side VVT oil hole on the No. 1 camshaft bearing cap, completely seal the oil hole with adhesive tape or equivalent as shown in the illustration to prevent air from leaking.

WARNING: Be sure to seal the oil hole completely because air leaks due to insufficient sealing will prevent the lock pin from being released.

2. Make a hole in the adhesive tape covering the oil hole as shown in the illustration. (Procedure A)
3. Apply approximately 150 kPa (1.5 kgf/cm², 22 psi.) of air pressure to the hole made in procedure A to release the lock pin.

**C****Fig. 29: Releasing Lock Pin**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:

- If air leaks out, reattach the adhesive tape.
- Cover the oil hole with a piece of cloth when applying air pressure to prevent oil from spraying.

4. Forcibly turn the camshaft timing gear in the advance direction (counterclockwise).

HINT:

Depending on the air pressure applied, the camshaft timing gear may turn in the advance direction without assistance by hand.

5. Turn the camshaft timing gear within its movable range (27.5°) 2 or 3 times without turning it to the most retarded position. Check that the camshaft timing gear turns smoothly.




Fig. 30: Turning Camshaft Timing Gear
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:

- Do not lock the camshaft timing gear assembly.
- If camshaft timing gear assembly is locked, release the lock pin again.

6. Remove the adhesive tape from the No. 1 camshaft bearing cap.

25. REMOVE CAMSHAFT TIMING GEAR ASSEMBLY

- a. While holding the hexagonal portion of the camshaft with a wrench, remove the camshaft timing gear assembly bolt with SST.




Fig. 31: Removing Camshaft Timing Gear Assembly Bolt

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09249-37010

NOTE:

- Before removing the camshaft timing gear, make sure that the lock pin has been released.
- Be sure not to remove the other 4 bolts.
- If the camshaft timing gear assembly is to be reused, be sure to use it with the lock pin released.

- b. Release the chain and remove the camshaft timing gear assembly

NOTE:

Keep the camshaft timing gear assembly horizontal while removing it from the camshaft.

- c. Suspend the chain with a string or equivalent.




Fig. 32: Suspending Chain

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

26. REMOVE CAMSHAFT BEARING CAP

- a. Uniformly loosen and remove the 10 bearing cap bolts in the sequence shown in the illustration.




Fig. 33: Identifying Bearing Cap Bolt Removal Sequence

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Be sure not to loosen the other 15 bearing cap bolts in this step.

HINT:

Arrange the removed parts in the correct order.

- b. Remove the 15 bolts and bearing caps in the order shown in the illustration. Immediately after removing bearing caps, install service bolts and spacers in the order shown in the illustration.




Fig. 34: Identifying Bearing Cap, Bolt & Spacer Removal Sequence
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

TEXT IN ILLUSTRATION

*1	Service Bolt and Spacer (used to temporarily secure the camshaft housing)	-	-
*a	The removal order of the parts	*b	The installation order of the bolts and spacer for temporarily tightening the camshaft housing

Torque: 27 N*m (275 kgf*cm, 20 ft.*lbf)

NOTE: • If the bolts are loosened all at once, FIPG on the camshaft

housing and cylinder head may peel off, resulting in oil oozing. Therefore, be sure to install the service bolts and spacers to one bearing cap at a time.

- Do not install the bearing caps when installing the service bolts and spacers.

HINT:

- Arrange the removed parts in the correct order.
- Part number for the service bolts used to temporarily secure the camshaft housing: 91551-G0875 (15 bolts)
- Part number for the service spacers used to temporarily secure the camshaft housing: 90387-12048 (15 spacers)

27. REMOVE CAMSHAFT

- a. Remove the camshaft from the camshaft housing.




Fig. 35: View Of Camshaft

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

28. REMOVE NO. 2 CAMSHAFT

- a. Remove the No. 2 camshaft from the camshaft housing.




Fig. 36: View Of No. 2 Camshaft

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

29. REMOVE NO. 1 CAMSHAFT BEARING

- a. Remove the 2 No. 1 camshaft bearings from the No. 1 camshaft bearing cap.




Fig. 37: Identifying No. 1 Camshaft Bearings


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Arrange the removed parts in the correct order.

30. REMOVE NO. 2 CAMSHAFT BEARING

- a. Remove the 2 No. 2 camshaft bearings.



T

Fig. 38: Identifying No. 2 Camshaft Bearings

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Arrange the removed parts in the correct order.

INSTALLATION

INSTALLATION

1. INSTALL NO. 1 CAMSHAFT BEARING

- a. Clean the both surfaces of the 2 No. 1 camshaft bearings.

NOTE: Do not apply engine oil to the bearings or the contact surfaces.

- b. Install the 2 No. 1 camshaft bearings to the No. 1 camshaft bearing cap.

- c. Using vernier calipers, measure the distance between the bearing cap's edge and the camshaft bearing's edge.




Fig. 39: Identifying Bearing Cap's Edge Dimension
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Dimension (A - B)

0.7 mm (0.0276 in.) or less

NOTE: **Position the bearing to the center of the bearing cap by measuring dimension A - B.**

2. INSTALL NO. 2 CAMSHAFT BEARING

- a. Clean both surfaces of the 2 No. 2 camshaft bearings.

NOTE: **Do not apply engine oil to the bearings or the contact surfaces.**

- b. Install the 2 No. 2 camshaft bearings.
- c. Using vernier calipers, measure the distance between the bearing cap's edge and the camshaft bearing's edge.




Fig. 40: Measuring Distance Between Bearing Cap Edge & Camshaft Bearing Edge
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


Dimension (A)

1.05 to 1.75 mm (0.042 to 0.068 in.)

NOTE: Position the bearing to the center of the bearing cap by measuring dimension A.

3. INSTALL NO. 2 CAMSHAFT

- a. Make sure that the valve rocker arm is installed as shown in the illustration.



P

Fig. 41: Applying Engine Oil To Lash Adjuster Tips And Valve Stem Cap Ends
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Clean the camshaft journals.
- c. Apply a light coat of engine oil to the camshaft journals, camshaft housings and bearing caps.
- d. Install the No. 2 camshaft to the camshaft housing.




Fig. 42: View Of No. 2 Camshaft

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

4. INSTALL CAMSHAFT

- a. Make sure that the valve rocker arm is installed as shown in the illustration.




Fig. 43: Applying Engine Oil To Lash Adjuster Tips And Valve Stem Cap Ends

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Clean the camshaft journals.
- c. Apply a light coat of engine oil to the camshaft journals, camshaft housings and bearing caps.
- d. Install the camshaft to the camshaft housing.





Fig. 44: View Of Camshaft

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

5. INSTALL CAMSHAFT BEARING CAP

- a. Check the marks and numbers on the camshaft bearing caps, and then remove the service bolts and spacers in the order shown in the illustration. Immediately after removing the service bolts and spacers in the location for bearing caps, install the bearing caps with the bolts in the order shown in the illustration.

**Fig. 45: Identifying Camshaft Bearing Cap**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

TEXT IN ILLUSTRATION

*1	Service Bolt and Spacer (used to temporarily secure the camshaft housing)	*2	Knock Pin
*a	The removal order of the bolts and spacers for temporarily tightening the camshaft housing	*b	The installation order of the parts
*c	50°	-	-

Torque: 27 N*m (275 kgf*cm, 20 ft.*lbf)


NOTE: If the bolts are loosened all at once, FIPG on the camshaft housing and cylinder head may peel off, resulting in oil oozing. Therefore, be

sure to remove the service bolt and spacer from one bearing cap at a time.

HINT:

Make sure that the knock pin of the camshaft is positioned as shown in the illustration.

- b. Tighten the 10 bolts in the order shown in the illustration.



T

Fig. 46: Identifying Bearing Cap Bolt Tightening Sequence
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 16 N*m (163 kgf*cm, 12 ft.*lbf)

- c. Check the torque of each bolt again.

6. INSTALL CAMSHAFT TIMING GEAR ASSEMBLY

- a. Check that the knock pin is installed on the camshaft.
- b. Hold up the chain and align the matchmark on the camshaft timing gear assembly and the paint mark on the chain.




Fig. 47: Aligning Camshaft Timing Gear Assembly & Chain
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- c. Put the camshaft timing gear and camshaft together with the knock pin and key groove misaligned, as shown in the illustration.





Fig. 48: Identifying Knock Pin & Key Groove

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Do not forcefully push in the camshaft timing gear assembly. This may cause the camshaft knock pin tip to damage the installation surface of the camshaft timing gear assembly.

- d. Turn the camshaft timing gear as shown in the illustration while pushing it gently against the camshaft. Push further at the position where the pin fits into the groove.



T

Fig. 49: Turning Camshaft Timing Gear

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Do not turn the camshaft timing gear in the retard direction (the right angle).

- e. Check that there is no clearance between the camshaft timing gear and camshaft flange.




Fig. 50: Checking For Clearance Between Camshaft Timing Gear & Camshaft Flange
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- f. Using SST and a wrench, hold the hexagonal portion of the camshaft and fix the camshaft timing gear assembly to the camshaft with the bolt.




Fig. 51: Fixing Camshaft Timing Gear Assembly To Camshaft
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09249-37010

without SST

Torque: 54 N*m (551 kgf*cm, 40 ft.*lbf)

without SST

Torque: 39 N*m (398 kgf*cm, 29 ft.*lbf)

NOTE: When tightening the bolts, do not allow the camshaft timing gear assembly to rotate.

HINT:

- The "with SST" torque value can be obtained by using a torque wrench with a fulcrum length of 260 mm (10.24 in.) and SST of 100 mm (3.94 in.). Refer to **PRECAUTION**.
 - This torque value is effective when SST is parallel to the torque wrench.
- g. Check that the camshaft timing gear can move to the retard angle side (the right direction) and is locked in the most retarded position.




Fig. 52: Checking Camshaft Timing Gear Movement
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

7. INSTALL CAMSHAFT TIMING EXHAUST GEAR ASSEMBLY

- a. Check that the knock pin is installed on the camshaft.
- b. Hold up the chain and align the matchmark on the camshaft timing gear assembly and the paint mark on the chain.




Fig. 53: Aligning Matchmark On Camshaft Timing Gear Assembly & Paint Mark On Chain
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- c. Put the camshaft timing exhaust gear and camshaft together by aligning the key groove and knock pin.




Fig. 54: Identifying Key Groove & Knock Pin
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Do not forcefully push in the camshaft timing exhaust gear assembly. This may cause the camshaft knock pin tip to damage the installation surface of the camshaft timing exhaust gear assembly.

- d. Using a wrench, hold the hexagonal portion of the No. 2 camshaft and fix the camshaft timing exhaust gear assembly to the No. 2 camshaft with the bolt.




Fig. 55: Fixing Camshaft Timing Exhaust Gear Assembly To No. 2 Camshaft
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 54 N*m (551 kgf*cm, 40 ft.*lbf)

8. INSTALL NO. 2 CHAIN VIBRATION DAMPER

- a. Install the No. 2 chain vibration damper with the 2 bolts.





Fig. 56: Identifying Chain Vibration Damper & Bolts
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)

9. INSTALL NO. 1 CHAIN TENSIONER ASSEMBLY See step 39

10. INSTALL SERVICE COVER

- a. Remove any old packing material from the contact surface.
- b. Make sure to clean and degrease the fitting surfaces of the service cover and timing chain cover so that they are free of grease, water or any contamination.
- c. Apply a continuous bead of seal packing (Diameter 5.0 mm (0.197 in.)) as shown in the illustration.

**C****Fig. 57: Identifying Seal Packing**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


NOTE:

- Remove any oil from the contact surface.
- Install the service cover within 3 minutes after applying seal packing.
- Do not add engine oil within 2 hours after installing the service cover.


- d. Install the service cover to the timing chain cover with the 5 bolts.

Torque: 9.1 N*m (93 kgf*cm, 81 in.*lbf)**11. SET NO. 1 CYLINDER TO TDC / COMPRESSION**

- a. Turn the crankshaft pulley until its timing notch (groove) and the timing mark "0" of the timing chain cover are aligned.



Matchmark



Timing Notch

T

Fig. 58: View Of Camshaft Timing Matchmark And Timing Notch
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Check that each matchmark of the camshaft timing gear and camshaft timing exhaust gear are aligned with each matchmark located as shown in the illustration. If not, turn the crankshaft 1

revolution (360°) to align the timing marks as shown in the illustration.

12. **REMOVE CYLINDER HEAD COVER GASKET** See step 41
13. **INSTALL CYLINDER HEAD COVER SUB-ASSEMBLY** See step 42
14. **INSTALL AIR TUBE ASSEMBLY**
 - a. Install the air tube assembly with the 2 bolts.




Fig. 59: Identifying Air Tube Assembly Bolts & Hoses
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)

- b. Connect the 4 hoses.
15. **CONNECT ENGINE WIRE**
 - a. Connect the 5 connectors and install the wire harness with the 2 bolts and 5 clamps.




Fig. 60: Locating Engine Wire Fasteners
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 8.4 N*m (86 kgf*cm, 74 in.*lbf)

16. CONNECT NO. 2 VENTILATION HOSE

- a. Connect the No. 2 ventilation hose.




Fig. 61: Locating No. 2 Ventilation Hose


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

17. **INSTALL RADIO SETTING CONDENSER** See step 24
18. **INSTALL IGNITION COIL ASSEMBLY** See step 25
19. **INSPECT FOR ENGINE OIL LEAK**
20. **INSTALL NO. 2 CYLINDER HEAD COVER** . Refer to **INSTALLATION - Step 3**
21. **INSTALL OUTER COWL TOP PANEL** See step 76
22. **INSTALL FRONT AIR SHUTTER SEAL RH** See step 77
23. **INSTALL FRONT WIPER MOTOR AND LINK** . Refer to **INSTALLATION - Step 2**
24. **INSTALL COWL TOP VENTILATOR LOUVER LH** . Refer to **INSTALLATION - Step 3**
25. **INSTALL COWL TOP VENTILATOR LOUVER SUB-ASSEMBLY** . Refer to **INSTALLATION - Step 4**
26. **INSTALL HOOD TO COWL TOP SEAL** . Refer to **INSTALLATION - Step 5**
27. **INSTALL FRONT WIPER ARM AND BLADE ASSEMBLY LH** . Refer to **INSTALLATION - Step 6**
28. **INSTALL FRONT WIPER ARM AND BLADE ASSEMBLY RH** . Refer to **INSTALLATION - Step 7**
29. **INSTALL FRONT WIPER ARM HEAD CAP** . Refer to **INSTALLATION - Step 8**
30. **INSPECT IGNITION TIMING** See step 6
31. **INSPECT ENGINE IDLING SPEED** See step 7

CYLINDER HEAD GASKET

COMPONENTS

ILLUSTRATION




N*m (kgf*cm, ft*lb) : Specified torque

Y

Fig. 62: Identifying Cylinder Head Gasket Replacement Components With Torque Specifications (1 Of 18)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



N*m (kgf*cm, ft*lbf) : Specified torque

Fig. 63: Identifying Cylinder Head Gasket Replacement Components With Torque Specifications (2 Of 18)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION





Fig. 64: Identifying Cylinder Head Gasket Replacement Components (3 Of 18)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION




N*m (kgf*cm, ft*lbf) : Specified torque

T

Fig. 65: Identifying Cylinder Head Gasket Replacement Components With Torque Specifications (4 Of 18)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION





N*m (kgf*cm, ft*lb) : Specified torque

Fig. 66: Identifying Cylinder Head Gasket Replacement Components With Torque Specifications (5 Of 18)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION




T

Fig. 67: Identifying Cylinder Head Gasket Components (6 Of 18)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



N·m (kgf*cm, ft*lbf) : Specified torque

● Non-reusable part


⬅ Do not apply lubricants to the threaded parts

Y

Fig. 68: Identifying Cylinder Head Gasket Replacement Components With Torque Specifications (7 Of 18)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



N*m (kgf*cm, ft*lb) : Specified torque

● Non-reusable part


T

Fig. 69: Identifying Cylinder Head Gasket Replacement Components With Torque Specifications (8 Of 18)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION

for Automatic Transaxle:



[N*m (kgf*cm, ft*lb)] : Specified torque

● Non-reusable part

Y

Fig. 70: Identifying Cylinder Head Gasket Replacement Components With Torque Specifications (9 of 18)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION

for Manual Transaxle:





Fig. 71: Identifying Cylinder Head Gasket Replacement Components With Torque Specifications (10 Of 18)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION




[N*m (kgf*cm, ft*lb)] : Specified torque

P

Fig. 72: Identifying Cylinder Head Gasket Replacement Components With Torque Specifications (11 Of 18)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION




[N*m (kgf*cm, ft*lb)] : Specified torque ● Non-reusable part

Y

Fig. 73: Identifying Cylinder Head Gasket Replacement Components With Torque Specifications (12 of 18)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION




N*m (kgf*cm, ft*lb) : Specified torque

Y

Fig. 74: Identifying Cylinder Head Gasket Replacement Components With Torque Specifications (13 Of 18)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



N*m (kgf*cm, ft*lb) : Specified torque


● Non-reusable part

Y

Fig. 75: Identifying Cylinder Head Gasket Replacement Components With Torque Specifications (14 Of 18)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



$\boxed{\text{N*m (kgf*cm, ft*lb)}} : \text{Specified torque}$


● Non-reusable part

T

Fig. 76: Identifying Cylinder Head Gasket Replacement Components With Torque Specifications (15 Of 18)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION




N*m (kgf*cm, ft*lb) : Specified torque

← MP Grease ● Non-reusable part

T

Fig. 77: Identifying Oil Pump Replacement Components With Torque Specifications(14 of 17)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



N*m (kgf*cm, ft*lb) : Specified torque


● Non-reusable part

T

Fig. 78: Identifying Cylinder Head Gasket Replacement Components With Torque Specifications (17 Of 18)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



T

Fig. 79: Identifying Cylinder Head Gasket Replacement Components With Torque Specifications (18 Of 18)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

REMOVAL**REMOVAL****1. DISCHARGE FUEL SYSTEM PRESSURE**

Refer to PRECAUTION

2. **REMOVE BATTERY** See step 2
3. **REMOVE BATTERY TRAY**
4. **REMOVE FRONT WHEELS**
5. **REMOVE ENGINE UNDER COVER LH**
6. **REMOVE ENGINE UNDER COVER RH**
7. **DRAIN ENGINE COOLANT** . Refer to REPLACEMENT - Step 1
8. **DRAIN ENGINE OIL** . Refer to REPLACEMENT - Step 1
9. **REMOVE FRONT WIPER ARM HEAD CAP** . Refer to REMOVAL - Step 1
10. **REMOVE FRONT WIPER ARM AND BLADE ASSEMBLY LH** . Refer to REMOVAL - Step 2
11. **REMOVE FRONT WIPER ARM AND BLADE ASSEMBLY RH** . Refer to REMOVAL - Step 3
12. **REMOVE HOOD TO COWL TOP SEAL** . Refer to REMOVAL - Step 4
13. **REMOVE COWL TOP VENTILATOR LOUVER SUB-ASSEMBLY** . Refer to REMOVAL - Step 5
14. **REMOVE COWL TOP VENTILATOR LOUVER LH** . Refer to REMOVAL - Step 6
15. **REMOVE FRONT WIPER MOTOR AND LINK** . Refer to REMOVAL - Step 7
16. **REMOVE FRONT AIR SHUTTER SEAL RH** See step 17
17. **REMOVE OUTER COWL TOP PANEL** See step 18
18. **REMOVE AIR CLEANER ASSEMBLY** See step 19
19. **REMOVE AIR CLEANER BRACKET** See step 20
20. **REMOVE BATTERY CARRIER** See step 21
21. **REMOVE NO. 2 CYLINDER HEAD COVER** . Refer to REMOVAL - Step 1
22. **REMOVE FAN AND GENERATOR V BELT** See step 3
23. **REMOVE NO. 2 RADIATOR HOSE** See step 24
24. **DISCONNECT NO. 1 RADIATOR HOSE** . Refer to REMOVAL - Step 7
25. **REMOVE FRONT BUMPER COVER** . Refer to REMOVAL - Step 1
26. **DISCONNECT NO. 1 OIL COOLER OUTLET HOSE (for Automatic Transaxle)** . Refer to REMOVAL - Step 9
27. **DISCONNECT NO. 2 OIL COOLER INLET HOSE (for Automatic Transaxle)** . Refer to REMOVAL - Step 8

28. **REMOVE HOOD LOCK ASSEMBLY** . Refer to **REMOVAL - Step 11**
29. **REMOVE NO. 1 COOLER COVER** . Refer to **REMOVAL - Step 12**
30. **REMOVE UPPER RADIATOR SUPPORT ABSORBER** . Refer to **DISASSEMBLY - Step 11**
31. **REMOVE UPPER RADIATOR SUPPORT SUB-ASSEMBLY** . Refer to **REMOVAL - Step 13**
32. **REMOVE RADIATOR ASSEMBLY** . Refer to **REMOVAL - Step 14**
33. **SEPARATE WITH PULLEY COMPRESSOR ASSEMBLY** . Refer to **REMOVAL - Step 7**
34. **SEPARATE TRANSMISSION CONTROL CABLE ASSEMBLY (for Automatic Transaxle)** See step 35
35. **SEPARATE TRANSMISSION CONTROL CABLE ASSEMBLY (for Manual Transaxle)** See step 36
36. **SEPARATE UNION TO CHECK VALVE HOSE** See step 37
37. **SEPARATE NO. 1 FUEL VAPOR FEED HOSE** See step 38
38. **DISCONNECT ENGINE WIRE** See step 39
39. **DISCONNECT HEATER WATER OUTLET HOSE A (FROM HEATER UNIT)** See step 40
40. **DISCONNECT HEATER WATER HOSE INLET A** See step 41
41. **DISCONNECT FUEL TUBE SUB-ASSEMBLY (for Manual Transaxle)** See step 42
42. **SEPARATE CLUTCH RELEASE CYLINDER ASSEMBLY (for Manual Transaxle)** See step 43
43. **REMOVE COLUMN HOLE COVER SILENCER SHEET** . Refer to **REMOVAL - Step 12**
44. **SEPARATE STEERING SLIDING YOKE SUB-ASSEMBLY** . Refer to **REMOVAL - Step 13**
45. **SEPARATE NO. 1 STEERING COLUMN HOLE COVER SUB-ASSEMBLY** . Refer to **REMOVAL - Step 14**
46. **REMOVE SHIFT LEVER KNOB SUB-ASSEMBLY (for Manual Transaxle)** . Refer to **REMOVAL - Step 1**
47. **REMOVE CONSOLE PANEL UPPER** . Refer to **REMOVAL - Step 2**
48. **REMOVE CONSOLE BOX COVER REAR** . Refer to **REMOVAL - Step 3**
49. **REMOVE CONSOLE BOX CARPET** . Refer to **REMOVAL - Step 4**
50. **REMOVE REAR CONSOLE BOX ASSEMBLY** . Refer to **REMOVAL - Step 5**
51. **REMOVE FRONT CONSOLE BOX** . Refer to **REMOVAL - Step 28**
52. **REMOVE FRONT FLOOR BRACE CENTER** . Refer to **REMOVAL - Step 10**
53. **REMOVE FRONT EXHAUST PIPE ASSEMBLY** See step 54
54. **REMOVE FRONT AXLE SHAFT LH NUT** . Refer to **REMOVAL - Step 5**
55. **REMOVE FRONT AXLE SHAFT RH NUT**

HINT:

The removal procedure for the RH side is the same as that for the LH side.

56. **SEPARATE SPEED SENSOR FRONT LH** . Refer to **REMOVAL - Step 6**
57. **SEPARATE SPEED SENSOR FRONT RH**

HINT:

The separation procedure for the RH side is the same as that for the LH side.

- 58. **SEPARATE TIE ROD END SUB-ASSEMBLY LH** . Refer to **REMOVAL - Step 8**
- 59. **SEPARATE TIE ROD END SUB-ASSEMBLY RH**

HINT:

The separation procedure for the RH side is the same as that for the LH side.

- 60. **SEPARATE FRONT STABILIZER LINK ASSEMBLY LH** . Refer to **REMOVAL - Step 7**
- 61. **SEPARATE FRONT STABILIZER LINK ASSEMBLY RH**

HINT:

The separation procedure for the RH side is the same as that for the LH side.

- 62. **SEPARATE FRONT LOWER SUSPENSION ARM SUB-ASSEMBLY LH** . Refer to **REMOVAL - Step 9**
- 63. **SEPARATE FRONT LOWER SUSPENSION ARM SUB-ASSEMBLY RH**

HINT:

The separation procedure for the RH side is the same as that for the LH side.


- 64. **SEPARATE FRONT AXLE ASSEMBLY LH** . Refer to **REMOVAL - Step 10**
- 65. **SEPARATE FRONT AXLE ASSEMBLY RH**

HINT:

The separation procedure for the RH side is the same as that for the LH side.

- 66. **REMOVE ENGINE ASSEMBLY WITH TRANSAXLE** See step 71
- 67. **REMOVE FRONT SUSPENSION CROSSMEMBER SUB-ASSEMBLY** See step 73
- 68. **REMOVE NO. 1 OIL COOLER INLET TUBE (for Automatic Transaxle)** . Refer to **REMOVAL - Step 5**
- 69. **REMOVE NO. 1 OIL COOLER OUTLET TUBE (for Automatic Transaxle)** . Refer to **REMOVAL - Step 6**
- 70. **REMOVE NO. 2 OIL COOLER TUBE CLAMP (for Automatic Transaxle)** . Refer to **REMOVAL - Step 7**
- 71. **REMOVE TRANSMISSION OIL LEVEL GAGE SUB-ASSEMBLY (for Automatic Transaxle)**
- 72. **SEPARATE TRANSMISSION OIL FILLER TUBE SUB-ASSEMBLY (for Automatic Transaxle)** . Refer to **REMOVAL - Step 8**

73. **REMOVE IGNITION COIL ASSEMBLY** See step 1
74. **REMOVE RADIO SETTING CONDENSER** See step 2
75. **REMOVE NO. 2 VENTILATION HOSE** See step 4
76. **REMOVE HEATER WATER OUTLET HOSE A (FROM HEATER UNIT)** See step 5
77. **REMOVE HEATER WATER HOSE INLET A** See step 6
78. **REMOVE NO. 1 RADIATOR HOSE** See step 7
79. **REMOVE INTAKE MANIFOLD** See step 8
80. **REMOVE FUEL DELIVERY PIPE SUB-ASSEMBLY** See step 9
81. **REMOVE NO. 1 DELIVERY PIPE SPACER** . Refer to **REMOVAL - Step 11**
82. **REMOVE INJECTOR VIBRATION INSULATOR** . Refer to **REMOVAL - Step 12**
83. **REMOVE FUEL INJECTOR ASSEMBLY** . Refer to **REMOVAL - Step 13**
84. **REMOVE GENERATOR ASSEMBLY** . Refer to **REMOVAL - Step 7**
85. **REMOVE FAN BELT ADJUSTING BAR** See step 14
86. **REMOVE OIL LEVEL DIPSTICK**
87. **REMOVE OIL LEVEL GAGE GUIDE** See step 17
88. **REMOVE WATER BY-PASS HOSE** See step 18
89. **REMOVE WATER INLET HOSE** See step 19
90. **REMOVE NO. 1 WATER BY-PASS PIPE** See step 20
91. **REMOVE AIR TUBE ASSEMBLY** See step 21
92. **REMOVE NO. 1 EXHAUST MANIFOLD HEAT INSULATOR** See step 22
93. **REMOVE MANIFOLD STAY** See step 23
94. **REMOVE EXHAUST MANIFOLD** See step 24
95. **REMOVE WIRE HARNESS CLAMP BRACKET** See step 25
96. **REMOVE WATER INLET** . Refer to **REMOVAL - Step 2**
97. **REMOVE THERMOSTAT** . Refer to **REMOVAL - Step 3**
98. **REMOVE CYLINDER HEAD COVER SUB-ASSEMBLY** See step 7
99. **SET NO. 1 CYLINDER TO TDC / COMPRESSION** See step 9
100. **REMOVE CRANKSHAFT PULLEY** See step 10
101. **REMOVE NO. 1 CHAIN TENSIONER ASSEMBLY** See step 11
102. **REMOVE TIMING CHAIN OR BELT COVER SUB-ASSEMBLY** See step 20
103. **REMOVE TIMING CHAIN OR BELT COVER OIL SEAL** . Refer to **REMOVAL - Step 91**
104. **REMOVE NO. 2 CHAIN VIBRATION DAMPER** See step 23
105. **REMOVE CHAIN TENSIONER SLIPPER** See step 24
106. **REMOVE NO. 1 CHAIN VIBRATION DAMPER** See step 25
107. **REMOVE CHAIN SUB-ASSEMBLY** See step 26
108. **REMOVE CRANKSHAFT TIMING GEAR OR SPROCKET** See step 27
109. **REMOVE CAMSHAFT BEARING CAP**
 - a. Uniformly loosen and remove the 10 bearing cap bolts in the sequence shown in the illustration.




T

Fig. 80: Identifying Bearing Cap Bolts And Loosening Sequence

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Uniformly loosen and remove the 15 bearing cap bolts in the sequence shown in the illustration.

**Fig. 81: Identifying Bearing Cap Bolts And Loosening Sequence**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:

- Uniformly loosen the bolts while keeping the camshaft level.
- If the camshaft bearing cap bolts have been loosened, reapply seal packing between the camshaft housing and cylinder head.

c. Remove the 5 bearing caps.

HINT:

Arrange the removed parts in the correct order.

110. REMOVE CAMSHAFT

- a. Remove the camshaft from the camshaft housing.



**T**

Fig. 82: Identifying Camshaft

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

111. REMOVE NO. 2 CAMSHAFT


- a. Remove the No. 2 camshaft from the camshaft housing.

**T****Fig. 83: Identifying No. 2 Camshaft**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

112. REMOVE NO. 1 VALVE ROCKER ARM SUB-ASSEMBLY

- a. Remove the 16 valve rocker arms.

**T****-A10****Fig. 84: Identifying Valve Rocker Arms**


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Arrange the removed parts in the correct order.

113. REMOVE VALVE LASH ADJUSTER ASSEMBLY

- a. Remove the 16 valve lash adjusters from the cylinder head.




T
Fig. 85: Identifying Valve Lash Adjusters
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Arrange the removed parts in the correct order.

114. REMOVE NO. 1 CAMSHAFT BEARING

- a. Remove the 2 No. 1 camshaft bearings.

**T****Fig. 86: Identifying No. 1 Camshaft Bearings****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.****HINT:**

Arrange the removed parts in the correct order.

115. REMOVE NO. 2 CAMSHAFT BEARING

- a. Remove the 2 No. 2 camshaft bearings.


**T**

Fig. 87: Identifying No. 2 Camshaft Bearings


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Arrange the removed parts in the correct order.

116. REMOVE CAMSHAFT HOUSING SUB-ASSEMBLY

- a. Remove the 2 bolts.

**T****Fig. 88: Locating Bolts****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

- b. Remove the camshaft housing by prying between the cylinder head and camshaft housing with a screwdriver.




Fig. 89: Removing Camshaft Housing By Prying
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Be careful not to damage the contact surfaces of the cylinder head and camshaft housing.

HINT:

Tape the screwdriver tip before use.

117. REMOVE CYLINDER HEAD SUB-ASSEMBLY

- a. Using several steps, loosen and remove the 10 cylinder head bolts uniformly with a 10 mm bi-hexagon wrench in the sequence shown in the illustration.


**T**

Fig. 90: Locating Cylinder Head Bolts And Loosening Sequence
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Remove the 10 cylinder head bolts and the plate washers.

NOTE:

- Do not drop the washers into the cylinder head.
- Head warpage or cracking could result from removing bolts in the wrong order.

- b. Remove the cylinder head sub-assembly.

118. REMOVE CYLINDER HEAD GASKET

- a. Remove the cylinder head gasket from the cylinder block.




Fig. 91: Identifying Cylinder Head Gasket


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

INSTALLATION

INSTALLATION

1. INSTALL CYLINDER HEAD GASKET

- Place a new cylinder head gasket on the cylinder block with the Lot No. stamp facing upward.



T

Fig. 92: Identifying Cylinder Head Gasket Lot No. Stamp

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:

- Remove any oil from the contact surface.


- Pay attention to the mounting orientation of the cylinder head gasket.
- Do not damage the cylinder gasket when installing the cylinder head onto the cylinder block.

2. INSTALL CYLINDER HEAD SUB-ASSEMBLY

HINT:

The cylinder head bolts are tightened in 2 successive steps.

- Apply a light coat of engine oil to the threads of the cylinder head bolts.
- Using several steps, install and tighten the 10 cylinder head bolts and plate washers uniformly with a 10 mm bi-hexagon wrench in the sequence shown in the illustration.



T

Fig. 93: Locating Cylinder Head Bolts And Tightening Sequence
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 49 N*m (500 kgf*cm, 36 ft.*lbf)

- Mark the front of the cylinder head bolt with paint.


**0**

Fig. 94: Identifying Cylinder Head Bolt Tightening Direction

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- d. Retighten the cylinder head bolts by additional 90° and one more additional 45° as shown in the illustration.
- e. Check that the paint mark is now at a 135° angle from the front.

3. INSTALL VALVE LASH ADJUSTER ASSEMBLY

NOTE:

- Keep the lash adjuster free of dirt and foreign objects.
 - Only use clean engine oil.
- a. Place the lash adjuster into a container filled with engine oil.
 - b. Insert the SST's tip into the lash adjuster's plunger and use the tip to press down on the check ball inside the plunger.


**T**

Fig. 95: Checking Movement Of Plunger And Bleed Air
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09276-75010

- c. Squeeze the SST and lash adjuster together to move the plunger up and down 5 or 6 times.
- d. Check the movement of the plunger and bleed the air.

OK

Plunger moves up and down.

NOTE: **When bleeding air from the high-pressure chamber, make sure that the tip of the SST is actually pressing the check ball as shown in the illustration. If the check ball is not pressed, air will not bleed.**

- e. After bleeding the air, remove the SST. Then, try to press the plunger quickly and firmly with a finger.

OK

Plunger is very difficult to move.

If the result is not as specified, replace the lash adjuster.

- f. Install the lash adjusters.

NOTE: **Install the lash adjuster into its original position.**

4. INSTALL NO. 1 VALVE ROCKER ARM SUB-ASSEMBLY

- a. Apply engine oil to the lash adjuster tip and valve stem cap end.
- b. Install the valve rocker arms as shown in the illustration.


**P**

Fig. 96: Applying Engine Oil To Lash Adjuster Tips And Valve Stem Cap Ends
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

5. INSTALL NO. 1 CAMSHAFT BEARING

- a. Clean the both surfaces of the bearing.
- b. Install the 2 No. 1 camshaft bearings.
- c. Using vernier calipers, measure the distance between the bearing cap's edge and the camshaft bearing's edge.




Fig. 97: Identifying Bearing Cap's Edge Dimension
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Dimension (A - B)

0.7 mm (0.0276 in.) or less

NOTE: **Position the bearing to the center of the bearing cap by measuring dimension A - B.**

6. INSTALL NO. 2 CAMSHAFT BEARING

- a. Clean both surfaces of the bearing.
- b. Install the 2 No. 2 camshaft bearings.
- c. Using vernier calipers, measure the distance between the bearing cap's edge and the camshaft bearing's edge.





Fig. 98: Identifying Bearing Cap's Edge Dimension
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


Dimension (A)

1.05 to 1.75 mm (0.042 to 0.068 in.)

NOTE: Position the bearing to the center of the bearing cap by measuring dimension A.

7. INSTALL NO. 2 CAMSHAFT

- a. Clean the camshaft journals.
- b. Apply a light coat of engine oil to the camshaft journals, camshaft housings and bearing caps.
- c. Install the No. 2 camshaft to the camshaft housing.




T

Fig. 99: Identifying No. 2 Camshaft


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

8. INSTALL CAMSHAFT

- a. Clean the camshaft journals.
- b. Apply a light coat of engine oil to the camshaft journals, camshaft housings and bearing caps.
- c. Install the camshaft to the camshaft housing.

**T****Fig. 100: Identifying Camshaft****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.****9. INSTALL CAMSHAFT BEARING CAP**

- a. Apply engine oil to the camshaft journals, camshaft housing and bearing caps.
- b. Check the marks and numbers on the camshaft bearing caps and place them in the proper position and direction.

**T****Fig. 101: Identifying Knock Pin Of Camshaft**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Make sure that the knock pin of the camshaft is positioned as shown in the illustration.

- c. Tighten the 10 bolts in the order shown in the illustration.




Fig. 102: Locating Bolts And Tightening Sequence

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 16 N*m (163 kgf*cm, 12 ft.*lbf)

10. INSTALL CAMSHAFT HOUSING SUB-ASSEMBLY

- a. Make sure that the valve rocker arm is installed as shown in the illustration.


**P**

Fig. 103: Applying Engine Oil To Lash Adjuster Tips And Valve Stem Cap Ends
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Apply seal packing in a continuous line as shown in the illustration.




Fig. 104: Applying Seal Packing

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Seal packing

Toyota Genuine Seal Packing Black, Three Bond 1207B or equivalent

Seal diameter

3.5 to 4.0 mm (0.138 to 0.158 in.)

NOTE:

- Remove any oil from the contact surface.
- Install the camshaft housing sub-assembly RH within 3 minutes of applying the seal packing.
- Do not start the engine for at least 2 hours after installing.

- c. Set the camshaft and No. 2 camshaft as shown in the illustration.




Fig. 105: Locating Camshaft Housing Bolts And Tightening Sequence
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- d. Install the camshaft housing and tighten the 17 bolts in the order shown in the illustration.

Torque: 27 N*m (275 kgf*cm, 20 ft.*lbf)

NOTE:

- After installing the camshaft housing, make sure that the cam lobes are positioned as shown in the illustration.
- If any of the bolts are loosened during installation, remove the camshaft housing, clean the installation surfaces, and reapply seal packing.
- If the camshaft housing is removed because any of the bolts are loosened during installation, make sure that the previously applied seal packing does not enter any oil passages.
- After installing the camshaft housing, wipe off any seal packing that seeped out from between the housing and the cylinder head.

11. **INSTALL CRANKSHAFT TIMING GEAR OR SPROCKET** See step 23
12. **INSTALL NO. 1 CHAIN VIBRATION DAMPER** See step 24
13. **INSTALL CHAIN SUB-ASSEMBLY** See step 25
14. **INSTALL CHAIN TENSIONER SLIPPER** See step 26
15. **INSTALL NO. 2 CHAIN VIBRATION DAMPER** See step 27
16. **INSTALL TIMING CHAIN OR BELT COVER OIL SEAL** . Refer to **INSTALLATION - Step 9**
17. **INSTALL TIMING CHAIN OR BELT COVER SUB-ASSEMBLY** See step 30
18. **INSTALL CRANKSHAFT PULLEY** See step 33
19. **INSTALL NO. 1 CHAIN TENSIONER ASSEMBLY** See step 39
20. **INSTALL CYLINDER HEAD COVER SUB-ASSEMBLY** See step 42
21. **INSTALL THERMOSTAT** . Refer to **INSTALLATION - Step 1**
22. **INSTALL WATER INLET** . Refer to **INSTALLATION - Step 2**
23. **INSTALL WIRE HARNESS CLAMP BRACKET** See step 1
24. **INSTALL EXHAUST MANIFOLD** See step 2
25. **INSTALL MANIFOLD STAY** See step 3
26. **INSTALL NO. 1 EXHAUST MANIFOLD HEAT INSULATOR** See step 4
27. **INSTALL AIR TUBE ASSEMBLY** See step 5
28. **INSTALL NO. 1 WATER BY-PASS PIPE** See step 6
29. **INSTALL WATER INLET HOSE** See step 7
30. **INSTALL WATER BY-PASS HOSE** See step 8
31. **INSTALL OIL LEVEL GAGE GUIDE** See step 9
32. **INSTALL OIL LEVEL DIPSTICK**
33. **INSTALL FAN BELT ADJUSTING BAR** See step 12
34. **INSTALL GENERATOR ASSEMBLY** . Refer to **INSTALLATION - Step 1**

- 35. **INSTALL FUEL INJECTOR** . Refer to **INSTALLATION - Step 1**
- 36. **INSTALL INJECTOR VIBRATION INSULATOR** . Refer to **INSTALLATION - Step 2**
- 37. **INSTALL NO. 1 DELIVERY PIPE SPACER** . Refer to **INSTALLATION - Step 3**
- 38. **INSTALL FUEL DELIVERY PIPE SUB-ASSEMBLY** See step 17
- 39. **INSTALL INTAKE MANIFOLD** See step 18
- 40. **INSTALL NO. 1 RADIATOR HOSE** See step 19
- 41. **INSTALL HEATER WATER HOSE INLET A** See step 20
- 42. **INSTALL HEATER WATER OUTLET HOSE A (FROM HEATER UNIT)** See step 21
- 43. **INSTALL NO. 2 VENTILATION HOSE** See step 22
- 44. **INSTALL RADIO SETTING CONDENSER** See step 24
- 45. **INSTALL IGNITION COIL ASSEMBLY** See step 25
- 46. **INSTALL TRANSMISSION OIL FILLER TUBE SUB-ASSEMBLY (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 9**
- 47. **INSTALL TRANSMISSION OIL LEVEL GAGE SUB-ASSEMBLY (for Automatic Transaxle)**
- 48. **INSTALL NO. 1 OIL COOLER OUTLET TUBE (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 12**
- 49. **INSTALL NO. 1 OIL COOLER INLET TUBE (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 13**
- 50. **INSTALL NO. 2 OIL COOLER TUBE CLAMP (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 11**
- 51. **INSTALL FRONT SUSPENSION CROSSMEMBER SUB-ASSEMBLY** See step 19
- 52. **INSTALL ENGINE ASSEMBLY WITH TRANSAXLE** See step 21
- 53. **INSTALL FRONT AXLE ASSEMBLY LH** . Refer to **INSTALLATION - Step 3**
- 54. **INSTALL FRONT AXLE ASSEMBLY RH**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

- 55. **INSTALL FRONT LOWER SUSPENSION ARM SUB-ASSEMBLY LH** . Refer to **INSTALLATION - Step 4**
- 56. **INSTALL FRONT LOWER SUSPENSION ARM SUB-ASSEMBLY RH**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

- 57. **INSTALL FRONT STABILIZER LINK ASSEMBLY LH** . Refer to **INSTALLATION - Step 6**
- 58. **INSTALL FRONT STABILIZER LINK ASSEMBLY RH**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

- 59. **INSTALL TIE ROD END SUB-ASSEMBLY LH** . Refer to **INSTALLATION - Step 5**
- 60. **INSTALL TIE ROD END SUB-ASSEMBLY RH**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

- 61. **INSTALL SPEED SENSOR FRONT LH** . Refer to **INSTALLATION - Step 7**
- 62. **INSTALL SPEED SENSOR FRONT RH**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

- 63. **INSTALL FRONT AXLE SHAFT LH NUT** . Refer to **INSTALLATION - Step 8**
- 64. **INSTALL FRONT AXLE SHAFT RH NUT**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

- 65. **INSTALL FRONT EXHAUST PIPE ASSEMBLY** See step 38
- 66. **INSTALL FRONT FLOOR BRACE CENTER** . Refer to **INSTALLATION - Step 2**
- 67. **INSTALL FRONT CONSOLE BOX** . Refer to **INSTALLATION - Step 16**
- 68. **INSTALL REAR CONSOLE BOX ASSEMBLY** . Refer to **INSTALLATION - Step 3**
- 69. **INSTALL CONSOLE BOX CARPET** . Refer to **INSTALLATION - Step 2**
- 70. **INSTALL CONSOLE BOX COVER REAR** . Refer to **INSTALLATION - Step 3**
- 71. **INSTALL CONSOLE PANEL UPPER** . Refer to **INSTALLATION - Step 4**
- 72. **INSTALL SHIFT LEVER KNOB SUB-ASSEMBLY (for Manual Transaxle)** . Refer to **INSTALLATION - Step 5**
- 73. **INSTALL NO. 1 STEERING COLUMN HOLE COVER SUB-ASSEMBLY** . Refer to **INSTALLATION - Step 18**
- 74. **INSTALL STEERING SLIDING YOKE SUB-ASSEMBLY** . Refer to **INSTALLATION - Step 19**
- 75. **INSTALL COLUMN HOLE COVER SILENCER SHEET** . Refer to **INSTALLATION - Step 20**
- 76. **INSTALL CLUTCH RELEASE CYLINDER ASSEMBLY (for Manual Transaxle)** See step 49
- 77. **CONNECT FUEL TUBE SUB-ASSEMBLY** See step 50
- 78. **CONNECT HEATER WATER HOSE INLET A** See step 51
- 79. **CONNECT HEATER WATER OUTLET HOSE A (FROM HEATER UNIT)** See step 52
- 80. **CONNECT ENGINE WIRE** See step 53
- 81. **INSTALL NO. 1 FUEL VAPOR FEED HOSE** See step 54

- 82. **INSTALL UNION TO CHECK VALVE HOSE** See step 55
- 83. **INSTALL TRANSMISSION CONTROL CABLE ASSEMBLY (for Automatic Transaxle)** See step 56
- 84. **INSTALL TRANSMISSION CONTROL CABLE ASSEMBLY (for Manual Transaxle)** See step 57
- 85. **INSTALL WITH PULLEY COMPRESSOR ASSEMBLY** . Refer to **INSTALLATION - Step 2**
- 86. **INSTALL RADIATOR ASSEMBLY** . Refer to **INSTALLATION - Step 6**
- 87. **INSTALL UPPER RADIATOR SUPPORT SUB-ASSEMBLY** . Refer to **INSTALLATION - Step 7**
- 88. **INSTALL UPPER RADIATOR SUPPORT ABSORBER** . Refer to **REASSEMBLY - Step 14**
- 89. **INSTALL NO. 1 COOLER COVER** . Refer to **INSTALLATION - Step 8**
- 90. **INSTALL HOOD LOCK ASSEMBLY** . Refer to **INSTALLATION - Step 9**
- 91. **CONNECT NO. 1 RADIATOR HOSE** . Refer to **INSTALLATION - Step 13**
- 92. **CONNECT NO. 2 OIL COOLER INLET HOSE (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 12**
- 93. **CONNECT NO. 1 OIL COOLER OUTLET HOSE (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 11**
- 94. **INSTALL NO. 2 RADIATOR HOSE** See step 67
- 95. **INSTALL FRONT BUMPER COVER** . Refer to **INSTALLATION - Step 1**
- 96. **INSTALL FAN & GENERATOR V BELT** See step 1
- 97. **ADJUST FAN & GENERATOR V BELT** See step 2
- 98. **INSPECT FAN & GENERATOR V BELT** See step 3
- 99. **INSTALL NO. 2 CYLINDER HEAD COVER** . Refer to **INSTALLATION - Step 3**
- 100. **INSTALL BATTERY CARRIER** See step 73
- 101. **INSTALL AIR CLEANER BRACKET** See step 74
- 102. **INSTALL AIR CLEANER ASSEMBLY** See step 75
- 103. **INSTALL OUTER COWL TOP PANEL** See step 76
- 104. **INSTALL FRONT AIR SHUTTER SEAL RH** See step 77
- 105. **INSTALL FRONT WIPER MOTOR AND LINK** . Refer to **INSTALLATION - Step 2**
- 106. **INSTALL COWL TOP VENTILATOR LOUVER LH** . Refer to **INSTALLATION - Step 3**
- 107. **INSTALL COWL TOP VENTILATOR LOUVER SUB-ASSEMBLY** . Refer to **INSTALLATION - Step 4**
- 108. **INSTALL HOOD TO COWL TOP SEAL** . Refer to **INSTALLATION - Step 5**
- 109. **INSTALL FRONT WIPER ARM AND BLADE ASSEMBLY LH** . Refer to **INSTALLATION - Step 6**
- 110. **INSTALL FRONT WIPER ARM AND BLADE ASSEMBLY RH** . Refer to **INSTALLATION - Step 7**
- 111. **INSTALL FRONT WIPER ARM HEAD CAP** . Refer to **INSTALLATION - Step 8**
- 112. **INSTALL BATTERY TRAY**
- 113. **INSTALL BATTERY** See step 86
- 114. **ADD ENGINE COOLANT** . Refer to **REPLACEMENT - Step 2**

- 115. **ADD ENGINE OIL** . Refer to **REPLACEMENT - Step 4**
- 116. **INSPECT FOR FUEL LEAK**
- 117. **INSPECT FOR ENGINE OIL LEAK**
- 118. **INSPECT FOR EXHAUST GAS LEAK**
- 119. **INSPECT FOR ENGINE COOLANT LEAK** . Refer to **ON-VEHICLE INSPECTION - Step 1**
- 120. **INSTALL ENGINE UNDER COVER RH**
- 121. **INSTALL ENGINE UNDER COVER LH**
- 122. **INSTALL FRONT WHEELS** See step 98
- 123. **INSPECT IGNITION TIMING** See step 6
- 124. **INSPECT ENGINE IDLING SPEED** See step 7
- 125. **INSPECT CO/HC** See step 9
- 126. **INSPECT FRONT WHEEL ALIGNMENT**

Refer to **ADJUSTMENT**


- 127. **CHECK VSC SENSOR SIGNAL**

Refer to **TEST MODE PROCEDURE**

CYLINDER HEAD

COMPONENTS

ILLUSTRATION



N*m (kgf*cm, ft.*lbf): Specified torque

● Non-reusable part

T


Fig. 106: Identifying Cylinder Head Replacement Components With Torque Specifications
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

DISASSEMBLY

DISASSEMBLY

1. REMOVE VALVE STEM CAP

- Remove the 16 valve stem caps from the cylinder head.

**T****Fig. 107: Identifying Valve Stem Caps**


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Arrange the removed parts in the correct order.

2. REMOVE INTAKE VALVE

- a. Using SST and wooden blocks, compress and remove the 2 valve retainer locks.

**T****Fig. 108: Compressing Spring**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09202-70020
09202-00010

HINT:

Arrange the removed parts in the correct order.


- Remove the retainer, valve spring and valve.

HINT:

Arrange the removed parts in the correct order.

3. REMOVE EXHAUST VALVE

- Using SST and wooden blocks, compress and remove the 2 valve retainer locks.

**T****Fig. 109: Compressing Valve Retainer Locks**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09202-70020
09202-00010

HINT:

Arrange the removed parts in the correct order.


- b. Remove the retainer, valve spring and valve.

HINT:

Arrange the removed parts in the correct order.

4. REMOVE VALVE STEM OIL SEAL

- a. Using needle-nose pliers, remove the oil seals.

**T****Fig. 110: Removing Oil Seals**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

5. REMOVE VALVE SPRING SEAT

- a. Using compressed air and a magnetic finger, remove the valve spring seats by applying air onto them.



**T**

Fig. 111: Removing Valve Spring Seats

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

6. REMOVE NO. 1 STRAIGHT SCREW PLUG

- a. Using a 10 mm straight hexagon wrench, remove the 3 screw plugs and 3 gaskets.


**T****Fig. 112: Identifying Screw Plugs And Gaskets**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


NOTE: If water leaks from the straight screw plug or the plug is corroded, replace it.

INSPECTION**INSPECTION****1. INSPECT CYLINDER HEAD FOR FLATNESS**


- a. Using a precision straight edge and a feeler gauge, measure the surface contacting the cylinder block and the manifolds for warpage.




Cylinder Head Lower Side:



Intake Side:



Exhaust Side:



T

Fig. 113: Measuring Surface Contacting Cylinder Block And Manifolds For Warpage
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Maximum warpage



Item	Specified Condition
Cylinder block side	0.05 mm (0.0020 in.)
Intake manifold side	0.10 mm (0.0039 in.)
Exhaust manifold side	0.10mm (0.0039 in.)

If the warpage is greater than the maximum, replace the cylinder head.

2. INSPECT CYLINDER HEAD FOR CRACKS

- Using a dye penetrant, check the intake ports, exhaust ports and cylinder surface for cracks.



T

Fig. 114: Inspecting Cylinder Head For Cracks
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

If cracked, replace the cylinder head.

3. INSPECT VALVE SEATS

- Apply a light coat of Prussian Blue to the valve face.





Fig. 115: Identifying Valve Seats Width

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Lightly press the valve face against the valve seat.
- c. Check the valve face and valve seat according to the following procedure:
 1. If Prussian Blue appears 360° around the valve face, the valve face is concentric. If not, replace the valve.
 2. If Prussian Blue appears 360° around the valve seat, the guide and valve face are concentric. If not, resurface the valve seat.
 3. Check that the valve seat contact is in the middle of the valve face with the valve seat width between 1.0 and 1.4 mm (Intake side (0.039 to 0.055 in.)).
 4. Check that the valve seat contact is in the middle of the valve face with the valve seat width between 1.0 and 1.4 mm (Exhaust side (0.039 to 0.055 in.)).

4. INSPECT CAMSHAFT THRUST CLEARANCE

- a. Install the camshafts. Refer to **INSTALLATION**.
- b. Using a dial indicator, measure the thrust clearance while moving the camshaft back and forth.



T

Fig. 116: Measuring Thrust Clearance

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard thrust clearance

Item	Specified Condition
Intake	0.06 to 0.155 mm (0.0024 to 0.0061 in.)
Exhaust	0.06 to 0.155 mm (0.0024 to 0.0061 in.)


Maximum thrust clearance

Item	Specified Condition
Intake	0.17 mm (0.0067 in.)
Exhaust	0.17 mm (0.0067 in.)

If the thrust clearance is greater than the maximum, replace the camshaft housing. If the thrust surface is damaged, replace the camshaft.

5. INSPECT CAMSHAFT OIL CLEARANCE

- a. Clean the bearing caps and camshaft journals.
- b. Place the camshafts on the camshaft housing.
- c. Lay a strip of Plastigage across each of the camshaft journals.



T


Fig. 117: Inspecting Camshaft Oil Clearance

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- d. Install the bearing caps. Refer to **INSTALLATION**.

NOTE: Do not turn the camshaft.

- e. Remove the bearing caps. Refer to **REMOVAL**.
- f. Measure the Plastigage at its widest point.



T

Fig. 118: Measuring Plastigage At Its Widest Point
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard oil clearance

Item	Specified Condition
Camshaft No. 1 journals	0.030 to 0.063 mm (0.0012 to 0.0024 in.)
Camshaft other journals	0.035 to 0.072 mm (0.0014 to 0.0028 in.)

Maximum oil clearance


Item	Specified Condition
Camshaft No. 1 journals	0.085 mm (0.0033 in.)
Camshaft other journals	0.09 mm (0.0035 in.)

NOTE: Completely remove the Plastigage after the inspection.

If the oil clearance is greater than the maximum, replace the camshaft. If necessary, replace the cylinder head.

6. INSPECT COMPRESSION SPRING

- a. Using vernier calipers, measure the free length of the valve spring.



EM0801

Fig. 119: Measuring Free Length Of Valve Spring
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Free length

53.36 mm (2.1008 in.)

If the free length is not as specified, replace the valve spring.

- b. Using steel squares, measure the deviation of the valve spring.




Fig. 120: Measuring Deviation Of Valve Spring
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


Maximum deviation

1.0 mm (0.0394 in.)

If the deviation is greater than the maximum, replace the valve spring.


7. INSPECT INTAKE VALVE

- a. Using a gasket scraper, scrape off any carbon on the valve head.

**P****Fig. 121: Cleaning Valve Head**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Using vernier calipers, measure the overall length of the valve.

**T****Fig. 122: Identifying Valve's Overall Length**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard overall length

109.34 mm (4.3047 in.)

Minimum overall length

108.84 mm (4.2850 in.)

If the overall length is less than the minimum, replace the valve.

- c. Using a micrometer, measure the diameter of the valve stem.




Fig. 123: Measuring Diameter Of Valve Stem

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Valve stem diameter

5.470 to 5.485 mm (0.2154 to 0.2159 in.)

If the valve stem diameter is not as specified, check the oil clearance.

- d. Using vernier calipers, measure the valve head margin thickness.




Fig. 124: Measuring Valve Head Margin Thickness
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard margin thickness

1.0 mm (0.0571 in.)


Minimum margin thickness

0.5 mm (0.0197 in.)


If the margin thickness is less than the minimum, replace the valve.

8. INSPECT EXHAUST VALVE

- a. Using a gasket scraper, scrape off any carbon on the valve head.

**P****Fig. 125: Cleaning Valve Head****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

- b. Using vernier calipers, measure the overall length of the valve.

**T****Fig. 126: Identifying Valve Overall Length****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

Standard overall length

108.25 mm (4.2618 in.)

Minimum overall length

107.75 mm (4.2421 in.)

If the overall length is less than the minimum, replace the valve.

- c. Using a micrometer, measure the diameter of the valve stem.




Fig. 127: Measuring Diameter Of Valve Stem

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Valve stem diameter

5.465 to 5.480 mm (0.2152 to 0.2157 in.)

If the valve stem diameter is not as specified, check the oil clearance.

- d. Using vernier calipers, measure the valve head margin thickness.




Fig. 128: Identifying Valve Head Margin Thickness
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard margin thickness

1.01 mm (0.0398 in.)


Minimum margin thickness

0.5 mm (0.0197 in.)

If the margin thickness is less than the minimum, replace the valve.

9. INSPECT VALVE GUIDE BUSH OIL CLEARANCE

- a. Using a caliper gauge, measure the inside diameter of the guide bush.



T

Fig. 129: Measuring Inside Diameter Of Guide Bush
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Bushing inside diameter

5.510 to 5.530 mm (0.2169 to 0.2177 in.)

- b. Subtract the valve stem diameter measurement from the guide bush inside diameter measurement.

Standard oil clearance

Item	Specified Condition
Intake	0.025 to 0.060 mm (0.0010 to 0.0024 in.)
Exhaust	0.030 to 0.065 mm (0.0012 to 0.0026 in.)

Maximum oil clearance

Item	Specified Condition
Intake	0.080 mm (0.0031 in.)

Exhaust	0.085 mm (0.0035 in.)
---------	--------------------------


If the clearance is greater than the maximum, replace the valve and guide bush.

REPLACEMENT

REPLACEMENT

1. REPLACE INTAKE VALVE GUIDE BUSH

- Heat the cylinder head to between 80 and 100°C (176 to 212°F).
- Place the cylinder head on wooden blocks.
- Using SST and a hammer, tap out the guide bush.



T

Fig. 130: Tapping Out Guide Bush

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09201-10000
09201-01050
- SST: 09950-70010
09951-07100

- Using a caliper gauge, measure the bush bore diameter of the cylinder head.




Fig. 131: Measuring Bush Bore Diameter Of Cylinder Head
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Cylinder bore diameter

10.285 to 10.306 mm (0.4049 to 0.4057 in.)


Select a new guide bush (STD or O/S 0.05)

Bush Size	Bush Bore Diameter
STD	10.285 to 10.306 mm (0.4049 to 0.4057 in.)
O/S 0.05	10.335 to 10.356 mm (0.4069 to 0.4077 in.)

If the bush bore diameter of the cylinder head is greater than 10.306 mm (0.4057 in.), machine the bush bore to the dimension of 10.335 to 10.356 mm (0.4069 to 0.4077 in.) to install an O/S 0.05 valve guide bush. If the bush bore diameter of the cylinder head is greater than 10.356 mm (0.4077 in.), replace the cylinder head.

- e. Heat the cylinder head to 80 to 100°C (176 to 212°F).
- f. Place the cylinder head on wooden blocks.

- g. Using SST and a hammer, tap in a new guide bush to the specified protrusion height.



T

Fig. 132: Tapping Guide Bush


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09201-10000
09201-01050
- SST: 09950-70010
09951-07100

Protrusion height

9.9 to 10.3 mm (0.3898 to 0.4055 in.)

- h. Using a sharp 5.5 mm reamer, ream the guide bush to obtain the standard specified clearance between the guide bush and valve stem.


**T****Fig. 133: Reaming Guide Bush****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

Standard oil clearance


0.025 to 0.060 mm (0.0010 to 0.0024 in.)

2. REPLACE EXHAUST VALVE GUIDE BUSH

- a. Heat the cylinder head to between 80 and 100°C (176 to 212°F).
- b. Place the cylinder head on wooden blocks.
- c. Using SST and a hammer, tap out the guide bush.

**T****Fig. 134: Tapping Out Guide Bush****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

- **SST: 09201-10000**
09201-01050
 - **SST: 09950-70010**
09951-07100
- d. Using a caliper gauge, measure the bush bore diameter of the cylinder head.



T

Fig. 135: Measuring Bush Bore Diameter Of Cylinder Head

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Diameter

10.285 to 10.306 mm (0.4049 to 0.4057 in.)

Select a new guide bush (STD or O/S 0.05)

Bush Size	Bush Bore Diameter
STD	10.285 to 10.306 mm (0.4049 to 0.4057 in.)
O/S 0.05	10.335 to 10.356 mm (0.4069 to 0.4077 in.)

If the bush bore diameter of the cylinder head is greater than 10.306 mm (0.4057 in.), machine the bush bore to the dimension of 10.335 to 10.356 mm (0.4069 to 0.4077 in.) to install an O/S 0.05 valve guide bush. If the bush bore diameter of the cylinder head is greater than 10.356 mm (0.4077 in.), replace the cylinder head.

- e. Heat the cylinder head to between 80 and 100°C (176 to 212°F).
- f. Place the cylinder head on wooden blocks.

- g. Using SST and a hammer, tap in a new guide bush to the specified protrusion height.




Fig. 136: Tapping Guide Bush


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09201-10000
09201-01050
- SST: 09950-70010
09951-07100

Protrusion height

11.15 to 11.55 mm (0.4390 to 0.4547 in.)

- h. Using a sharp 5.5 mm reamer, ream the guide bush to obtain the standard specified clearance between the guide bush and valve stem.

**T****Fig. 137: Reaming Guide Bush****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

Standard oil clearance

0.030 to 0.065 mm (0.0012 to 0.0026 in.)

3. REPLACE RING PIN

NOTE: It is not necessary to remove the ring pin unless it is being replaced.

- a. Remove the 2 ring pins.
- b. Using a plastic-faced hammer, tap in 2 new ring pins to the specified protrusion height.

Upper Side:




Fig. 138: Locating Ring Pins

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Protrusion height

6.5 to 7.5 mm (0.26 to 0.30 in.)


4. REPLACE STUD BOLT

NOTE: If the stud bolt is deformed or the threads are damaged, replace it.




- Remove the stud bolts.
- Using E8 "TORX" socket, install the stud bolts.

Torque: 9.5 N*m (97 kgf*cm, 84 in.*lbf)

Intake Side:



Exhaust Side:



T

Fig. 139: Identifying Stud Bolts

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

REASSEMBLY

REASSEMBLY

1. INSTALL NO. 1 STRAIGHT SCREW PLUG

- Using a 10 mm straight hexagon wrench, install 3 new gaskets and the 3 straight screw plugs.


**T**

Fig. 140: Identifying Screw Plugs And Gaskets

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 44 N*m (449 kgf*cm, 33 ft.*lbf)

2. INSTALL VALVE SPRING SEAT


- a. Install the valve spring seats onto the cylinder head.

3. INSTALL VALVE STEM OIL SEAL

- a. Apply a light coat of engine oil to a new oil seal.

Intake Side:

Exhaust Side:

**C****Fig. 141: Identifying Oil Seal**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Pay close attention when installing the intake and exhaust oil seals. For example, installing the intake oil seal onto the exhaust side or installing the exhaust oil seal onto the intake side can cause installation problems later.

HINT:

The intake valve oil seal is gray and the exhaust valve oil seal is black.

- b. Using SST, push in the oil seal.




Fig. 142: Pushing Oil Seal

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


- SST: 09201-41020

NOTE: Failure to use SST will cause the seal to be damaged or improperly seated.


4. INSTALL INTAKE VALVE

- When installing the intake valves onto the cylinder head, check the marks on the end of the valve stem.

Intake Valve:



Exhaust Valve:




T

Fig. 143: Identifying Intake And Exhaust Valve

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Sufficiently apply engine oil to the tip area of the intake valve shown in the illustration.



30 mm (1.18 in.) or more

T


Fig. 144: Identifying Intake Valve Dimension

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- c. Install the valve, compression spring and spring retainer onto the cylinder head.

NOTE: Install the same parts in the same combination onto the original locations.

- d. Using SST and wooden blocks, compress the spring and install the 2 retainer locks.




T

Fig. 145: Compressing Spring

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09202-70020
09202-00010

- e. Using a plastic-faced hammer, lightly tap the valve stem tip to ensure a proper fit.

**T****Fig. 146: Tapping Valve Stem**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


NOTE:

- Be careful not to damage the valve stem tip.
- Be careful not to damage the retainer.


5. INSTALL EXHAUST VALVE

- a. When installing the exhaust valves onto the cylinder head, check the marks on the end of the valve stem.

Intake Valve:



Exhaust Valve:




T

Fig. 147: Identifying Intake And Exhaust Valve

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Sufficiently apply engine oil to the tip area of the exhaust valve, as shown in the illustration.



30 mm (1.18 in.) or more

T


Fig. 148: Identifying Exhaust Valve Dimension

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- c. Install the valve, compression spring and spring retainer onto the cylinder head.

NOTE: Install the same parts in the same combination onto the original locations.

- d. Using SST and wooden blocks, compress the spring and install the 2 retainer locks.




T

Fig. 149: Compressing Valve Retainer Locks
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09202-70020
09202-00010

- e. Using a plastic-faced hammer, lightly tap the valve stem tip to ensure a proper fit.


**T****Fig. 150: Tapping Valve Stem**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:

- Be careful not to damage the valve stem tip.
- Be careful not to damage the retainer.

6. INSTALL VALVE STEM CAP

**T****Fig. 151: Identifying Valve Stem Caps**


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- a. Apply a light coat of engine oil to the valve stem caps.
- b. Install the 16 valve stem caps onto the cylinder head.

REPAIR**REPAIR****1. REPAIR VALVE SEATS****NOTE:**

- Repair the seat while checking the seating position.
- Keep the lip free from foreign matter.

- a. Using a 45° cutter, resurface the valve seat so that the valve seat width is more than the specification listed below.

**T****Fig. 152: Grinding Valve Seat Using Cutter****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

- b. Using 30° and 75° cutters, correct the valve seat so that the valve contacts the entire circumference of the seat. The contact should be in the center of the valve seat, and the valve seat width should be maintained within the specified range around the entire circumference of the seat.





Fig. 153: Identifying Valve Seat Angle**Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

Valve seat width

Item	Specified Condition
Intake Side	1.0 to 1.4 mm (0.039 to 0.055 in.)
Exhaust Side	1.0 to 1.4 mm (0.039 to 0.055 in.)

- c. Handrub the valve and valve seat with an abrasive compound.
- d. Check the valve seating position.

CYLINDER BLOCK**COMPONENTS****ILLUSTRATION**



N*m (kgf*cm, ft*lbf) : Specified torque

Fig. 154: Identifying Cylinder Block Replacement Components With Torque Specifications (1 Of 2)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION





Fig. 155: Identifying Cylinder Block Replacement Components With Torque Specifications (2 Of 2)
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

DISASSEMBLY

DISASSEMBLY

1. REMOVE NO. 1 VENTILATION CASE

- Remove the 6 bolts and 2 nuts.

**T****Fig. 156: Locating No. 1 Ventilation Case Bolts****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

- b. Remove the No. 1 ventilation case by prying between the No. 1 ventilation case and cylinder block with a screwdriver as shown the illustration.




Fig. 157: Prying No. 1 Ventilation Case
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Be careful not to damage the contact surfaces of the cylinder block and No. 1 ventilation case.

HINT:

Tape the screwdriver tip before use.

2. REMOVE PISTON SUB-ASSEMBLY WITH CONNECTING ROD

- a. Using a ridge reamer, remove all carbon from the top of the cylinder.




Fig. 158: Removing Carbon From Top Of Cylinder
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Check that the alignment mark on the connecting rod and cap are aligned to ensure correct reassembly.




Fig. 159: Identifying Alignment Mark On Connecting Rod And Cap

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

The alignment mark on the connecting rods and caps are provided to ensure correct reassembly.

- c. Using SST, uniformly loosen the 2 bolts.





Fig. 160: Loosening Bolts

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09205-16011

- d. Using the 2 loose connecting rod cap bolts, remove the connecting rod cap and lower bearing by wiggling the connecting rod cap right and left.

**T****Fig. 161: Loosening Connecting Rod Cap Bolts**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Keep the lower bearing inserted in the connecting rod cap.

- e. Push the piston, connecting rod assembly and upper bearing through the top of the cylinder block.

HINT:

- Keep the bearing, connecting rod and cap together.
- Arrange the piston and connecting rod assemblies in the correct order.

3. REMOVE CONNECTING ROD BEARING


- a. Remove the connecting rod bearings.

HINT:

Arrange the removed parts in the correct order.

4. REMOVE PISTON RING SET

- a. Using a piston ring expander, remove the 2 compression rings.

**T****Fig. 162: Removing Compression Rings****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**


- b. Remove the oil ring rail and oil ring expander by hand.

HINT:


Arrange the removed parts in the correct order.

5. REMOVE PISTON PIN HOLE SNAP RING


- a. Using a screwdriver, pry out the 2 snap rings.

**T****Fig. 163: Prying Out Snap Rings****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.****6. REMOVE PISTON SUB-ASSEMBLY WITH PIN**

- a. Gradually heat each piston to between 80 and 90°C (176 to 194°F).

**Y****Fig. 164: Heating Piston****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

- b. Using a plastic hammer and brass bar, lightly tap out the piston pin and remove the connecting rod.



P

Fig. 165: Removing Connecting Rod


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

- The piston and pin are a matched set.
- Arrange the pistons, pins, rings, connecting rods and bearings in the correct order.

7. REMOVE CRANKSHAFT

- a. Uniformly loosen and remove the 10 main bearing cap bolts in the sequence shown in the illustration.




T

Fig. 166: Locating Main Bearing Cap Bolts And Loosening Sequence

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Use 2 loose main bearing cap bolts to remove the 5 main bearing caps and 5 lower bearings.



T

Fig. 167: Loosening Main Bearing Cap Bolts

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Insert the bolts into the caps in turn. Ease the cap out by gently pulling up and applying force toward the front and back sides of the cylinder block, as shown in the illustration. Take care not to damage the contact surfaces of the cap and cylinder block.


HINT:

- Keep the lower bearing and main bearing cap together.
- Arrange the main bearing caps in the correct order.

- c. Lift out the crankshaft.

8. REMOVE UPPER CRANKSHAFT THRUST WASHER


- a. Remove the upper crankshaft thrust washers from the cylinder block.

**T****Fig. 168: Locating Upper Crankshaft Thrust Washers**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

9. REMOVE CRANKSHAFT BEARING

- a. Remove the 5 upper main bearings from the cylinder block.


**T****Fig. 169: Locating Upper Main Bearings**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Arrange the bearings in the correct order.

- b. Remove the 5 lower main bearings from the 5 main bearing caps.



T

Fig. 170: Identifying Lower Main Bearing


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Arrange the bearings in the correct order.

10. REMOVE NO. 1 OIL NOZZLE SUB-ASSEMBLY

- a. Using a socket hexagon wrench 5, remove the bolts and oil nozzles.

**T****Fig. 171: Locating Bolts And Oil Nozzles**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

11. CLEAN CYLINDER BLOCK


NOTE: If the cylinder is washed at high temperatures, the cylinder liner will stick out beyond the cylinder block. Always wash the cylinder block at a temperature of 45°C (113°F) or less.

INSPECTION

INSPECTION

1. INSPECT CONNECTING ROD THRUST CLEARANCE

- Install the connecting rod cap. Refer to **REASSEMBLY**.
- Using a dial indicator, measure the thrust clearance while moving the connecting rod back and forth.



T

Fig. 172: Measuring Thrust Clearance**Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

Standard thrust clearance

0.160 to 0.342 mm (0.0063 to 0.0135 in.)

Maximum thrust clearance

0.342 mm (0.0135 in.)

If the thrust clearance is greater than the maximum, replace the connecting rod. If necessary, replace the crankshaft.

2. INSPECT CONNECTING ROD OIL CLEARANCE

- a. Clean the crank pin and bearing.
- b. Check the crank pin and bearing for pitting and scratches.
- c. Lay a strip of Plastigage on the crank pin.


**T**

Fig. 173: Laying Strip Of Plastigage On Crank Pin
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- d. Check that the front mark of the connecting rod cap is facing forward.



**T**

Fig. 174: Identifying Front Mark Of Connecting Rod Cap
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- e. Install the connecting rod cap. Refer to **REASSEMBLY**.

NOTE: **Do not turn the crankshaft.**

- f. Remove the 2 bolts and connecting rod cap. Refer to **DISASSEMBLY**.
- g. Measure the Plastigage at its widest point.



T

Fig. 175: Measuring Plastigage At Its Widest Point
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard oil clearance

0.030 to 0.062 mm (0.0012 to 0.0024 in.)

Maximum oil clearance

0.07 mm (0.0028 in.)

If the oil clearance is greater than the maximum, replace the connecting rod bearings. If necessary, inspect the crankshaft.

NOTE: **Completely remove the Plastigage after the measurement.**

HINT:

If replacing a bearing, replace it with one that has the same number as its respective connecting rod cap. Each bearing's standard thickness is indicated by a 1, 2, or 3 mark on its surface.

Standard connecting rod large end bore diameter

Mark	Specified Condition
Mark 1	47.000 to 47.008 mm (1.8504 to 1.8507 in.)
Mark 2	47.009 to 47.016 mm (1.8507 to 1.8510 in.)
Mark 3	47.017 to 47.024 mm (1.8511 to 1.8513 in.)

Standard connecting rod bearing thickness



Mark	Specified Condition
Mark 1	1.489 to 1.493 mm (0.0586 to 0.0588 in.)
Mark 2	1.494 to 1.497 mm (0.0588 to 0.0589 in.)
Mark 3	1.498 to 1.501 mm (0.0590 to 0.0591 in.)

Standard crankshaft pin diameter

Mark	Specified Condition
Mark 1, 2, 3	43.992 to 44.000 mm (1.7320 to 1.7323 in.)

3. INSPECT CYLINDER BLOCK FOR WARPAGE

- a. Using a precision straightedge and feeler gauge, measure the warpage of the surface that is in contact with the cylinder head gasket.

**T****Fig. 176: Measuring Warpage Of Surface****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**


Maximum warpage

0.05 mm (0.0020 in.)

If the warpage is greater than the maximum, replace the cylinder block.

4. INSPECT CYLINDER BORE

- a. Using a cylinder gauge, measure the cylinder bore diameter at positions A and B in both thrust and axial directions.



T

Fig. 177: Measuring Cylinder Bore Diameter

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard diameter

80.500 to 80.513 mm (3.1693 to 3.1698 in.)


Maximum diameter

80.633 mm (3.1745 in.)

If the average diameter of the 4 positions is greater than the maximum, replace the cylinder block.

5. INSPECT PISTON SUB-ASSEMBLY WITH PIN


- a. Using a gasket scraper, remove the carbon from the piston top.



0

Fig. 178: Removing Carbon From Piston Top
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Using a groove cleaning tool or broken ring, clean the piston ring grooves.




0

Fig. 179: Cleaning Piston Ring Grooves

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- c. Using a brush and solvent, thoroughly clean the piston.




0

Fig. 180: Cleaning Piston

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Do not use a wire brush.

- d. Using a micrometer, measure the piston diameter at right angles to the piston pin hole, and at a point 10.3 mm (0.4055 in.) from the base of the piston head.



T

Fig. 181: Measuring Piston Diameter

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard piston diameter

80.471 to 80.491 mm (3.1681 to 3.1689 in.)

If the diameter is not as specified, replace the piston.

6. INSPECT PISTON OIL CLEARANCE

- a. Subtract the piston diameter measurement from the cylinder bore diameter measurement.

Standard oil clearance

0.009 to 0.042 mm (0.0004 to 0.0017 in.)


Maximum oil clearance

0.09 mm (0.0035 in.)

If the oil clearance is greater than the maximum, replace all pistons. If necessary, replace the cylinder block.

7. INSPECT RING GROOVE CLEARANCE

- Using a feeler gauge, measure the clearance between a new piston ring and the wall of the ring groove.



T

Fig. 182: Measuring Clearance Between Piston Ring And Wall Of Ring Groove
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


Standard ring groove clearance

Item	Specified Condition
No. 1 Ring	0.02 to 0.07 mm (0.0008 to 0.0028 in.)
No. 2 Ring	0.02 to 0.06 mm (0.0008 to 0.0024 in.)
Oil Ring	0.02 to 0.065 mm (0.0008 to 0.0026 in.)


If the groove clearance is not as specified, replace the piston.

8. INSPECT PISTON RING END GAP

- Using a piston, push the piston ring a little beyond the bottom of the ring travel, 50 mm (1.97 in.) from the top of the cylinder block.

**T****Fig. 183: Pushing Piston Ring****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

- b. Using a feeler gauge, measure the end gap.

**Fig. 184: Measuring End Gap****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

Standard end gap

Item	Specified Condition
No. 1 Ring	0.2 to 0.3 mm (0.0079 to 0.0118 in.)
No. 2 Ring	0.35 to 0.5 mm (0.0138 to 0.0197 in.)
Oil Ring	0.1 to 0.4 mm (0.0039 to 0.0157 in.)


Maximum end gap

Item	Specified Condition
No. 1 Ring	0.5 mm (0.0197 in.)
No. 2 Ring	0.7 mm (0.0276 in.)
Oil Ring	0.7 mm (0.0276 in.)

If the end gap is greater than the maximum, replace the piston ring. If the end gap is greater than the maximum, even with a new piston ring, replace the cylinder block.

9. INSPECT PISTON PIN OIL CLEARANCE

- a. Using a caliper gauge, measure the piston pin bore diameter.

**T****Fig. 185: Measuring Piston Pin Bore Diameter**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


Standard piston pin bore diameter

20.006 to 20.015 mm (0.7876 to 0.7880 in.)

Item	Specified Condition
A	20.006 to 20.009 mm (0.7876 to 0.7878 in.)
B	20.010 to 20.012 mm (0.7878 to 0.7879 in.)
C	20.013 to 20.015 mm (0.7879 to 0.7880 in.)

If the diameter is not as specified, replace the piston.

- b. Using a micrometer, measure the piston pin diameter.

**T****Fig. 186: Measuring Piston Pin Diameter****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

Standard piston pin diameter

20.004 to 20.013 mm (0.7876 to 0.7879 in.)

Item	Specified Condition
A	20.004 to 20.007 mm (0.7876 to 0.7877 in.)
B	20.008 to 20.010 mm (0.7877 to

	0.7878 in.)
C	20.011 to 20.013 mm (0.7878 to 0.7879 in.)

If the diameter is not as specified, replace the piston pin.

- c. Using a caliper gauge, measure the connecting rod small end bore diameter.




Fig. 187: Measuring Connecting Rod Small End Bore Diameter
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard connecting rod small end bore diameter

20.012 to 20.021 mm (0.7879 to 0.7882 in.)

Item	Specified Condition
A	20.012 to 20.015 mm (0.7879 to 0.7880 in.)
B	20.016 to 20.018 mm (0.7880 to 0.7881 in.)

C	20.019 to 20.021 mm (0.7881 to 0.7882 in.)
---	---

If the diameter is not as specified, replace the connecting rod.

- d. Subtract the piston pin diameter measurement from the piston pin bore diameter measurement.

Standard oil clearance

-0.001 to 0.005 mm (-0.00004 to 0.0002 in.)

Maximum oil clearance

0.008 mm (0.0003 in.)

If the oil clearance is greater than the maximum, replace the connecting rod. If necessary, replace the piston and piston pin as a set.

- e. Subtract the piston pin diameter measurement from the connecting rod small end bore diameter measurement.

Upper Side:

Lower Side:




Fig. 188: Identifying Connecting Rod Small End Bore Diameter Mark
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard oil clearance

0.005 to 0.011 mm (0.0002 to 0.0004 in.)


Maximum oil clearance

0.014 mm (0.0006 in.)

If the oil clearance is greater than the maximum, replace the connecting rod. If necessary, replace the connecting rod and piston pin as a set.

10. INSPECT CONNECTING ROD BOLT

- a. Using vernier calipers, measure the diameter of the unthreaded portion of the the bolt.



A36651

Fig. 189: Identifying Connecting Rod Bolt Dimension
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard diameter

6.6 to 6.7 mm (0.2598 to 0.2638 in.)

Minimum diameter

6.4 mm (0.2520 in.)

If the diameter is less than the minimum, replace the connecting rod bolt.

11. INSPECT CONNECTING ROD SUB-ASSEMBLY

- a. Using a connecting rod aligner and feeler gauge, check the connecting rod alignment.




Fig. 190: Checking Connecting Rod Alignment
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

1. Check for misalignment.

Maximum misalignment

0.05 mm (0.0020 in.) per 100 mm (3.94 in.)

If the misalignment is greater than the maximum, replace the connecting rod.

2. Check for twist.




Fig. 191: Checking For Twist

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


Maximum twist

0.15 mm (0.0059 in.) per 100 mm (3.94 in.)

If the twist is greater than the maximum, replace the connecting rod.

12. INSPECT CRANKSHAFT

- Using a dial indicator and V-blocks, measure the circle runout as shown in the illustration.



T

Fig. 192: Measuring Circle Runout



Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Maximum circle runout

0.03 mm (0.0012 in.)

If the runout is greater than the maximum, replace the crankshaft.

- b. Using a micrometer, measure the diameter of each main journal.



T

Fig. 193: Identifying Diameter Of Main Journal
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard diameter

47.988 to 48.000 mm (1.8893 to 1.8898 in.)

If the diameter is not as specified, check the crankshaft oil clearance.

- c. Check each main journal for taper and distortion as shown in the illustration.

Maximum taper and distortion

0.004 mm (0.0002 in.)

If the taper and distortion are greater than the maximum, replace the crankshaft.

Standard diameter (Reference)

Mark	Specified Condition
0	47.999 to 48.000 mm (1.8897 to 1.8898 in.)
1	47.997 to 47.998 mm (1.8896 to 1.8897 in.)
2	47.995 to 47.996 mm (1.8896 to 1.8896 in.)
3	47.993 to 47.994 mm (1.8895 to 1.8895 in.)
4	47.991 to 47.992 mm (1.8894 to 1.8894 in.)
5	47.988 to 47.990 mm (1.8893 to 1.8894 in.)

- d. Using a micrometer, measure the diameter of each crank pin.




Fig. 194: Measuring Diameter Of Each Crank Pin
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard diameter

43.992 to 44.000 mm (1.7320 to 1.7323 in.)

If the diameter is not as specified, check the connecting rod oil clearance.

- e. Inspect each crank pin for taper and distortion as shown in the illustration.

Maximum taper and distortion

0.004 mm (0.0002 in.)

If the taper and distortion are greater than the maximum, replace the crankshaft.

13. INSPECT CRANKSHAFT THRUST CLEARANCE

- a. Install the main bearing cap. Refer to **REASSEMBLY**.
- b. Using a dial indicator, measure the thrust clearance while prying the crankshaft back and forth with a screwdriver.




Fig. 195: Measuring Thrust Clearance

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard thrust clearance

0.04 to 0.14 mm (0.0016 to 0.0055 in.)

Maximum thrust clearance

0.18 mm (0.0070 in.)

If the thrust clearance is greater than the maximum, replace the thrust washers as a set.

HINT:

The thrust washer thickness is 2.43 to 2.48 mm (0.0957 to 0.0976 in.).

14. INSPECT CRANKSHAFT OIL CLEARANCE

- a. Check the crank journal and bearing for pitting and scratches.
- b. Install the crankshaft bearing. Refer to **REASSEMBLY**.
- c. Place the crankshaft on the cylinder block.
- d. Lay a strip of Plastigage across each journal.


**T**

Fig. 196: Measuring Plastigage At Its Widest Point (1 Of 2)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- e. Examine the front marks and numbers and install the bearing caps onto the cylinder block.

HINT:

A number is marked on each main bearing cap to indicate the installation position.

- f. Install the main bearing cap. Refer to **REASSEMBLY**.

NOTE: **Do not turn the crankshaft.**

- g. Remove the main bearing caps. Refer to **DISASSEMBLY**.
- h. Measure the Plastigage at its widest point.




Fig. 197: Measuring Plastigage At Its Widest Point (2 Of 2)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard oil clearance

0.016 to 0.039 mm (0.0006 to 0.0015 in.)

Maximum oil clearance

0.050 mm (0.0020 in.)

If the oil clearance is greater than the maximum, replace the crankshaft bearing. If necessary, replace the crankshaft.

NOTE: Remove the Plastigage completely after the measurement.

HINT:

- If replacing a bearing, select a new one with the same number. If the number of the bearing cannot be determined, calculate the correct bearing number by adding together the numbers imprinted on the cylinder block and crankshaft. Then select a new bearing with the calculated number according to the chart below. There are 4 sizes of standard bearings, marked "1", "2", "3" and "4".
- EXAMPLE: Cylinder block "3" + Crankshaft "5" = Total number 8 (Use bearing "3")

Cylinder block + Crankshaft	0 to 2	3 to 5	6 to 8	9 to 11
Bearing to be used	"1"	"2"	"3"	"4"

Standard cylinder block journal bore diameter

Mark	Specified Condition
------	------------------------

0	52.000 to 52.003 mm (2.0472 to 2.0474 in.)
1	52.003 to 52.005 mm (2.0474 to 2.0474 in.)
2	52.005 to 52.007 mm (2.0474 to 2.0475 in.)
3	52.007 to 52.010 mm (2.0475 to 2.0476 in.)
4	52.010 to 52.012 mm (2.0476 to 2.0477 in.)
5	52.012 to 52.014 mm (2.0477 to 2.0478 in.)
6	52.014 to 52.016 mm (2.0478 to 2.0479 in.)

Standard crankshaft journal diameter

Mark	Specified Condition
0	47.999 to 48.000 mm (1.8897 to 1.8898 in.)
1	47.997 to 47.998 mm (1.8896 to 1.8897 in.)
2	47.995 to 47.996 mm (1.8896 to 1.8896 in.)
	47.993 to

3	47.994 mm (1.8895 to 1.8895 in.)
4	47.991 to 47.992 mm (1.8894 to 1.8894 in.)
5	47.988 to 47.990 mm (1.8893 to 1.8894 in.)

Standard bearing center wall thickness

Mark	Specified Condition
1	1.994 to 1.997 mm (0.0785 to 0.0786 in.)
2	1.998 to 2.000 mm (0.0787 to 0.0787 in.)
3	2.001 to 2.003 mm (0.0788 to 0.0789 in.)
4	2.004 to 2.006 mm (0.0789 to 0.0790 in.)

15. INSPECT CYLINDER HEAD SET BOLT

- Using vernier calipers, measure the tension portion diameter of the bolts.

Standard bolt length

84.3 to 85.7 mm (3.3189 to 3.3740 in.)

Maximum bolt length

86.7 mm (3.4134 in.)

If the bolt length is greater than the maximum, replace the bolt.

- Using vernier calipers, measure the minimum diameter of the elongated thread at the measuring point.




Fig. 198: Identifying Bolt Length Dimension

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard outside diameter

9.77 to 9.96 mm (0.3846 to 0.3921 in.)

Minimum outside diameter

9.1 mm (0.3583 in.)

HINT:

Using a straightedge, visually check for thinner areas of the threaded part of the crankshaft bearing cap bolt.

If the diameter is less than the minimum, replace the bolt.

16. INSPECT NO. 1 OIL NOZZLE SUB-ASSEMBLY

- a. Check the oil nozzles for damage or clogging.

HINT:


If there is damage or clogging, replace the oil nozzle.

REPLACEMENT**REPLACEMENT****1. REPLACE RING PIN**

NOTE: It is not necessary to remove the ring pins unless they are being replaced.


- a. Using a plastic hammer, tap in the 2 new ring pins.

Upper Side:



12.9 to 13 mm
(0.508 to 0.512 in.)

7.5 to 8.5 mm



T

Fig. 199: Locating Ring Pins

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard protrusion


7.5 to 8.5 mm (0.295 to 0.335 in.)

2. REPLACE STUD BOLT


NOTE: If a stud bolt is deformed or the threads are damaged, replace it.

- a. Using "TORX" socket E6, install the stud bolt as shown in the illustration.

LH Side:



16 mm (0.630 in.)



9 mm (0.354 in.)

T

Fig. 200: Installing Stud Bolt

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


Torque: 5.0 N*m (51 kgf*cm, 44 in.*lbf)

3. REPLACE STRAIGHT PIN


NOTE: It is not necessary to remove the straight pins unless they are being replaced.

- a. Using a plastic hammer, tap in the straight pin.


Front Side:



Lower Side:



Rear Side:



LH Side:





Fig. 201: Locating Straight Pin Location
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard protrusion

Item	Protrusion
Pin A	18.5 to 19.5 mm (0.729 to 0.768 in.)
Pin B	5.0 to 7.0 mm (0.197 to 0.276 in.)
	11.0 to 13.0


Pin C	mm (0.433 to 0.512 in.)
Pin D	5.0 to 7.0 mm (0.197 to 0.276 in.)
Pin E	5.0 to 6.0 mm (0.197 to 0.236 in.)

REASSEMBLY

REASSEMBLY

1. INSTALL NO. 1 OIL NOZZLE SUB-ASSEMBLY

- Using a socket hexagon wrench 5, install the oil nozzles with the bolts.



T


Fig. 202: Locating Bolts And Oil Nozzles

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)

2. INSTALL PISTON SUB-ASSEMBLY WITH PIN

- Using a screwdriver, install a new snap ring at one end of the piston pin hole.

**T****Fig. 203: Identifying Piston Pin Hole****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.****HINT:**

Make sure that the end gap of the snap ring is not aligned with the service hole on the piston.

- b. Gradually heat the piston to between 80 and 90°C (176 to 194°F).
- c. Align the front marks of the piston and connecting rod, and push in the piston by hand.


**T**

Fig. 204: Identifying Front Marks Of Piston And Connecting Rod
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:


The piston and pin are a matched set.

- d. Using a screwdriver, install a new snap ring on the other end of the piston pin hole.

HINT:

Make sure that the end gap of the snap ring is not aligned with the service hole on the piston.

- e. Check the fitting condition between the piston and piston pin by moving the piston back and forth on the piston pin.



T

Fig. 205: Checking Fitting Condition Between Piston And Piston Pin
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

3. INSTALL PISTON RING SET

- a. Install the oil ring expander and oil ring rail by hand.





Fig. 206: Identifying Oil Ring Expander And Oil Ring Rail
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:

- Install the expander and oil ring so that their ring ends are at opposite sides.
 - Securely install the expander onto the inner groove of the oil ring.
- b. Using a piston ring expander, install the 2 compression rings so that the paint marks are positioned as shown in the illustration.

**T****Fig. 207: Installing Piston Ring**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:

- Install the compression ring No. 1 with the code mark (A1)

facing upward.

- Install the compression ring No. 2 with the code mark (A2) facing upward.
- Paint marks can only be checked on new piston rings. When reusing piston rings, check each piston ring profile in order to install them into the correct positions.

c. Position the piston rings so that the ring ends are as shown in the illustration.




Fig. 208: Identifying Piston Ring Gap Direction
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

4. INSTALL CRANKSHAFT BEARING

- a. Install the upper bearing (for except No. 3 journal).
 1. Install the upper bearing with the oil groove on the cylinder block.

2. Using vernier calipers, measure the distance between the cylinder block edge and the upper bearing edge.


**T**

Fig. 209: Identifying Distance Between Cylinder Block Edge And Upper Bearing Edge
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


NOTE: Do not apply engine oil to the bearings or the contact surfaces.

Dimension (A)

0.5 to 1.0 mm (0.020 to 0.039 in.)

- b. Install the upper bearing (for No. 3 journal).
 1. Install the upper bearing with an oil groove on the cylinder block.
 2. Using vernier calipers, measure the distance between the cylinder block edge and the upper

bearing's edge.



T

Fig. 210: Identifying Distance Between Cylinder Block Edge And Upper Bearing's Edge
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Do not apply engine oil to the bearings or the contact surfaces.

Dimension (A - B)

0.5 mm (0.0196 in.) or less

- c. Install the lower bearing.
 1. Install the lower bearing onto the bearing cap.
 2. Using vernier calipers, measure the distance between the bearing cap edge and the lower bearing edge.


**T**

Fig. 211: Identifying Distance Between Bearing Cap Edge And Lower Bearing Edge
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


Dimension (A - B)

0.5 mm (0.0196 in.) or less

NOTE: Do not apply engine oil to the bearings and the contact surfaces.

5. INSTALL UPPER CRANKSHAFT THRUST WASHER

- Install the 2 thrust washers under the No. 3 journal of the cylinder block with the oil grooves facing outward.


**T****Fig. 212: Locating Thrust Washers****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

- b. Apply engine oil to the crankshaft thrust washer.

6. INSTALL CRANKSHAFT

- a. Apply engine oil to the upper bearing and install the crankshaft on the cylinder block.
- b. Apply engine oil to the lower bearing.
- c. Examine the front marks and install the bearing caps on the cylinder block.

← Front




T

Fig. 213: Identifying Marks On Bearing Caps

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- d. Apply a light coat of engine oil to the threads and under the bearing cap bolts.
- e. Temporarily install the 10 main bearing cap bolts.



T

Fig. 214: Locating Main Bearing Cap Bolts**Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

- f. Insert the main bearing cap with your hand until the clearance between the main bearing cap and the cylinder block is less than 5 mm (0.20 in.).



**T**

Fig. 215: Identifying Clearance Between Main Bearing Cap And Cylinder Block
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- g. Using a plastic hammer, lightly tap the bearing cap to ensure a proper fit.

**T****Fig. 216: Tapping Bearing Cap****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

- h. Install the crankshaft bearing cap bolts.

NOTE: **The main bearing cap bolts are tightened in 2 progressive steps.**

- i. Step 1


**T**

Fig. 217: Locating Main Bearing Cap Bolts And Tightening Sequence

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

1. Install and uniformly tighten the 10 main bearing cap bolts in the sequence shown in the illustration.

Torque: 40 N*m (408 kgf*cm, 30 ft.*lbf)

j. Step 2




Fig. 218: Retightening Bearing Cap Bolts 90Degrees
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

1. Mark the front of the bearing cap bolts with paint.
 2. Further tighten the bearing cap bolts by 90° in the numerical order shown in the previous illustration.
- k. Check that the paint mark is now at a 90° angle to the front.
- l. Check that the crankshaft turns smoothly.
- m. Check the crankshaft thrust clearance See step 13.

7. INSTALL CONNECTING ROD BEARING

- a. Install the connecting rod bearing onto the connecting rod and bearing cap.
- b. Using vernier calipers, measure the distance between the connecting rod and connecting rod bearing, and the connecting rod cap and connecting rod bearing.


**T**

Fig. 219: Identifying Distance Between Connecting Rod And Connecting Rod Bearing
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Dimension (A - B)

0.7 mm (0.0276 in.) or less

NOTE: Do not apply engine oil to the bearings or the contact surfaces.

8. INSTALL PISTON SUB-ASSEMBLY WITH CONNECTING ROD

- Apply engine oil to the cylinder walls, the pistons, and the surfaces of the connecting rod bearings.
- Position the piston rings so that the ring ends are as shown in the illustration.






Fig. 220: Identifying Piston Ring Gap Direction
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Do not align the ring ends.

- c. Using a piston ring compressor, push the correctly numbered piston and connecting rod assembly into the cylinder with the front mark of the piston facing forward.



Front Marks



T

Fig. 221: Pushing Piston And Connecting Rod Assembly Into Cylinder
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:

- When inserting the piston with connecting rod, do not allow it to make contact with the oil nozzle.

- Match the numbered connecting rod cap with the connecting rod.
- d. Check that the protrusion of the connecting rod cap is facing in the correct direction.


**T**

Fig. 222: Identifying Front Mark Of Connecting Rod Cap
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- e. Apply a light coat of engine oil to the threads and under the heads of the connecting rod cap bolts.
- f. Install the connecting cap bolts.

NOTE: The connecting cap bolts should be tightened in 2 progressive steps.

- g. Step 1




Fig. 223: Tightening Bolts

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- **SST: 09205-16011**

1. Using SST, install and alternately tighten the bolts of the connecting rod cap in several steps.

Torque: 20 N*m (204 kgf*cm, 15 ft.*lbf)

h. Step 2




**P**

Fig. 224: Retightening Connecting Rod Bolts By 90Degrees
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

1. Mark the front of the connecting rod cap bolts with paint.
2. Further tighten the cap bolts by 90° as shown in the illustration.
 - i. Check that the crankshaft turns smoothly.
 - j. Check the connecting rod thrust clearance See step 1.

9. INSTALL NO. 1 VENTILATION CASE

- a. Apply seal packing in a continuous line as shown in the illustration.

**T****Fig. 225: Applying Seal Packing****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

Seal packing

Toyota Genuine Seal Packing Black, Three Bond 1207B or equivalent


Seal diameter

2.0 mm (0.0787 in.)

NOTE:

- Remove any oil from the contact surface.
- Install the oil pan within 3 minutes and tighten the bolts and nuts within 15 minutes of applying seal packing.
- Do not start the engine for at least 2 hours after installing.

- b. Install the No. 1 ventilation case with the 6 bolts and 2 nuts.



T

Fig. 226: Locating No. 1 Ventilation Case Bolts


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)

FRONT CRANKSHAFT OIL SEAL

COMPONENTS

ILLUSTRATION




N*m (kgf*cm, ft*lbf) : Specified torque



Fig. 227: Identifying Front Crankshaft Oil Seal Replacement Components With Torque Specification (1 Of 2)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



N*m (kgf*cm, ft*lb) : Specified torque ● Non-reusable part ← MP Grease

T

Fig. 228: Identifying Front Crankshaft Oil Seal Replacement Components With Torque Specifications (2 Of 2)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

REMOVAL

REMOVAL

1. REMOVE ENGINE UNDER COVER RH

2. **REMOVE NO. 2 CYLINDER HEAD COVER** . Refer to **REMOVAL - Step 1**
3. **REMOVE FAN AND GENERATOR V BELT** See step 3
4. **REMOVE CRANKSHAFT PULLEY**
 - a. Using SST, hold the pulley in place and loosen the pulley bolt.





Fig. 229: Loosening Pulley Bolt
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09213-58013
91651-60855
- SST: 09330-00021


- b. Using SST, remove the pulley bolt and pulley.



T
Fig. 230: Removing Pulley Bolt And Pulley
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09950-50013
09951-05010
09952-05010
09953-05020
09954-05021

5. REMOVE TIMING CHAIN OR BELT COVER OIL SEAL

**C****Fig. 231: Prying Out Oil Seal**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- Using a knife, cut off the oil seal lip.
- Using a screwdriver with its tip taped, pry out the oil seal.

NOTE: After the removal, check the crankshaft for damage. If it is damaged, smooth the surface with 400-grit sandpaper.

INSTALLATION

INSTALLATION

1. INSTALL TIMING CHAIN OR BELT COVER OIL SEAL




Fig. 232: Installing Oil Seal

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- Apply MP grease to a new oil seal lip.
- Using SST and a hammer, tap the oil seal until its surface is flush with the timing chain cover edge.
 - SST: 09223-22010

NOTE:

- Do not tap the oil seal at an angle.
- Keep the lip free of foreign matter.

HINT:

The pressing-in depth should be within the range of -1 mm and 1 mm from the chain cover edge.

2. INSTALL CRANKSHAFT PULLEY

- a. Align the pulley set key with the key groove of the pulley.
- b. Using SST, hold the pulley in place and tighten the bolt.




Fig. 233: Tightening Bolt

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09213-58013
91651-60855
- SST: 09330-00021

Torque: 190 N*m (1940 kgf*cm, 140 ft.*lbf)


3. **INSTALL FAN AND GENERATOR V BELT** See step 1
4. **ADJUST FAN AND GENERATOR V BELT** See step 2
5. **INSPECT FAN AND GENERATOR V BELT** See step 3

6. **INSTALL NO. 2 CYLINDER HEAD COVER** . Refer to **INSTALLATION - Step 3**
7. **INSPECT FOR ENGINE OIL LEAK**
8. **INSTALL ENGINE UNDER COVER RH**

REAR CRANKSHAFT OIL SEAL

COMPONENTS

ILLUSTRATION




$\boxed{\text{N}\cdot\text{m (kgf}\cdot\text{cm, ft}\cdot\text{lbf)}}$: Specified torque

Y

Fig. 234: Identifying Rear Crankshaft Oil Seal Replacement Components With Torque Specifications (1 Of 13)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



N*m (kgf*cm, ft*lb) : Specified torque

Fig. 235: Identifying Rear Crankshaft Oil Seal Replacement Components With Torque Specifications (2 Of 13)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION





Fig. 236: Identifying Rear Crankshaft Oil Seal Components (3 Of 13)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION




N*m (kgf*cm, ft*lbf) : Specified torque

T

Fig. 237: Identifying Rear Crankshaft Oil Seal Replacement Components With Torque Specifications (4 Of 13)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION





 **N*m (kgf*cm, ft*lb)** : Specified torque

Fig. 238: Identifying Rear Crankshaft Oil Seal Replacement Components With Torque Specifications (5 Of 13)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


ILLUSTRATION



T

Fig. 239: Identifying Rear Crankshaft Oil Seal Replacement Components (6 Of 13)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



N*m (kgf*cm, ft*lbf) : Specified torque ● Non-reusable part


◀ Do not apply lubricants to the threaded parts

Y

Fig. 240: Identifying Rear Crankshaft Oil Seal Replacement Components With Torque Specifications (7 Of 13)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



N*m (kgf*cm, ft*lb) : Specified torque


● Non-reusable part

T

Fig. 241: Identifying Rear Crankshaft Oil Seal Replacement Components With Torque Specifications (8 Of 13)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION




$\boxed{\text{N}\cdot\text{m (kgf}\cdot\text{cm, ft}\cdot\text{lbf)}}$: Specified torque

P

Fig. 242: Identifying Rear Crankshaft Oil Seal Replacement Components With Torque Specifications (9 Of 13)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



● Non-reusable part


◀ Do not apply lubricants to the threaded parts

Y

Fig. 243: Identifying Rear Crankshaft Oil Seal Replacement Components (10 Of 13)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION

for Automatic Transaxle:



N*m (kgf*cm, ft*lb) : Specified torque ● Non-reusable part

★ Precoated part


Y

Fig. 244: Identifying Rear Crankshaft Oil Seal Replacement Components With Torque Specifications (11 Of 13)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION

for Manual Transaxle:




N*m (kgf*cm, ft*lb) : Specified torque ● Non-reusable part ★ Precoated part

Y

Fig. 245: Identifying Rear Crankshaft Oil Seal Replacement Components With Torque Specifications (12 Of 13)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



T

Fig. 246: Identifying Rear Crankshaft Oil Seal Components (13 Of 13)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

REMOVAL

REMOVAL

1. DISCHARGE FUEL SYSTEM PRESSURE

Refer to **PRECAUTION**

2. **REMOVE BATTERY** See step 2

3. **REMOVE BATTERY TRAY**

4. **REMOVE FRONT WHEELS**

5. **REMOVE ENGINE UNDER COVER LH**

6. **REMOVE ENGINE UNDER COVER RH**

7. **DRAIN ENGINE COOLANT** . Refer to **REPLACEMENT - Step 1**

8. **DRAIN MANUAL TRANSAXLE OIL (for Manual Transaxle)**
9. **DRAIN AUTOMATIC TRANSAXLE OIL (for Automatic Transaxle)**
10. **REMOVE FRONT WIPER ARM HEAD CAP** . Refer to **REMOVAL - Step 1**
11. **REMOVE FRONT WIPER ARM AND BLADE ASSEMBLY LH** . Refer to **REMOVAL - Step 2**
12. **REMOVE FRONT WIPER ARM AND BLADE ASSEMBLY RH** . Refer to **REMOVAL - Step 3**
13. **REMOVE HOOD TO COWL TOP SEAL** . Refer to **REMOVAL - Step 4**
14. **REMOVE COWL TOP VENTILATOR LOUVER SUB-ASSEMBLY** . Refer to **REMOVAL - Step 5**
15. **REMOVE COWL TOP VENTILATOR LOUVER LH** . Refer to **REMOVAL - Step 6**
16. **REMOVE FRONT WIPER MOTOR AND LINK** . Refer to **REMOVAL - Step 7**
17. **REMOVE FRONT AIR SHUTTER SEAL RH** See step 17
18. **REMOVE OUTER COWL TOP PANEL** See step 18
19. **REMOVE AIR CLEANER ASSEMBLY** See step 19
20. **REMOVE AIR CLEANER BRACKET** See step 20
21. **REMOVE BATTERY CARRIER** See step 21
22. **REMOVE NO. 2 CYLINDER HEAD COVER** . Refer to **REMOVAL - Step 1**
23. **REMOVE FAN & GENERATOR V BELT** See step 3
24. **REMOVE NO. 2 RADIATOR HOSE** See step 24
25. **REMOVE FRONT BUMPER COVER** . Refer to **REMOVAL - Step 1**
26. **DISCONNECT NO. 1 RADIATOR HOSE** . Refer to **REMOVAL - Step 7**
27. **DISCONNECT NO. 1 OIL COOLER OUTLET HOSE (for Automatic Transaxle)** . Refer to **REMOVAL - Step 9**
28. **DISCONNECT NO. 2 OIL COOLER INLET HOSE (for Automatic Transaxle)** . Refer to **REMOVAL - Step 8**
29. **REMOVE HOOD LOCK ASSEMBLY** . Refer to **REMOVAL - Step 11**
30. **REMOVE NO. 1 COOLER COVER** . Refer to **REMOVAL - Step 12**
31. **REMOVE UPPER RADIATOR SUPPORT ABSORBER** . Refer to **DISASSEMBLY - Step 11**
32. **REMOVE UPPER RADIATOR SUPPORT SUB-ASSEMBLY** . Refer to **REMOVAL - Step 13**
33. **REMOVE RADIATOR ASSEMBLY** . Refer to **REMOVAL - Step 14**
34. **SEPARATE WITH PULLEY COMPRESSOR ASSEMBLY** . Refer to **REMOVAL - Step 7**
35. **SEPARATE TRANSMISSION CONTROL CABLE ASSEMBLY (for Automatic Transaxle)** See step 35
36. **SEPARATE TRANSMISSION CONTROL CABLE ASSEMBLY (for Manual Transaxle)** See step 36
37. **SEPARATE UNION TO CHECK VALVE HOSE** See step 37
38. **SEPARATE NO. 1 FUEL VAPOR FEED HOSE** See step 38
39. **DISCONNECT ENGINE WIRE** See step 39
40. **DISCONNECT HEATER WATER HOSE OUTLET A** See step 40
41. **DISCONNECT HEATER WATER HOSE INLET A** See step 41

- 42. **DISCONNECT FUEL TUBE SUB-ASSEMBLY** See step 42
- 43. **SEPARATE CLUTCH RELEASE CYLINDER ASSEMBLY (for Manual Transaxle)** See step 43
- 44. **REMOVE COLUMN HOLE COVER SILENCER SHEET** . Refer to **REMOVAL - Step 12**
- 45. **SEPARATE STEERING SLIDING YOKE SUB-ASSEMBLY** . Refer to **REMOVAL - Step 13**
- 46. **SEPARATE NO. 1 STEERING COLUMN HOLE COVER SUB-ASSEMBLY** . Refer to **REMOVAL - Step 14**
- 47. **REMOVE SHIFT LEVER KNOB SUB-ASSEMBLY (for Manual Transaxle)** . Refer to **REMOVAL - Step 1**
- 48. **REMOVE CONSOLE PANEL UPPER** . Refer to **REMOVAL - Step 2**
- 49. **REMOVE CONSOLE BOX COVER REAR** . Refer to **REMOVAL - Step 3**
- 50. **REMOVE CONSOLE BOX CARPET** . Refer to **REMOVAL - Step 4**
- 51. **REMOVE REAR CONSOLE BOX ASSEMBLY** . Refer to **REMOVAL - Step 5**
- 52. **REMOVE FRONT CONSOLE BOX** . Refer to **REMOVAL - Step 28**
- 53. **REMOVE FRONT FLOOR BRACE CENTER** . Refer to **REMOVAL - Step 10**
- 54. **REMOVE FRONT EXHAUST PIPE ASSEMBLY** See step 54
- 55. **REMOVE FRONT AXLE SHAFT LH NUT** . Refer to **REMOVAL - Step 5**
- 56. **REMOVE FRONT AXLE SHAFT RH NUT**

HINT:

The removal procedure for the RH side is the same as that for the LH side.

- 57. **SEPARATE SPEED SENSOR FRONT LH** . Refer to **REMOVAL - Step 6**
- 58. **SEPARATE SPEED SENSOR FRONT RH**

HINT:

The removal procedure for the RH side is the same as that for the LH side.

- 59. **SEPARATE TIE ROD END SUB-ASSEMBLY LH** . Refer to **REMOVAL - Step 8**
- 60. **SEPARATE TIE ROD END SUB-ASSEMBLY RH**

HINT:

The removal procedure for the RH side is the same as that for the LH side.

- 61. **SEPARATE FRONT STABILIZER LINK ASSEMBLY LH** . Refer to **REMOVAL - Step 7**
- 62. **SEPARATE FRONT STABILIZER LINK ASSEMBLY RH**

HINT:

The removal procedure for the RH side is the same as that for the LH side.

- 63. **SEPARATE FRONT LOWER SUSPENSION ARM SUB-ASSEMBLY LH** . Refer to **REMOVAL - Step 9**
- 64. **SEPARATE FRONT LOWER SUSPENSION ARM SUB-ASSEMBLY RH**

HINT:

The removal procedure for the RH side is the same as that for the LH side.

- 65. **SEPARATE FRONT AXLE ASSEMBLY LH** . Refer to **REMOVAL - Step 10**
- 66. **SEPARATE FRONT AXLE ASSEMBLY RH**

HINT:

The removal procedure for the RH side is the same as that for the LH side.

- 67. **REMOVE FRONT DRIVE SHAFT ASSEMBLY LH** . Refer to **REMOVAL - Step 11**
- 68. **REMOVE FRONT DRIVE SHAFT ASSEMBLY RH** . Refer to **REMOVAL - Step 12**
- 69. **REMOVE FLYWHEEL HOUSING UNDER COVER (for Automatic Transaxle)** . Refer to **REMOVAL - Step 3**
- 70. **REMOVE DRIVE PLATE AND TORQUE CONVERTER CLUTCH SETTING BOLT (for Automatic Transaxle)** . Refer to **REMOVAL - Step 4**
- 71. **REMOVE ENGINE ASSEMBLY WITH TRANSAXLE** See step 71
- 72. **REMOVE FRONT SUSPENSION CROSSMEMBER SUB-ASSEMBLY** See step 73
- 73. **REMOVE FLYWHEEL HOUSING SIDE COVER** . Refer to **REMOVAL - Step 4**
- 74. **REMOVE STARTER ASSEMBLY** . Refer to **REMOVAL - Step 5**
- 75. **REMOVE NO. 1 OIL COOLER INLET TUBE (for Automatic Transaxle)** . Refer to **REMOVAL - Step 5**
- 76. **REMOVE NO. 1 OIL COOLER OUTLET TUBE (for Automatic Transaxle)** . Refer to **REMOVAL - Step 6**
- 77. **REMOVE NO. 2 OIL COOLER TUBE CLAMP (for Automatic Transaxle)** . Refer to **REMOVAL - Step 7**
- 78. **REMOVE TRANSMISSION OIL LEVEL GAGE SUB-ASSEMBLY (for Automatic Transaxle)**
- 79. **SEPARATE TRANSMISSION OIL FILLER TUBE SUB-ASSEMBLY (for Automatic Transaxle)** . Refer to **REMOVAL - Step 8**
- 80. **REMOVE AUTOMATIC TRANSAXLE ASSEMBLY (for Automatic Transaxle)** . Refer to **REMOVAL - Step 14**
- 81. **REMOVE NO. 1 TRANSMISSION CONTROL CABLE BRACKET (for Manual Transaxle)** See step 85
- 82. **REMOVE MANUAL TRANSAXLE ASSEMBLY (for Manual Transaxle)** . Refer to **REMOVAL - Step 7**
- 83. **REMOVE CLUTCH COVER ASSEMBLY (for Manual Transaxle)** . Refer to **REMOVAL - Step 7**
- 84. **REMOVE CLUTCH DISC ASSEMBLY (for Manual Transaxle)**

85. **REMOVE DRIVE PLATE AND RING GEAR SUB-ASSEMBLY (for Automatic Transaxle)** See step 89
86. **REMOVE FLYWHEEL SUB-ASSEMBLY (for Manual Transaxle)** See step 90
87. **REMOVE ENGINE REAR OIL SEAL**
 - a. Using a knife, cut off the oil seal lip.




Fig. 247: Prying Out Oil Seal

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Using a screwdriver with its tip taped, pry out the oil seal.

NOTE: After removing the oil seal, check the crankshaft for damage.

If it is damaged, smooth the surface with 400-grit sandpaper.

INSTALLATION

INSTALLATION

1. INSTALL ENGINE REAR OIL SEAL




Fig. 248: Installing Oil Seal

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- a. Apply MP grease to a new oil seal lip.
- b. Using SST and a hammer, evenly tap the oil seal until its surface is flush with the rear oil seal retainer edge.

- SST: 09223-15030
- SST: 09950-70010
- 09951-07100

NOTE:

- Keep the lip free from foreign materials.
- Do not tap on the oil seal at an angle.
- Wipe off extra grease on the crankshaft.

HINT:

The pressing-in depth should be within the range of -1 mm and 1 mm from the rear oil seal retainer edge.

2. **INSTALL DRIVE PLATE AND RING GEAR SUB-ASSEMBLY (for Automatic Transaxle)** See step 1
3. **INSTALL AUTOMATIC TRANSAXLE ASSEMBLY (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 3**
4. **INSTALL TRANSMISSION OIL FILLER TUBE SUB-ASSEMBLY (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 9**

5. **INSTALL TRANSMISSION OIL LEVEL GAGE SUB-ASSEMBLY (for Automatic Transaxle)**
6. **INSTALL NO. 1 OIL COOLER OUTLET TUBE (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 12**
7. **INSTALL NO. 1 OIL COOLER INLET TUBE (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 13**
8. **INSTALL NO. 2 OIL COOLER TUBE CLAMP (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 11**
9. **INSTALL FLYWHEEL SUB-ASSEMBLY (for Manual Transaxle)** See step 8
10. **INSTALL CLUTCH DISC ASSEMBLY (for Manual Transaxle)** . Refer to **INSTALLATION - Step 1**
11. **INSTALL CLUTCH COVER ASSEMBLY (for Manual Transaxle)** . Refer to **INSTALLATION - Step 2**
12. **INSPECT AND ADJUST CLUTCH COVER ASSEMBLY (for Manual Transaxle)** . Refer to **INSTALLATION - Step 3**
13. **INSTALL MANUAL TRANSAXLE ASSEMBLY (for Manual Transaxle)** . Refer to **INSTALLATION - Step 1**
14. **INSTALL NO. 1 TRANSMISSION CONTROL CABLE BRACKET (for Manual Transaxle)** See step 13
15. **INSTALL STARTER ASSEMBLY** . Refer to **INSTALLATION - Step 1**
16. **INSTALL FLYWHEEL HOUSING SIDE COVER** . Refer to **INSTALLATION - Step 2**
17. **INSTALL FRONT SUSPENSION CROSSMEMBER SUB-ASSEMBLY** See step 19
18. **INSTALL ENGINE ASSEMBLY WITH TRANSAXLE** See step 21
19. **INSTALL DRIVE PLATE AND TORQUE CONVERTER CLUTCH SETTING BOLT (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 14**
20. **INSTALL FLYWHEEL HOUSING UNDER COVER (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 15**
21. **INSTALL FRONT DRIVE SHAFT ASSEMBLY LH** . Refer to **INSTALLATION - Step 1**
22. **INSTALL FRONT DRIVE SHAFT ASSEMBLY RH** . Refer to **INSTALLATION - Step 2**
23. **INSTALL FRONT AXLE ASSEMBLY LH** . Refer to **INSTALLATION - Step 8**
24. **INSTALL FRONT AXLE ASSEMBLY RH**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

25. **INSTALL FRONT LOWER SUSPENSION ARM SUB-ASSEMBLY LH** . Refer to **INSTALLATION - Step 4**
26. **INSTALL FRONT LOWER SUSPENSION ARM SUB-ASSEMBLY RH**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

- 27. **INSTALL FRONT STABILIZER LINK ASSEMBLY LH** . Refer to **INSTALLATION - Step 6**
- 28. **INSTALL FRONT STABILIZER LINK ASSEMBLY RH**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

- 29. **INSTALL TIE ROD END SUB-ASSEMBLY LH** . Refer to **INSTALLATION - Step 5**
- 30. **INSTALL TIE ROD END SUB-ASSEMBLY RH**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

- 31. **INSTALL SPEED SENSOR FRONT LH** . Refer to **INSTALLATION - Step 7**
- 32. **INSTALL SPEED SENSOR FRONT RH**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

- 33. **INSTALL FRONT AXLE SHAFT LH NUT** . Refer to **INSTALLATION - Step 8**
- 34. **INSTALL FRONT AXLE SHAFT RH NUT**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

- 35. **INSTALL FRONT EXHAUST PIPE ASSEMBLY** See step 38
- 36. **INSTALL FRONT FLOOR BRACE CENTER** . Refer to **INSTALLATION - Step 2**
- 37. **INSTALL FRONT CONSOLE BOX** . Refer to **INSTALLATION - Step 16**
- 38. **INSTALL REAR CONSOLE BOX ASSEMBLY** . Refer to **INSTALLATION - Step 3**
- 39. **INSTALL CONSOLE BOX COVER REAR** . Refer to **INSTALLATION - Step 3**
- 40. **INSTALL CONSOLE BOX CARPET** . Refer to **INSTALLATION - Step 2**
- 41. **INSTALL CONSOLE PANEL UPPER** . Refer to **INSTALLATION - Step 4**
- 42. **INSTALL SHIFT LEVER KNOB SUB-ASSEMBLY (for Manual Transaxle)** . Refer to **INSTALLATION - Step 5**
- 43. **INSTALL NO. 1 STEERING COLUMN HOLE COVER SUB-ASSEMBLY** . Refer to **INSTALLATION - Step 18**
- 44. **INSTALL STEERING SLIDING YOKE SUB-ASSEMBLY** . Refer to **INSTALLATION - Step 19**
- 45. **INSTALL COLUMN HOLE COVER SILENCER SHEET** . Refer to **INSTALLATION - Step 20**
- 46. **INSTALL CLUTCH RELEASE CYLINDER ASSEMBLY (for Manual Transaxle)** See step 49
- 47. **CONNECT FUEL TUBE SUB-ASSEMBLY** See step 50

48. **CONNECT HEATER WATER HOSE INLET A** See step 51
49. **CONNECT HEATER WATER HOSE OUTLET A** See step 52
50. **CONNECT ENGINE WIRE** See step 53
51. **INSTALL NO. 1 FUEL VAPOR FEED HOSE** See step 54
52. **INSTALL UNION TO CHECK VALVE HOSE** See step 55
53. **INSTALL TRANSMISSION CONTROL CABLE ASSEMBLY (for Automatic Transaxle)** See step 56
54. **INSTALL TRANSMISSION CONTROL CABLE ASSEMBLY (for Manual Transaxle)** See step 57
55. **INSTALL WITH PULLEY COMPRESSOR ASSEMBLY** . Refer to **INSTALLATION - Step 2**
56. **INSTALL RADIATOR ASSEMBLY** . Refer to **INSTALLATION - Step 6**
57. **INSTALL UPPER RADIATOR SUPPORT SUB-ASSEMBLY** . Refer to **INSTALLATION - Step 7**
58. **INSTALL UPPER RADIATOR SUPPORT ABSORBER** . Refer to **REASSEMBLY - Step 14**
59. **INSTALL NO. 1 COOLER COVER** . Refer to **INSTALLATION - Step 8**
60. **INSTALL HOOD LOCK ASSEMBLY** . Refer to **INSTALLATION - Step 9**
61. **CONNECT NO. 2 OIL COOLER INLET HOSE (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 12**
62. **CONNECT NO. 1 OIL COOLER OUTLET HOSE (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 11**
63. **CONNECT NO. 1 RADIATOR HOSE** . Refer to **INSTALLATION - Step 13**
64. **INSTALL NO. 2 RADIATOR HOSE** See step 67
65. **INSTALL FRONT BUMPER COVER** . Refer to **INSTALLATION - Step 1**
66. **INSTALL FAN & GENERATOR V BELT** See step 1
67. **ADJUST FAN & GENERATOR V BELT** See step 2
68. **INSPECT FAN & GENERATOR V BELT** See step 3
69. **INSTALL NO. 2 CYLINDER HEAD COVER** . Refer to **INSTALLATION - Step 3**
70. **INSTALL BATTERY CARRIER** See step 73
71. **INSTALL AIR CLEANER BRACKET** See step 74
72. **INSTALL AIR CLEANER ASSEMBLY** See step 75
73. **INSTALL OUTER COWL TOP PANEL** See step 76
74. **INSTALL FRONT AIR SHUTTER SEAL RH** See step 77
75. **INSTALL FRONT WIPER MOTOR AND LINK** . Refer to **INSTALLATION - Step 2**
76. **INSTALL COWL TOP VENTILATOR LOUVER LH** . Refer to **INSTALLATION - Step 3**
77. **INSTALL COWL TOP VENTILATOR LOUVER SUB-ASSEMBLY** . Refer to **INSTALLATION - Step 4**
78. **INSTALL HOOD TO COWL TOP SEAL** . Refer to **INSTALLATION - Step 5**
79. **INSTALL FRONT WIPER ARM AND BLADE ASSEMBLY LH** . Refer to **INSTALLATION - Step 6**
80. **INSTALL FRONT WIPER ARM AND BLADE ASSEMBLY RH** . Refer to **INSTALLATION - Step 7**

- 81. **INSTALL FRONT WIPER ARM HEAD CAP**
- 82. **INSTALL BATTERY TRAY**
- 83. **INSTALL BATTERY** See step 86
- 84. **ADD ENGINE COOLANT** . Refer to **REPLACEMENT - Step 2**
- 85. **ADD AUTOMATIC TRANSAXLE OIL (for Automatic Transaxle)**
- 86. **INSPECT AUTOMATIC TRANSAXLE OIL (for Automatic Transaxle)** . Refer to **ON-VEHICLE INSPECTION - Step 1**
- 87. **ADD MANUAL TRANSAXLE OIL (for Manual Transaxle)**
- 88. **INSPECT MANUAL TRANSAXLE OIL (for Manual Transaxle)** . Refer to **ON-VEHICLE INSPECTION - Step 1**
- 89. **INSPECT FOR FUEL LEAK**
- 90. **INSPECT FOR ENGINE OIL LEAK**
- 91. **INSPECT FOR EXHAUST GAS LEAK**
- 92. **INSPECT FOR ENGINE COOLANT LEAK** . Refer to **ON-VEHICLE INSPECTION - Step 1**
- 93. **INSTALL ENGINE UNDER COVER RH**
- 94. **INSTALL ENGINE UNDER COVER LH**
- 95. **INSTALL FRONT WHEELS** See step 98
- 96. **INSPECT IGNITION TIMING** See step 6
- 97. **INSPECT ENGINE IDLING SPEED** See step 7
- 98. **INSPECT CO/HC** See step 9
- 99. **INSPECT FRONT WHEEL ALIGNMENT**

Refer to **ADJUSTMENT**


- 100. **CHECK VSC SENSOR SIGNAL**

Refer to **TEST MODE PROCEDURE**

ENGINE ASSEMBLY

COMPONENTS

ILLUSTRATION




N*m (kgf*cm, ft*lbf) : Specified torque

Y

Fig. 249: Identifying Engine Assembly Replacement Components With Torque Specifications (1 Of 12)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



N*m (kgf*cm, ft*lbf) : Specified torque

Fig. 250: Identifying Engine Assembly Replacement Components With Torque Specifications (2 Of 12)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION





Fig. 251: Identifying Engine Assembly Replacement Components (3 Of 12)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION




N*m (kgf*cm, ft*lbf) : Specified torque

T

Fig. 252: Identifying Engine Assembly Replacement Components With Torque Specifications (4 Of 12)
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION





N*m (kgf*cm, ft*lbft) : Specified torque

Fig. 253: Identifying Engine Assembly Replacement Components With Torque Specifications (5 Of 12)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION


for Manual Transaxle:



T

Fig. 254: Identifying Engine Assembly Replacement Components (6 Of 12)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION




N*m (kgf*cm, ft*lbft) : Specified torque ● Non-reusable part

⬅ Do not apply lubricants to the threaded parts

Y

Fig. 255: Identifying Engine Assembly Replacement Components With Torque Specifications (7 Of 12)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


ILLUSTRATION




T

Fig. 256: Identifying Engine Assembly Replacement Components With Torque Specifications (8 Of 12)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


ILLUSTRATION



for Automatic Transaxle:



for Manual Transaxle:




N*m (kgf*cm, ft.*lbf): Specified torque

● Non-reusable part

Fig. 257: Identifying Engine Assembly Replacement Components With Torque Specifications (9 Of 12)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



● Non-reusable part


➡ Do not apply lubricants to the threaded parts

Y

Fig. 258: Identifying Engine Assembly Replacement Components (10 Of 12)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION

for Automatic Transaxle:



N*m (kgf*cm, ft*lbf) : Specified torque ● Non-reusable part


★ Precoated part

Y

Fig. 259: Identifying Engine Assembly Replacement Components With Torque Specifications (11 Of 12)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION

for Manual Transaxle:



N*m (kgf*cm, ft*lbf) : Specified torque ● Non-reusable part ★ Precoated part

Y

Fig. 260: Identifying Engine Assembly Components And Torque Specifications (12 Of 12)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

REMOVAL

REMOVAL**1. DISCHARGE FUEL SYSTEM PRESSURE**

Refer to **PRECAUTION**

2. REMOVE BATTERY

- a. Disconnect the cable from the battery terminal.
- b. Loosen the nut and remove the battery clamp.
- c. Remove the battery.

3. REMOVE BATTERY TRAY**4. REMOVE FRONT WHEELS****5. REMOVE ENGINE UNDER COVER LH****6. REMOVE ENGINE UNDER COVER RH****7. DRAIN ENGINE COOLANT . Refer to REPLACEMENT - Step 1****8. DRAIN MANUAL TRANSAXLE OIL (for Manual Transaxle)****9. DRAIN AUTOMATIC TRANSAXLE OIL (for Automatic Transaxle)****10. REMOVE FRONT WIPER ARM HEAD CAP . Refer to REMOVAL - Step 1****11. REMOVE FRONT WIPER ARM AND BLADE ASSEMBLY LH . Refer to REMOVAL - Step 2****12. REMOVE FRONT WIPER ARM AND BLADE ASSEMBLY RH . Refer to REMOVAL - Step 3****13. REMOVE HOOD TO COWL TOP SEAL . Refer to REMOVAL - Step 4****14. REMOVE COWL TOP VENTILATOR LOUVER SUB-ASSEMBLY . Refer to REMOVAL - Step 5****15. REMOVE COWL TOP VENTILATOR LOUVER LH . Refer to REMOVAL - Step 6****16. REMOVE FRONT WIPER MOTOR AND LINK . Refer to REMOVAL - Step 7****17. REMOVE FRONT AIR SHUTTER SEAL RH**




Fig. 261: Identifying Claws Locations

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- a. Disengage the 2 claws and remove the front air shutter seal RH.

18. REMOVE OUTER COWL TOP PANEL




Fig. 262: Locating Wire Harness Clamp

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- a. Disengage the wire harness clamp.
- b. Remove the 9 bolts and remove the outer cowl top panel.




Fig. 263: Locating Bolts And Outer Cowl Top Panel
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

19. REMOVE AIR CLEANER ASSEMBLY

**T****Fig. 264: Locating Clamps****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

- a. Separate the intake air flow meter connector and 2 wire harness clamps.
- b. Separate the ventilation hose from the air cleaner hose.
- c. Unfasten the 2 clamps.
- d. Remove the air cleaner cap sub-assembly with air cleaner hose.
- e. Remove the air cleaner element.
- f. Separate the wire harness clamp from the air cleaner case.


**T**

Fig. 265: Locating Air Cleaner Hose Clamp

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- g. Remove the 2 bolts and remove the air cleaner case with air cleaner inlet.

20. REMOVE AIR CLEANER BRACKET





Fig. 266: Locating Air Cleaner Bracket

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- a. Separate the wire harness clamp from the air cleaner bracket.
- b. Remove the 2 bolts and remove the air cleaner bracket.

21. REMOVE BATTERY CARRIER**Fig. 267: Locating Bolts And Battery Carrier**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- a. Separate the wire harness clamp from the battery carrier.
- b. Remove the 5 bolts and remove the battery carrier.

22. REMOVE NO. 2 CYLINDER HEAD COVER . Refer to REMOVAL - Step 1**23. REMOVE FAN AND GENERATOR V BELT** See step 3**24. REMOVE NO. 2 RADIATOR HOSE**

- a. Loosen the 2 clips and remove the No. 2 radiator hose.



**T**

Fig. 268: Locating Clips And No. 2 Radiator Hose

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

25. **REMOVE FRONT BUMPER COVER** . Refer to **REMOVAL - Step 1**
26. **DISCONNECT NO. 1 RADIATOR HOSE** . Refer to **REMOVAL - Step 7**

27. **DISCONNECT NO. 1 OIL COOLER OUTLET HOSE (for Automatic Transaxle)** . Refer to **REMOVAL - Step 9**
28. **DISCONNECT NO. 2 OIL COOLER INLET HOSE (for Automatic Transaxle)** . Refer to **REMOVAL - Step 8**
29. **REMOVE HOOD LOCK ASSEMBLY** . Refer to **REMOVAL - Step 11**
30. **REMOVE NO. 1 COOLER COVER** . Refer to **REMOVAL - Step 12**
31. **REMOVE UPPER RADIATOR SUPPORT ABSORBER** . Refer to **DISASSEMBLY - Step 11**
32. **REMOVE UPPER RADIATOR SUPPORT SUB-ASSEMBLY** . Refer to **REMOVAL - Step 13**
33. **REMOVE RADIATOR ASSEMBLY** . Refer to **REMOVAL - Step 14**
34. **SEPARATE WITH PULLEY COMPRESSOR ASSEMBLY** . Refer to **REMOVAL - Step 7**
35. **SEPARATE TRANSMISSION CONTROL CABLE ASSEMBLY (for Automatic Transaxle)**


**P**

Fig. 269: Identifying Nut And Control Cable

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- a. Remove the nut and disconnect the transmission control cable assembly from the control shaft lever.
36. **SEPARATE TRANSMISSION CONTROL CABLE ASSEMBLY (for Manual Transaxle)**
 - a. Remove the 2 clips and the washers, and disconnect the 2 cables from the transaxle.




Fig. 270: Locating Control Cable Bracket

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Remove the 2 clips and disconnect the 2 cables from the control cable bracket.

37. SEPARATE UNION TO CHECK VALVE HOSE

- a. Loosen the clip and separate the union to check valve hose.




Fig. 271: Locating Clip And Check Valve Hose
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

38. SEPARATE NO. 1 FUEL VAPOR FEED HOSE

- a. Separate the No. 1 fuel vapor feed hose from the vacuum switching valve assembly.




Fig. 272: Locating No. 1 Fuel Vapor Feed Hose
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

39. DISCONNECT ENGINE WIRE

- a. Remove the bolt and wire harness clamp and separate the transaxle earth wire (for Automatic Transaxle).




Fig. 273: Locating Bolt And Wire Harness Clamp

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Remove the bolt and 2 wire harness clamp and separate the transaxle earth wire (for Manual Transaxle).





Fig. 274: Locating Bolt And Wire Harness Clamp

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- c. Disconnect the 2 connectors.



T

Fig. 275: Locating Connectors

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- d. Pull up the lever and disconnect the connector from the engine control computer.




Fig. 276: Locating Wire Harness Clamps

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- e. Separate the 2 wire harness clamps.
- f. Remove the 2 connectors and clamp from the engine room junction block and disconnect the 2 wire harness clamps.




Fig. 277: Locating Connectors And Clamp


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- g. Disconnect all wire harnesses and connectors.

NOTE: **Make sure that no wire harness is connected between the body and engine.**

40. DISCONNECT HEATER WATER OUTLET HOSE A (FROM HEATER UNIT)


- a. Disconnect heater water outlet hose A from the heater unit.

**Fig. 278: Locating Heater Water Outlet Hose**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

41. DISCONNECT HEATER WATER HOSE INLET A


- a. Disconnect heater water inlet hose A from the heater unit.

**T****Fig. 279: Locating Heater Water Inlet Hose**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

42. DISCONNECT FUEL TUBE SUB-ASSEMBLY

- a. Remove the No. 1 fuel pipe clamp.

**T****Fig. 280: Locating No. 1 Fuel Pipe Clamp**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Pinch the retainer as illustrated, then pull the fuel tube connector out of the pipe.




Fig. 281: Identifying Fuel Tube Connector

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:

- Remove any dirt and foreign matter from the fuel tube connector before performing this work.
- Do not allow any scratches or foreign matter on the parts when disconnecting, as the fuel tube connector has the O-rings that seal the pipe.
- Perform this work by hand. Do not use any tools.
- Do not forcibly bend, twist or turn the nylon tube.
- Protect the disconnected parts by covering them with vinyl bags after disconnecting the fuel tube.
- If the fuel tube connector and pipe are stuck, push and pull them to release them.

43. SEPARATE CLUTCH RELEASE CYLINDER ASSEMBLY (for Manual Transaxle)

- a. Remove the 4 bolts, then separate the clutch release cylinder.





Fig. 282: Identifying Bolts, Separating Clutch Release Cylinder
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Suspend the clutch release cylinder with a piece of rope so as not to overload the clutch pipe.

44. **REMOVE COLUMN HOLE COVER SILENCER SHEET** . Refer to **REMOVAL - Step 12**
45. **SEPARATE STEERING SLIDING YOKE SUB-ASSEMBLY** . Refer to **REMOVAL - Step 13**
46. **SEPARATE NO. 1 STEERING COLUMN HOLE COVER SUB-ASSEMBLY** . Refer to **REMOVAL - Step 14**
47. **REMOVE SHIFT LEVER KNOB SUB-ASSEMBLY (for Manual Transaxle)** . Refer to **REMOVAL - Step 1**
48. **REMOVE CONSOLE PANEL UPPER** . Refer to **REMOVAL - Step 2**
49. **REMOVE CONSOLE BOX COVER REAR** . Refer to **REMOVAL - Step 3**
50. **REMOVE CONSOLE BOX CARPET** . Refer to **REMOVAL - Step 4**
51. **REMOVE REAR CONSOLE BOX ASSEMBLY** . Refer to **REMOVAL - Step 5**
52. **REMOVE FRONT CONSOLE BOX** . Refer to **REMOVAL - Step 28**
53. **REMOVE FRONT FLOOR BRACE CENTER** . Refer to **REMOVAL - Step 10**
54. **REMOVE FRONT EXHAUST PIPE ASSEMBLY**
 - a. Disconnect the heated oxygen sensor connector.




T

Fig. 283: Locating Heated Oxygen Sensor Connector

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Remove the grommet and pull the sensor connector out of the cabin through the floor panel.
- c. Remove the 2 bolts and 2 springs and separate the front exhaust pipe assembly from the exhaust tail pipe assembly.




T

Fig. 284: Locating Bolts And Springs

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- d. Remove the 2 bolts and 2 springs and separate the front exhaust pipe assembly from the exhaust manifold.

**Fig. 285: Locating Bolts And Springs**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- e. Remove the 3 exhaust pipe supports and remove the front exhaust pipe assembly.
55. **REMOVE FRONT AXLE SHAFT LH NUT** . Refer to **REMOVAL - Step 5**
56. **REMOVE FRONT AXLE SHAFT RH NUT**

HINT:

The removal procedure for the RH side is the same as that for the LH side.

57. **SEPARATE SPEED SENSOR FRONT LH** . Refer to **REMOVAL - Step 6**
58. **SEPARATE SPEED SENSOR FRONT RH**

HINT:

The separation procedure for the RH side is the same as that for the LH side.

59. **SEPARATE TIE ROD END SUB-ASSEMBLY LH** . Refer to **REMOVAL - Step 8**
60. **SEPARATE TIE ROD END SUB-ASSEMBLY RH**

HINT:

The separation procedure for the RH side is the same as that for the LH side.

- 61. **SEPARATE FRONT STABILIZER LINK ASSEMBLY LH** . Refer to **REMOVAL - Step 7**
- 62. **SEPARATE FRONT STABILIZER LINK ASSEMBLY RH**

HINT:

The separation procedure for the RH side is the same as that for the LH side.

- 63. **SEPARATE FRONT LOWER SUSPENSION ARM SUB-ASSEMBLY LH** . Refer to **REMOVAL - Step 9**
- 64. **SEPARATE FRONT LOWER SUSPENSION ARM SUB-ASSEMBLY RH**

HINT:

The separation procedure for the RH side is the same as that for the LH side.

- 65. **SEPARATE FRONT AXLE ASSEMBLY LH** . Refer to **REMOVAL - Step 10**
- 66. **SEPARATE FRONT AXLE ASSEMBLY RH**

HINT:

The separation procedure for the RH side is the same as that for the LH side.

- 67. **REMOVE FRONT DRIVE SHAFT ASSEMBLY LH** . Refer to **REMOVAL - Step 11**
- 68. **REMOVE FRONT DRIVE SHAFT ASSEMBLY RH** . Refer to **REMOVAL - Step 12**
- 69. **REMOVE FLYWHEEL HOUSING UNDER COVER (for Automatic Transaxle)** . Refer to **REMOVAL - Step 3**
- 70. **REMOVE DRIVE PLATE AND TORQUE CONVERTER CLUTCH SETTING BOLT (for Automatic Transaxle)** . Refer to **REMOVAL - Step 4**
- 71. **REMOVE ENGINE ASSEMBLY WITH TRANSAXLE**
 - a. Set the engine lifter.




Fig. 286: Identifying Engine Lifter

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Remove 2 bolts and remove the engine mounting stay RH.




Fig. 287: Locating Bolts And Engine Mounting Stay RH

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- c. Remove the 6 bolts and nut and remove the engine mounting insulator RH.





Fig. 288: Locating Bolts And Engine Mounting Insulator RH
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Be sure not to remove the other bolt A.

- d. Remove the through bolt and nut and separate the transverse engine mounting insulator.




T

Fig. 289: Locating Through Bolt And Nut

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- e. Remove the 6 bolts and remove the engine assembly with transaxle and front suspension crossmember from the vehicle.




T

Fig. 290: Locating Bolts And Front Suspension Crossmember

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

72. REMOVE TRANSVERSE ENGINE MOUNTING INSULATOR

- a. Remove the 5 bolts and remove the transverse engine mounting insulator.



T

Fig. 291: Locating Bolts And Transverse Engine Mounting Insulator
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

73. REMOVE FRONT SUSPENSION CROSSMEMBER SUB-ASSEMBLY

- a. Remove the bolt and remove the air fuel ratio sensor bracket.
- b. Install the engine hangers with the bolts, as shown in the illustration.




Fig. 292: Identifying Engine Hangers With Bolts
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 43 N*m (439 kgf*cm, 32 ft.*lbf)

Part No.

12281-37020 (engine hanger No. 1)

12282-37010 (engine hanger No. 2)

91552-81050 (bolt)

- c. Using an engine sling device and a chain block, suspend the engine assembly with transaxle and front suspension crossmember.
- d. Remove the through bolt from the engine moving control rod and remove the front suspension crossmember.

- 74. **REMOVE ENGINE MOVING CONTROL ROD COVER** . Refer to **REMOVAL - Step 30**
- 75. **REMOVE ENGINE MOVING CONTROL ROD (for Automatic Transaxle)** . Refer to **REMOVAL - Step 31**
- 76. **REMOVE ENGINE MOVING CONTROL ROD (for Manual Transaxle)** . Refer to **REMOVAL - Step 32**
- 77. **REMOVE FLYWHEEL HOUSING SIDE COVER** . Refer to **REMOVAL - Step 4**
- 78. **REMOVE STARTER ASSEMBLY** . Refer to **REMOVAL - Step 5**
- 79. **REMOVE NO. 1 OIL COOLER INLET TUBE (for Automatic Transaxle)** . Refer to **REMOVAL - Step 5**

80. **REMOVE NO. 1 OIL COOLER OUTLET TUBE (for Automatic Transaxle)** . Refer to **REMOVAL - Step 6**
81. **REMOVE NO. 2 OIL COOLER TUBE CLAMP (for Automatic Transaxle)** . Refer to **REMOVAL - Step 7**
82. **REMOVE TRANSMISSION OIL LEVEL GAGE SUB-ASSEMBLY (for Automatic Transaxle)**
83. **SEPARATE TRANSMISSION OIL FILLER TUBE SUB-ASSEMBLY (for Automatic Transaxle)** . Refer to **REMOVAL - Step 8**
84. **REMOVE AUTOMATIC TRANSAXLE ASSEMBLY (for Automatic Transaxle)** . Refer to **REMOVAL - Step 14**
85. **REMOVE NO. 1 TRANSMISSION CONTROL CABLE BRACKET (for Manual Transaxle)**
 - a. Remove the 2 bolts and the control cable bracket.




Fig. 293: Locating Control Cable Bracket

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

86. **REMOVE MANUAL TRANSAXLE ASSEMBLY (for Manual Transaxle)** . Refer to **REMOVAL - Step 7**
87. **REMOVE CLUTCH COVER ASSEMBLY (for Manual Transaxle)** . Refer to **REMOVAL - Step 7**
88. **REMOVE CLUTCH DISC ASSEMBLY (for Manual Transaxle)**
89. **REMOVE DRIVE PLATE AND RING GEAR SUB-ASSEMBLY (for Automatic Transaxle)**
 - a. Hold the crankshaft with SST.




Fig. 294: Holding Crankshaft With SST
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09213-58013
91651-60855
- SST: 09330-00021

b. Remove the 8 bolts and remove the rear spacer, drive plate and front spacer.


**T**

Fig. 295: Locating Bolts And Drive Plate

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

90. REMOVE FLYWHEEL SUB-ASSEMBLY (for Manual Transaxle)

- a. Hold the crankshaft with SST.





Fig. 296: Holding Crankshaft With SST
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09213-58013
91651-60855
- SST: 09330-00021

b. Remove the 8 bolts and remove the flywheel sub-assembly.



T

Fig. 297: Locating Bolts And Flywheel Sub-Assembly
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

INSTALLATION

INSTALLATION

1. **INSTALL DRIVE PLATE AND RING GEAR SUB-ASSEMBLY (for Automatic Transaxle)**
 - a. Using SST, hold the crankshaft.




Fig. 298: Holding Crankshaft With SST
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09213-58013
91651-60855
- SST: 09330-00021


- b. Clean the bolt and the bolt hole.
- c. Apply adhesive to 2 or 3 threads of the bolt end.

Adhesive

Toyota Genuine Adhesive 1324, Three Bond 1324 or equivalent

- d. Install the front spacer, drive plate and rear spacer with the 8 bolts.

Uniformly tighten the 8 bolts.



T

Fig. 299: Locating Bolts And Drive Plate
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 88 N*m (897 kgf*cm, 65 ft.*lbf)

2. **INSTALL AUTOMATIC TRANSAXLE ASSEMBLY (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 3**
3. **INSTALL TRANSMISSION OIL FILLER TUBE SUB-ASSEMBLY (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 9**
4. **INSTALL TRANSMISSION OIL LEVEL GAGE SUB-ASSEMBLY (for Automatic Transaxle)**
5. **INSTALL NO. 1 OIL COOLER OUTLET TUBE (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 12**
6. **INSTALL NO. 1 OIL COOLER INLET TUBE (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 13**
7. **INSTALL NO. 2 OIL COOLER TUBE CLAMP (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 11**
8. **INSTALL FLYWHEEL SUB-ASSEMBLY (for Manual Transaxle)**
 - a. Hold the crankshaft with SST.





Fig. 300: Holding Crankshaft With SST
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09213-58013
91651-60855
 - SST: 09330-00021
- b. Clean the 8 bolts and their holes.
 - c. Apply adhesive to the 2 or 3 end threads of the bolts.



Y
Fig. 301: Applying Bolt Adhesive
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


TEXT IN ILLUSTRATION

*1	Adhesive
----	----------

Adhesive

Toyota Genuine Adhesive 1324, Three Bond 1324 or equivalent.

- d. Install the flywheel with the 8 bolts in the order shown in the illustration.




T

Fig. 302: Locating Flywheel And Bolts

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 49 N*m (500 kgf*cm, 38 ft.*lbf)

- e. Mark paint marks on the upper edge of the bolt heads.



P

Fig. 303: Tightening Flywheel Bolts Additional 90 Degrees
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

TEXT IN ILLUSTRATION

*a Paint Mark

- f. Tighten the bolts 90° in the sequence order shown in the illustration.

NOTE: Do not start the engine for at least 1 hour after performing the installation.

9. **INSTALL CLUTCH DISC ASSEMBLY (for Manual Transaxle)** . Refer to INSTALLATION - Step 1
10. **INSTALL CLUTCH COVER ASSEMBLY (for Manual Transaxle)** . Refer to INSTALLATION - Step 2
11. **INSPECT AND ADJUST CLUTCH COVER ASSEMBLY (for Manual Transaxle)** . Refer to INSTALLATION - Step 3
12. **INSTALL MANUAL TRANSAXLE ASSEMBLY (for Manual Transaxle)** . Refer to INSTALLATION - Step 1
13. **INSTALL NO. 1 TRANSMISSION CONTROL CABLE BRACKET (for Manual Transaxle)**
 - a. Install the control cable bracket with 2 bolts.




Fig. 304: Locating Control Cable Bracket
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 25 N*m (255 kgf*cm, 18 ft.*lbf)

14. **INSTALL STARTER ASSEMBLY** . Refer to INSTALLATION - Step 1
15. **INSTALL FLYWHEEL HOUSING SIDE COVER** . Refer to INSTALLATION - Step 2
16. **INSTALL ENGINE MOVING CONTROL ROD (for Automatic Transaxle)** . Refer to INSTALLATION - Step 2
17. **INSTALL ENGINE MOVING CONTROL ROD (for Manual Transaxle)** . Refer to INSTALLATION - Step 3
18. **INSTALL ENGINE MOVING CONTROL ROD COVER** . Refer to INSTALLATION - Step 4
19. **INSTALL FRONT SUSPENSION CROSSMEMBER SUB-ASSEMBLY**

- a. Install the engine moving control rod with the through bolt.


Torque: 120 N*m (1224 kgf*cm, 89 ft.*lbf)

- b. Remove the 2 bolts and remove the 2 engine hangers.
- c. Install the air fuel ratio sensor bracket with bolt.

Torque: 43 N*m (439 kgf*cm, 32 ft.*lbf)

20. **INSTALL TRANSVERSE ENGINE MOUNTING INSULATOR**

- a. Install the transverse engine mounting insulator with the 5 bolts.



T

Fig. 305: Locating Bolts And Transverse Engine Mounting Insulator
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 52 N*m (530 kgf*cm, 38 ft.*lbf)

21. INSTALL ENGINE ASSEMBLY WITH TRANSAXLE

- a. Set the engine assembly with transaxle and front suspension crossmember on the engine lifter.





Fig. 306: Identifying Engine Lifter

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Operate the engine lifter and lift the engine assembly with transaxle and front suspension crossmember to the position where the engine mounting insulator RH and transverse engine mounting insulator can be installed.
- c. Install the transverse engine mounting insulator with the through bolt and nut.

**P****Fig. 307: Locating Through Bolt And Nut**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 52 N*m (530 kgf*cm, 38 ft.*lbf)

- d. Install the engine mounting insulator RH with the 6 bolts and nut.


**P**

Fig. 308: Identifying Engine Mounting Insulator Bolt Location

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

TEXT IN ILLUSTRATION

*a	Nut C
----	-------

Torque: 88 N*m (897 kgf*cm, 65 ft.*lbf)

for Bolt A


Torque: 45 N*m (459 kgf*cm, 33 ft.*lbf)

for Bolt B

Torque: 52 N*m (530 kgf*cm, 38 ft.*lbf)

for Nut C

- e. Install the engine mounting stay RH with the 2 bolts.

**T****Fig. 309: Locating Bolts And Engine Mounting Stay RH**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 26 N*m (265 kgf*cm, 19 ft.*lbf)

- f. w/o Painted Bolt:
1. Operate the engine lifter and provisionally install the engine assembly with transaxle and

front suspension crossmember onto the vehicle with the 6 bolts.




Fig. 310: Identifying Front Suspension Crossmember And Bolts
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

g. w/ Painted Bolt:

1. Operate the engine lifter and provisionally install the engine assembly with transaxle and front suspension crossmember onto the vehicle with bolt A, bolt C and a new bolt B.

NOTE: If bolt B has orange paint on the bolt head, it is a non-reusable bolt and must be replaced with a new bolts (Part No.: 90119-14151) if they are removed.

- h. Insert SST into the datum holes in the front suspension crossmember RH and LH alternately and tighten bolts A, B and C on both sides in several sequences.



TEXT IN ILLUSTRATION

*1	Bolt A	*2	Bolt B
*3	Bolt C	-	-
*a	Front	*b	Datum Hole
*c	OK	*d	NG

- for Bolt C

© 2011 Mitchell Repair Information Company, LLC.

- 23. **INSTALL FLYWHEEL HOUSING UNDER COVER (for Automatic Transaxle) . Refer to INSTALLATION - Step 15**
- 24. **INSTALL FRONT DRIVE SHAFT ASSEMBLY LH . Refer to INSTALLATION - Step 1**
- 25. **INSTALL FRONT DRIVE SHAFT ASSEMBLY RH . Refer to INSTALLATION - Step 2**
- 26. **INSTALL FRONT AXLE ASSEMBLY LH . Refer to INSTALLATION - Step 3**
- 27. **INSTALL FRONT AXLE ASSEMBLY RH**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

- 28. **INSTALL FRONT LOWER SUSPENSION ARM SUB-ASSEMBLY LH . Refer to INSTALLATION - Step 4**
- 29. **INSTALL FRONT LOWER SUSPENSION ARM SUB-ASSEMBLY RH**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

- 30. **INSTALL FRONT STABILIZER LINK ASSEMBLY LH . Refer to INSTALLATION - Step 6**
- 31. **INSTALL FRONT STABILIZER LINK ASSEMBLY RH**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

- 32. **INSTALL TIE ROD END SUB-ASSEMBLY LH . Refer to INSTALLATION - Step 5**
- 33. **INSTALL TIE ROD END SUB-ASSEMBLY RH**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

- 34. **INSTALL SPEED SENSOR FRONT LH . Refer to INSTALLATION - Step 7**
- 35. **INSTALL SPEED SENSOR FRONT RH**

HINT:

The installation procedure for the RH side is the same as that for the LH side.


- 36. **INSTALL FRONT AXLE SHAFT LH NUT . Refer to INSTALLATION - Step 8**
- 37. **INSTALL FRONT AXLE SHAFT RH NUT**

HINT:

The installation procedure for the RH side is the same as that for the LH side.

38. INSTALL FRONT EXHAUST PIPE ASSEMBLY

- a. Using vernier calipers, measure the free length of the compression spring.



Y

Fig. 312: Measuring Free Length Of Compression Spring
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Minimum length (Front side)

40.5 mm (1.594 in.)

Minimum length (Rear side)

38.5 (1.516 in.)

If the length is not as specified, replace the compression spring.

- b. Using a plastic hammer and a wooden block, tap in a new exhaust pipe gasket until its surface is flush with the exhaust manifold.


**Y**

Fig. 313: Identifying Wooden Block And Gasket
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

TEXT IN ILLUSTRATION

*1	Gasket
*2	Wooden Block


NOTE:

- Install the exhaust pipe gasket in the correct direction.
- Do not damage the outer surface of the exhaust pipe gasket.
- Do not reuse the exhaust pipe gasket.
- Do not push in the gasket with the exhaust pipe when connecting it.

- c. Install the 3 exhaust pipe supports.
- d. Install the exhaust front pipe assembly and a new exhaust pipe gasket with the 4 compression springs and 4 bolts.

Torque: 43 N*m (438 kgf*cm, 32 ft.*lbf)

- e. Pass the sensor connector through the floor panel and install the grommet.
- f. Connect the heated oxygen sensor connector.

**T****Fig. 314: Locating Heated Oxygen Sensor Connector**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

39. **INSTALL FRONT FLOOR BRACE CENTER** . Refer to **INSTALLATION - Step 2**
40. **INSTALL FRONT CONSOLE BOX** . Refer to **INSTALLATION - Step 16**
41. **INSTALL REAR CONSOLE BOX ASSEMBLY** . Refer to **INSTALLATION - Step 3**
42. **INSTALL CONSOLE BOX COVER REAR** . Refer to **INSTALLATION - Step 3**
43. **INSTALL CONSOLE BOX CARPET** . Refer to **INSTALLATION - Step 2**
44. **INSTALL CONSOLE PANEL UPPER** . Refer to **INSTALLATION - Step 4**
45. **INSTALL SHIFT LEVER KNOB SUB-ASSEMBLY (for Manual Transaxle)** . Refer to **INSTALLATION - Step 5**
46. **INSTALL NO. 1 STEERING COLUMN HOLE COVER SUB-ASSEMBLY** . Refer to **INSTALLATION - Step 18**
47. **INSTALL STEERING SLIDING YOKE SUB-ASSEMBLY** . Refer to **INSTALLATION - Step 19**
48. **INSTALL COLUMN HOLE COVER SILENCER SHEET** . Refer to **INSTALLATION - Step 20**
49. **INSTALL CLUTCH RELEASE CYLINDER ASSEMBLY (for Manual Transaxle)**
 - a. Install the clutch release cylinder and clutch pipe with the 4 bolts.




Fig. 315: Locating Clutch Release Cylinder Assembly With Bolts
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 12 N*m (120 kgf*cm, 9 ft.*lbf)


for bolt A

Torque: 12 N*m (122 kgf*cm, 9 ft.*lbf)

for bolt B

50. CONNECT FUEL TUBE SUB-ASSEMBLY

- a. Connect the fuel tube connector and fuel pipe, and install the No. 1 fuel pipe clamp.


**T****Fig. 316: Locating No. 1 Fuel Pipe Clamp**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

WARNING: Align the fuel tube connector with the pipe, then push the fuel tube connector in until the retainer makes a click sound. If the connection is tight, apply a small amount of engine oil to the the tip of the pipe. After connecting, pull the pipe and connector to make sure that they are securely connected.

51. CONNECT HEATER WATER HOSE INLET A


- a. Connect heater water inlet hose A to the heater unit.

**T****Fig. 317: Locating Heater Water Inlet Hose**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

52. CONNECT HEATER WATER OUTLET HOSE A (FROM HEATER UNIT)

- a. Connect heater water outlet hose A to the heater unit.

**T****Fig. 318: Locating Heater Water Outlet Hose**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

53. CONNECT ENGINE WIRE

- a. Connect the 2 engine wire harness connectors and 2 wire harness clamps to the engine room junction block.





Fig. 319: Locating Connectors And Clamp
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Connect the engine wire harness connector to the ECM.




T

Fig. 320: Locating Wire Harness Clamps

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- c. Connect the 2 wire harness clamps.
- d. Connect the 2 connectors.




T

Fig. 321: Locating Connectors

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


- e. Install the transaxle earth wire with the bolt and 2 wire harness clamps (for Manual Transaxle).



T
Fig. 322: Locating Bolt And Wire Harness Clamp
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 26 N*m (260 kgf*cm, 19 ft.*lbf)

- f. Install the transaxle earth wire with the bolt and wire harness clamp (for Automatic Transaxle).




T
Fig. 323: Locating Bolt And Wire Harness Clamp
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 8.4 N*m (85 kgf*cm, 74 in.*lbf)

54. INSTALL NO. 1 FUEL VAPOR FEED HOSE


- a. Install the No. 1 fuel vapor feed hose into the vacuum switching valve assembly.

**T****Fig. 324: Locating No. 1 Fuel Vapor Feed Hose**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


55. INSTALL UNION TO CHECK VALVE HOSE

- a. Install the union to check valve hose with the clip.

**T****Fig. 325: Locating Clip And Check Valve Hose**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

56. INSTALL TRANSMISSION CONTROL CABLE ASSEMBLY (for Automatic Transaxle)



P

Fig. 326: Identifying Transmission Control Cable Assembly Nut
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- a. Install the transmission control cable assembly onto the control shaft lever with the nut.

TEXT IN ILLUSTRATION

*1	Control Cable Bracket
*a	Marking

Torque: 12 N*m (122 kgf*cm, 9 ft.*lbf)

- b. Fix the transmission control cable assembly onto the control cable bracket with a new clip.

NOTE: Make sure that the marking on the cable is aligned with the slit in the transmission control cable bracket before installing the cable.

57. INSTALL TRANSMISSION CONTROL CABLE ASSEMBLY (for Manual Transaxle)




Fig. 327: Locating Control Cable Bracket

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- a. Install the control cable assembly onto the control cable bracket with 2 new clips.
- b. Connect the control cable assembly and install the 2 washers and 2 clips.
- c. Install the control cable assembly onto the shift lever retainer.


**Y**

Fig. 328: Removing/Installing Control Cable Assembly On Shift Lever Retainer
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

TEXT IN ILLUSTRATION

*a	Projecting Part
*b	Lock

NOTE:

- Install the cable with the protruding portion of the cable outer facing upward.
- After installing, check that the lock of the cable outer is protruding beyond portion A, as shown in the illustration.

58. **INSTALL WITH PULLEY COMPRESSOR ASSEMBLY** . Refer to INSTALLATION - Step 2

59. **INSTALL RADIATOR ASSEMBLY** . Refer to INSTALLATION - Step 6

- 60. **INSTALL UPPER RADIATOR SUPPORT SUB-ASSEMBLY** . Refer to **INSTALLATION - Step 7**
- 61. **INSTALL UPPER RADIATOR SUPPORT ABSORBER** . Refer to **REASSEMBLY - Step 14**
- 62. **INSTALL NO. 1 COOLER COVER** . Refer to **INSTALLATION - Step 8**
- 63. **INSTALL HOOD LOCK ASSEMBLY** . Refer to **INSTALLATION - Step 9**
- 64. **CONNECT NO. 2 OIL COOLER INLET HOSE (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 12**
- 65. **CONNECT NO. 1 OIL COOLER OUTLET HOSE (for Automatic Transaxle)** . Refer to **INSTALLATION - Step 11**
- 66. **CONNECT NO. 1 RADIATOR HOSE** . Refer to **INSTALLATION - Step 13**
- 67. **INSTALL NO. 2 RADIATOR HOSE**
 - a. Install the No. 2 radiator hose with the 2 clips.



**T**

Fig. 329: Locating Clips And No. 2 Radiator Hose

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

68. **INSTALL FRONT BUMPER COVER** . Refer to **INSTALLATION - Step 1**
69. **INSTALL FAN & GENERATOR V BELT** See step 1

- 70. **ADJUST FAN & GENERATOR V BELT** See step 2
- 71. **INSPECT FAN & GENERATOR V BELT** See step 3
- 72. **INSTALL NO. 2 CYLINDER HEAD COVER** . Refer to **INSTALLATION - Step 3**
- 73. **INSTALL BATTERY CARRIER**


**T**

Fig. 330: Locating Bolts And Battery Carrier
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- a. Install the battery carrier with the 5 bolts.

Torque: 17 N*m (173 kgf*cm, 13 ft.*lbf)

- b. Install the clamp.

- 74. **INSTALL AIR CLEANER BRACKET**




Fig. 331: Locating Air Cleaner Bracket


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- a. Install the air cleaner bracket with the 2 bolts.

Torque: 19 N*m (194 kgf*cm, 14 ft.*lbf)

- b. Connect the wire harness clamp to the air cleaner bracket.

75. INSTALL AIR CLEANER ASSEMBLY

**T****Fig. 332: Locating Air Cleaner Hose Clamp****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

- a. Install the air cleaner case with air cleaner inlet with the 2 bolts.

Torque: 7.8 N*m (80 kgf*cm, 69 in.*lbf)

- b. Connect the wire harness to the air cleaner case.
- c. Install the air cleaner element.
- d. Install and lock the air cleaner cap with air cleaner hose and then tighten the air cleaner hose clamp.

**T****Fig. 333: Locating Clamps**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 3.0 N*m (31 kgf*cm, 27 in.*lbf)

- e. Connect the ventilation hose to the air cleaner hose.
- f. Connect the intake air flow meter connector and 2 wire harness clamps.

76. INSTALL OUTER COWL TOP PANEL


**T**

Fig. 334: Locating Bolts And Outer Cowl Top Panel
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- a. Install the outer cowl top panel with the 9 bolts.

Torque: 6.5 N*m (66 kgf*cm, 58 in.*lbf)

- b. Connect the wire harness clamp.



Fig. 335: Locating Wire Harness Clamp

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

77. INSTALL FRONT AIR SHUTTER SEAL RH




Fig. 336: Identifying Claws Locations

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- a. Engage the 2 claws to install the front air shutter seal RH.

- 78. **INSTALL FRONT WIPER MOTOR AND LINK** . Refer to **INSTALLATION - Step 2**
- 79. **INSTALL COWL TOP VENTILATOR LOUVER LH** . Refer to **INSTALLATION - Step 3**
- 80. **INSTALL COWL TOP VENTILATOR LOUVER SUB-ASSEMBLY** . Refer to **INSTALLATION - Step 4**
- 81. **INSTALL HOOD TO COWL TOP SEAL** . Refer to **INSTALLATION - Step 5**
- 82. **INSTALL FRONT WIPER ARM AND BLADE ASSEMBLY LH** . Refer to **INSTALLATION - Step 6**
- 83. **INSTALL FRONT WIPER ARM AND BLADE ASSEMBLY RH** . Refer to **INSTALLATION - Step 7**
- 84. **INSTALL FRONT WIPER ARM HEAD CAP** . Refer to **INSTALLATION - Step 8**
- 85. **INSTALL BATTERY TRAY**
- 86. **INSTALL BATTERY**

- a. Install the battery onto the vehicle with the battery clamp.

Torque: 3.5 N*m (36 kgf*cm, 31 in.*lbf)

- b. Connect the cable to the battery terminal.

Torque: 5.4 N*m (55 kgf*cm, 48 in.*lbf)

- 87. **ADD ENGINE COOLANT** . Refer to **REPLACEMENT - Step 2**
- 88. **ADD AUTOMATIC TRANSAXLE OIL (for Automatic Transaxle)**
- 89. **INSPECT AUTOMATIC TRANSAXLE OIL (for Automatic Transaxle)** . Refer to **ON-VEHICLE INSPECTION - Step 1**
- 90. **ADD MANUAL TRANSAXLE OIL (for Manual Transaxle)**
- 91. **INSPECT MANUAL TRANSAXLE OIL (for Manual Transaxle)** . Refer to **ON-VEHICLE INSPECTION - Step 1**
- 92. **INSPECT FOR FUEL LEAK**
- 93. **INSPECT FOR ENGINE OIL LEAK**
- 94. **INSPECT FOR EXHAUST GAS LEAK**
- 95. **INSPECT FOR ENGINE COOLANT LEAK** . Refer to **ON-VEHICLE INSPECTION - Step 1**
- 96. **INSTALL ENGINE UNDER COVER RH**
- 97. **INSTALL ENGINE UNDER COVER LH**
- 98. **INSTALL FRONT WHEELS**

Torque: 103 N*m (1, 050 kgf*cm, 76 ft.*lbf)

- 99. **INSPECT IGNITION TIMING** See step 6
- 100. **INSPECT ENGINE IDLING SPEED** See step 7
- 101. **INSPECT CO/HC** See step 9


102. INSPECT FRONT WHEEL ALIGNMENT

Refer to **ADJUSTMENT**

103. CHECK VSC SENSOR SIGNAL

Refer to **TEST MODE PROCEDURE**

ENGINE UNIT**COMPONENTS****ILLUSTRATION**




N*m (kgf*cm, ft*lb): Specified torque ● Non-reusable part

Y

Fig. 337: Identifying Engine Unit Replacement Components With Torque Specifications (1 Of 9)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION




N*m (kgf*cm, ft*lb) : Specified torque

Y

Fig. 338: Identifying Engine Unit Replacement Components With Torque Specifications (2 of 9)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION




N*m (kgf*cm, ft*lbf) : Specified torque

Y

Fig. 339: Identifying Cylinder Head Gasket Components And Torque Specifications (13 Of 18)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



N*m (kgf*cm, ft*lb) : Specified torque

● Non-reusable part

Y

Fig. 340: Identifying Engine Unit Replacement Components With Torque Specifications (4 Of 9)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION





Fig. 341: Identifying Engine Unit Replacement Components With Torque Specifications(5 Of 9)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


ILLUSTRATION



T

Fig. 342: Identifying Engine Unit Replacement Components With Torque Specifications (6 of 9)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION




[N*m (kgf*cm, ft.*lbf)] : Specified torque

● Non-reusable part

T

Fig. 343: Identifying Engine Unit Replacement Components With Torque Specifications(7 Of 9)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


ILLUSTRATION



T

Fig. 344: Identifying Engine Unit Replacement Components With Torque Specifications(8 Of 9)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

ILLUSTRATION



T

Fig. 345: Identifying Engine Unit Replacement Components With Torque Specifications(9 Of 9)
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

REMOVAL

REMOVAL**1. REMOVE IGNITION COIL ASSEMBLY**

- a. Disconnect the 4 ignition coil assembly connectors.





Fig. 346: Locating Bolts And Ignition Coil Assemblies
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Remove the 4 bolts and remove the 4 ignition coil assemblies.

2. REMOVE RADIO SETTING CONDENSER

- a. Disconnect the radio setting condenser connector.



P
Fig. 347: Locating Radio Setting Condenser Connector
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Remove the bolt and remove the radio setting condenser.
- 3. **REMOVE ENGINE WIRE**
- 4. **REMOVE NO. 2 VENTILATION HOSE**
 - a. Remove the No. 2 ventilation hose.




Fig. 348: Locating No. 2 Ventilation Hose
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

5. REMOVE HEATER WATER OUTLET HOSE A (FROM HEATER UNIT)

- a. Loosen the clip and remove heater water outlet hose A.




Fig. 349: Locating Clip And Heater Water Outlet Hose A

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

6. REMOVE HEATER WATER HOSE INLET A

- a. Loosen the clip and remove heater water inlet hose A.





Fig. 350: Locating Clip And Heater Water Inlet Hose A
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

7. REMOVE NO. 1 RADIATOR HOSE


- a. Loosen the clip and remove the No. 1 radiator hose.

**P****Fig. 351: Locating Clip And No. 1 Radiator Hose**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

8. REMOVE INTAKE MANIFOLD

- a. Loosen the 2 clips and separate the 2 water by-pass hoses.

**P****Fig. 352: Locating Clips And Water By-Pass Hoses**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Separate the No. 1 fuel vapor feed hose from the throttle body.
- c. Loosen the clip and separate the No. 1 vacuum transmitting hose.
- d. Separate the ventilation hose.




Fig. 353: Locating Wire Harness Clamp

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- e. Separate the wire harness clamp from the intake manifold.
- f. Remove the 4 bolt and 2 nuts and remove the intake manifold and manifold stay.




Fig. 354: Locating Bolt And Nuts And Intake Manifold And Manifold Stay
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

g. Remove the gasket from the intake manifold.

9. REMOVE FUEL DELIVERY PIPE SUB-ASSEMBLY

a. Remove the 3 bolts and remove the fuel delivery pipe with the 4 fuel injectors.





Fig. 355: Locating Bolts And Fuel Delivery Pipe

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Do not drop the fuel injectors when removing the fuel delivery pipe.

10. **REMOVE NO. 1 DELIVERY PIPE SPACER** . Refer to **REMOVAL - Step 11**
11. **REMOVE INJECTOR VIBRATION INSULATOR** . Refer to **REMOVAL - Step 12**
12. **REMOVE FUEL INJECTOR ASSEMBLY** . Refer to **REMOVAL - Step 13**
13. **REMOVE GENERATOR ASSEMBLY** . Refer to **REMOVAL - Step 7**
14. **REMOVE FAN BELT ADJUSTING BAR**
 - a. Remove the bolt and remove the fan belt adjusting bar.

**Fig. 356: Locating Bolt And Fan Belt Adjusting Bar**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

15. **REMOVE VENTILATION HOSE**
 - a. Remove the ventilation hose.




Fig. 357: Locating Ventilation Hose

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

16. REMOVE OIL LEVEL DIPSTICK

17. REMOVE OIL LEVEL GAGE GUIDE

- a. Remove the bolt and remove the oil level gage guide.





Fig. 358: Locating Bolt And Oil Level Gage Guide
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

18. REMOVE WATER BY-PASS HOSE

- a. Loosen the clip and remove the water by-pass hose.



P

Fig. 359: Locating Clip And Water By-Pass Hose
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

19. REMOVE WATER INLET HOSE

- a. Loosen the 2 clips and remove the water inlet hose.




Fig. 360: Locating Clips And Water Inlet Hose

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

20. REMOVE NO. 1 WATER BY-PASS PIPE





Fig. 361: Locating Bolts And Water By-Pass Pipe

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- a. Loosen the clip and disconnect the No. 3 water by-pass hose.
- b. Remove the 2 bolts and remove the water by-pass pipe.

21. REMOVE AIR TUBE ASSEMBLY

- a. Remove the 2 bolts and remove the air tube assembly.



P

Fig. 362: Locating Bolts And Air Tube Assembly

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

22. REMOVE NO. 1 EXHAUST MANIFOLD HEAT INSULATOR

- a. Remove the 4 bolts and remove the No. 1 exhaust manifold heat insulator.


**P**

Fig. 363: Locating Bolts And No. 1 Exhaust Manifold Heat Insulator
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

23. REMOVE MANIFOLD STAY

- a. Remove the 3 bolts and remove the manifold stay.


**P**

Fig. 364: Locating Bolts And Manifold Stay

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

24. REMOVE EXHAUST MANIFOLD

- a. Remove the 5 nuts and remove the exhaust manifold.






Fig. 365: Locating Exhaust Manifold Nuts

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

25. REMOVE WIRE HARNESS CLAMP BRACKET

- a. Remove the 4 bolts and remove the 4 wire harness clamp brackets.



P

Fig. 366: Locating Bolts And Wire Harness Clamp Brackets
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

DISASSEMBLY

DISASSEMBLY**1. REMOVE ENGINE HANGER**

- a. Remove the 2 bolts and 2 engine hangers.




**T**

Fig. 367: Locating Bolts And Engine Hangers

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

2. REMOVE OIL FILLER CAP SUB-ASSEMBLY


- a. Remove the oil filler cap.

**Fig. 368: Locating Oil Filler Cap**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

3. REMOVE OIL FILLER CAP GASKET


- a. Remove the oil filler cap gasket.

**T****Fig. 369: Locating Oil Filler Cap Gasket**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

4. REMOVE SPARK PLUG

- a. Using a 14 mm socket wrench, remove the 4 spark plugs.

**T****Fig. 370: Installing Spark Plugs**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

5. REMOVE CAMSHAFT POSITION SENSOR

- a. Remove the 2 bolts and 2 sensors.




Fig. 371: Locating Bolts And Sensors

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

6. REMOVE CAMSHAFT TIMING OIL CONTROL VALVE ASSEMBLY

- a. Remove the 2 bolts, 2 O-rings, bracket and 2 oil control valves.




Fig. 372: Locating Bolts, O-Rings, Bracket And Oil Control Valves
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

7. REMOVE CYLINDER HEAD COVER SUB-ASSEMBLY

- a. Remove the 13 bolts, seal washer and cylinder head cover.





Fig. 373: Locating Bolts, Seal Washer And Cylinder Head Cover

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Remove the 3 gaskets from the camshaft bearing cap.



T

Fig. 374: Locating Gaskets

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: When removing the cylinder head cover, some of the gaskets may stick to it so be careful not to drop any of the gaskets into the engine.

8. REMOVE CYLINDER HEAD COVER GASKET

- a. Remove the cylinder head cover gasket.




**T**

Fig. 375: Identifying Cylinder Head Cover Gasket

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

9. SET NO. 1 CYLINDER TO TDC / COMPRESSION

- a. Turn the crankshaft pulley, and align its timing notch with the "0" timing mark on the timing chain cover sub-assembly.



T

Fig. 376: Identifying Timing Marks On Camshaft Timing Exhaust Gear And Camshaft Timing Gear

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Check that timing marks on both the camshaft timing exhaust gear and camshaft timing gear are

facing upward, as shown in the illustration.

HINT:

If not, turn the crankshaft 1 complete revolution (360°) and align the marks as above.

10. REMOVE CRANKSHAFT PULLEY

- a. Using SST, hold the pulley in place and loosen the pulley bolt.




Fig. 377: Loosening Pulley Bolt
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09213-58013
91651-60855
- SST: 09330-00021

- b. Using SST, remove the pulley bolt and pulley.




Fig. 378: Removing Pulley Bolt And Pulley
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09950-50013
09951-05010
09952-05010
09953-05020
09954-05021

11. REMOVE NO. 1 CHAIN TENSIONER ASSEMBLY

- a. Remove the 2 nuts, bracket, No. 1 chain tensioner assembly and gasket.




Fig. 379: Locating No. 1 Chain Tensioner Assembly And Bolt
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Do not turn the crankshaft after you have removed the chain tensioner.

12. REMOVE CRANKSHAFT POSITION SENSOR

- Remove the bolt and crankshaft position sensor.




Fig. 380: Locating Bolt And Crankshaft Position Sensor
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

13. REMOVE ENGINE OIL PRESSURE SWITCH ASSEMBLY

- Using a 24 mm deep socket wrench, remove the engine oil pressure switch assembly.




Fig. 381: Locating Engine Oil Pressure Switch Assembly
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

14. REMOVE NO. 1 TAPER SCREW PLUG

- a. Remove the No. 1 taper screw plug.




Fig. 382: Locating No. 1 Taper Screw Plug

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

15. REMOVE KNOCK SENSOR

- a. Remove the bolt and knock sensor.




Fig. 383: Locating Bolt And Knock Sensor

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

16. REMOVE ENGINE WATER TEMPERATURE SENSOR

- a. Using a 19 mm deep socket wrench, remove the engine water temperature sensor.




Fig. 384: Identifying Engine Coolant Temperature Sensor
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Remove the gasket from the engine water temperature sensor.

17. REMOVE OIL FILTER SUB-ASSEMBLY

- a. Using SST, remove the oil filter cap.




Fig. 385: Removing Oil Filter Cap Using SST


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09228-06501

HINT:

Use a container to catch the draining oil. After the oil filter cap is loosened approximately 4 turns and the cap rib is facing straight down, engine oil will begin to drain from the gap between the oil filter cap and oil pan.

- Remove the oil filter element and O-ring from the oil filter cap.

**T****Fig. 386: Identifying Oil Filter Element And O-Ring**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Be sure to remove the O-ring (for the cap) by hand, without using any tools, to prevent damage to the O-ring groove on the cap.

18. REMOVE WATER INLET

- Remove the 2 nuts and remove the water inlet.


**T**

Fig. 387: Locating Nuts And Water Inlet
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

19. REMOVE THERMOSTAT

- Remove the thermostat from the cylinder block.


**T**

Fig. 388: Locating Gasket

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Remove the gasket from the thermostat.

20. **REMOVE TIMING CHAIN OR BELT COVER SUB-ASSEMBLY**

- a. Remove the 3 bolts and remove the engine mounting bracket RH.




Fig. 389: Locating Bolts And Engine Mounting Bracket RH
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Remove the 4 bolts and remove the oil filter bracket.





Fig. 390: Locating Bolts And Oil Filter Bracket
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- c. Remove the 2 O-rings from the timing chain cover sub-assembly.




T

Fig. 391: Locating O-Rings

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


- d. Remove the 19 bolts.

**T****Fig. 392: Locating Bolts**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- e. Remove the timing chain or belt cover sub-assembly by prying between the timing chain or belt cover sub-assembly and cylinder head or cylinder block with a screwdriver wrapped in protective

tape.




T

Fig. 393: Prying Timing Chain Or Belt Cover Sub-Assembly
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Be careful not to damage the contact surfaces of the timing chain or belt cover sub-assembly, cylinder block and cylinder head.

- f. Remove the 3 O-rings from the cylinder head and cylinder block.



T

Fig. 394: Locating O-Rings

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- g. Remove the 3 bolts and the engine water pump assembly.


**T**

Fig. 395: Locating Bolts And Water Pump Assembly
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- h. Remove the gasket from the timing chain or belt cover sub-assembly.


**T**

Fig. 396: Identifying Gasket
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

21. REMOVE WATER INLET HOUSING

- a. Remove the 3 bolts, gasket and water inlet housing.



**T**

Fig. 397: Locating Bolts, Gasket And Water Inlet Housing
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

22. REMOVE NO. 1 GENERATOR BRACKET


- a. Remove the 4 bolts and generator bracket.

**T****Fig. 398: Locating Bolts And Generator Bracket**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

23. REMOVE NO. 2 CHAIN VIBRATION DAMPER


- a. Remove the 2 bolts and remove the No. 2 chain vibration damper.

**T****Fig. 399: Locating Bolts And No. 2 Chain Vibration Damper**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

24. REMOVE CHAIN TENSIONER SLIPPER

- a. Remove the chain tensioner slipper from the cylinder block.



T

Fig. 400: Identifying Chain Tensioner Slipper

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

25. REMOVE NO. 1 CHAIN VIBRATION DAMPER

- a. Remove the 2 bolts and the chain vibration damper.


**T**

Fig. 401: Locating Bolts And Chain Vibration Damper
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

26. REMOVE CHAIN SUB-ASSEMBLY

- a. Hold the hexagonal portion of the camshaft with a wrench and turn the camshaft timing gear assembly counterclockwise to loosen the chain on the camshaft timing gears.




Fig. 402: Holding Hexagonal Portion Of Camshaft With Wrench
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. With the chain loosened, release the chain from the camshaft timing gear assembly and rest it on the camshaft timing gear assembly.

HINT:

Be sure to release the chain from the sprocket completely.

- c. Turn the camshaft clockwise to return it to the original position and remove the chain.

27. REMOVE CRANKSHAFT TIMING GEAR OR SPROCKET

- a. Remove the crankshaft timing gear or sprocket.


**T**

Fig. 403: Locating Crankshaft Timing Gear Or Sprocket
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

28. REMOVE NO. 2 CHAIN SUB-ASSEMBLY

- a. Turn the crankshaft 90° clockwise to align the adjusting hole of the oil pump drive shaft gear with the groove of the oil pump.


**T**

Fig. 404: Turning Crankshaft 90Degrees Clockwise
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Insert a 4 mm diameter bar into the adjusting hole of the oil pump drive shaft gear to lock the gear in position, and then remove the nut.


**T**

Fig. 405: Identifying Bar Into Adjusting Hole Of Oil Pump Drive Shaft Gear
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- c. Remove the bolt, chain tensioner plate and spring.


**T**

Fig. 406: Identifying Bolt, Chain Tensioner Plate And Spring
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- d. Remove the oil pump drive shaft gear, oil pump drive gear and chain.





Fig. 407: Identifying Crankshaft Timing Sprocket, Oil Pump Drive Shaft Gear And No. 2 Chain Sub-Assembly

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

29. REMOVE NO. 1 CRANKSHAFT POSITION SENSOR PLATE

- a. Remove the No. 1 crankshaft position sensor plate.



T

Fig. 408: Identifying No. 1 Crankshaft Position Sensor Plate
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

30. REMOVE CRANKSHAFT TIMING GEAR KEY

- a. Using a screwdriver, remove the 2 crankshaft timing gear keys.




Fig. 409: Removing Crankshaft Timing Gear Keys
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Tape the screwdriver tip before use.


31. REMOVE CAMSHAFT TIMING GEAR ASSEMBLY

- a. Check the lock of the camshaft timing gear.
- b. Release the lock pin.

NOTE: Before removing the camshaft timing gear assembly, make sure that the lock pin has been released.

1. After cleaning and degreasing the VVT oil hole on the intake side of the No. 1 camshaft bearing cap, completely seal the oil hole with adhesive tape or equivalent as shown in the illustration to prevent air from leaking.

Adhesive Tape Sealing Area



C

Fig. 410: Identifying Adhesive Tape Sealing Area

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Be sure to cover the oil hole completely because air leaks due to insufficient sealing will prevent the lock pin from being released.

2. Prick a hole in the tape covering the oil hole as shown in the illustration. (Procedure A)
3. Apply approximately 150 kPa (1.5 kgf/cm², 22 psi) of air pressure to the hole pricked in procedure A to release the lock pin.




Fig. 411: Applying Air Pressure To Hole


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:

- If air leaks out, reattach the adhesive tape.
- Cover the oil hole with a shop rag or piece of cloth when applying air pressure to prevent oil from spraying.
- Do not lock the camshaft timing gear assembly. If it is locked, release the lock pin again.

HINT:

- The camshaft timing gear assembly may be turned in the advance direction without applying any force.
 - If enough air pressure cannot be applied because of air leakage from the port, releasing the lock pin may be difficult.
4. Remove the adhesive tape from the No. 1 camshaft bearing cap.
- c. Remove the flange bolt while holding the hexagonal portion of the camshaft, and then remove the camshaft timing gear assembly.

**T****Fig. 412: Identifying Flange Bolt**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:

- Before removing the camshaft timing gear, make sure that the lock pin has been released.
- Be sure not to remove the other 4 bolts.
- Keep the camshaft timing gear assembly horizontal while removing it from the camshaft.

32. REMOVE CAMSHAFT TIMING EXHAUST GEAR ASSEMBLY

- a. Remove the flange bolt while holding the hexagonal portion of the camshaft, and then remove the camshaft timing exhaust gear assembly.




Fig. 413: Identifying Flange Bolt


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:

- Be sure not to remove the other 4 bolts.
- Keep the camshaft timing exhaust gear assembly horizontal while removing it from the camshaft.

33. REMOVE CAMSHAFT BEARING CAP

- a. Uniformly loosen and remove the 10 bearing cap bolts in the sequence shown in the illustration.




T

Fig. 414: Identifying Bearing Cap Bolts And Loosening Sequence

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Uniformly loosen and remove the 15 bearing cap bolts in the sequence shown in the illustration.

**Fig. 415: Identifying Bearing Cap Bolts And Loosening Sequence**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Uniformly loosen the bolts while keeping the camshaft level.

- c. Remove the 5 bearing caps.


HINT:

Arrange the removed parts in the correct order.

- d. Remove the camshaft and No. 2 camshaft.

34. REMOVE CAMSHAFT

- a. Remove the camshaft.




T

Fig. 416: Identifying Camshaft

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

35. REMOVE NO. 2 CAMSHAFT


- a. Remove the No. 2 camshaft.

**T****Fig. 417: Identifying No. 2 Camshaft**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

36. REMOVE NO. 1 VALVE ROCKER ARM SUB-ASSEMBLY

- a. Remove the 16 valve rocker arms.

**T****-A10****Fig. 418: Identifying Valve Rocker Arms**


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Arrange the removed parts in the correct order.

37. REMOVE VALVE LASH ADJUSTER ASSEMBLY

- a. Remove the 16 valve lash adjusters from the cylinder head.



T

Fig. 419: Identifying Valve Lash Adjusters


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Arrange the removed parts in the correct order.

38. REMOVE OIL CONTROL VALVE FILTER


- a. Remove the oil control valve filter.

**T****Fig. 420: Removing Oil Control Valve Filter**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

39. REMOVE NO. 1 CAMSHAFT BEARING

- a. Remove the 2 No. 1 camshaft bearings.

**T****Fig. 421: Identifying No. 1 Camshaft Bearings**


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Arrange the removed parts in the correct order.

40. REMOVE NO. 2 CAMSHAFT BEARING

- a. Remove the 2 No. 2 camshaft bearings.



T

Fig. 422: Identifying No. 2 Camshaft Bearings


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Arrange the removed parts in the correct order.

41. REMOVE CAMSHAFT HOUSING SUB-ASSEMBLY

- a. Remove the 2 bolts.

**T****Fig. 423: Locating Bolts****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

- b. Remove the camshaft housing by prying between the cylinder head and camshaft housing with a screwdriver.




Fig. 424: Removing Camshaft Housing By Prying
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Be careful not to damage the contact surfaces of the cylinder head and camshaft housing.

HINT:

Tape the screwdriver tip before use.


42. REMOVE CYLINDER HEAD SUB-ASSEMBLY**T**

Fig. 425: Locating Cylinder Head Bolts And Loosening Sequence

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- a. Using several steps, loosen and remove the 10 cylinder head bolts uniformly with a 10 mm bi-hexagon wrench in the sequence shown in the illustration.

Remove the 10 cylinder head bolts and the plate washers.

NOTE:

- Do not drop the washers into the cylinder head.
- Head warpage or cracking could result from removing bolts in the wrong order.

- b. Remove the cylinder head sub-assembly.

43. REMOVE CYLINDER HEAD GASKET**44. REMOVE CYLINDER BLOCK WATER DRAIN COCK SUB-ASSEMBLY**

- a. Remove the water drain cock plug from the water drain cock assembly.




Fig. 426: Locating Water Drain Cock Plug
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Remove the water drain cock assembly from the cylinder block.
45. **REMOVE VENTILATION VALVE SUB-ASSEMBLY**
- a. Remove the ventilation valve.




Fig. 427: Locating Ventilation Valve

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

46. REMOVE OIL PAN DRAIN PLUG

- a. Remove the oil pan drain plug and gasket.




Fig. 428: Locating Oil Pan Drain Plug

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

47. REMOVE NO. 2 OIL PAN SUB-ASSEMBLY

- a. Remove the 10 bolts and 2 nuts.




Fig. 429: Locating Bolts And Nuts

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Install the blade of oil pan seal cutter between the No. 2 oil pan sub-assembly and stiffening crankcase assembly, and cut off the applied sealer and remove the No. 2 oil pan sub-assembly.




Fig. 430: Inserting Blade Of Oil Pan Seal Cutter Between Oil Pans

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Do not damage the No. 2 oil pan sub-assembly or stiffening

crankcase assembly.**48. REMOVE OIL PUMP ASSEMBLY**

- a. Remove the 3 bolts and remove the oil pump assembly.



**T**

Fig. 431: Locating Bolts And Oil Pump Assembly
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

49. REMOVE STIFFENING CRANKCASE ASSEMBLY

- a. Remove the 11 bolts.

**Fig. 432: Locating Bolts**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Using a screwdriver with its tip wrapped in protective tape, remove the crankcase by prying between the crankcase and cylinder block.


**T**

Fig. 433: Prying Between Crankcase And Cylinder Block
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Be careful not to damage the contact surfaces of the crankcase and cylinder block.

INSPECTION**INSPECTION****1. INSPECT NO. 1 VALVE ROCKER ARM SUB-ASSEMBLY**

- a. Turn the roller by hand to check that it turns smoothly.


**T**

Fig. 434: Turning Roller By Hand For Checking Smoothly Turns
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

If the roller does not turn smoothly, replace the valve rocker arm sub-assembly.

2. INSPECT VALVE LASH ADJUSTER ASSEMBLY**NOTE:**

- Keep the lash adjuster free of dirt and foreign objects.
- Only use clean engine oil.

- a. Place the lash adjuster into a container filled with engine oil.
- b. Insert the SST's tip into the lash adjuster's plunger and use the tip to press down on the check ball inside the plunger.


**T**

Fig. 435: Checking Movement Of Plunger And Bleed Air
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09276-75010

- c. Squeeze the SST and lash adjuster together to move the plunger up and down 5 to 6 times.
- d. Check the movement of the plunger and bleed it.

OK

Plunger moves up and down.

NOTE: **When bleeding the high-pressure chamber, make sure that the tip of the SST is actually pressing the check ball as shown in the illustration. If the check ball is not pressed, the high-pressure chamber will not be bled.**

- e. After bleeding, remove the SST. Then try to quickly and firmly press the plunger with a finger.


OK

Plunger is very difficult to move.

If the result is not as specified, replace the lash adjuster.

3. INSPECT CAMSHAFT TIMING GEAR ASSEMBLY

- a. Install the camshaft timing gear. Refer to **REASSEMBLY**.
- b. Check the lock of the camshaft timing gear.
 - 1. Confirm that the camshaft timing gear is locked.
- c. Release the lock pin.

**T****Fig. 436: Locating Retard Side Path**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

1. Cover the 4 oil paths of the cam journal with vinyl tape as shown in the illustration.

HINT:

There are 4 oil paths in the groove of the camshaft. Plug three of the paths with pieces of rubber.

2. Prick a hole in the tape placed on the advance side path. Prick a hole in the tape placed on the retard side path, on the opposite side to that of the advance side path, as shown in the illustration.
3. While applying approximately 150 kPa (2.0 kgf/cm², 22 psi) of air pressure to the oil paths, forcibly turn the camshaft timing gear assembly in the advance direction (counterclockwise).




Fig. 437: Applying Air Pressure To Oil Paths
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

WARNING: Cover the paths with a piece of cloth when applying pressure to keep oil from splashing.

NOTE: Do not lock the camshaft timing gear assembly. If it is locked, release the lock pin again.


HINT:

- The camshaft timing gear assembly may be turned in the advance direction without applying any force.
 - If enough air pressure cannot be applied because of air leakage from the port, releasing the lock pin may be difficult.
- d. Check for smooth rotation.
1. Turn the camshaft timing gear within its movable range (26.5 to 28.5°) 2 or 3 times, but do not turn it to the most retarded position. Make sure that the gear turns smoothly.

NOTE: Do not lock the camshaft timing gear assembly. If it is locked, release the lock pin again.

4. INSPECT CAMSHAFT TIMING EXHAUST GEAR ASSEMBLY

- a. Install the camshaft timing gear. Refer to **REASSEMBLY**.
- b. Check the camshaft timing exhaust gear lock.
 1. Make sure that the camshaft timing exhaust gear is locked.
- c. Release the lock pin.



T

Fig. 438: Identifying Retard And Advance Side Path
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

1. Cover the 4 oil paths of the cam journal with vinyl tape as shown in the illustration.

HINT:

4 oil paths are provided in the groove. Plug 2 paths with rubber pieces.

2. Prick a hole in the tape placed on the advance side path. Prick a hole in the tape placed on the retard side path, on the opposite side to that of the advance side path, as shown in the illustration.
3. Apply approximately 200 kPa (2.0 kgf/cm², 28 psi) of air pressure to the 2 broken paths (the advance side path and the retard side path).



**T**

Fig. 439: Applying Air Pressure To Broken Paths
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

WARNING: Cover the paths with a piece of cloth when applying pressure to keep oil from splashing.

4. Make sure that the camshaft timing exhaust gear turns in the retard direction when reducing the air pressure applied to the advance side path.

**T****Fig. 440: Applying Air Pressure To Broken Paths**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

The lock pin is released and the camshaft timing exhaust gear turns in the retard direction.

5. When the camshaft timing exhaust gear moves to the most retarded position, release the air pressure from the advance side path, and then release the air pressure from the retard side path.

NOTE: Be sure to release the air pressure from the advance side path first. If the air pressure of the retard side path is released first, the camshaft timing exhaust gear may abruptly shift in the advance direction and break the lock pin or other parts.

- d. Check for smooth rotation.

1. Turn the camshaft timing exhaust gear within its movable range (19 to 21°) 2 or 3 times, but do not turn it to the most advanced position. Make sure that the gear turns smoothly.

NOTE: When the air pressure is released from the advance side path and then from the retard side path, the gear automatically returns to the most advanced position due to the advance assist spring operation and locks. Gradually release the air pressure from the retard side path before performing the smooth rotation check.

e. Check the lock at the most advanced position.

1. Make sure that the camshaft timing exhaust gear is locked at the most advanced position.

5. INSPECT CHAIN SUB-ASSEMBLY

a. Pull the chain with a force of 147 N (15 kgf, 33 lbf) as shown in the illustration.




Fig. 441: Measuring Length Of Links

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

b. Using vernier calipers, measure the length of 15 links.

Maximum chain elongation

115.2 mm (4.535 in.)

NOTE: Perform the measurement at 3 random places. Use the average of the measurements.

If the average elongation is greater than the maximum, replace the chain.

6. INSPECT NO. 2 CHAIN SUB-ASSEMBLY

a. Pull the chain with a force of 147 N (15 kgf, 33 lbf) as shown in the illustration.




Fig. 442: Measuring Length Of Links

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Using vernier calipers, measure the length of 15 links.

Maximum chain elongation

102.1 mm (4.019 in.)

NOTE: Perform the measurement at 3 random places. Use the average of the measurements.

If the average elongation is greater than the maximum, replace the No. 2 chain.

7. INSPECT OIL PUMP DRIVE GEAR

- a. Place the chain around the gear.




Fig. 443: Measuring Timing Gear Diameter With Chain
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Using vernier calipers, measure the diameter of the gear and chain.

Minimum gear diameter (with chain)

48.2 mm (1.898 in.)

NOTE: The vernier calipers must be in contact with the chain rollers when measuring.

If the diameter is less than the minimum, replace the chain and gear.

8. INSPECT OIL PUMP DRIVE SHAFT GEAR

- a. Place the chain around the gear.




Fig. 444: Inspecting Oil Pump Drive Shaft Gear
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Using vernier calipers, measure the diameter of the gear and chain.

Minimum gear diameter (with chain)

48.8 mm (1.922 in.)

NOTE: The vernier calipers must be in contact with the chain rollers when measuring.

If the diameter is less than the minimum, replace the chain and gear.

9. INSPECT CAMSHAFT TIMING GEAR ASSEMBLY

- a. Place the chain around the gear.




Fig. 445: Inspecting Camshaft Timing Gear Assembly
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Using vernier calipers, measure the diameter of the gear and chain.

Minimum gear diameter (with chain)


96.8 mm (3.811 in.)

NOTE: The vernier calipers must be in contact with the chain rollers when measuring.

If the diameter is less than the minimum, replace the chain and gear.

10. INSPECT CAMSHAFT TIMING EXHAUST GEAR ASSEMBLY

- a. Place the chain around the sprocket.



T

Fig. 446: Measuring Diameter Of Gear And Chain
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Using vernier calipers, measure the diameter of the sprocket and chain.

Minimum sprocket diameter (with chain)

96.8 mm (3.811 in.)

NOTE: **The vernier calipers must be in contact with the chain rollers when measuring.**

If the diameter is less than the minimum, replace the chain and sprocket.

11. INSPECT CRANKSHAFT TIMING GEAR

- a. Place the chain around the gear.




Fig. 447: Measuring Timing Gear Diameter With Chain
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Using vernier calipers, measure the diameter of the gear and chain.

Minimum gear diameter (with chain)

51.1 mm (2.012 in.)

NOTE: The vernier calipers must be in contact with the chain rollers when measuring.

If the diameter is less than the minimum, replace the chain and gear.

12. INSPECT CHAIN TENSIONER SLIPPER

- a. Using vernier calipers, measure the tensioner slipper wear.


**T**

Fig. 448: Identifying Tensioner Slipper Wear Clearance
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


Maximum wear

1.0 mm (0.039 in.)

If the wear is greater than the maximum, replace the chain tensioner slipper.

13. INSPECT NO. 1 CHAIN VIBRATION DAMPER

- a. Using vernier calipers, measure the vibration damper wear.



T
Fig. 449: Identifying Vibration Damper Wear Clearance
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Maximum wear

1.0 mm (0.039 in.)

If the wear is greater than the maximum, replace the No. 1 chain vibration damper.

14. INSPECT NO. 2 CHAIN VIBRATION DAMPER

- a. Using vernier calipers, measure the vibration damper wear.


**T**

Fig. 450: Identifying Vibration Damper Wear Clearance
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


Maximum wear

1.0 mm (0.039 in.)

If the wear is greater than the maximum, replace the No. 2 chain vibration damper.

15. INSPECT CHAIN TENSIONER PLATE

- a. Using vernier calipers, measure the vibration damper wear.

**T****Fig. 451: Identifying Vibration Damper Wear****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

Maximum wear

1.0 mm (0.039 in.)

If the wear is greater than the maximum, replace the chain tensioner plate.

16. INSPECT NO. 1 CHAIN TENSIONER

- a. Check that the plunger moves smoothly when the ratchet pawl is raised with your finger.




Fig. 452: Inspecting No. 1 Chain Tensioner
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Release the ratchet pawl, then check that the plunger is locked in place by the ratchet pawl and does not move when pushed with your finger.

17. INSPECT CAMSHAFT

- a. Inspect the camshaft for runout.




Fig. 453: Inspecting Camshaft For Runout**Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**


1. Place the camshaft on V-blocks.
2. Using a dial indicator, measure the circle runout at the center journal.

Maximum circle runout

0.04 mm (0.0016 in.)

If the circle runout is greater than the maximum, replace the camshaft.

- b. Inspect the cam lobes.

**Fig. 454: Inspecting Cam Lobes****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

1. Using a micrometer, measure the cam lobe height.

Standard cam lobe height

42.816 to 42.916 mm (1.6857 to 1.6896 in.)

Minimum cam lobe height

42.666 mm (1.6798 in.)

If the cam lobe height is less than the minimum, replace the camshaft.

- c. Inspect the camshaft journals.




Fig. 455: Inspecting Camshaft Journals
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

1. Using a micrometer, measure the journal diameter.

Standard journal diameter

Journal Position	Specified Condition
No. 1	34.449 to 34.465 mm (1.3563 to 1.3569 in.)
Other	22.949 to 22.965 mm (0.9035 to 0.9041 in.)

If the journal diameter is not as specified, check the oil clearance See step 5.

18. INSPECT NO. 2 CAMSHAFT

- a. Inspect the No. 2 camshaft for runout.




Fig. 456: Inspecting Camshaft For Runout
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

1. Place the No. 2 camshaft on V-blocks.
2. Using a dial indicator, measure the circle runout at the center journal.

Maximum circle runout

0.04 mm (0.0016 in.)

If the circle runout is greater than the maximum, replace the No. 2 camshaft.

- b. Inspect the cam lobes.




Fig. 457: Inspecting Cam Lobes

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

1. Using a micrometer, measure the cam lobe height.

Standard cam lobe height

44.336 to 44.436 mm (1.7455 to 1.7494 in.)

Minimum cam lobe height

44.186 mm (1.7396 in.)

If the cam lobe height is less than the minimum, replace the No. 2 camshaft.

- c. Inspect the camshaft journals.




Fig. 458: Inspecting Camshaft Journals
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

1. Using a micrometer, measure the journal diameter.

Standard journal diameter

Journal Position	Specified Condition
No. 1	34.449 to 34.465 mm (1.3563 to 1.3569 in.)
Other	22.949 to 22.965 mm (0.9035 to 0.9041 in.)

If the journal diameter is not as specified, check the oil clearance See step 5.

19. INSPECT CYLINDER HEAD SET BOLT

- a. Using vernier calipers, measure the length of the cylinder head set bolt from the seat to the end.

Measuring Point




Fig. 459: Identifying Length Of Cylinder Head Set Bolt
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard bolt length

146.8 to 148.2 mm (5.7795 to 5.8346 in.)

Maximum bolt length

149.2 mm (5.874 in.)

If the bolt length is greater than the maximum, replace the cylinder head set bolt.

- b. Using vernier calipers, measure the minimum diameter of the elongated thread at the measuring point.

Standard outside diameter

9.77 to 9.96 mm (0.3846 to 0.3921 in.)

Minimum outside diameter

9.4 mm (0.3701 in.)

HINT:

Using a straightedge, visually check for thinner areas of the threaded part of the cylinder head set bolt.

If the diameter is less than the minimum, replace the cylinder head set bolt.

20. INSPECT EXHAUST MANIFOLD

- a. Using a precision straightedge and feeler gauge, measure the warpage on the contact surface of the cylinder head.




Fig. 460: Measuring Warpage On Contact Surface Of Cylinder Head
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Maximum warpage

0.7 mm (0.028 in.)

HINT:

If the warpage is greater than the maximum, replace the manifold.

REPLACEMENT

REPLACEMENT

1. REPLACE RING PIN

- Remove the 2 ring pins.
- Using a plastic-faced hammer, tap in 2 new ring pins to the crankcase.




Fig. 461: Locating Ring Pins

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Standard protrusion

3 mm (0.1181 in.)

2. REPLACE STUD BOLT

a. for Crankcase:

1. Remove the 2 stud bolts.
2. Using "TORX" socket wrench E5, install the 2 stud bolts as shown in the illustration.





Fig. 462: Locating Stud Bolts

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 5.0 N*m (51 kgf*cm, 44 in.*lbf)

b. for water inlet housing:




Fig. 463: Identifying Stud Bolts Dimension

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

1. Remove the 2 stud bolts.
2. Using a "TORX" socket E5, install the 2 stud bolts as shown in the illustration.

Torque: 5.0 N*m (51 kgf*cm, 44 in.*lbf)

3. REPLACE SPARK PLUG TUBE GASKET

- a. Pry up the claws of the ventilation baffle plate.




Fig. 464: Identifying Claws Of Baffle Plate

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Do not deform the claws of the baffle plate more than necessary.

- b. Remove the 4 gaskets from the cylinder head covers.


NOTE:

- Try not to deform the plug tube gaskets. The removed gaskets will be used when reinstalling the gaskets.
- Do not damage the connection of the cylinder head cover.

- c. Using a cutter, cut off the sealing part of the removed plug tube gasket.

Before cutting off

After cutting off




T  : Area to be cut off

Fig. 465: Identifying Area To Be Cut Off

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- d. Using a plug tube gasket which has had the sealing part cut off, uniformly tap in a plug tube gasket all the way.

**T****Fig. 466: Installing Plug Tube Gasket**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:

- Keep the lip free of foreign matter.

- Do not tap on the oil seal at an angle.

HINT:

If a plug tube gasket that will be used to install a new gasket is deformed, and cannot be positioned on a new gasket, correct the deformation using pliers.

- e. Return the claws of the ventilation baffle plate to their original positions.

4. REPLACE TIMING CHAIN OR BELT COVER OIL SEAL

- a. Using a screwdriver and hammer, remove the oil seal.


**T**

Fig. 467: Removing Oil Seal


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Be careful not to damage the timing chain cover sub-assembly.

HINT:

Tape the screwdriver tip before use.

- b. Using SST, tap in a new oil seal until its surface is flush with the timing gear case edge.

**T****Fig. 468: Tapping Oil Seal****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

- SST: 09223-22010

c. Apply a light coat of MP grease to the lip of the oil seal.

NOTE:

- Keep the lip free of foreign matter.
- Do not tap on the oil seal at an angle.
- Make sure that the oil seal edge does not stick out of the timing chain cover.

5. REPLACE ENGINE REAR OIL SEAL

a. Using a knife, cut off the oil seal lip.




Fig. 469: Prying Out Oil Seal

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Using a screwdriver with its tip taped, pry out the oil seal.

NOTE: After removing the oil seal, check the crankshaft for damage. If it is damaged, smooth the surface with 400-grit sandpaper.

- c. Apply MP grease to the new oil seal lip.
- d. Using SST and a hammer, evenly tap in a new oil seal until its surface is flush with the rear oil seal retainer edge.




Fig. 470: Installing Oil Seal

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09223-15030
- SST: 09950-70010
09951-07100

NOTE:


- Keep the lip free from foreign materials.
- Do not tap on the oil seal at an angle.
- Wipe off any grease that is on the crankshaft.

REASSEMBLY

REASSEMBLY

1. INSTALL STIFFENING CRANKCASE ASSEMBLY

- a. Apply seal packing in a continuous bead (diameter: 2.5 mm (0.098 in.)) to the places shown in the illustration.

**T****Fig. 471: Applying Seal Packing**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Seal packing

Toyota Genuine Seal Packing Black, Three Bond 1207B or equivalent

NOTE:

- Remove any oil from the contact surface.
- Install the crankcase within 3 minutes of applying the seal packing.
- Do not start the engine for at least 2 hours after installing the stiffening crankcase.

b. Install the stiffening crankcase with the 11 bolts.




Fig. 472: Locating Bolts

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 21 N*m (214 kgf*cm, 16 ft.*lbf)

Bolt length

Item	Length
Bolt A	138 mm (5.43 in.)
Bolt B	35 mm (1.38 in.)
Bolt C	70 mm (2.76 in.)


- c. Recheck the torque for bolts 1 and 2.

Torque: 21 N*m (214 kgf*cm, 16 ft.*lbf)

- d. Wipe off any excess seal packing with a clean piece of cloth.

2. INSTALL OIL PUMP ASSEMBLY

- a. Install the oil pump assembly with the 3 bolts.



T


Fig. 473: Locating Bolts And Oil Pump Assembly
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 21 N*m (214 kgf*cm, 16 ft.*lbf)

3. INSTALL NO. 2 OIL PAN SUB-ASSEMBLY

- a. Remove any old packing material from the contact surface.
- b. Apply seal packing in a continuous bead (diameter: 4 mm (0.157 in.)) to the places shown in the

illustration.



T

Fig. 474: Applying Seal Packing

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Seal packing

Toyota Genuine Seal Packing Black, Three Bond 1207B or equivalent

NOTE:

- Remove any oil from the contact surface.
- Install the No. 2 oil pan sub-assembly within 3 minutes and tighten the bolts within 15 minutes of applying the seal packing.
- Do not expose the seal to engine oil for 2 hours after installation.

- c. Install the No. 2 oil pan sub-assembly with the 10 bolts and 2 nuts.

Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)





Fig. 475: Locating Bolts And Nuts

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

4. INSTALL OIL PAN DRAIN PLUG

- a. Install a new gasket and the oil pan drain plug.



T

Fig. 476: Locating Oil Pan Drain Plug

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 37 N*m (377 kgf*cm, 27 ft.*lbf)

5. INSTALL CYLINDER BLOCK WATER DRAIN COCK ASSEMBLY

- a. Apply adhesive to the threads of the drain cock.





Fig. 477: Applying Adhesive Around Drain Cocks
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Adhesive

Toyota Genuine Adhesive 1344, Three Bond 1344 or equivalent

- b. Install the water drain cock as shown in the illustration.



T
Fig. 478: Locating Water Drain Cock Plug
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 20 N*m (204 kgf*cm, 15 ft.*lbf)

NOTE:

- Do not rotate the drain cock more than 1 revolution (360°) after tightening it to the specified torque.

- Install the water drain cock within 3 minutes after applying the adhesive.
- Do not start the engine for at least 2 hours after installing the water drain cock.

c. Install the water drain cock plug to the water drain cock.

Torque: 13 N*m (130 kgf*cm, 9 ft.*lbf)

6. INSTALL VENTILATION VALVE SUB-ASSEMBLY

- a. Apply adhesive to the threads of the ventilation valve.




Fig. 479: Applying Adhesive To Threads Of Ventilation Valve
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Install the ventilation valve.




Fig. 480: Locating Ventilation Valve

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 20 N*m (204 kgf*cm, 15 ft.*lbf)

Adhesive

Toyota Genuine Adhesive 1324, Three Bond 1324 or equivalent

NOTE:

- Install the crankcase within 3 minutes after applying the adhesive.
- Do not start the engine for at least 2 hours after installing the ventilation valve.

7. INSTALL CYLINDER HEAD GASKET

- a. Place a new cylinder head gasket on the cylinder block with the Lot No. stamp facing upward.




Fig. 481: Identifying Cylinder Head Gasket Lot No. Stamp

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:


- Remove any oil from the contact surface.
- Pay attention to the mounting orientation of the cylinder head gasket.
- Do not damage the cylinder gasket when installing the cylinder head onto the cylinder block.

8. INSTALL CYLINDER HEAD SUB-ASSEMBLY

HINT:

The cylinder head bolts are tightened in 2 successive steps.

- a. Apply a light coat of engine oil to the threads of the cylinder head bolts.
- b. Using several steps, install and tighten the 10 cylinder head bolts and plate washers uniformly with as a 10 mm bi-hexagon wrench in the sequence shown in the illustration.




T

Fig. 482: Locating Cylinder Head Bolts And Tightening Sequence

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 49 N*m (500 kgf*cm, 36 ft.*lbf)

- c. Mark the front of the cylinder head bolt with paint.



O


Fig. 483: Identifying Cylinder Head Bolt Tightening Direction**Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.**

- d. Retighten the cylinder head bolts by additional 90° and one more additional 45° as shown in the illustration.
- e. Check that the paint mark is now at a 135° angle from the front.

9. INSTALL VALVE LASH ADJUSTER ASSEMBLY**NOTE:**

- **Keep the lash adjuster free of dirt and foreign objects.**
- **Only use clean engine oil.**

- a. Place the lash adjuster into a container filled with engine oil.
- b. Insert the SST's tip into the lash adjuster's plunger and use the tip to press down on the check ball inside the plunger.



T

Fig. 484: Checking Movement Of Plunger And Bleed Air
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09276-75010

- c. Squeeze the SST and lash adjuster together to move the plunger up and down 5 or 6 times.
- d. Check the movement of the plunger and bleed the air.

OK

Plunger moves up and down.

NOTE: **When bleeding air from the high-pressure chamber, make sure that the tip of the SST is actually pressing the check ball as shown in the illustration. If the check ball is not pressed, air will not bleed.**

- e. After bleeding the air, remove the SST. Then, try to press the plunger quickly and firmly with a finger.

OK

Plunger is very difficult to move.

If the result is not as specified, replace the lash adjuster.

- f. Install the lash adjusters.

NOTE: **Install the lash adjuster into its original position.**

10. INSTALL NO. 1 VALVE ROCKER ARM SUB-ASSEMBLY

- a. Apply engine oil to the lash adjuster tip and valve stem cap end.
- b. Install the valve rocker arms as shown in the illustration.


**P**

Fig. 485: Applying Engine Oil To Lash Adjuster Tips And Valve Stem Cap Ends
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

11. INSTALL NO. 1 CAMSHAFT BEARING

- a. Clean the both surfaces of the bearing.
- b. Install the 2 No. 1 camshaft bearings.
- c. Using vernier calipers, measure the distance between the bearing cap's edge and the camshaft bearing's edge.




Fig. 486: Identifying Bearing Cap's Edge Dimension
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Dimension (A - B)

0.7 mm (0.0276 in.) or less

NOTE: Position the bearing to the center of the bearing cap by measuring dimension A - B.

12. INSTALL OIL CONTROL VALVE FILTER

- a. Check that there is no foreign matter on the mesh part of the filter.
- b. Install the oil control valve filter.




Fig. 487: Installing Oil Control Valve Filter
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Do not touch the mesh when installing the oil control valve filter.

13. INSTALL NO. 2 CAMSHAFT BEARING

- a. Clean both surfaces of the bearing.
- b. Install the 2 No. 2 camshaft bearings.
- c. Using vernier calipers, measure the distance between the bearing cap's edge and the camshaft bearing's edge.




Fig. 488: Identifying Bearing Cap's Edge Dimension
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


Dimension (A)

1.05 to 1.75 mm (0.042 to 0.068 in.)

NOTE: Position the bearing to the center of the bearing cap by measuring dimension A.

14. INSTALL NO. 2 CAMSHAFT


- a. Clean the camshaft journals.
- b. Apply a light coat of engine oil to the camshaft journals, camshaft housings and bearing caps.
- c. Install the No. 2 camshaft to the camshaft housing.




T
Fig. 489: Identifying No. 2 Camshaft
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

15. INSTALL CAMSHAFT

- a. Clean the camshaft journals.
- b. Apply a light coat of engine oil to the camshaft journals, camshaft housings and bearing caps.
- c. Install the camshaft to the camshaft housing.

**T****Fig. 490: Identifying Camshaft****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.****16. INSTALL CAMSHAFT BEARING CAP**

- a. Apply engine oil to the camshaft journals, camshaft housing and bearing caps.
- b. Check the marks and numbers on the camshaft bearing caps and place them in the proper position and direction.

**T****Fig. 491: Identifying Knock Pin Of Camshaft**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Make sure that the knock pin of the camshaft is positioned as shown in the illustration.

- c. Tighten the 10 bolts in the order shown in the illustration.




Fig. 492: Locating Bolts And Tightening Sequence

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 16 N*m (163 kgf*cm, 12 ft.*lbf)

17. INSTALL CAMSHAFT HOUSING SUB-ASSEMBLY

- a. Make sure that the valve rocker arm is installed as shown in the illustration.


**P**

Fig. 493: Applying Engine Oil To Lash Adjuster Tips And Valve Stem Cap Ends
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Apply seal packing in a continuous line as shown in the illustration.




Fig. 494: Applying Seal Packing

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Seal packing

Toyota Genuine Seal Packing Black, Three Bond 1207B or equivalent

Seal diameter

3.5 to 4.0 mm (0.138 to 0.158 in.)

NOTE:

- Remove any oil from the contact surface.
- Install the camshaft housing sub-assembly RH within 3 minutes of applying the seal packing.
- Do not start the engine for at least 2 hours after installing.

- c. Set the camshaft and No. 2 camshaft as shown in the illustration.




Fig. 495: Locating Camshaft Housing Bolts And Tightening Sequence
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- d. Install the camshaft housing and tighten the 17 bolts in the order shown in the illustration.

Torque: 27 N*m (275 kgf*cm, 20 ft.*lbf)

NOTE:

- After installing the camshaft housing, make sure that the cam lobes are positioned as shown in the illustration.
- If any of the bolts are loosened during installation, remove the camshaft housing, clean the installation surfaces, and reapply seal packing.
- If the camshaft housing is removed because any of the bolts are loosened during installation, make sure that the previously applied seal packing does not enter any oil passages.
- After installing the camshaft housing, wipe off any seal packing that seeped out from between the housing and the cylinder head.

18. INSTALL CAMSHAFT TIMING GEAR ASSEMBLY

- a. Check that the knock pin is installed on the camshaft.
- b. Put the camshaft timing gear and camshaft together with the straight pin and key groove misaligned, as shown in the illustration.





Fig. 496: Identifying Straight Pin And Key Groove
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Do not forcefully push in the camshaft timing gear assembly. This

may cause the camshaft knock pin tip to damage the installation surface of the camshaft timing gear assembly.

- c. Turn the camshaft timing gear as shown in the illustration while pushing it gently against the camshaft. Push further at the position where the pin fits into the groove.




T

Fig. 497: Identifying Straight Pin And Key Groove
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Do not turn the camshaft timing gear in the retard direction (the right angle).

- d. Measure the clearance between the gear and the camshaft.




Clearance:
0.1 to 0.4 mm

Fig. 498: Identifying Clearance Between Gear And Camshaft
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Clearance

0.1 to 0.4 mm (0.004 to 0.016 in.)

- e. Tighten the flange bolt with the camshaft timing gear fixed in place.




T

Fig. 499: Locating Flange Bolt

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 54 N*m (551 kgf*cm, 40 ft.*lbf)

- f. Check that the camshaft timing gear can move to the retard angle side (the right direction) and is locked in the most retarded position.



T

Fig. 500: Identifying Camshaft Timing Gear Direction

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

19. INSTALL CAMSHAFT TIMING EXHAUST GEAR ASSEMBLY

- a. Check that the knock pin is installed on the camshaft.
- b. Put the camshaft timing exhaust gear and camshaft together by aligning the key groove and straight pin.





Fig. 501: Aligning Key Groove And Straight Pin

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- c. Lightly press the gear against the camshaft, and turn the gear. Push further at the position where the pin enters the groove.

NOTE: Be sure not to turn the camshaft timing exhaust gear in the retard direction (the right angle).

- d. Check that there is no clearance between the gear's flange and the camshaft.
- e. Tighten the flange bolt with the camshaft timing exhaust gear fixed.



T

Fig. 502: Locating Flange Bolt

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 54 N*m (551 kgf*cm, 40 ft.*lbf)

f. Check the camshaft timing exhaust gear lock.

1. Make sure that the camshaft timing exhaust gear is locked.

20. INSTALL NO. 1 CRANKSHAFT POSITION SENSOR PLATE

a. Install the sensor plate with the "F" mark facing forward.


**T**

Fig. 503: Identifying No. 1 Crankshaft Position Sensor Plate

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

21. INSTALL CRANKSHAFT TIMING GEAR KEY

- a. Using a plastic-faced hammer, tap in the 2 crankshaft timing gear keys.




Fig. 504: Identifying Crankshaft Timing Gear Keys


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

Tap in the crankshaft timing gear keys until they come in contact with the crankshaft.

22. INSTALL NO. 2 CHAIN SUB-ASSEMBLY

- a. Set the crankshaft key as shown in the illustration.



T
Fig. 505: Locating Crankshaft Key
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Turn the drive shaft so that the cutout faces right.
- c. Align the yellow mark links with the timing marks of each gear as shown in the illustration.


**T**

Fig. 506: Identifying Yellow Mark Links And Timing Marks

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- d. Install the gears onto the crankshaft and oil pump shaft with the chain on the gears.
- e. Temporarily tighten the oil pump drive shaft gear with the nut.
- f. Insert the damper spring into the adjusting hole, and then install the chain tensioner plate with the bolt.


**T**

Fig. 507: Identifying Bolt, Chain Tensioner Plate And Spring
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)

- g. Align the adjusting hole of the oil pump drive shaft gear with the groove of the oil pump.


**T**

Fig. 508: Turning Crankshaft 90Degrees Clockwise
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- h. Insert a 4 mm diameter bar into the adjusting hole of the oil pump drive shaft gear to lock the gear in position, and then tighten the nut.


**T**

Fig. 509: Identifying Bar Into Adjusting Hole Of Oil Pump Drive Shaft Gear
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 28 N*m (286 kgf*cm, 21 ft.*lbf)

23. INSTALL CRANKSHAFT TIMING GEAR OR SPROCKET

- a. Install the crankshaft timing gear or sprocket.


**T**

Fig. 510: Locating Crankshaft Timing Gear Or Sprocket
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

24. INSTALL NO. 1 CHAIN VIBRATION DAMPER

- a. Install the No. 1 chain vibration damper with the 2 bolts.


**T**

Fig. 511: Locating No. 1 Chain Vibration Damper And Bolts

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 21 N*m (214 kgf*cm, 16 ft.*lbf)

25. INSTALL CHAIN SUB-ASSEMBLY

- a. Check the No. 1 cylinder TDC/compression.
 1. Temporarily tighten the crankshaft pulley bolt.
 2. Turn the crankshaft counterclockwise until the timing gear key is facing up.




Fig. 512: Identifying Timing Gear Key

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

3. Remove the crankshaft pulley bolt.
4. Check the timing mark on each camshaft timing gear.





Fig. 513: Identifying Timing Mark On Camshaft Timing Gear
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Align the mark plate (orange) with the timing mark as shown in the illustration and install the chain.




T

Fig. 514: Identifying Mark Plate And Timing Mark
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

- Be sure to position the mark plate at the front of the engine.
 - The mark plate on the camshaft side is colored orange.
 - Do not pass the chain around the sprocket of the camshaft timing gear assembly. Only place it on the sprocket.
 - Pass the chain through the No. 1 vibration damper.
- c. Place the chain on the crankshaft without passing it around the shaft.




T

Fig. 515: Identifying Chain On Crankshaft

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- d. Hold the hexagonal portion of the camshaft with a wrench and turn the camshaft timing gear assembly counterclockwise to align the mark plate (orange) and timing mark.



T
Fig. 516: Holding Hexagonal Portion Of Camshaft With Wrench
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

- Be sure to position the mark plate at the front of the engine.
 - The mark plate on the camshaft side is colored orange.
- e. Hold the hexagonal portion of the camshaft with a wrench and turn the camshaft timing gear assembly clockwise.

HINT:

When tensioning the chain, turn the camshaft timing gear assembly clockwise slowly to prevent the chain from being misaligned.

- f. Align the mark plate (yellow) and timing mark and install the chain to the crankshaft timing gear.


**T**

Fig. 517: Identifying Mark Plate (Yellow) And Timing Mark (1 Of 2)

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

The mark plate on the crankshaft side is colored yellow.

- g. Recheck each timing mark at TDC/compression.





Fig. 518: Identifying Mark Plate (Yellow) And Timing Mark (2 Of 2)
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

26. INSTALL CHAIN TENSIONER SLIPPER

- a. Install the chain tensioner slipper.



T

Fig. 519: Identifying Chain Tensioner Slipper
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

27. INSTALL NO. 2 CHAIN VIBRATION DAMPER

- a. Install the No. 2 chain vibration damper with the 2 bolts.



**T**

Fig. 520: Locating Bolts And No. 2 Chain Vibration Damper
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)

28. INSTALL NO. 1 GENERATOR BRACKET

- a. Install the No. 1 generator bracket with the 4 bolts.

**T****Fig. 521: Locating Bolts And Generator Bracket****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.****Torque: 21 N*m (214 kgf*cm, 16 ft.*lbf)****29. INSTALL WATER INLET HOUSING**

- a. Install a new gasket and the water inlet housing with the 3 bolts.



**T**

Fig. 522: Locating Bolts, Gasket And Water Inlet Housing
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 21 N*m (214 kgf*cm, 16 ft.*lbf)

30. INSTALL TIMING CHAIN OR BELT COVER SUB-ASSEMBLY

- a. Remove any old packing (FIPG) material and be careful not to drop any oil on the contact surfaces of the timing chain cover, cylinder head and cylinder block.



■ :Clean and degrease

Fig. 523: Identifying Old Packing (FIPG) Material

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Install 3 new O-rings.




Fig. 524: Locating O-Rings

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- c. Apply seal packing as shown in the illustration.




Fig. 525: Applying Seal Packing

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Seal packing

Toyota Genuine Seal Packing Black, Three Bond 1207B or equivalent

Seal diameter

3.0 mm (0.118 in.)

NOTE:

- **Remove any oil from the contact surface.**
- **Install the chain cover within 3 minutes of applying the seal packing.**
- **Do not start the engine for at least 2 hours after installing.**

- d. Apply seal packing in a continuous line to the timing chain cover, as shown in the following illustration.




Fig. 526: Applying Seal Packing To Timing Chain Cover
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:


- When the contact surfaces are wet, wipe them with oil-free cloth before applying seal packing.
- Install the chain cover within 3 minutes and tighten the bolts within 15 minutes of applying the seal packing.

- **Do not start the engine for at least 2 hours after installation.**

Apply seal packing as follows

Area	Seal Packing Diameter	Application Position from Inside Seal Line	Seal packing
Continuous Line Area	3.0 mm (0.118 in.)	2.5 mm (0.098 in.)	Toyota Genuine Seal Packing Black, Three Bond 1207B or equivalent
Dashed Line Area	4.0 mm (0.156 in.)	3.0 mm (0.118 in.)	Toyota Genuine Seal Packing Black 1282B, Three Bond 1282B or equivalent

- e. Install a new gasket.




T

Fig. 527: Identifying Gasket

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Remove any oil from the contact surface.

- f. Install 2 new O-rings.




T

Fig. 528: Locating O-Rings

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- g. Install the timing chain cover with the 19 bolts as shown in the illustration.



T

Fig. 529: Locating Timing Chain Cover Bolts

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Bolt A and C

Torque: 26 N*m (260 kgf*cm, 19 ft.*lbf)

Bolt B and D

Torque: 51 N*m (520 kgf*cm, 38 ft.*lbf)

Bolt E

Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)

NOTE:

- When the contact surfaces are wet, wipe them with oil-free cloth before applying seal packing.
- Install the chain cover within 3 minutes and tighten the bolts within 15 minutes of applying seal packing.
- Do not start the engine for at least 2 hours after installation.
- Tighten bolt D through the engine mounting bracket, pressing it against the timing chain or belt cover sub-assembly.
- Tighten bolt C through the oil filter bracket, pressing it against the timing chain or belt cover sub-assembly.

Bolt length

Item	Length
Bolt A and C	35 mm (1.38 in.)
Bolt B	55 mm (2.16 in.)
Bolt D	80 mm (3.15 in.)
Bolt E	40 mm (1.57 in.)

- h. Install the engine water pump with the 3 bolts.




Fig. 530: Locating Bolts And Water Pump Assembly
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 24 N*m (245 kgf*cm, 18 ft.*lbf)

31. INSTALL THERMOSTAT

- a. Install a new gasket onto the thermostat.
- b. Install the thermostat with the jiggle valve facing upward.


**T**

Fig. 531: Identifying Jiggle Valve Facing Upward

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

HINT:

The jiggle valve may be set within 10° on either side, as shown in the illustration.

32. INSTALL WATER INLET

- a. Install the water inlet with the 2 nuts.


**T**

Fig. 532: Locating Nuts And Water Inlet

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)

33. INSTALL CRANKSHAFT PULLEY

- a. Align the pin hole in the crankshaft pulley with the pin position and install the crankshaft pulley.
- b. Provisionally install the bolt.
- c. Using SST, tighten the bolt while holding the crankshaft pulley.




Fig. 533: Tightening Bolt

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09213-58013
91651-60855
- SST: 09330-00021

Torque: 190 N*m (1940 kgf*cm, 140 ft.*lbf)

NOTE: Check the SST installation positions when installing them, to avoid the SST fixing bolts from coming into contact with the timing chain or belt cover sub-assembly.

34. INSTALL ENGINE OIL PRESSURE SWITCH ASSEMBLY

- Apply adhesive to 2 or 3 threads of the oil pressure switch.





Fig. 534: Applying Adhesive To Threads Of Oil Pressure Switch
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Adhesive

Toyota Genuine Adhesive 1344, Three Bond 1344 or equivalent

- b. Using a 24 mm deep socket wrench, install the oil pressure switch.



T
Fig. 535: Locating Engine Oil Pressure Switch Assembly
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


Torque: 15 N*m (153 kgf*cm, 11 ft.*lbf)

NOTE:

- Install the oil pressure switch within 3 minutes of applying the adhesive.
- Do not start the engine within 1 hour of installation.

35. INSTALL ENGINE WATER TEMPERATURE SENSOR

- a. Install a new gasket to the engine water temperature sensor.



T
Fig. 536: Identifying Engine Coolant Temperature Sensor
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Install the engine water temperature sensor.

Torque: 20 N*m (204 kgf*cm, 15 ft.*lbf)

36. INSTALL KNOCK SENSOR

- a. Install the knock sensor with the bolt.




Fig. 537: Locating Knock Control Sensor With Bolt
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 20 N*m (204 kgf*cm, 15 ft.*lbf)

NOTE: Make sure that the knock sensor is in the correct position.

37. INSTALL NO. 1 TAPER SCREW PLUG

- a. Apply adhesive to 2 or 3 threads of the plug, and install the plug.




Fig. 538: Locating No. 1 Taper Screw Plug
 Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 43 N*m (439 kgf*cm, 32 ft.*lbf)

NOTE:

- Install the plug within 3 minutes of applying the adhesive.
- Do not start the engine within 1 hour of installation.

Adhesive

Toyota Genuine Adhesive 1324, Three Bond 1324 or equivalent

38. INSTALL CRANKSHAFT POSITION SENSOR

- a. Apply a light coat of engine oil to the O-ring of the sensor.




Fig. 539: Identifying O-Ring Of Sensor

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Install the crankshaft position sensor with the bolt.




Fig. 540: Locating Bolt And Crankshaft Position Sensor

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)

39. INSTALL NO. 1 CHAIN TENSIONER ASSEMBLY

- a. Release the ratchet pawl, then fully push in the plunger and hook the hook on the pin so that the plunger is in the position shown in the illustration.



**T**

Fig. 541: Checking No. 1 Chain Tensioner Assembly
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Make sure that the cam engages the first tooth of the plunger to allow the hook to pass over the pin.

- b. Install a new gasket, bracket and the No. 1 chain tensioner with the 2 nuts.



T

Fig. 542: Locating Gasket, Bracket And No. 1 Chain Tensioner
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)

NOTE: If the hook releases the plunger while the chain tensioner is being installed, set the hook again.

- c. Turn the crankshaft counterclockwise, then disconnect the plunger knock pin from the hook.


**T**

Fig. 543: Turning Crankshaft Counterclockwise
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- d. Turn the crankshaft clockwise, then check that the plunger is extended.


**T**

Fig. 544: Turning Crankshaft Clockwise
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

40. INSTALL OIL FILTER SUB-ASSEMBLY

- a. Clean the inside of the oil filter cap, threads and O-ring groove.


**T**

Fig. 545: Identifying Oil Filter Element And O-Ring
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Apply a small amount of engine oil to a new O-ring and install it onto the oil filter cap.
- c. Set a new oil filter element into the oil filter cap.
- d. Remove any dirt or foreign matter from the installation surface of the engine.
- e. Apply a small amount of engine oil to the O-ring again and install the oil filter cap.
- f. Using SST, tighten the oil filter cap.




Fig. 546: Tightening Oil Filter Cap

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- SST: 09228-06501

Torque: 25 N*m (255 kgf*cm, 18 ft.*lbf)

NOTE:

- Make sure that the oil filter is installed securely as shown in the illustration.
- Be careful that the O-ring does not get caught between the parts.

41. INSTALL CYLINDER HEAD COVER GASKET

- a. Install the gasket to the cylinder head cover.



**T**

Fig. 547: Identifying Cylinder Head Cover Gasket
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE: Remove any oil from the contact surface.

42. INSTALL CYLINDER HEAD COVER SUB-ASSEMBLY

- a. Install 3 new gaskets onto the No. 1 camshaft bearing cap.




T

Fig. 548: Locating Gaskets

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Apply seal packing as shown the illustration.



T

Fig. 549: Locating Seal Packing Area

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Seal packing

Toyota Genuine Seal Packing Black, Three Bond 1207B or equivalent

NOTE:

- Remove any oil from the contact surface.
- Install the cylinder head cover within 3 minutes and tighten the bolts within 15 minutes of applying seal packing.
- Do not start the engine for at least 2 hours after the installation.

- c. Install the cylinder head cover with a new seal washer and the 13 bolts.




Fig. 550: Locating Bolts, Seal Washer And Cylinder Head Cover
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)

43. INSTALL CAMSHAFT TIMING OIL CONTROL VALVE ASSEMBLY

- a. Apply a light coat of engine oil to 2 new O-rings, then install each of them onto the camshaft timing oil control valve.





Fig. 551: Identifying O-Ring

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Install the 2 camshaft timing oil control valves and bracket with the 2 bolts.



T


Fig. 552: Locating Bolts, O-Rings, Bracket And Oil Control Valves

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)

44. INSTALL CAMSHAFT POSITION SENSOR

- a. Apply a light coat of engine oil to the O-ring of the sensor.



P

Fig. 553: Identifying Camshaft Position Sensor O-Ring
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Install the 2 sensors with the 2 bolts.





Fig. 554: Locating Bolts And Sensors

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.


Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)

45. INSTALL SPARK PLUG

- a. Using a socket wrench 14 mm, install the 4 spark plugs.

**T****Fig. 555: Installing Spark Plugs****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.****Torque: 20 N*m (204 kgf*cm, 15 ft.*lbf)****46. INSTALL OIL FILLER CAP GASKET**


- a. Install the gasket to the cap.

**T****Fig. 556: Locating Oil Filler Cap Gasket**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

47. INSTALL OIL FILLER CAP SUB-ASSEMBLY



- a. Install the oil filler cap.

**T****Fig. 557: Locating Oil Filler Cap**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

48. INSTALL ENGINE HANGER

- a. Install the 2 engine hangers with the 2 bolts.



T

Fig. 558: Locating Bolts And Engine Hangers**Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.****Torque: 43 N*m (439 kgf*cm, 32 ft.*lbf)****INSTALLATION****INSTALLATION****1. INSTALL WIRE HARNESS CLAMP BRACKET**

- a. Install the 4 wire harness clamp brackets with the 4 bolts.



**P**

Fig. 559: Locating Wire Harness Clamp Brackets And Bolts
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)

for bolt A

Torque: 13 N*m (130 kgf*cm, 9 ft.*lbf)

for bolt B

2. INSTALL EXHAUST MANIFOLD

- a. Install a new exhaust manifold gasket and exhaust manifold with the 5 nuts in the sequence shown in the illustration.




Fig. 560: Identifying Exhaust Manifold Nuts
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 21 N*m (214 kgf*cm, 16 ft.*lbf)

for Type A

Torque: 37 N*m (377 kgf*cm, 27 ft.*lbf)


for Type B

TEXT IN ILLUSTRATION

*A	Nut Type A
*B	Nut Type B

3. INSTALL MANIFOLD STAY

- a. Install the manifold stay with the 3 bolts.



P

Fig. 561: Locating Bolts And Manifold Stay

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 43 N*m (438 kgf*cm, 32 ft.*lbf)

4. INSTALL NO. 1 EXHAUST MANIFOLD HEAT INSULATOR

- a. Install the No. 1 exhaust manifold heat insulator with the 4 bolts.



**P**

Fig. 562: Locating Bolts And No. 1 Exhaust Manifold Heat Insulator
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 12 N*m (122 kgf*cm, 9 ft.*lbf)

5. INSTALL AIR TUBE ASSEMBLY

- a. Install the air tube assembly with the 2 bolts.

**P****Fig. 563: Locating Bolts And Air Tube Assembly****Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.****Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)****6. INSTALL NO. 1 WATER BY-PASS PIPE**

- a. Install the water by-pass pipe with the 2 bolts.


**P**

Fig. 564: Locating Bolts And Water By-Pass Pipe


Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 21 N*m (214 kgf*cm, 16 ft.*lbf)

- b. Connect the No. 3 water by-pass hose with the clip.

7. INSTALL WATER INLET HOSE


- a. Install the water inlet hose with the 2 clips.

**P****Fig. 565: Locating Clips And Water Inlet Hose**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

8. INSTALL WATER BY-PASS HOSE


- a. Install the water by-pass hose with the clip.

**P****Fig. 566: Locating Clip And Water By-Pass Hose**

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

9. INSTALL OIL LEVEL GAGE GUIDE

- a. Install a new O-ring.



P

Fig. 567: Locating Bolt And Oil Level Gage Guide

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Install the oil level gage guide with the bolt.

Torque: 21 N*m (214 kgf*cm, 16 ft.*lbf)

10. INSTALL OIL LEVEL DIPSTICK

11. INSTALL VENTILATION HOSE

- a. Install the ventilation hose.




Fig. 568: Locating Ventilation Hose

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

12. INSTALL FAN BELT ADJUSTING BAR

- a. Install the fan belt adjusting bar with the bolt.




Fig. 569: Locating Bolt And Fan Belt Adjusting Bar

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 19 N*m (189 kgf*cm, 14 ft.*lbf)

13. **INSTALL GENERATOR ASSEMBLY** . Refer to INSTALLATION - Step 1
14. **INSTALL FUEL INJECTOR** . Refer to INSTALLATION - Step 1
15. **INSTALL INJECTOR VIBRATION INSULATOR** . Refer to INSTALLATION - Step 2
16. **INSTALL NO. 1 DELIVERY PIPE SPACER** . Refer to INSTALLATION - Step 3
17. **INSTALL FUEL DELIVERY PIPE SUB-ASSEMBLY**
 - a. Install the fuel delivery pipe with the 4 fuel injectors, then provisionally install the 3 bolts.




Fig. 570: Locating Bolts And Fuel Delivery Pipe

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

NOTE:

- Do not drop the fuel injectors when installing the fuel delivery pipe.
- Check that the fuel injectors rotate smoothly after installing the fuel delivery pipe.

- b. Tighten the 3 bolts to the specified torque.

Torque: 21 N*m (214 kgf*cm, 16 ft.*lbf)

18. INSTALL INTAKE MANIFOLD

- a. Install a new gasket onto the intake manifold.




Fig. 571: Locating Bolt And Nuts And Intake Manifold And Manifold Stay
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- b. Provisionally tighten the intake manifold and manifold stay with the 4 bolts and 2 nuts in the order shown in the illustration, and then tighten them to the specified torque.

Torque: 28 N*m (286 kgf*cm, 21 ft.*lbf)

- c. Install the wire harness clamp onto the intake manifold.




Fig. 572: Locating Wire Harness Clamp

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- d. Install the ventilation hose into the intake manifold.
- e. Install the No. 1 vacuum transmitting hose with the clip.
- f. Install the No. 1 fuel vapor feed hose into the throttle body manifold.





Fig. 573: Locating Clips And Water By-Pass Hoses
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

- g. Install the 2 water by-pass hoses with the 2 clips.

19. INSTALL NO. 1 RADIATOR HOSE

- a. Install the No. 1 radiator hose with the clip.



P

Fig. 574: Locating Clip And No. 1 Radiator Hose
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

20. INSTALL HEATER WATER HOSE INLET A

- a. Install heater water inlet hose A with the clip.




Fig. 575: Locating Clip And Heater Water Inlet Hose A
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

21. INSTALL HEATER WATER OUTLET HOSE A (FROM HEATER UNIT)

- a. Install heater water outlet hose A with the clip.




Fig. 576: Locating Clip And Heater Water Outlet Hose A

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

22. INSTALL NO. 2 VENTILATION HOSE

- a. Install the No. 2 ventilation hose.




Fig. 577: Locating No. 2 Ventilation Hose

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

23. INSTALL ENGINE WIRE

24. INSTALL RADIO SETTING CONDENSER

- a. Install the radio setting condenser with the bolt.




Fig. 578: Locating Radio Setting Condenser Connector

Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)

- b. Connect the radio setting condenser connector.

25. INSTALL IGNITION COIL ASSEMBLY

- a. Install the 4 ignition coil assemblies with the 4 bolts.




Fig. 579: Locating Bolts And Ignition Coil Assemblies
Courtesy of TOYOTA MOTOR SALES, U.S.A., INC.

Torque: 10 N*m (102 kgf*cm, 7 ft.*lbf)

- b. Connect the 4 ignition coil assembly connectors.