ENGINE

Engine (V8 S/C 5.0L Petrol)

ENGINE (V8 S/C 5.0L PETROL)

SPECIFICATIONS

ENGINE DATA

Engine Description	Engine Capacity	Maximum Engine Torque (EEC)	Maximum Engine Power (EEC)	Compression Ratio	Bore	Stroke
90° "Vee" 8 Cylinder 32 Valves	4.999 ccm	625 Nm at 2.500 - 5.500 RPM	375 kW at 6.000 - 6.500 RPM	9.5 ± 0.50	92.5 mm	93 mm

ENGINE FIRING ORDER

Firing Order
1:2:7:3:4:5:6:8

ENGINE VALVE CLEARANCE (COLD)

Intake Valve	Exhaust Valve
0.20 ±0.02	0.25 ±0.02

SPARK PLUGS

Specification	Spark Plug Gap
ILKR6C-10	1 mm

LUBRICANTS, FLUIDS, SEALERS AND ADHESIVES

Description	Specification
Engine Oil	WSS-M2C925-A
Sealant	WSE-M4G323-A6
Core plug and stub pipe retainer	WSK-M2G349-A7

CAPACITIES

Description	Liters
Engine oil, initial fill	9.65
Engine oil, service fill with oil filter change	8.0

CYLINDER HEAD AND VALVE TRAIN

Item	Specification
Cylinder head maximum permitted warp (mm) (flatness specfication)	

© 2011 Mitchell Repair Information Company, LLC.

overall	0.08
over 150x150 mm area	0.05
over 25x25 mm area	0.02
Valve guide inner diameter (mm)	5.51 ± 0.01
Intake valve effective length (mm) (tip to gauge line)	117.21 ± 0.1
Exhaust valve effective length (mm) (tip to gauge line)	94.39 ± 0.1
Valve stem to guide clearance intake diametrical (mm)	0.022 - 0.057
Valve stem to guide clearance exhaust diametrical (mm)	0.03 - 0.065
Valve head diameter intake (mm)	36 ± 0.1
Valve head diameter exhaust (mm)	30 ± 0.1
Intake valve face angle (degrees)	44.875 ± 0.125
Exhaust valve face angle (degrees)	44.875 ± 0.125
Valve stem diameter intake (mm)	5.4705 ± 0.0075
Valve stem diameter exhaust (mm)	5.4625 ± 0.0075
Valve spring free length (mm) - inlet	46.1
Valve spring free length (mm) - exhaust	46.1
Valve spring installed height (mm) - inlet	35.74
Valve spring installed height (mm) - exhaust	35.1
Camshaft lobe lift intake (mm)	10
Camshaft lobe lift exhaust (mm)	9.36
Camshaft journal to cylinder head bearing surface clearance diametrical (mm)	0.025 - 0.065
Camshaft journal diameter - all positions	26.965 ± 0.01
Bearing diameter - all positions	27.01 ± 0.01
Camshaft journal maximum run out limit (mm)	
Camshaft journals to end journals	0.03
Camshaft journals to adjacent journals	0.015
Camshaft journal maximum out of round (mm) - all journals	0.005

NOTE: A = Refer to procedure for correct torque sequence.

TORQUE SPECIFICATIONS

Description	Nm	lb-ft	lb-in
Engine cover mounting bolts	10	7	-
Accessory drive belt tensioner retaining bolt	40	30	-
Supercharger belt idler/tensioner bracket retaining bolts	25	18	-
Secondary drive belt idler retaining bolts	40	30	-
Power steering pump pulley retaining bolts	25	18	-
Power steering pump retaining bolts	25	18	-
Power steering pump bracket to engine retaining bolts	25	18	-
Generator retaining bolts	48	35	-

© 2011 Mitchell Repair Information Company, LLC.

Starter motor retaining bolts	40	30	-
Air conditioning compressor retaining bolts	25	18	-
Engine mounting to engine mounting bracket retaining nuts	100	74	-
Engine mounting to subframe retaining bolts	56	41	-
Engine mounting bracket to engine retaining bolts	45 + 60°	33 + 60°	-
Crankshaft damper pulley retaining LH threaded bolt	200 + 270°	148 + 180°	-
Flexplate retaining bolts	45 + 90°	33 + 90°	-
Exhaust manifold heat shield retaining bolts	**A**	-	-
Exhaust manifold retaining bolts	**A**	-	-
Engine wiring harness bracket retaining bolts	10	7	-
Coolant outlet pipe	10	7	-
Intercooler retaining bolts	25	18	-
Intake manifold retaining bolts	25	18	-
Oil Cooler retaining bolts	13	10	-
Knock sensor (KS) retaining bolt	20	14	-
Ignition coil retaining bolts	8	-	71
Spark plugs	20	15	-
Fuel rail retaining bolts	**A**	-	-
High pressure fuel pipe retaining bolts	**A**	-	-
High pressure fuel pump retaining bolts	12	9	-
Oil filter housing assembly retaining bolts	12	9	-
Oil filter cap	25	18	-
Lifting eye bolts	25 + 90°	18 + 90°	-
Manifold absolute pressure and temperature (MAPT) sensor retaining bolts	5	-	44
Coolant pump retaining bolts	12	9	-
Variable valve timing (VVT) oil control solenoid retaining bolts	10	7	-
Camshaft position (CMP) sensor retaining bolts	10	7	-
Camshaft cover retaining bolts	13	10	-
Front upper timing cover retaining bolts	12	9	-
Front lower timing cover retaining bolts	**A**	-	-
Engine rear cover retaining bolts	**A**	-	-
VVT to camshaft retaining bolts	32	24	-
Camshaft bearing caps retaining bolts	11	8	-
Primary timing chain fixed guide retaining bolts	12	9	-
Primary timing chain tensioner retaining bolts	12	9	-
Primary timing chain tensioner guide blade retaining bolts	25	18	-
Auxiliary chain tensioner guide retaining bolts	21	15	-
Auxiliary chain fixed guide retaining bolt	12	9	-

 © 2011 Mitchell Repair Information Company, LLC.

Oil pump sprocket retaining bolt	21	15	-
Cylinder head retaining bolts	**A**	-	-
Engine oil level (EOL) sensor retaining bolt	12	9	-
Crankshaft position (CKP) sensor retaining bolt	10	7	-
Oil sump body to engine retaining bolts	25	18	-
Oil pan drain plug	24	18	-
Oil transfer tube to Oil pan body retaining bolts	11	8	-
Oil pump to engine block retaining bolts	25	18	-
Pick-up pipe to oil pump retaining bolts	12	9	-
Windage tray retaining bolts	25	18	-
Piston cooling jet retaining bolts	12	9	-
Engine block coolant draining plug	50	37	-
Cooling fan pulley	25	18	-

DESCRIPTION & OPERATION

ENGINE

EXTERNAL VIEW

 © 2011 Mitchell Repair Information Company, LLC.



INTRODUCTION

The 5.0L supercharger (SC) gasoline engine is a liquid cooled V8 unit featuring direct fuel injection, four overhead camshafts and four valves per cylinder. All four camshafts incorporate variable camshaft timing

 © 2011 Mitchell Repair Information Company, LLC.

(VCT).

The main structural components of the engine are all manufactured from aluminum alloy. The engine is built around a very stiff, lightweight, enclosed V, deep skirt cylinder block. A structural windage tray is bolted to the bottom of the cylinder block to further improve the block stiffness, minimize noise, vibration and harshness (NVH) and help reduce oil foaming. To further enhance the stiffness of the lower engine structure, a heavily ribbed sump is installed. The sump also helps to reduce engine noise. A transverse hole is incorporated into the sump to accommodate the right-hand (RH) front drive halfshaft.

© 2011 Mitchell Repair Information Company, LLC.



Item Number	Description
1	LH (left hand) cylinder head (bank B)
2	Cylinder block

 © 2011 Mitchell Repair Information Company, LLC.

3	Windage tray
4	Sump
5	RH (right hand) cylinder head (bank A)

CYLINDER BLOCK



 © 2011 Mitchell Repair Information Company, LLC.



The cylinder block is a 90 degree configuration with cast-in iron cylinder liners and an open deck die-cast coolant jacket. The low volume coolant jacket gives good warm-up times and low piston noise levels. The longitudinal flow design of the coolant jacket, with a single cylinder head coolant transfer port in each bank, provides good rigidity and head gasket sealing.

The cylinders are numbered as shown below, with cylinders 1 and 2 being at the front of the engine.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

Item Number	Description
1	Engine data location

Engine data is marked on the cylinder block at the rear of the RH cylinder bank.

CRANKSHAFT

 © 2011 Mitchell Repair Information Company, LLC.



© 2011 Mitchell Repair Information Company, LLC.

The crankshaft is made from spheroidal graphite cast iron, which, compared with grey cast iron, has higher mechanical strength, ductility and increased shock resistance. The undercut and rolled fillets also improve strength. Eight counter-balance weights ensure low vibration levels and the large, cross-drilled main bearing journals are designed to contribute to stiffness.

An oil groove in the upper half of each main bearing transfers the oil into the crankshaft for lubrication of the connecting rod bearings. A thrust washer is installed each side of the top half of the center main bearing.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

Item Number	Description
1	Pin journal classification and plant identification
2	Main journal classification
3	Date and time codes

The main bearings are numbered 1 to 5 starting from the front of the engine. There are five grades of main bearing available, each being color coded. Journal sizes are marked on the rear of the crankshaft. Refer to **Crankshaft Main Bearing Journal Clearance** information.



Item Number	Description
1	Coolant drain plug
2	Torque converter access plug
3	Drive plate
4	Rear cover
5	Main bearing cap
6	Identification mark

 © 2011 Mitchell Repair Information Company, LLC.

7	Front cover
8	Front pulley

The main bearing caps are made from cast iron and are cross bolted to increase rigidity. An identification mark on the bearing cap faces the front of the engine.

At the front of the crankshaft, a tuned torsional vibration damper is incorporated into the crankshaft front pulley. At the rear of the crankshaft a pressed steel drive plate, with a steel starter ring gear, is installed to transfer drive from the engine to the transmission. The reluctor ring for the crankshaft position (CKP) sensor is integrated into the perimeter of the drive plate.

The crankshaft seals are located in the front and rear covers.

PISTONS AND CONNECTING RODS

 © 2011 Mitchell Repair Information Company, LLC.



The diameter of each piston is graded and precisely matched to each cylinder bore to help reduce noise. In the vertical plane, the pistons have a slight barrel form, which helps to ensure a reliable oil film is maintained between the piston and the cylinder bore. A solid film lubricant coating is applied to both reaction faces of the piston to reduce wear and improve fuel economy.

 © 2011 Mitchell Repair Information Company, LLC.

A three-ring piston-sealing system is used. The steel top ring is treated with a PVD (physical vapor deposition) peripheral coating. PVD is a coating technique where material can be deposited with improved properties to ensure good cylinder bore compatibility and wear resistance. A Napier center ring helps cylinder pressure and oil management, while the three-piece oil control lower ring is produced from nitrided steel.

The pistons are cooled with engine oil from four piston cooling jets installed under the valley of the cylinder block. Each piston cooling jet sprays oil onto the underside of the two adjacent pistons, one from each cylinder bank.

The connecting rods are forged from high strength steel. The cap is fracture-split from the rod to ensure precision re-assembly for bearing shell alignment. There are three grades of large end bearing available, each being color coded. Refer to **Connecting Rod Large End Bore** information.



Item Number	Description
1	Alignment marks
2	Connecting rod
3	Cap
4	Bearings

 © 2011 Mitchell Repair Information Company, LLC.

The correct alignment of the cap with the connecting rod is indicated by marks on adjacent faces of the two components.



Item Number	Description
A	Front of engine
1	Alignment mark
2	LH side (bank B)
3	Alignment mark
4	RH side (bank A)
5	Piston orientation arrow

The orientation of the connecting rods and pistons on the crankshaft are given below:

- Bank A - The arrow on the piston crown must face the front of the engine and the cap and connecting rod alignment marks must face the rear of the engine.
- Bank B - The arrow on the piston crown must face the front of the engine and the cap and connecting rod alignment marks must face the front of the engine.

CYLINDER HEADS

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: right-hand (RH) (A bank) cylinder head shown, left-hand (LH) (B bank) cylinder head similar.

The cylinder heads are manufactured in gravity die cast aluminum alloy and are unique for each cylinder bank. Deep-seated bolts reduce distortion and secure the cylinder heads to the cylinder block.

Each cylinder is served by four valves. To help achieve the required gas-flow characteristics, these are arranged asymmetrically around the cylinder bore. Each cylinder has a centrally mounted fuel injector and spark plug.

The cylinder head gasket is of a multi-layer steel construction.

EXHAUST MANIFOLD

 © 2011 Mitchell Repair Information Company, LLC.



Item Number	Description
1	Cylinder head
2	Gasket
3	Heat shield
4	Gasket
5	Exhaust manifold
6	Bolt (8 off)
7	Heat shield
8	Bolt (4 off)
9	Spacer (8 off)

NOTE: LH (B bank) installation shown, RH (A bank) installation similar.

The high SiMo (silicon molybdenum) cast iron exhaust manifolds are unique for each cylinder bank. Each exhaust manifold installation includes two metal gaskets and two heat shields. Spacers on the securing bolts allow the manifolds to expand and contract with changes of temperature while maintaining the clamping loads.

 © 2011 Mitchell Repair Information Company, LLC.

VALVE TRAIN



Item Number	Description
1	Inlet camshafts
2	Exhaust camshaft
3	Inverted tooth timing chain
4	Nylon chain guide
5	Auxiliary chain tensioner
6	Auxiliary drive chain
7	Oil pump drive
8	Auxiliary drive camshaft
9	Timing chain tensioner
10	Tensioner lever
11	VCT unit
12	VCT solenoids

The lightweight valve train provides good economy and noise levels and is chain driven from the crankshaft.

 © 2011 Mitchell Repair Information Company, LLC.

Double overhead camshafts on each cylinder head operate the valves. For each cylinder head, an inverted tooth timing chain transfers drive from the crankshaft to the variable camshaft timing (VCT) unit on the front of each camshaft. Graded tappets enable setting of inlet and exhaust valve clearances.

Each timing chain has a hydraulic tensioner operated by engine oil pressure. The chain tensioners incorporate a ratchet mechanism, which maintains tension while the engine is stopped to eliminate start-up noise. The chains are lubricated with engine oil from jets located at the front of the engine block. Nylon chain guides control chain motion on the drive side.

Variable Camshaft Timing



Item Number	Description
1	VCT units
2	Intake camshaft VCT solenoid
3	Camshaft position sensors
4	Exhaust camshaft VCT solenoid

The variable camshaft timing (VCT) system varies the timing of the intake and exhaust camshafts to deliver

 © 2011 Mitchell Repair Information Company, LLC.

optimum engine power, efficiency and emissions. The timing of the intake camshafts has a range of 62 degrees of crankshaft angle. The timing of the exhaust camshafts has a range of 50 degrees of crankshaft angle.

In the base timing position:

- The intake camshafts are fully retarded.
- The exhaust camshafts are fully advanced.

VARIABLE CAMSHAFT TIMING (VCT) OPERATING RANGES

Camshaft	Valve Opens	Valve Closes
Intake	29 degrees before top dead center (BTDC) to 33 degrees after top dead center (ATDC)	207 to 269 degrees after top dead center (ATDC)
Exhaust	244 to 194 degrees before top dead center (BTDC)	6 to 56 degrees after top dead center (ATDC)

The system consists of a variable camshaft timing (VCT) unit and a variable camshaft timing (VCT) solenoid for each camshaft. The engine control module (ECM) controls the system using pulse width modulation (PWM) signals to the variable camshaft timing (VCT) solenoids.

The torsional energy generated by the valve springs and the inertia of the valve train components are used to operate the system.

Variable Camshaft Timing Units

The variable camshaft timing (VCT) units change the position of the camshafts in relation to the timing chains.



 © 2011 Mitchell Repair Information Company, LLC.

Item Number	Description
1	Bolt (3 off)
2	VCT unit
3	Filter
4	Camshaft
5	Inner plate
6	Housing and sprocket
7	Rotor assembly
8	Reed plate
9	Spring and lock pin
10	Spring (3 off)
11	Tip seal (3 off)
12	Spring (2 off)
13	Tip seal (2 off)
14	Spring
15	Dowel pin
16	Bias spring
17	Snap ring
18	Reluctor ring
19	Center plate
20	Snap ring
21	Screw (6 off)
22	Spool valve
23	Outer plate

Each variable camshaft timing (VCT) unit is attached to the camshaft by three bolts. A rotor assembly and a reed plate are installed inside a sprocket housing, which consists of a sprocket, an outer plate and an inner plate held together by six screws.

A reluctor ring, for the camshaft position (CMP) sensor, a center plate and a bias spring are installed at the front of the variable camshaft timing (VCT) unit. The ends of the bias spring locate on the center plate assembly and the sprocket housing, to give a turning moment to the camshaft in the advance direction. A snap ring locates the reluctor ring on to a sleeve installed in the center of the rotor assembly. The opposite end of the sleeve locates in a bore in the front face of the camshaft, which contains a filter.

A spring and spool valve are installed in the rotor assembly sleeve and retained by a snap ring. The spring keeps the spool valve in contact with the armature of the related variable camshaft timing (VCT) solenoid.

Each variable camshaft timing (VCT) unit is supplied with engine oil from an oil gallery in the cylinder head, through the camshaft front bearing cap and a bore in the center of the camshaft.

Variable Camshaft Timing Solenoids

The variable camshaft timing (VCT) solenoids control the position of the spool valves in the variable camshaft

 © 2011 Mitchell Repair Information Company, LLC.

timing (VCT) units.



The variable camshaft timing (VCT) solenoids are installed in the front upper timing covers, immediately in front of their related variable camshaft timing (VCT) units. Each variable camshaft timing (VCT) solenoid is secured with two screws and sealed with an O-ring. A two pin electrical connector provides the interface with the engine harness.

Each variable camshaft timing (VCT) solenoid incorporates a spindle that acts on the spool valve in the related variable camshaft timing (VCT) unit to advance and retard the camshaft timing. The variable camshaft timing (VCT) solenoids operate independently and are controlled by a pulse width modulation (PWM) signal from the engine control module (ECM).

Variable Camshaft Timing Operation

When the engine is running, the compression and expansion of the valve springs causes momentary increases and decreases in the torque acting on the camshafts. These momentary changes of torque are sensed in the variable camshaft timing (VCT) units and used to change the camshaft timing.

 © 2011 Mitchell Repair Information Company, LLC.



Item Number	Description
A	Camshaft torque
B	Camshaft rotation (degrees)

 © 2011 Mitchell Repair Information Company, LLC.

C	Valve opening
D	Peak lift
E	Valve closing
1	1000 rev/min
2	4000 rev/min
3	7000 rev/min
4	Inertia effects from valve train rotating components
5	Force caused by valve spring
6	Bias torque from friction



Item Number	Description
1	Advance chamber
2	Retard chamber
3	Sprocket housing
4	Rotor assembly
5	Lock pin

© 2011 Mitchell Repair Information Company, LLC.

6	Sleeve
7	Engine oil supply from camshaft
8	Inlet check valve
9	Lock pin drain
10	Spool valve
11	Advance check valve
12	Retard check valve

NOTE: Intake camshaft variable camshaft timing (VCT) unit shown. For exhaust camshaft variable camshaft timing (VCT) unit, read advance for retard and retard for advance.

NOTE: The following description is for intake camshaft variable camshaft timing (VCT) units. For exhaust camshaft variable camshaft timing (VCT) units, read advance for retard, and retard for advance.

At engine start-up, once the engine oil pressure in the camshaft is sufficient to open the inlet check valve, engine oil flows across the spool valve, through the advance and retard check valves and into the advance and retard chambers. During the start cycle, the engine control module (ECM) signals the variable camshaft timing (VCT) solenoid to move the spool valve into the sleeve and connect the lock pin to inlet oil pressure. The inlet oil pressure causes the lock pin to retract from the inner plate and unlock the rotor assembly and camshaft from the sprocket housing.

There is a constant supply of oil to the variable camshaft timing (VCT) to ensure the unit remains filled during operation.

 © 2011 Mitchell Repair Information Company, LLC.



To advance the camshaft timing, the engine control module (ECM) adjusts the signal to the variable camshaft timing (VCT) solenoid to move the spool valve so that the advance chamber oil passage is closed and the retard chamber oil passage is connected to inlet oil.

Each momentary increase of the torque acting on the camshaft generates a pressure pulse in the retard chamber. Oil moves from the retard chamber, through the spool valve and the advance check valve to the advance chamber, to equalize the pressures in the two chambers. The displacement of oil from the retard chamber causes the rotor assembly to advance in relation to the sprocket housing. Each momentary decrease of torque acting on the camshaft also generates a pressure pulse in the advance chamber, but, with the advance chamber oil passage closed, no movement of oil between the advance and retard chambers occurs and the rotor assembly cannot move in the retard direction.

 © 2011 Mitchell Repair Information Company, LLC.



Once the camshaft has reached the required timing position the engine control module (ECM) adjusts the signal to the variable camshaft timing (VCT) solenoid to set the spool valve in the null position. In the null position, the advance and retard chamber oil passages are both closed by the spool valve and the rotor assembly is hydraulically locked to the sprocket housing.

 © 2011 Mitchell Repair Information Company, LLC.



To retard the camshaft timing, the engine control module (ECM) adjusts the signal to the variable camshaft timing (VCT) solenoid to move the spool valve to close the retard chamber oil passage and connect the advance chamber oil passage to the inlet oil.

 © 2011 Mitchell Repair Information Company, LLC.

Each momentary decrease of the torque acting on the camshaft causes oil to transfer from the advance chamber, through the spool valve and the retard check valve to the retard chamber, and so retard the camshaft timing.

LUBRICATION SYSTEM



Item Number	Description
1	Oil pump outlet tube
2	Anti-drain valve
3	Oil cooler
4	Oil filter
5	Piston cooling jet (4 off)
6	Timing chain lubrication jet (2 off)
7	Oil evacuation tube
8	Oil pump
9	Oil pick-up
10	Oil temperature and level sensor

© 2011 Mitchell Repair Information Company, LLC.

The oil pump is attached to the underside of the windage tray. The input shaft of the oil pump is driven from the front of the crankshaft, by the auxiliary chain, at 0.87 engine speed.

The oil pump draws oil from the sump through a centrally mounted pick-up pipe. The oil is pressurized and pumped through an output tube to the cylinder block. After passing through an anti-drain valve and a plate type oil cooler, the oil is filtered by a replaceable cartridge installed on the front of the right-hand (RH) cylinder head.

The output from the oil filter is distributed through oil galleries in the cylinder heads and cylinder block. All moving parts are lubricated by pressure or splash oil. Pressurized oil is also provided for the variable camshaft timing (VCT) system, the timing chain tensioners, the piston cooling jets and the timing chain lubrication jets.

The oil returns to the oil pan under gravity. Large drain holes through the cylinder heads and cylinder block ensure the rapid return of the oil to the sump. System replenishment is through the oil filler cap on the left-hand (LH) cylinder head cover.

An oil evacuation tube is installed to allow oil to be drawn from the sump. The upper end of the oil evacuation tube is located under the oil filler cap.

An oil drain plug is installed in the right-hand (RH) side of the sump.

OIL PUMP NOMINAL OPERATING PRESSURES

Engine Speed, rev/min	Temperature, °C (°F)	Pressure, bar (lbf/in^2)
Idle	20 (68)	2.0 (29.0)
1500	20 (68)	6.0 (87.0)
3000	40 (104)	6.2 (90.0)
3000	110 (230)	5.0 (72.5)
3000	130 (266)	4.0 (58.0)

Oil Level Monitoring

Oil level monitoring is provided by an oil level and temperature sensor that measures the oil level in the sump. The oil level can be displayed in the message center of the instrument cluster.

 © 2011 Mitchell Repair Information Company, LLC.



The oil level and temperature sensor supplies the engine control module (ECM) with a signal containing the level and temperature of the oil in the sump. The oil level and temperature sensor is secured to the bottom of the sump with three screws and sealed with a gasket.

 © 2011 Mitchell Repair Information Company, LLC.

The oil level and temperature sensor sends an ultrasonic pulse vertically upward and measures the time taken for the pulse to be reflected back from the top surface of the oil. This time is compared with the time taken for an ultrasonic pulse to travel a reference distance within the oil level and temperature sensor to determine the oil level. The oil level reading is combined with the oil temperature reading and transmitted in a pulse width modulation (PWM) signal to the engine control module (ECM).

OIL LEVEL AND TEMPERATURE SENSOR SPECIFICATIONS

Feature	Details
Power Source	Battery Voltage
Level Accuracy	±2 mm (±0.08 in.) at temperatures of -30 °C (-22 °F)) and above; (±4 mm (±0.16 in.) at temperatures below -30 °C (-22 °F))
Temperature Accuracy	±2 °C (±3.6 °F)
Operating Level Range	116 to 147 mm (4.57 to 5.79 in.)
Operating Temperature Range	-40 to 160 °C (-40 to 320 °F)

Oil Level Check

Engine Oil Draining and Filling.

For accuracy, oil level checks should be performed with the vehicle on level ground when the oil is hot. The vehicle needs to stand for approximately 10 minutes, after the engine is switched off, to allow the oil to drain back into the sump and the oil level to stabilize. The oil level system will not give a reading until the oil level has stabilized.

To check the oil level, make sure that the ignition is on, the engine stopped and the transmission is in P (park). Access the vehicle information and settings menu, then select **Oil Level Display** from the **Service Menu** . An **Engine Oil Level** sight glass will be displayed in the message center. The current oil level will be displayed in the sight glass. One of the following messages will also be displayed:

- If the oil level is within acceptable limits, the message **OK** is displayed.
- If the oil level is less than acceptable, a message advising how much oil to add is displayed e.g. **Add 0.5 Liter Refer to handbook for oil type** , or **Add 0.5 Quart Refer to handbook for oil type** , depending on the market.
- If the message **Overfilled Refer to handbook** is displayed, the oil level must be reduced to within acceptable limits before starting the engine again.
- If the message **Not available** is displayed, the oil level is still stabilizing. Wait 10 minutes and then recheck level.

© 2011 Mitchell Repair Information Company, LLC.



DIAGNOSTIC PROCEDURES

ENGINE

For additional information. Refer to **Engine - 5.0L Petrol** information.

GENERAL PROCEDURES

ENGINE OIL DRAINING AND FILLING

DRAINING

CAUTION: Correct installation of the oil filler cap can be obtained by tightening the cap until hard stop.

WARNING: The spilling of hot engine oil is unavoidable during this procedure, care must be taken to prevent scalding.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: Clean the components general area prior to dismantling

CAUTION: Make sure the engine is warm

1. Start the engine and allow to run for 10 minutes, stop the engine.
2. See figure.

 © 2011 Mitchell Repair Information Company, LLC.

3. Refer to appropriate Engine Cover Interior Trim and Ornamentation, Removal and Installation instructions.
4. Loosen the element cover 4 complete turns to allow engine oil to drain from the filter cover.

 © 2011 Mitchell Repair Information Company, LLC.

Make sure that the O-ring seal is exposed.



5. Allow 10 minutes for the engine oil to drain from the oil filter housing.
6. Remove and discard the O-ring seal.

 © 2011 Mitchell Repair Information Company, LLC.



7. Remove and discard the oil filter element.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.



WARNING: Do not work on or under a vehicle supported only by a jack. Always support the vehicle on safety stands.

8. Raise and support the vehicle.
9. Refer to appropriate Engine Undershield Front End Body Panels, Removal and Installation instructions.

CAUTION: Be prepared to collect escaping oil.

CAUTION: Allow at least 10 minutes for the engine oil to drain.

10. Discard sealing washer.

FILLING

 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Make sure that the area around the component is clean and free of foreign material.

1. Install a new sealing washer



Torque: 24 Nm

 © 2011 Mitchell Repair Information Company, LLC.

2. Refer to appropriate Engine Undershield Front End Body Panels, Removal and Installation information.

NOTE: Install new O-ring seals

3. Lubricate the oil filter element O-ring seal with clean engine oil.



CAUTION: Tighten the component finger tight first.

4. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that the vehicle is left for 5 minutes from filling with oil and that the engine oil level is reading at least minimum (by following Steps 9-16), before starting the engine.

5. Fill the engine with oil - for filling values on vehicles with supercharger, refer to appropriate Specifications Engine - V8 S/C 5.0L Petrol, Specifications instructions.

   Fill the engine with oil - for filling values on vehicles without supercharger, refer to appropriate Specifications Engine - V8 5.0L Petrol, Specifications instructions.

   Clean any residual engine oil from the oil filler cap area.

6. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that the vehicle has been left for 5 minutes from filling with oil.

7. Follow the Steps 9-16 before starting the engine.
8. Start the engine and allow to run for 10 minutes, stop the engine.

   Check for leaks.

CAUTION: Make sure that the selector lever and the gearshift mechanism are in the park (P) position.

CAUTION: Make sure that the hood is open.

9. Turn the ignition on.
10. Press the right-hand directional button to access the instrument cluster menu.

 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

11. Press the right-hand OK button.



12. Press the right-hand directional button to access the Oil Level Display.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

13. Press the right-hand OK button and follow the instructions.

 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

14. Press the cruise control cancel button twice within 2 seconds.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

15.

- The message center display will revert to the normal display in the trip computer.
- Press the right-hand OK button and follow the instructions.
- Check that the oil level display shows an oil level reading.
- Only after having started and run the engine for 10 minutes (as indicated in Step 8), switch off the engine, then stabilizing for 10 minutes, take a reading from the oil level display and, if necessary top up with engine oil.

 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: If instructed to follow Steps 9-16 in a previous step, return to Step 8 and continue the procedure.

16. Turn the ignition off.
17. Allow 10 minutes for the engine oil level to stabilize if there has been additional oil top up.

NOTE: The following steps are to update the average oil level value.

18. Turn the ignition on. Press and hold the cruise control cancel button for more than 2 seconds.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

19. The message center display will revert to the normal display in the trip computer.
20. Turn the ignition off.
21. Turn the ignition on.
22. Press the right-hand directional button to access the instrument cluster menu.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

23. Press the right-hand OK button.



24. Press the right-hand directional button to access the Oil Level Display.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

25. Press the right-hand OK button and follow the instructions.

    Make sure that the average oil level value has now been updated.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

26. Refer to appropriate Engine Cover - V8 5.0L Petrol/V8 S/C 5.0L Petrol (Interior Trim and Ornamentation, Removal and Installation) information.

ENGINE OIL VACUUM DRAINING AND FILLING

DRAINING

WARNING: The spilling of hot engine oil is unavoidable during this procedure, care must be taken to prevent scalding.

CAUTION: Correct installation of the oil filler cap can be obtained by tightening the cap until hard stop.

NOTE: Make sure that the vehicle is parked on level ground.

NOTE: Clean the components general area prior to dismantling.

1. Start the engine and allow to run for 10 minutes, stop the engine.

CAUTION: Allow 10 minutes from turning the engine off before starting oil extraction.

2. See figure.

 © 2011 Mitchell Repair Information Company, LLC.

3. Refer to appropriate Engine Cover - V8 5.0L Petrol/V8 S/C 5.0L Petrol Interior Trim and Ornamentation, Removal and Installation information.
4. Loosen the element cover 4 complete turns to allow engine oil to drain from the filter cover.

 © 2011 Mitchell Repair Information Company, LLC.



5. Using the oil vacuum pump drain the oil out through the oil extraction tube.

 © 2011 Mitchell Repair Information Company, LLC.



6. Remove oil vacuum pump.
7. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Discard the O-ring seals

8. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



FILLING

NOTE: Install new O-ring seals.

1. Lubricate the oil filter element O-ring seal with clean engine oil.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Tighten the component finger tight first.

2. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that the vehicle is left for 5 minutes from filling with oil and that the engine oil level is reading at least minimum (by following Steps 9-16), before starting the engine.

3. See figure.

   Fill the engine with oil - for filling values on vehicles with supercharger, refer to appropriate Specifications Engine - V8 S/C 5.0L Petrol, Specifications instructions.

   Fill the engine with oil - for filling values on vehicles without supercharger, refer to appropriate Specifications Engine - V8 5.0L Petrol, Specifications instructions.

4. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that the vehicle has been left for 5 minutes from filling with oil.

5. Follow the Steps 7-14 before starting the engine.
6. Start the engine and allow to run for 10 minutes, stop the engine. Check for leaks.

CAUTION: Make sure that the selector lever and the gearshift mechanism are in the park (P) position.

CAUTION: Make sure that the hood is open.

7. Turn the ignition on.
8. Press the right-hand directional button to access the instrument cluster menu.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

9. Press the right-hand OK button.



10. Press the right-hand directional button to access the Oil Level Display.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

11. Press the right-hand OK button and follow the instructions.

 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

12. Press the cruise control cancel button twice within 2 seconds.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

13.

- The message center display will revert to the normal display in the trip computer.
- Press the right-hand OK button and follow the instructions.
- Check that the oil level display shows an oil level reading.
- Only after having started and run the engine for 10 minutes (as indicated in Step 8), switch off the engine, then stabilizing for 10 minutes, take a reading from the oil level display and, if necessary top up with engine oil.

 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: If instructed to follow Steps 9-16 in a previous step, return to Step 8 and continue the procedure.

14. Turn the ignition off.
15. Allow 10 minutes for the engine oil level to stabilize if there has been additional oil top up.

NOTE: The following steps are to update the average oil level value.

16. Turn the ignition on. Press and hold the cruise control cancel button for more than 2 seconds.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

17. The message center display will revert to the normal display in the trip computer.
18. Turn the ignition off.
19. Turn the ignition on.
20. Press the right-hand directional button to access the instrument cluster menu.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

21. Press the right-hand OK button.



22. Press the right-hand directional button to access the Oil Level Display.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

23. Press the right-hand OK button and follow the instructions.

    Make sure that the average oil level value has now been updated.

 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

24. Refer to appropriate Engine Cover - V8 5.0L Petrol/V8 S/C 5.0L Petrol (Interior Trim and Ornamentation, Removal and Installation) information.

FUEL PUMP CAMSHAFT TIMING CHECK

SPECIAL TOOLS

Special Tool: 303-1447 Timing Tool

 © 2011 Mitchell Repair Information Company, LLC.

Special Tool: JLR-303-1613 Alignment Tool, Fuel Pump Camshaft Timing

 © 2011 Mitchell Repair Information Company, LLC.

CHECK

1. Disconnect the battery ground cable.

 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Do not work on or under a vehicle supported only by a jack. Always support the vehicle on safety stands.

2. Raise and support the vehicle.
3. Refer to appropriate Engine Undershield Front End Body Panels, Removal and Installation instructions.
4. Refer to appropriate Radiator Splash Shield Front End Body Panels, Removal and Installation.

CAUTION: Be prepared to collect escaping oil.

NOTE: Collect the engine oil in a clean container.

5. Discard the sealing washer.

 © 2011 Mitchell Repair Information Company, LLC.



6. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



IMPORTANT: Only rotate the crankshaft clockwise.

IMPORTANT: Make sure that the crankshaft is fully locked.

7. Install the Special Tool(s): 303-1447

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

8. Using a suitable marker, mark the position of the crankshaft pulley as illustrated.



9. Discard the seal.

 © 2011 Mitchell Repair Information Company, LLC.



10. Remove the Special Tool(s): 303-1447

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

11. If required, carefully adjust the crankshaft position to allow correct installation of the special tool.

    Install the Special Tool(s): JLR-303-1613



CAUTION: Do not use excessive force when adjusting the crankshaft position.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: If the crankshaft timing tool cannot be installed, adjustment of the fuel pump camshaft timing will be required.

12. If required, carefully adjust the crankshaft position to allow correct installation of the special tool.

    Install the Special Tool(s): 303-1447 If the crankshaft timing tool cannot be installed, adjustment of the fuel pump camshaft timing will be required.

    Refer to appropriate Fuel Pump Camshaft Timing Adjustment Engine - V8 5.0L Petrol, General Procedures instructions.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

13. Remove the Special Tool(s): JLR-303-1613



NOTE: Install a new seal.

14. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



15. Remove the Special Tool(s): 303-1447

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

16. Torque: 10 Nm



NOTE: Install a new sealing washer

17. Torque: 24 Nm

 © 2011 Mitchell Repair Information Company, LLC.



18. Connect the battery ground cable.

CAUTION: Make sure that the vehicle is left for 5 minutes from filling with oil and that the engine oil level is reading at least minimum (by following Steps 22-29), before starting the engine.

 © 2011 Mitchell Repair Information Company, LLC.

19.

- Fill the engine with oil - for filling values on vehicles without supercharger:
- See appropriate Specifications Engine - V8 5.0L Petrol, Specifications instructions. Fill the engine with oil - for filling values on vehicles with supercharger.
- See appropriate Specifications Engine - V8 S/C 5.0L Petrol, Specifications instructions. Clean any residual engine oil from the oil filler cap area.

CAUTION: Make sure that the vehicle has been left for 5 minutes from filling with oil.

20. Follow the Steps 22-29 before starting the engine.
21. Start the engine and allow to run for 10 minutes, stop the engine. Check for leaks.

CAUTION: Make sure that the selector lever and the gearshift mechanism are in the park (P) position.

CAUTION: Make sure that the hood is open.

22. Turn the ignition on.
23. Press the right-hand directional button to access the instrument cluster menu.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

24. Press the right-hand OK button.



25. Press the right-hand directional button to access the Oil Level Display.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

26. Press the right-hand OK button and follow the instructions.

 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

27. Press the cruise control cancel button twice within 2 seconds.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

28.

- The message center display will revert to the normal display in the trip computer.
- Press the right-hand OK button and follow the instructions.
- Check that the oil level display shows an oil level reading.
- Only after having started and run the engine for 10 minutes (as indicated in Step 21), switch off the engine, then stabilizing for 10 minutes, take a reading from the oil level display and, if necessary top up with engine oil.

 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: If instructed to follow Steps 22-29 in a previous step, return to Step 21 and continue the procedure.

29. Turn the ignition off.
30. Allow 10 minutes for the engine oil level to stabilize if there has been additional oil top up.

NOTE: The following steps are to update the average oil level value.

31. Turn the ignition on. Press and hold the cruise control cancel button for more than 2 seconds.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

32. The message center display will revert to the normal display in the trip computer.
33. Turn the ignition off.
34. Turn the ignition on.
35. Press the right-hand directional button to access the instrument cluster menu.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

36. Press the right-hand OK button.



37. Press the right-hand directional button to access the Oil Level Display.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

38. Press the right-hand OK button and follow the instructions.

    Make sure that the average oil level value has now been updated.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

39. Refer to appropriate Engine Undershield Front End Body Panels, Removal and Installation instructions.
40. Refer to appropriate Radiator Splash Shield (501-02 Front End Body Panels, Removal and Installation instructions.

FUEL PUMP CAMSHAFT TIMING CHECK

SPECIAL TOOLS

303-1447 Timing Tool

 © 2011 Mitchell Repair Information Company, LLC.

JLR-303-1613 Alignment Tool, Fuel Pump Camshaft Timing

 © 2011 Mitchell Repair Information Company, LLC.

CHECK

1. Disconnect the battery ground cable.

 © 2011 Mitchell Repair Information Company, LLC.

WARNING: Do not work on or under a vehicle supported only by a jack. Always support the vehicle on safety stands.

2. Raise and support the vehicle.
3. Refer to appropriate Engine Undershield Front End Body Panels, Removal and Installation information.
4. Refer to: Radiator Splash Shield (501-02 Front End Body Panels, Removal and Installation).

CAUTION: Be prepared to collect escaping oil.

NOTE: Collect the engine oil in a clean container.

5. Discard the sealing washer.

 © 2011 Mitchell Repair Information Company, LLC.



6. See illustration.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Only rotate the crankshaft clockwise.

CAUTION: Make sure that the crankshaft is fully locked.

 © 2011 Mitchell Repair Information Company, LLC.

7. Install the Special Tool(s): 303-1447



 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

8. Using a suitable marker, mark the position of the crankshaft pulley as illustrated.



9. Discard the seal.

 © 2011 Mitchell Repair Information Company, LLC.



10. Remove the Special Tool(s): 303-1447

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

11. If required, carefully adjust the crankshaft position to allow correct installation of the special tool.

    Install the Special Tool(s): JLR-303-1613



CAUTION: Do not use excessive force when adjusting the crankshaft position.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: If the crankshaft timing tool cannot be installed, adjustment of the fuel pump camshaft timing will be required.

12.

- If required, carefully adjust the crankshaft position to allow correct installation of the special tool.
- Install the Special Tool(s): 303-1447 If the crankshaft timing tool cannot be installed, adjustment of the fuel pump camshaft timing will be required.
- Refer to appropriate Fuel Pump Camshaft Timing Adjustment Engine - V8 5.0L Petrol, General Procedures information.

13. Remove the Special Tool(s): JLR-303-1613

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Install a new seal

14. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



15. Remove the special tool: 303-1447

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

16. Torque: 10 Nm



NOTE: Install a new sealing washer.

17. Torque: 24 Nm

 © 2011 Mitchell Repair Information Company, LLC.



18. Connect the battery ground cable.
19. Fill the engine with oil.
    - For filling values on vehicles without supercharger, see appropriate Engine - V8 5.0L Petrol, Specifications information.
    - For filling values on vehicles with supercharger, see appropriate Engine - V8 S/C 5.0L Petrol,

 © 2011 Mitchell Repair Information Company, LLC.

Specifications information.

Clean any residual engine oil from the oil filler cap area.

CAUTION: Make sure that the vehicle has been left for 5 minutes from filling with oil.

20. Follow the Steps 22-29 before starting the engine.
21.
    - Start the engine and allow to run for 10 minutes, stop the engine.
    - Check for leaks.

    CAUTION: Make sure that the selector lever and the gearshift mechanism are in the park (P) position.

    CAUTION: Make sure that the hood is open.

22. Turn the ignition on.
23. Press the right-hand directional button to access the instrument cluster menu.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

24. Press the right-hand OK button.



25. Press the right-hand directional button to access the Oil Level Display.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

26. Press the right-hand OK button and follow the instructions.

 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

27. Press the cruise control cancel button twice within 2 seconds.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

28.
- The message center display will revert to the normal display in the trip computer.
- Press the right-hand OK button and follow the instructions.
- Check that the oil level display shows an oil level reading.
- Only after having started and run the engine for 10 minutes (as indicated in Step 21), switch off the engine, then stabilizing for 10 minutes, take a reading from the oil level display and, if necessary top up with engine oil.

NOTE: If instructed to follow Steps 22-29 in a previous step, return to Step 21 and continue the procedure.

29. Turn the ignition off.
30. Allow 10 minutes for the engine oil level to stabilize if there has been additional oil top up.

NOTE: The following steps are to update the average oil level value.

31.
- Turn the ignition on.
- Press and hold the cruise control cancel button for more than 2 seconds.

32. The message center display will revert to the normal display in the trip computer.
33. Turn the ignition off.
34. Turn the ignition on.
35. Press the right-hand directional button to access the instrument cluster menu.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

36. Press the right-hand OK button.



37. Press the right-hand directional button to access the Oil Level Display.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

38.

- Press the right-hand OK button and follow the instructions.
- Make sure that the average oil level value has now been updated.

 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

39. Install Engine Undershield. See appropriate Engine Undershield Front End Body Panels, Removal and Installation instructions.
40. Install Radiator Splash Shield. See appropriate Radiator Splash Shield Front End Body Panels, Removal and Installation instructions.

FUEL PUMP CAMSHAFT TIMING ADJUSTMENT

SPECIAL TOOLS

See: **SPECIAL TOOLS**

ADJUSTMENT

1. Disconnect the battery ground cable.

WARNING: Do not work on or under a vehicle supported only by a jack. Always support the vehicle on safety stands.

2. Raise and support the vehicle.
3. See appropriate Fuel Pump Camshaft Timing Check Engine - V8 S/C 5.0L Petrol, General Procedures information.
4. See appropriate Lower Timing Cover Engine - V8 5.0L Petrol, Removal and Installation information.

CAUTION: Make sure that the area around the component is clean and free of foreign material.

5. Inspect the 3 timing chain oil nozzles for signs of damage, install as necessary.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Using a suitable tie strap, position the tensioner to one side.

6. Special Tool(s): JLR-303-1613

   Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

7. See appropriate Lower Timing Cover V8 5.0L Petrol, Removal and Installation instructions.

   See appropriate Lower Timing Cover V8 S/C 5.0L Petrol, Removal and Installation instructions.

8. Remove the special tool 303-1447.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

9. Torque: 10 Nm



10. Torque: 24 Nm

 © 2011 Mitchell Repair Information Company, LLC.



11. Connect the battery ground cable.

CAUTION: Make sure that the vehicle is left for 5 minutes from filling with oil and that the engine oil level is reading at least minimum (by following Steps 15-22), before starting the engine.

12. Fill the engine with oil.
    - See appropriate Specifications Engine - V8 5.0L Petrol, Specifications information.
    - See appropriate Specifications Engine - V8 S/C 5.0L Petrol, Specifications information.
    - Clean any residual engine oil from the oil filler cap area.

CAUTION: Make sure that the vehicle has been left for 5 minutes from filling with oil.

13. Follow the Steps 15-22 before starting the engine.
14. Start the engine and allow to run for 10 minutes, stop the engine. Check for leaks.

 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Make sure that the selector lever and the gearshift mechanism are in the park (P) position.

CAUTION: Make sure that the hood is open.

15. Turn the ignition on.
16. Press the right-hand directional button to access the instrument cluster menu.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

17. Press the right-hand OK button.



18. Press the right-hand directional button to access the Oil Level Display.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

19. Press the right-hand OK button and follow the instructions.

 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

20. Press the cruise control cancel button twice within 2 seconds.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

21.

- The message center display will revert to the normal display in the trip computer. Press the right-hand OK button and follow.
- Press the right-hand OK button and follow the instructions.
- Check that the oil level display shows an oil level reading.
- Only after having started and run the engine for 10 minutes (as indicated in Step 14), switch off the engine, then stabilizing for 10 minutes, take a reading from the oil level display and, if necessary top up with engine oil.

© 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: If instructed to follow Steps 15-22 in a previous step, return to Step 14 and continue the procedure.

22. Turn the ignition off.
23. Allow 10 minutes for the engine oil level to stabilize if there has been additional oil top up.

NOTE: The following steps are to update the average oil level value.

24. Turn the ignition on. Press and hold the cruise control cancel button for more than 2 seconds.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

25. The message center display will revert to the normal display in the trip computer.
26. Turn the ignition off.
27. Turn the ignition on.
28. Press the right-hand directional button to access the instrument cluster menu.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

29. Press the right-hand OK button
30. Press the right-hand directional button to access the Oil Level Display.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

31. Press the right-hand OK button and follow the instructions. Make sure that the average oil level value has now been updated.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

32. Install Engine Undershield. See appropriate Engine Undershield Front End Body Panels, Removal and Installation instructions.
33. Install Radiator Splash Shield. See appropriate Radiator Splash Shield Front End Body Panels, Removal and Installation instructions.

REMOVAL AND INSTALLATION

CAMSHAFT LH

REMOVAL

CAUTION: Make sure that the orientation and code on the top of the camshaft bearing caps is noted (along with the bank - A or B), so that on installation the components are installed to their original position. Failure to follow this instruction may cause damage to the vehicle.

NOTE: Removal steps in this procedure may contain installation details.

1. Disconnect the battery ground cable. Refer to **Specifications** information.

WARNING: Make sure to support the vehicle with axle stands.

2. Raise and support the vehicle.
3. See **Timing Drive Components**.

CAUTION: Rotate the camshafts until all the valves are at their minimum open point.

CAUTION: Evenly and progressively, release the camshaft bearing caps.

NOTE: Remove the camshaft bearing caps. Note: their position, orientation and markings. Each is marked with its position (number) and an orientation (arrow).

4. See figure

 © 2011 Mitchell Repair Information Company, LLC.



INSTALLATION

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Prior to installing the camshafts, position the crankshaft 45 degrees ATDC cylinder 1A to prevent valve/piston collision.

CAUTION: Make sure that the camshafts and camshaft bearing caps are installed in their original locations.

 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Evenly and progressively install and tighten the camshaft bearing caps.

NOTE: Lubricate the camshafts and the camshaft bearing caps with EP90 oil (or 75/90 viscosity oil will suffice) prior to installation.

1. See figure

   Torque: 3 Nm

   NOTE: Tighten the bolts in the indicated sequence.

2. See figure.

   Torque: 12 Nm



CAUTION: Only rotate the crankshaft clockwise.

 © 2011 Mitchell Repair Information Company, LLC.

3. Rotate the crankshaft until the camshaft lobe on the valve being checked is 180 degrees from the maximum opening position.

NOTE: If the valve clearance is incorrect, continue to the next step. If the valve clearance is correct, continue to step 8.

4. Using feeler gauge check the gap between the tappet and the camshaft lobe and check against specifications table.

CAUTION: Do not use a magnet to remove the tappet.

CAUTION: Use the following formula to calculate the required bucket thickness. Original thickness + measured clearance - desired clearance = required bucket thickness.

5. Remove the tappet and measure the thickness.

NOTE: If a new tappet is installed then go back to step 1 of the install procedure.

6. Install a new tappet if required.
7. Using feeler gauge check the gap between the tappet and the camshaft lobe and check against specifications table.
8. See **Timing Drive Components**.
9. Connect the battery ground cable. Refer to **Specifications** information.

CAMSHAFT RH

REMOVAL

CAUTION: Make sure that the orientation and code on the top of the camshaft bearing caps is noted (along with the bank - A or B), so that on installation the components are installed to their original position. Failure to follow this instruction may cause damage to the vehicle.

NOTE: Removal steps in this procedure may contain installation details.

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

1. Refer to **Specifications** information.

 © 2011 Mitchell Repair Information Company, LLC.

WARNING: Make sure to support the vehicle with axle stands.

2. Raise and support the vehicle.
3. See **Timing Drive Components**.



CAUTION: Rotate the camshafts until all the valves are at their minimum open point.

CAUTION: Evenly and progressively, release the camshaft bearing caps.

NOTE: Remove the camshaft bearing caps. Note: their position, orientation and markings. Each is marked with its position (number) and an orientation (arrow).

 © 2011 Mitchell Repair Information Company, LLC.

4. See figure.

INSTALLATION



CAUTION: Prior to installing the camshafts, position the crankshaft 45 degrees ATDC cylinder 1A to prevent valve/piston collision.

CAUTION: Evenly and progressively install and tighten the camshaft bearing caps.

CAUTION: Make sure that the camshafts and camshaft bearing caps are installed in their original locations.

NOTE: Lubricate the camshafts and the camshaft bearing caps with EP90 oil (or 75/90 viscosity oil will suffice) prior to installation.

 © 2011 Mitchell Repair Information Company, LLC.

1. See figure.

   Torque: 3 Nm



NOTE: Tighten the bolts in the indicated sequence.

2. See figure.

   Torque: 12 Nm

CAUTION: Only rotate the crankshaft clockwise.

3. Rotate the crankshaft until the camshaft lobe on the valve being checked is 180 degrees from the maximum opening position.

NOTE: If the valve clearance is incorrect, continue to the next step. If the valve

 © 2011 Mitchell Repair Information Company, LLC.

clearance is correct, continue to step 8.

4. Using feeler gauge check the gap between the tappet and the camshaft lobe and check against specifications table.

CAUTION: Use the following formula to calculate the required bucket thickness. Original thickness + measured clearance - desired clearance = required bucket thickness.

CAUTION: Do not use a magnet to remove the tappet.

5. Remove the tappet and measure the thickness.

NOTE: If a new tappet is installed then go back to step 1 of the install procedure.

6. Install a new tappet if required.
7. Using feeler gauge check the gap between the tappet and the camshaft lobe and check against specifications table.
8. See **Timing Drive Components**.
9. Refer to **Specifications** information.

CRANKSHAFT FRONT SEAL

SPECIAL TOOL(S)

	303-1434 Remover/Installer, Front Cran

 © 2011 Mitchell Repair Information Company, LLC.



REMOVAL

NOTE: Removal steps in this procedure may contain installation details.

Some variation in the illustrations may occur, but the essential information is always correct.

1. Disconnect the battery ground cable. Refer to **Specifications** information.
2. See **Crankshaft Pulley**.

 © 2011 Mitchell Repair Information Company, LLC.



3. Installer/remover, Front Crankshaft Seal (303-1434)

INSTALLATION

 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Do not over tighten the crankshaft front seal. Failure to follow this instruction may result in damage to the vehicle.

CAUTION: Take extra care not to damage the seal.

1. To install, reverse the removal procedure.

CRANKSHAFT PULLEY

REMOVAL

	303-1437 Crankshaft Damper Remover/Installer
	303-1438 Crankshaft Damper Bolt Remover/Installer

 © 2011 Mitchell Repair Information Company, LLC.

 E115257	
E115258	303-1439 Crankshaft Damper Removal Plate
	303-1440 Crankshaft Damper Removal/Installation Stud

 © 2011 Mitchell Repair Information Company, LLC.

 E107676	
E115260	303-1441 Crankshaft Damper Remover/Installer Body
	303-1448 Locking Tool

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: **Removal steps in this procedure may contain installation details.**

NOTE: **Some variation in the illustrations may occur, but the essential information is always correct.**

1. Disconnect the battery ground cable. Refer to **Specifications** information.

WARNING: **Make sure to support the vehicle with axle stands.**

2. Raise and support the vehicle.
3. Refer to **Radiator - Vehicles With: Supercharger** information.
4. Refer to **Starter Motor** information.
5. Refer to **Supercharger Belt** information.

 © 2011 Mitchell Repair Information Company, LLC.



6. Install the special tool.

   Locking Tool (303-1448)

 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Before removing the crankshaft pulley bolt, note the numbers on the bolt head. If the bolt head shows 10.9, the bolt must be removed counter clockwise. If the bolt head shows 12.9, the bolt must be removed clockwise. Failure to follow this instruction may result in damage to the crankshaft.

7. Note the markings on the crankshaft pulley bolt.



8. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

9. See figure.



 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

10. Install the special tool.

    Crankshaft Damper Bolt Remover/Installer (303-1438)

    Crankshaft Damper Remover/Installer (303-1437)



11. See figure.

    Torque: 65 Nm

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: **The graphic shows the tool position for LH thread only, RH thread will be the opposite.**

12. Using a suitable wooden block and an axle stand extension, support the special tool.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: **The crankshaft pulley bolt will be very tight.**

NOTE: **Discard the bolt after removal.**

NOTE: **The graphic shows the step for LH thread only, RH thread will be the opposite.**

13. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



14. See figure.

 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: **If the crankshaft damper is fitted with an early RH thread crankshaft bolt then the pulley can be removed with a standard puller.**

15. Remove the special tool.



16. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



17. Install the special tool.

    Crankshaft Damper Removal/Installation Stud (303-1440)

 © 2011 Mitchell Repair Information Company, LLC.



18. Install the special tool.

    Crankshaft Damper Remover/Installer Body (303-1441)

 © 2011 Mitchell Repair Information Company, LLC.



19. Install the special tool.

    Crankshaft Damper Removal Plate (303-1439)

 © 2011 Mitchell Repair Information Company, LLC.



20. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Discard the friction washer after removing the crankshaft pulley.

NOTE: Make sure to clean the threads in the end of the crankshaft and that the crank nose is free of any foreign materials.

21. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



22. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



23. See figure.

INSTALLATION

 © 2011 Mitchell Repair Information Company, LLC.



1. See figure.
    - Apply RTV sealant to the crankshaft pulley keyway.
    - Make sure that the RTV sealant is applied in a 2mm diameter bead.
    - Make sure that when the RTV sealant is applied that the RTV sealant is level with the top of the keyway.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Install a new friction washer before installing the crankshaft pulley.

NOTE: Make sure to clean the threads in the end of the crankshaft and that the crank nose is free of any foreign materials.

NOTE: Skip to step 11 for engines fitted with early RH thread crankshaft bolt.

2. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



3. Install the special tool.

 © 2011 Mitchell Repair Information Company, LLC.



4. Install the special tool.

 © 2011 Mitchell Repair Information Company, LLC.



5. Install the special tool.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Rotate the crankshaft pulley installation tool anti-clockwise until the pulley is fully located, do not over tighten. Failure to do this may result in damage to the components.

6. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



7. Remove the special tool.

 © 2011 Mitchell Repair Information Company, LLC.



8. See figure.
    - Remove the special tool.
    - Torque: 15 Nm

 © 2011 Mitchell Repair Information Company, LLC.



9. Remove the special tool.

 © 2011 Mitchell Repair Information Company, LLC.



10. See figure.

WARNING: Make sure that a new bolt is installed.

- Apply Loctite 270 to the thread of the bolts.
- Torque: 65 Nm

 © 2011 Mitchell Repair Information Company, LLC.



11. Remove the special tool.

 © 2011 Mitchell Repair Information Company, LLC.



WARNING: **Make sure that a new bolt is installed.**

12. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



13. Install the special tool.

 © 2011 Mitchell Repair Information Company, LLC.



14. Torque: 65 Nm

 © 2011 Mitchell Repair Information Company, LLC.



15. See figure

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: **The graphic shows the tool position for LH thread only, RH thread will be the opposite.**

16. Using a suitable wooden block and an axle stand extension, support the special tool.

 © 2011 Mitchell Repair Information Company, LLC.



17. Torque: 200 Nm

 © 2011 Mitchell Repair Information Company, LLC.



18. See figure.

NOTE: The use of a torque multiplier capable of 600Nm will be required.

- Torque: 270°
- Make sure that the socket is turned through 270 degrees not the torque wrench.

 © 2011 Mitchell Repair Information Company, LLC.



19. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



20. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



21. Remove the special tool.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

22. See figure.
    - Apply Loctite 270 to the thread of the bolts.
    - Torque: 65 Nm



23. See figure.
24. Refer to **Starter Motor** information.
25. Refer to **Radiator - Vehicles With: Supercharger** information.
26. Refer to **Supercharger Belt** information.
27. Connect the battery ground cable. Refer to **Specifications** information.

CRANKSHAFT REAR SEAL

SPECIAL TOOL(S)

	303-1442 Rear Crankshaft Seal Installer

 © 2011 Mitchell Repair Information Company, LLC.

 E107678	
 E107679	303-1443 Rear Crankshaft Cover Alignment Tool

REMOVAL

NOTE: Removal steps in this procedure may contain installation details.

 © 2011 Mitchell Repair Information Company, LLC.

1. See **Flexplate**.
2. See figure.



INSTALLATION

1. Install the special tool.

 © 2011 Mitchell Repair Information Company, LLC.

Rear Crankshaft Seal Installer (303-1442)

Rear Crankshaft Cover Alignment Tool (303-1443)



NOTE: Tighten the bolts in the indicated sequence.

 © 2011 Mitchell Repair Information Company, LLC.

2. See figure.

   Torque: 11 Nm



3. See figure.

 © 2011 Mitchell Repair Information Company, LLC.

Torque: 11 Nm



4. See **Flexplate**.

CYLINDER HEAD LH

REMOVAL

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: Removal steps in this procedure may contain installation details.

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

1. Disconnect the battery ground cable. Refer to **Specifications** information.

WARNING: Make sure to support the vehicle with axle stands.

2. Raise and support the vehicle.
3. See **Camshaft LH**.
4. See **Exhaust Manifold LH**.

 © 2011 Mitchell Repair Information Company, LLC.



5. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



6. See figure.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

7. See figure.



8. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Be prepared to collect escaping coolant.

9. See figure.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Be prepared to collect escaping coolant.

10. See figure.



NOTE: Clamp the hose to minimize coolant loss.

11. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



12. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Discard the seals.

13. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



14. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



15. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: If a new cylinder head has been installed then new tappets must be installed.

CAUTION: If the cylinder head is being removed without a new component being installed, the tappets must be installed in their original positions.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: Left-hand shown, right-hand similar.

16. See figure.



17. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

18. See figure.

INSTALLATION



CAUTION: An acceptable flatness of the cylinder head is 0.1mm.

1. Check cylinder head face for distortion, across the center and from corner to corner.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

WARNING: Make sure care is taken when handling the cylinder head gasket.

CAUTION: The head gasket must be installed over the cylinder block dowels.

CAUTION: Make sure that the mating faces are clean and free of foreign material.

NOTE: Install a new cylinder head gasket.

2. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that new cylinder head bolts are installed.

NOTE: Tighten the bolts in the indicated sequence.

 © 2011 Mitchell Repair Information Company, LLC.

3. See figure.

   Torque: 20 Nm



NOTE: Tighten the bolts in the indicated sequence.

 © 2011 Mitchell Repair Information Company, LLC.

4. See figure.

   Torque: 35 Nm



NOTE: Tighten the bolts in the indicated sequence.

 © 2011 Mitchell Repair Information Company, LLC.

5. Tighten the bolts 1 to 10, a further 90 degrees.



NOTE: Tighten the bolts in the indicated sequence.

6. Tighten the bolts 1 to 10, a further 120 degrees.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

7. See figure.

   Torque: 25 Nm



NOTE: Tighten the bolts in the indicated sequence.

8. See figure.

   Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: If a new cylinder head has been installed then new tappets must be installed.

CAUTION: If the cylinder head is being removed without a new component being installed, the tappets must be installed in their original positions.

 © 2011 Mitchell Repair Information Company, LLC.

9. Lubricate the valve tappets with clean engine oil.



10. See figure.

    Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



11. See figure.

    Torque: 10 Nm

 © 2011 Mitchell Repair Information Company, LLC.



12. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



13. See figure.

    Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Install the new seals.

14. See figure.

    Torque: 10 Nm

 © 2011 Mitchell Repair Information Company, LLC.



15. See figure.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

16. See figure.

    Torque: 10 Nm



17. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



18. See figure.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

19. See figure.

    Torque:



20. See figure.

 © 2011 Mitchell Repair Information Company, LLC.

Torque: 20 Nm

21. See **Exhaust Manifold LH**.
22. See **Camshaft LH**.
23. Connect the battery ground cable. Refer to **Specifications** information.

CYLINDER HEAD RH

REMOVAL

NOTE: Removal steps in this procedure may contain installation details.

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

1. Disconnect the battery ground cable. Refer to **Specifications** information.

WARNING: Make sure to support the vehicle with axle stands.

2. Raise and support the vehicle.
3. See **Camshaft RH**.
4. See **Exhaust Manifold RH**.
5. See figure.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Be prepared to collect escaping coolant.

6. See figure.



 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Be prepared to collect escaping coolant.

7. See figure.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

8. See figure.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

9. See figure.



10. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Clamp the hose to minimize coolant loss.

11. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



12. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Discard the seals.

13. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



14. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Remove and discard the O-ring seal.

15. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Discard the gasket.

16. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



17. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: If a new cylinder head has been installed then new tappets must be installed.

CAUTION: If the cylinder head is being removed without a new component being installed, the tappets must be installed in their original positions.

 © 2011 Mitchell Repair Information Company, LLC.

18. See figure.



CAUTION: Discard the bolts.

 © 2011 Mitchell Repair Information Company, LLC.

19. See figure.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

NOTE: Discard the gasket.

20. See figure.



INSTALLATION

 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: An acceptable flatness of the cylinder head is 0.1mm.

NOTE: For cylinder head with distortion above the maximum allowance, the cylinder head material must be measured.

1. Check cylinder head face for distortion, across the center and from corner to corner.



WARNING: Make sure care is taken when handling the cylinder head gasket.

NOTE: Install a new gasket.

2. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that new cylinder head bolts are installed.

3. Torque: 20 Nm

 © 2011 Mitchell Repair Information Company, LLC.





© 2011 Mitchell Repair Information Company, LLC.

4. Torque: 35 Nm

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

5. Tighten the bolts 1 to 10, a further 90 degrees.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

6. Tighten the bolts 1 to 10, a further 120 degrees.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

7. Torque: 25 Nm



8. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: If a new cylinder head has been installed then new tappets must be installed.

CAUTION: If the cylinder head is being removed without a new component being installed, the tappets must be installed in their original positions.

 © 2011 Mitchell Repair Information Company, LLC.

9. Lubricate the valve tappets with clean engine oil.



NOTE: Install a new gasket.

10. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: A new O-ring seal is to be installed.

NOTE: Install a new engine oil filter.

 © 2011 Mitchell Repair Information Company, LLC.

11. See figure.



12. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



13. Torque: 20 Nm

 © 2011 Mitchell Repair Information Company, LLC.



14. Torque: 20 Nm

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Install the new seals.

15. Torque: 10 Nm

 © 2011 Mitchell Repair Information Company, LLC.



16. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



17. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



18. See figure.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

19. See figure.



20. Torque: 10 Nm

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

21. Torque: 25 Nm



22. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



23. See **Exhaust Manifold RH**.
24. See **Camshaft RH**.
25. Connect the battery ground cable. Refer to **Specifications** information.

ENGINE MOUNT LH

SPECIAL TOOL(S)

	100-012 Slide Hammer

 © 2011 Mitchell Repair Information Company, LLC.

	205-735 Remover, Halfshaft Inner Joint
	303-1142 Viscous Coupling Wrench

 © 2011 Mitchell Repair Information Company, LLC.

	303-1143 Viscous Coupling Holding Tool
	308-621-2 Installer/Guide, Halfshaft Oil Seal

 © 2011 Mitchell Repair Information Company, LLC.

	308-626 Installer - Halfshaft Seal

REMOVAL

All vehicles

 © 2011 Mitchell Repair Information Company, LLC.

1. Disconnect the battery ground cable. Refer to **Specifications** information.

WARNING: Make sure to support the vehicle with axle stands.

2. Raise and support the vehicle.
3. Refer to **Air Cleaner Outlet Pipe T-Connector** information.
4. Refer to **Differential Draining and Filling** information.

 © 2011 Mitchell Repair Information Company, LLC.



5. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



6. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



7. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



8. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



9. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



10. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



11. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



12. See figure.

CAUTION: Support the halfshaft.

- Remove and discard the retaining clip.

Remover, Halfshaft Inner Joint (205-735)

 © 2011 Mitchell Repair Information Company, LLC.



13. See figure.

CAUTION: Keep the halfshaft horizontal to avoid damaging the oil seal.

CAUTION: Make sure no damage occurs to the halfshaft seal when installing the halfshaft.

NOTE: With assistance remove the components.

- Install a new halfshaft oil seal.

Left-hand drive vehicles

1. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



2. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



All vehicles

1. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Always protect the cooling pack elements to prevent accidental damage.

NOTE: The thread is right handed.

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

2. Viscous Coupling Wrench (303-1142)

   Viscous Coupling Holding Tool (303-1143)

 © 2011 Mitchell Repair Information Company, LLC.



3. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Use a wooden block to protect the oil pan when supporting the engine.

4. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

INSTALLATION

All vehicles

1. Torque:

   1: 45 Nm

   1: 60°

   2: 56 Nm

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

2. Torque: 100 Nm



3. Torque: 10 Nm

 © 2011 Mitchell Repair Information Company, LLC.



Left-hand drive vehicles

 © 2011 Mitchell Repair Information Company, LLC.



1. Torque: 24 Nm

 © 2011 Mitchell Repair Information Company, LLC.



2. Torque: 100 Nm

All vehicles

1. See figure.

CAUTION: Keep the halfshaft horizontal to avoid damaging the oil seal.

CAUTION: Make sure no damage occurs to the halfshaft seal when installing the halfshaft.

- Install a new halfshaft oil seal.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: The seal protector must be left in place until the halfshaft has been installed.

NOTE: LH illustration shown, RH is similar.

2.

1. Clean the component mating faces.

   Slide Hammer (100-012)

   Installer - Halfshaft Seal (308-626)

   Installer/Guide halfshaft oil seal (308-621-2)

   CAUTION: Keep the halfshaft horizontal to avoid damaging the oil seal.

 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Pull on the halfshaft inboard joint to make sure the clip has fully engaged and retains the halfshaft inboard joint within the differential case.

NOTE: Do not fully engage the halfshaft until the oil seal protector has been removed.

3.

- Install a new retaining clip.
- Open the halfshaft oil seal protector.
- Lubricate the seal with clean differential fluid.



4. Torque:

   Stage 1: 165 Nm

   Stage 2: 90°

 © 2011 Mitchell Repair Information Company, LLC.



5. Torque: 250 Nm

 © 2011 Mitchell Repair Information Company, LLC.



6. Torque: 8 Nm

 © 2011 Mitchell Repair Information Company, LLC.



7. Torque: 80 Nm

 © 2011 Mitchell Repair Information Company, LLC.



8. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



9. Torque: 275 Nm

 © 2011 Mitchell Repair Information Company, LLC.



10. Refer to **Differential Draining and Filling** information.
11. Refer to **Air Cleaner Outlet Pipe T-Connector** information.
12. Connect the battery ground cable. Refer to **Specifications** information.

ENGINE MOUNT RH

 © 2011 Mitchell Repair Information Company, LLC.

SPECIAL TOOL(S)

	303-1142 Viscous Coupling Wrench
	303-1143 Viscous Coupling Holding Tool

REMOVAL

 © 2011 Mitchell Repair Information Company, LLC.

All vehicles

WARNING: Make sure to support the vehicle with axle stands.

1. Raise and support the vehicle.
2. Refer to **Specifications** information.
3. Refer to **Exhaust System** information.
4. Refer to **Air Cleaner Outlet Pipe T-Connector** information.
5. Refer to **Air Cleaner RH** information.

NOTE: RH side only.

6. See figure.



NOTE: RH side only.

 © 2011 Mitchell Repair Information Company, LLC.

7. See figure.



Right-hand drive vehicles

CAUTION: Do not turn the steering wheel with the steering column lower shaft disconnected as damage to the clockspring and steering wheel switches may occur.

1.

- Note the fitted position.
- Align the steering wheel to straight ahead.
- Remove and discard the Torx bolt.

 © 2011 Mitchell Repair Information Company, LLC.



2. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



3. Remove and discard the 2 nuts and Torx bolts.

 © 2011 Mitchell Repair Information Company, LLC.



All vehicles

CAUTION: Always protect the cooling pack elements to prevent accidental damage.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: The thread is right handed.

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

1. Viscous Coupling Wrench (303-1142)

   Viscous Coupling Holding Tool (303-1143)

   Torque: 65 Nm



2. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



3. Using a suitable hydraulic jack, raise and support the engine.
4. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

INSTALLATION

All vehicles

1. Torque:
    - 1: 45 Nm

      1: 60°

      2: 56 Nm

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

2. See figure.



CAUTION: Always protect the cooling pack elements to prevent accidental damage.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: The thread is right handed.

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

3. Viscous Coupling Wrench (303-1142)

   Viscous Coupling Holding Tool (303-1143)

   Torque: 65 Nm



Right-hand drive vehicles

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

1. Torque: 100 Nm

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: **Some variation in the illustrations may occur, but the essential information is always correct.**

2. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Do not turn the steering wheel with the steering column lower shaft disconnected as damage to the clockspring and steering wheel switches may occur.

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

 © 2011 Mitchell Repair Information Company, LLC.

3.

- Align the steering wheel to straight ahead.
- Return the steering column to its original position.



All vehicles

 © 2011 Mitchell Repair Information Company, LLC.

1. See figure.



2. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



3. Refer to **Air Cleaner RH** information.
4. Refer to **Air Cleaner Outlet Pipe T-Connector** information.
5. Refer to **Exhaust System** information.
6. Connect the battery ground cable. Refer to **Specifications** information.

ENGINE UNDERSHIELD

REMOVAL

1. Authoring Template

INSTALLATION

1. Authoring Template

EXHAUST MANIFOLD LH

SPECIAL TOOL(S)

 © 2011 Mitchell Repair Information Company, LLC.

 E115261	303-1444-01 Exhaust Manifold Installation Guide Pins - Threaded
	303-1444-02 Exhaust Manifold Installation Guide Pins - Unthreaded

 © 2011 Mitchell Repair Information Company, LLC.



REMOVAL

NOTE: Removal steps in this procedure may contain installation details.

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

1. Disconnect the battery ground cable. Refer to **Specifications** information.

WARNING: Do not work on or under a vehicle supported only by a jack. Always support the vehicle on safety stands.

2. Raise and support the vehicle.
3. Refer to **Power Steering Pump - 5.0L** information.
4. Refer to **Exhaust System** information.

 © 2011 Mitchell Repair Information Company, LLC.

5. See figure.



CAUTION: Discard the bolts.

NOTE: Discard the gasket.

NOTE: Make sure that the position of the spacers is noted before removal of the manifold.

6. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Do not disassemble further if the component is removed for access only.

7. See figure

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Remove and discard the gasket.

8. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



9. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



10. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



INSTALLATION

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that the mating faces are clean and free of foreign material.

CAUTION: Make sure the anti-seize compound does not contact the catalyst monitor sensor tip.

 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: If accidentally dropped or knocked install a new sensor.

CAUTION: Make sure the catalyst monitor sensor wiring harness is not twisted more than 180 degrees and is not in contact with either the exhaust or driveshaft.

NOTE: If the original sensor is to be installed, apply lubricant meeting specification ESE-M12A4-A to the thread of the sensor.

1. Torque: 45 Nm



NOTE: Install a new gasket.

2. Special Tool(s): Exhaust Manifold Installation Guide Pins - Threaded (303-1444-01)

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: If a new cylinder head is installed use the special tools in the illustration.

3. See figure.

Special Tool(s): Exhaust Manifold Installation Guide Pins - Unthreaded (303-1444-02)

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that new bolts are installed.

NOTE: Install the spacers in the noted position.

 © 2011 Mitchell Repair Information Company, LLC.

4. See figure.

   Torque: 10 Nm



5. Remove the special tool.

 © 2011 Mitchell Repair Information Company, LLC.





© 2011 Mitchell Repair Information Company, LLC.

CAUTION: Make sure that new bolts are installed.

NOTE: Install the spacers in the noted position.

6. Torque: 10 Nm

 © 2011 Mitchell Repair Information Company, LLC.



7. Torque: 18 Nm

 © 2011 Mitchell Repair Information Company, LLC.



8. Torque: 3 Nm

 © 2011 Mitchell Repair Information Company, LLC.



9. Torque: 10 Nm

 © 2011 Mitchell Repair Information Company, LLC.



10. Torque: 10 Nm
11. Refer to **Exhaust System** information.
12. Refer to **Power Steering Pump - 5.0L** information.
13. Connect the battery ground cable. Refer to **Specifications** information.

EXHAUST MANIFOLD RH

 © 2011 Mitchell Repair Information Company, LLC.

SPECIAL TOOL(S)

	303-1444-01 Exhaust Manifold Installation Guide Pins - Threaded
	303-1444-02 Exhaust Manifold Installation Guide Pins - Unthreaded

 © 2011 Mitchell Repair Information Company, LLC.



REMOVAL

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

1. Disconnect the battery ground cable. Refer to **Specifications** information.

WARNING: Make sure to support the vehicle with axle stands.

2. Raise and support the vehicle.
3. Refer to **Exhaust System** information.

NOTE: Remove and discard the gasket.

4. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



5. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



6. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



7. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Discard the bolts.

CAUTION: LH illustration shown, RH is similar.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: **Discard the gasket.**

NOTE: **Make sure that the position of the spacers is noted before removal of the manifold.**

8. See figure.



 © 2011 Mitchell Repair Information Company, LLC.

NOTE: Do not disassemble further if the component is removed for access only.

9. See figure.



INSTALLATION

 © 2011 Mitchell Repair Information Company, LLC.



1. Torque: 45 Nm

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: LH illustration shown, RH is similar.

NOTE: Install a new gasket.

2. Install the special tool.

   Exhaust Manifold Installation Guide Pins - Threaded (303-1444-01)

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: LH illustration shown, RH is similar.

NOTE: If a new cylinder head is installed use the special tools in the illustration.

3. Exhaust Manifold Installation Guide Pins - Unthreaded (303-1444-02)

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that new bolts are installed.

CAUTION: LH illustration shown, RH is similar.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: Install the spacers in the noted position.

4. Torque: 10 Nm



CAUTION: LH illustration shown, RH is similar.

 © 2011 Mitchell Repair Information Company, LLC.

5. Remove the special tool.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Make sure that new bolts are installed.

CAUTION: LH illustration shown, RH is similar.

NOTE: Install the spacers in the noted position.

6. Torque: 10 Nm



 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: LH illustration shown, RH is similar.

7. Torque: 18 Nm

 © 2011 Mitchell Repair Information Company, LLC.



8. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



9. Torque: 10 Nm

 © 2011 Mitchell Repair Information Company, LLC.



10. Torque: 10 Nm

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Install a new gasket.

11. Torque: 48 Nm
12. Refer to **Exhaust System** information.
13. Connect the battery ground cable. Refer to **Specifications** information.

 © 2011 Mitchell Repair Information Company, LLC.

FLEXPLATE

REMOVAL

NOTE: Removal steps in this procedure may contain installation details.

1. Disconnect the battery ground cable. Refer to **Specifications** information.

WARNING: Make sure to support the vehicle with axle stands.

2. Raise and support the vehicle.
3. See appropriate Transmission - 5.0L information.

CAUTION: Install all the bolts finger tight before final tightening.

CAUTION: The bolts can only be used 3 times, mark the bolts with a center punch. If 2 punch marks are visible, discard the bolts.

CAUTION: Make sure that no components fall off during removal.

CAUTION: Install the bolts in the noted position.

NOTE: Make sure the crankshaft and flexplate mating faces are clean before installation.

NOTE: Make sure that the crankshaft is not rotated.

NOTE: Tighten the retaining bolts working diagonally.

4. Torque:

Stage 1: 45 Nm

Stage 2: 90°

 © 2011 Mitchell Repair Information Company, LLC.



INSTALLATION

1. To install, reverse the removal procedure.

OIL COOLER

REMOVAL

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: Removal steps in this procedure may contain installation details.

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

1. Disconnect the battery ground cable. Refer to **Specifications** information.

WARNING: Make sure to support the vehicle with axle stands.

2. Raise and support the vehicle.
3. See appropriate Engine Oil Draining and Filling information
4. Refer to **Supercharger** information.
5. See figure.



6. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Be prepared to collect escaping oil.

CAUTION: Be prepared to collect escaping coolant.

 © 2011 Mitchell Repair Information Company, LLC.

7. Torque: 13 Nm



CAUTION: Make sure that these components are installed to the noted removal position.

NOTE: Install a new gasket.

8. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that these components are installed to the noted removal position.

CAUTION: Install new o-ring seals

9. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



INSTALLATION

CAUTION: Install all the bolts finger tight before final tightening.

 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Make sure that the area around the component is clean and free of foreign material.

CAUTION: Install the new seals.

NOTE: Tighten the bolts in the indicated sequence.

1. To install, reverse the removal procedure.

 © 2011 Mitchell Repair Information Company, LLC.



OIL FILTER ELEMENT

REMOVAL

NOTE: Removal steps in this procedure may contain installation details.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

1. Refer to **Engine Cover - 5.0L** information.
2. Allow the engine oil to drain from the oil filter element housing for two minutes.



3. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



4. See figure

 © 2011 Mitchell Repair Information Company, LLC.



INSTALLATION

1. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



2. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



3. Check and top-up the engine oil.
4. Start and run the engine.
5. Refer to **Engine Cover - 5.0L** information.

OIL PAN EXTENSION

SPECIAL TOOL(S)

	303-1433 Lower Timing Cover Alignment tool

 © 2011 Mitchell Repair Information Company, LLC.

 E120139	
E107678	303-1442 Rear Crankshaft Seal Installer
	303-1443 Rear Crankshaft Cover Alignment Tool

 © 2011 Mitchell Repair Information Company, LLC.

 E107679	
 E119168	303-1500 Installer, Stretchy Belt

REMOVAL

NOTE: Removal steps in this procedure may contain installation details.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

1. Disconnect the battery ground cable. Refer to **Specifications** information.

WARNING: Do not work on or under a vehicle supported only by a jack. Always support the vehicle on safety stands.

2. Raise and support the vehicle.
3. See **Crankshaft Pulley**.
4. Engine Refer to appropriate information.
5. See figure.

 © 2011 Mitchell Repair Information Company, LLC.

6. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



7. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



8. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



9. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



10. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



11. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



12. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



13.

- Discard the O-ring seal.
- Remove and discard the halfshaft oil seal.

 © 2011 Mitchell Repair Information Company, LLC.



14. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: The bolts can only be used 3 times, mark the bolts with a center punch. If 2 punch marks are visible, discard the bolts.

CAUTION: Make sure that no components fall off during removal.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: **Make sure that the crankshaft is not rotated.**

NOTE: **Make sure the crankshaft and flexplate mating faces are clean before installation.**

15. See figure.



 © 2011 Mitchell Repair Information Company, LLC.

16. See figure.



17. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



18. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



19. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



20. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



21. See figure.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

22. See figure.



23. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



24. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Be prepared to collect escaping fluids.

25. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Be prepared to collect escaping fluids.

26. See figure.

 © 2011 Mitchell Repair Information Company, LLC.

27. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Be prepared to collect escaping fluids.

28. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Be prepared to collect escaping fluids.

29. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



30. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Discard the component.

31. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

32. See figure.



33. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: **Make sure to use the aluminum lug provided on the oil pan extension to lever against.**

34. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Do not disassemble further if the component is removed for access only.

35. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



INSTALLATION

1. Torque: 10 Nm

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that the mating faces are clean and free of foreign material.

CAUTION: Use only a plastic scraper when removing the sealing material.

2. Apply RTV sealant WSE-M4G323-A6 (Loctite 5901G) to the areas shown, and tighten the bolts within 7 minutes.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Tighten the bolts in the indicated sequence.

3. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that the mating faces are clean and free of foreign material.

4. Apply RTV sealant WSE-M4G323-A6 (Loctite 5901G) to the areas shown, and tighten the bolts within 7 minutes.

 © 2011 Mitchell Repair Information Company, LLC.



© 2011 Mitchell Repair Information Company, LLC.

CAUTION: Make sure that the mating faces are clean and free of foreign material.

NOTE: Install new lower timing cover.

5. Install the bolts, but do not tighten fully at this stage.

   Lower Timing Cover Alignment tool (303-1433)

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Tighten the bolts in the indicated sequence.

6.

- Torque:

  M8 20 Nm

 © 2011 Mitchell Repair Information Company, LLC.

M6 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

7. Remove the special tools.
8. Torque: 12 Nm



9.
    1. Rear Crankshaft Seal Installer (303-1442)

 © 2011 Mitchell Repair Information Company, LLC.

2. Rear Crankshaft Cover Alignment Tool (303-1443)



10. Remove the special tools.

NOTE: Tighten the bolts in the indicated sequence.

 © 2011 Mitchell Repair Information Company, LLC.

11. Torque: 11 Nm



12. Torque: 11 Nm

 © 2011 Mitchell Repair Information Company, LLC.



13. Torque: 11 Nm

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: The high-pressure fuel pumps are removed from the illustration for clarity.

14. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

NOTE: Lubricate the fuel rail high-pressure fuel pump bucket with clean engine oil.

15. See figure.



CAUTION: Tighten the Torx screws a turn at a time until the correct torque is

 © 2011 Mitchell Repair Information Company, LLC.

achieved.

NOTE: Lubricate the fuel rail high-pressure fuel pump O-ring seal with clean engine oil.

16. Torque: 11 Nm



17. Loosen the Torx screws half a turn each.

 © 2011 Mitchell Repair Information Company, LLC.



18. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: **Lubricate the fuel rail high-pressure fuel pump bucket with clean engine oil.**

19. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Tighten the Torx screws a turn at a time until the correct torque is achieved.

NOTE: Lubricate the fuel rail high-pressure fuel pump O-ring seal with clean engine oil.

20. Torque: 11 Nm

 © 2011 Mitchell Repair Information Company, LLC.



21. Loosen the Torx screws half a turn each.

 © 2011 Mitchell Repair Information Company, LLC.



22. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Care must be taken when positioning the fuel rail high-pressure fuel pump cover to one side.

NOTE: Fuel rail high-pressure fuel pump cover shown removed for clarity.

23. Torque: 11 Nm

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Care must be taken when positioning the fuel rail high-pressure fuel pump cover to one side.

NOTE: Fuel rail high-pressure fuel pump cover shown removed for clarity.

24. Torque: 11 Nm

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Install new high-pressure fuel supply lines.

CAUTION: Lubricate only the union threads with clean engine oil.

NOTE: Remove and discard the blanking caps.

NOTE: Install the bolt and unions fully finger tight before final tightening.

25. Do not fully tighten at this stage.

 © 2011 Mitchell Repair Information Company, LLC.



26. Torque: 21 Nm

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: **Install the bolt and unions finger tight before final tightening.**

NOTE: **Remove and discard the blanking caps.**

27. Torque:

    Unions 21 Nm

    M6 11 Nm

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that a new component is installed.

28. Torque: 21 Nm

 © 2011 Mitchell Repair Information Company, LLC.



29. Torque:

    Unions 21 Nm

    M6 8 Nm

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

30. See figure.



31. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



32. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Install all the bolts finger tight before final tightening.

33. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



34. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



35. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



36. Torque:

    Stage 1: 45 Nm

    Stage 2: 60°

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Install all the bolts finger tight before final tightening.

NOTE: Tighten the bolts in the indicated sequence.

37. Torque: 48 Nm

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Install all the bolts finger tight before final tightening.

CAUTION: The bolts can only be used 3 times, mark the bolts with a center punch. If 2 punch marks are visible, discard the bolts.

CAUTION: Install the bolts in the noted position.

NOTE: Make sure that the crankshaft is not rotated.

NOTE: Make sure the crankshaft and flexplate mating faces are clean before installation.

NOTE: Tighten the retaining bolts working diagonally.

 © 2011 Mitchell Repair Information Company, LLC.

38. Torque:

    Stage 1: 45 Nm

    Stage 2: 90°



 © 2011 Mitchell Repair Information Company, LLC.

39. Torque: 48 Nm



40. Install a new O-ring seal to the differential case.

CAUTION: Make sure the O ring seal remains in its fitted position.

CAUTION: Make sure that new bolts are installed.

41. With assistance, align and secure the front differential case.

 © 2011 Mitchell Repair Information Company, LLC.



42. Tighten the 100 mm length bolts.

    Torque:

- Stage 1: 50 Nm
- Stage 2: 90°

 © 2011 Mitchell Repair Information Company, LLC.



43. Tighten the 55 mm length bolts.

    Torque:

- Stage 1: 50 Nm
- Stage 2: 60°

 © 2011 Mitchell Repair Information Company, LLC.



44. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



45. Torque: 22 Nm

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Install the bolt finger tight before final tightening.

46. Torque: 40 Nm

 © 2011 Mitchell Repair Information Company, LLC.



47. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



48. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.

49. See **Crankshaft Pulley**.
50. Special Tool: Installer, Stretchy Belt (303-1500)

 © 2011 Mitchell Repair Information Company, LLC.



51.

- Install the cooling fan belt.
- Rotate the engine clockwise twice, making sure that the belt is seated on both pulleys correctly.
- Remove the special tool.

 © 2011 Mitchell Repair Information Company, LLC.



52. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



53. Refer to appropriate Engine - V8 5.0L Petrol, Installation information.
54. Lower the vehicle.
55. Connect the battery ground cable. Refer to **Specifications** information.

OIL PUMP

REMOVAL

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

1. Disconnect the battery ground cable. Refer to **Specifications** information.

WARNING: Make sure to support the vehicle with axle stands.

2. Raise and support the vehicle.

 © 2011 Mitchell Repair Information Company, LLC.

3. See **Oil Pan Extension**.

NOTE: Tsubaki timing drive only.

4. See figure.



NOTE: INA timing drive only.

5. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



6. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Remove and discard the O-ring seal.

7. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Remove and discard the O-ring seals.

8. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Remove and discard the O-ring seal.

9. See figure.

 © 2011 Mitchell Repair Information Company, LLC.

INSTALLATION

1. Lubricate and install the new O-ring seals.

 © 2011 Mitchell Repair Information Company, LLC.

2. Torque:

   M8 25 Nm

   M6 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



3. Lubricate and install a new O-ring seal.

 © 2011 Mitchell Repair Information Company, LLC.

4. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

5. Torque: 21 Nm



NOTE: Tsubaki timing drive only.

6. Install the lower timing chain making sure the colored chain links align correctly with the fuel rail high-pressure fuel pumps camshaft and crankshaft sprocket markings.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that the tensioner spring is correctly located.

NOTE: Tsubaki timing drive only.

 © 2011 Mitchell Repair Information Company, LLC.

7. Torque: 21 Nm



NOTE: INA timing drive only.

8. Install the lower timing chain making sure the colored chain links align correctly with the fuel rail high-pressure fuel pumps camshaft and crankshaft sprocket markings.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that the tensioner spring is correctly located.

NOTE: INA timing drive only.

9. Torque: 21 Nm

 © 2011 Mitchell Repair Information Company, LLC.



10. See **Oil Pan Extension**.
11. Connect the battery ground cable. Refer to **Specifications** information.

TIMING COVER

SPECIAL TOOL(S)

	303-1433 Lower Timing Cover Alignment tool

 © 2011 Mitchell Repair Information Company, LLC.



REMOVAL

NOTE: Removal steps in this procedure may contain installation details.

1. Disconnect the battery ground cable. Refer to **Specifications** information.

WARNING: Make sure to support the vehicle with axle stands.

2. Raise and support the vehicle.
3. See **Crankshaft Pulley**.

CAUTION: Be prepared to collect escaping oil.

NOTE: Discard the seal.

4. See figure

 © 2011 Mitchell Repair Information Company, LLC.



5. See **Valve Cover LH**.
6. See **Valve Cover RH**.
7. Cooling System Draining, Filling and Bleeding - V8 S/C 5.0L Petrol. Refer to appropriate information.
8. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



9. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Be prepared to collect escaping coolant.

10. See figure

 © 2011 Mitchell Repair Information Company, LLC.



11. See figure.

 © 2011 Mitchell Repair Information Company, LLC.

12. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



13. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



14. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



15. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



16. See figure.

 © 2011 Mitchell Repair Information Company, LLC.

17. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



18. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



19. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

INSTALLATION

CAUTION: Make sure that the mating faces are clean and free of foreign material.

- **Apply RTV sealant WSE-M4G323-A6 (Loctite 5901G) to the areas shown, and tighten the bolts within 7 minutes.**

1. See figure.



CAUTION: Make sure that the mating faces are clean and free of foreign material.

- **Apply RTV sealant WSE-M4G323-A6 (Loctite 5901G) to the areas shown, and tighten the bolts within 7 minutes.**

2. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Tighten the bolts in the indicated sequence.

3. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Tighten the bolts in the indicated sequence.

4. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that the mating faces are clean and free of foreign material.

5. Apply RTV sealant WSE-M4G323-A6 (Loctite 5901G) to the areas shown, and tighten the bolts within 7 minutes.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Make sure that the mating faces are clean and free of foreign material.

6. Install the bolts, but do not tighten fully at this stage.

   Special Tool(s): Lower Timing Cover Alignment tool (303-1433)



 © 2011 Mitchell Repair Information Company, LLC.

7. Torque: M6 12 Nm

   Torque: M8 20 Nm

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

8. Torque: 12 Nm



9. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



10. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.

11. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



12. Torque: 40 Nm

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Install the bolt finger tight before final tightening.

13. Torque: 40 Nm

 © 2011 Mitchell Repair Information Company, LLC.



14. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



15. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



16. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.

17. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



18. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



19. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



20. See **Crankshaft Pulley**.
21. See **Valve Cover LH**.
22. See **Valve Cover RH**.
23. Cooling System Draining, Filling and Bleeding - V8 S/C 5.0L Petrol. Refer to **Cooling System Draining, Filling and Bleeding (V8 S/C 5.0L Petrol) - General Procedures** .
24. Connect the battery ground cable. Refer to **Specifications** information.

TIMING DRIVE COMPONENTS

SPECIAL TOOL(S)

	303-1445 Timing Tool - Camshaft Alignment

 © 2011 Mitchell Repair Information Company, LLC.

	
	303-1447 Timing Tool
	303-1448 Locking Tool

 © 2011 Mitchell Repair Information Company, LLC.

E115265	
E115270	303-1452 Camshaft Rotating Tool
	303-1482 Tensioner Tool

 © 2011 Mitchell Repair Information Company, LLC.

REMOVAL

CAUTION: Check all timing components for wear and install new components if required.

NOTE: Removal steps in this procedure may contain installation details.

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

1. Disconnect the battery ground cable. Refer to **Specifications** information.

   WARNING: Make sure to support the vehicle with axle stands.

2. Raise and support the vehicle.
3. See **Timing Cover**.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

4. See figure.



CAUTION: Only rotate the crankshaft clockwise.

 © 2011 Mitchell Repair Information Company, LLC.

5. Install the special tool.

   Timing Tool (303-1447)

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: If the noted position of the Woodruff key is at the 9 o'clock position, then a new flexplate must be installed. If the Woodruff key is in the 6 o'clock position then proceed with the next step.

6. Note the position of the crankshaft Woodruff key.
7. See figure.



 © 2011 Mitchell Repair Information Company, LLC.

8. See figure.



 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

9. See figure.



CAUTION: If the variable valve timing (VVT) units are knocked or dropped then the VVT must be replaced.

 © 2011 Mitchell Repair Information Company, LLC.

10. Remove the timing chain with the VVT units.



11. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



12. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



13. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: If the VVT is knocked or dropped then the VVT must be replaced.

14. Remove the timing chain with the VVT units.

 © 2011 Mitchell Repair Information Company, LLC.



15. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Discard the friction washer.

16. See figure.



INSTALLATION

 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Install a new friction washer.

1. See figure.



2. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

3.

1. Install the special tool to each Camshaft.
2. Camshaft Rotating Tool (303-1452)
3. Torque: 10 Nm



 © 2011 Mitchell Repair Information Company, LLC.

4. Carefully rotate the camshafts if the position is not as shown.



5. Install the special tool 303-1445 to the rear of the camshafts making sure the key way's are correctly located into each slot on each of the camshafts.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Do not overturn the camshafts.

CAUTION: Tighten the wing nuts finger tight. Failure to follow this instruction may result in damage to the components.

 © 2011 Mitchell Repair Information Company, LLC.

6.

1. Using a suitable tool, carefully rock the camshaft clockwise then anti-clockwise. Turn the special tool locking nuts until there is no movement left in camshafts.
2. Repeat steps 3- 6 for the camshafts on the other cylinder head.



 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Do not allow the camshaft to rotate.

CAUTION: If the VVT is knocked or dropped then the VVT must be replaced.

NOTE: Do not tighten at this stage.

7.

1. Install the timing chain with the variable valve timing (VVT) units.



8. Make sure that all the timing chain alignment marks are in the positions shown.

 © 2011 Mitchell Repair Information Company, LLC.



9. Torque: 24 Nm

 © 2011 Mitchell Repair Information Company, LLC.



10. Make sure the tensioner piston is fully extended. Then fully depress and lock the tensioner piston with the grenade pin before installation, failure to do this may result in damage to the engine.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Do not release the timing chain tensioner locking pin at this stage.

11. Torque: 10 Nm

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Do not allow the camshafts to rotate.

CAUTION: If the VVT is knocked or dropped then the VVT must be replaced.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: Do not tighten at this stage.

12. Install the timing chain with the VVT units.



13. Make sure that all the timing chain alignment marks are in the positions shown.

 © 2011 Mitchell Repair Information Company, LLC.



14. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

15. Make sure the tensioner piston is fully extended. Then fully depress and lock the tensioner piston with the grenade pin before installation, failure to do this may result in damage to the engine.



CAUTION: Do not release the timing chain tensioner locking pin at this stage.

 © 2011 Mitchell Repair Information Company, LLC.

16. Torque: 10 Nm



17. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Do not use mechanical force.

18. Make sure that the tensioners are fully deployed.
19. Release and reposition the oil suction tube to one side.

 © 2011 Mitchell Repair Information Company, LLC.



20.

- Install the special tool.
- Tensioner Tool (303-1482)

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Apply the torque to the end of the special tool.

CAUTION: Make sure that the torque wrench is aligned with the special tool as illustrated in the graphic.

 © 2011 Mitchell Repair Information Company, LLC.

21.

1. Install the torque wrench to the special tool.
2. Torque: 35 Nm



CAUTION: Make sure that the torque wrench does not move whilst tightening the VVT bolts.

NOTE: Make sure to tighten the exhaust VVT unit bolts first.

22.

- Torque: 32 Nm
- Tensioner Tool (303-1482)

 © 2011 Mitchell Repair Information Company, LLC.



23.

- Install the oil suction tube.
- Torque: 10 Nm

 © 2011 Mitchell Repair Information Company, LLC.



24.

- Install the special tool.
- Tensioner Tool (303-1482)

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Apply the torque to the end of the special tool.

CAUTION: Make sure that the torque wrench is aligned with the special tool as illustrated in the graphic.

25.

1. Install the torque wrench to the special tool.
2. Torque: 35 Nm

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that the torque wrench does not move whilst tightening the VVT bolts.

NOTE: Make sure to tighten the inlet VVT unit bolts first.

 © 2011 Mitchell Repair Information Company, LLC.

26. Torque: 32 Nm



27. Remove the special tool.

 © 2011 Mitchell Repair Information Company, LLC.



28. Remove the special tool.

 © 2011 Mitchell Repair Information Company, LLC.



29. See figure.
    - Remove the special tool.
    - Timing Tool (303-1447)

 © 2011 Mitchell Repair Information Company, LLC.



30. See figure.
    - Install the special tool.
    - Locking Tool (303-1448)

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Install the crankshaft pulley bolt with an M16 washer to prevent damage to the crankshaft on installation.

31. Torque: 50 Nm

 © 2011 Mitchell Repair Information Company, LLC.



32.

- Remove the special tool.
- Locking Tool (303-1448)

 © 2011 Mitchell Repair Information Company, LLC.



33. Rotate the engine two complete turns clockwise.

CAUTION: Only rotate the crankshaft clockwise.

34.

 © 2011 Mitchell Repair Information Company, LLC.

- Install the special tool.
- Timing Tool (303-1447)



35.

- Install the special tool.

 © 2011 Mitchell Repair Information Company, LLC.

- Locking Tool (303-1448)



36. See figure

 © 2011 Mitchell Repair Information Company, LLC.



37.

- Remove the special tool.
- Locking Tool (303-1448)

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: If the special tool cannot be installed, return to step 22 of the installation until the special tool 303-1445 is installed correctly.

CAUTION: If directed to step 22, make sure that the VVT unit retaining bolts are loosened prior to installing the special tool(s).

 © 2011 Mitchell Repair Information Company, LLC.

38. Install the special tool.

Timing Tool - Camshaft Alignment (303-1445)



CAUTION: If the special tool cannot be installed, the timing chain installation steps must be repeated.

 © 2011 Mitchell Repair Information Company, LLC.

39. Install the special tool.



40.

- Remove the special tool.

 © 2011 Mitchell Repair Information Company, LLC.



41. See figure.
    - Remove the special tool.

 © 2011 Mitchell Repair Information Company, LLC.



42. See figure.
    - Remove the special tool.
    - Timing Tool (303-1447)

 © 2011 Mitchell Repair Information Company, LLC.



43. Torque: 10 Nm

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

44. See **Timing Cover**.
45. Connect the battery ground cable. Refer to **Specifications** information.

VALVE COVER LH

SPECIAL TOOL(S)

	303-1446 Valve Cover Alignment Tool

REMOVAL

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

NOTE: Removal steps in this procedure may contain installation details.

1. Disconnect the battery ground cable. Refer to **Specifications** information.
2. Refer to **Supercharger** information.
3. Refer to **Air Cleaner Outlet Pipe LH** information.
4. Refer to **Fuel Rail LH** information.
5. Torque: 10 Nm

 © 2011 Mitchell Repair Information Company, LLC.



6. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



7. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



8. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



INSTALLATION

CAUTION: Use only a plastic scraper when removing the sealing material.

CAUTION: Use lint free cloth.

CAUTION: Make sure that the mating faces are clean and free of corrosion and foreign material.

CAUTION: Installation of the valve cover and tightening must be carried out within 7 minutes of applying the sealant.

NOTE: Apply two beads of silicone gasket sealant (Loctite 5901) as shown on the illustration. The application of the sealant must be 1.5mm diameter 12mm

 © 2011 Mitchell Repair Information Company, LLC.

long. Install the valve cover immediately after applying the sealant. The cover should be fitted directly to the head without smearing the sealant or the seals.

1. To install, reverse the removal procedure.



2. Valve Cover Alignment Tool (303-1446)

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Tighten the bolts in the indicated sequence.

3. Torque: 13 Nm

 © 2011 Mitchell Repair Information Company, LLC.



VALVE COVER RH

SPECIAL TOOL(S)

	303-1446 Valve Cover Alignment Tool

 © 2011 Mitchell Repair Information Company, LLC.



REMOVAL

NOTE: Removal steps in this procedure may contain installation details.

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

1. Disconnect the battery ground cable. Refer to **Specifications** information.
2. Refer to **Supercharger** information.
3. Refer to **Air Cleaner Outlet Pipe RH** information.
4. Refer to **Fuel Rail RH** information.
5. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



6. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



7. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



INSTALLATION

CAUTION: Use only a plastic scraper when removing the sealing material.

 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Use lint free cloth.

CAUTION: Make sure that the mating faces are clean and free of corrosion and foreign material.

CAUTION: Installation of the valve cover and tightening must be carried out within 7 minutes of applying the sealant.

NOTE: Apply two beads of silicone gasket sealant (Loctite 5901) as shown on the illustration. The application of the sealant must be 1.5mm diameter 12mm long. Install the valve cover immediately after applying the sealant. The cover should be fitted directly to the head without smearing the sealant or the seals.

1. To install, reverse the removal procedure.



 © 2011 Mitchell Repair Information Company, LLC.

2. See figure.

Valve Cover Alignment Tool (303-1446)



NOTE: Tighten the bolts in the indicated sequence.

 © 2011 Mitchell Repair Information Company, LLC.

3. Torque: 13 Nm



CYLINDER BLOCK OIL GALLERY PLUG

REMOVAL

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: Removal steps in this procedure may contain installation details.

NOTE: Some variation in the illustrations may occur, but the essential information is always correct.

1. Refer to **Plenum Chamber** information.

WARNING: Do not work on or under a vehicle supported only by a jack. Always support the vehicle on safety stands.

2. Raise and support the vehicle.
3. Refer to **Engine Undershield** information.
4. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



5. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that the mating faces are clean and free of corrosion and foreign material.

6. Torque:

   Stage 1: 40 Nm

 © 2011 Mitchell Repair Information Company, LLC.

Stage 2: 180°



INSTALLATION

1. To install, reverse the removal procedure.

FUEL PUMP CAMSHAFT

 © 2011 Mitchell Repair Information Company, LLC.

REMOVAL

1. Authoring Template

INSTALLATION

1. Authoring Template

FUEL PUMP CAMSHAFT (ASSEMBLY PART NUMBER: INA TIMING DRIVE)

REMOVAL

NOTE: Some illustrations may show the engine removed for clarity.

1. Disconnect the battery ground cable. Refer to **Specifications** information.

WARNING: Make sure to support the vehicle with axle stands.

2. Raise and support the vehicle.
3. See **Oil Pan Extension**.
4. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



5. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



6. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Take extra care when removing the component, prevent damage to the mating faces.

7. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



INSTALLATION

CAUTION: Make sure that the mating faces are clean and free of foreign material.

1. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Take extra care not to damage the mating faces.

2. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



3. Torque: 21 Nm

 © 2011 Mitchell Repair Information Company, LLC.



4. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



5. Install the lower timing chain making sure the colored chain links align correctly with the fuel rail high-pressure fuel pumps camshaft and crankshaft sprocket markings.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that the tensioner spring is correctly located.

6. Torque: 21 Nm

 © 2011 Mitchell Repair Information Company, LLC.



7. See **Oil Pan Extension**.
8. Connect the battery ground cable. Refer to **Specifications** information.

FUEL PUMP CAMSHAFT (ASSEMBLY PART NUMBER: TSUBAKI TIMING DRIVE)

REMOVAL

NOTE: Some illustrations may show the engine removed for clarity.

1. Disconnect the battery ground cable. Refer to **Specifications** information.

WARNING: Make sure to support the vehicle with axle stands.

2. Raise and support the vehicle.
3. See **Oil Pan Extension**.
4. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



5. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



6. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Take extra care when removing the component, prevent damage to the mating faces.

7. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



INSTALLATION

CAUTION: Make sure that the mating faces are clean and free of foreign material.

1. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Take extra care not to damage the mating faces.

2. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



3. Torque: 21 Nm

 © 2011 Mitchell Repair Information Company, LLC.



4. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.



5. Install the lower timing chain making sure the colored chain links align correctly with the fuel rail high-pressure fuel pumps camshaft and crankshaft sprocket markings.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that the tensioner spring is correctly located.

6. Torque: 21 Nm

 © 2011 Mitchell Repair Information Company, LLC.



7. See **Oil Pan Extension**.
8. Connect the battery ground cable. Refer to **Specifications** information.

LOWER TIMING COVER

SPECIAL TOOL(S)

	303-1433 Lower Timing Cover Alignment tool

 © 2011 Mitchell Repair Information Company, LLC.



REMOVAL

1. Disconnect the battery ground cable. Refer to **Specifications** information.

WARNING: Make sure to support the vehicle with axle stands.

2. Raise and support the vehicle.
3. See **Crankshaft Pulley**.
4. Refer to **Brake Vacuum Pump - V8 5.0L Petrol/V8 S/C 5.0L Petrol** information.
5. See figure.

 © 2011 Mitchell Repair Information Company, LLC.

6. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



7. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



8. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



INSTALLATION

1. Apply RTV sealant WSE-M4G323-A6 (Loctite 5901G) to the areas shown, and tighten the bolts within 7 minutes.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Make sure that the mating faces are clean and free of foreign material.

2. Install the bolts, but do not tighten fully at this stage.

   Lower Timing Cover Alignment tool (303-1433)



 © 2011 Mitchell Repair Information Company, LLC.

NOTE: Tighten the bolts in the indicated sequence.

3. Torque:

   M6 12 Nm

   M8 20 Nm

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

4. Torque: 12 Nm



5. Torque: 40 Nm

 © 2011 Mitchell Repair Information Company, LLC.



6. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



7. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.

8. Refer to **Brake Vacuum Pump - V8 5.0L Petrol/V8 S/C 5.0L Petrol** information.
9. See **Crankshaft Pulley**.
10. Connect the battery ground cable. Refer to **Specifications** information.

CAUTION: Make sure that the vehicle is left for 5 minutes from filling with oil and

 © 2011 Mitchell Repair Information Company, LLC.

that the engine oil level is reading at least minimum (by following Steps 14-21), before starting the engine.

11.
    1. Fill the engine with oil - for filling values on vehicles without supercharger: Refer to **Specifications** information.
    2. Fill the engine with oil - for filling values on vehicles with supercharger: See **Specifications**.
    3. Clean any residual engine oil from the oil filler cap area.

CAUTION: Make sure that the vehicle has been left for 5 minutes from filling with oil.

12. Follow the Steps 14-21 before starting the engine.
13.
    - Start the engine and allow to run for 10 minutes, stop the engine.
    - Check for leaks.

CAUTION: Make sure that the selector lever and the gearshift mechanism are in the park (P) position.

CAUTION: Make sure that the hood is open.

14. Turn the ignition on.
15. Press the right-hand directional button to access the instrument cluster menu.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

16. Press the right-hand OK button.



17. Press the right-hand directional button to access the Oil Level Display.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

18. Press the right-hand OK button and follow the instructions.

 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

19. Press the cruise control cancel button twice within 2 seconds.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

20.

1. The message center display will revert to the normal display in the trip computer.
2. Press the right-hand OK button and follow the instructions.
3. Check that the oil level display shows an oil level reading.
4. Only after having started and run the engine for 10 minutes (as indicated in Step 13), switch off the engine, then stabilizing for 10 minutes, take a reading from the oil level display and, if necessary top up with engine oil.

 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: If instructed to follow Steps 14-21 in a previous step, return to Step 13 and continue the procedure.

21. Turn the ignition off.
22. Allow 10 minutes for the engine oil level to stabilize if there has been additional oil top up.

NOTE: The following steps are to update the average oil level value.

23.

- Turn the ignition on.
- Press and hold the cruise control cancel button for more than 2 seconds.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

24.
- The message center display will revert to the normal display in the trip computer.

25. Turn the ignition off.
26. Turn the ignition on.
27. Press the right-hand directional button to access the instrument cluster menu.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

28. Press the right-hand OK button.



29. Press the right-hand directional button to access the Oil Level Display.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

30.

- Press the right-hand OK button and follow the instructions.
- Make sure that the average oil level value has now been updated.

 © 2011 Mitchell Repair Information Company, LLC.

 © 2011 Mitchell Repair Information Company, LLC.

31. Refer to **Engine Undershield** information.
32. Refer to **Radiator Splash Shield** information.

REMOVAL

ENGINE

ALL VEHICLES

1. Disconnect the battery ground cable.

WARNING: Make sure to support the vehicle with axle stands.

2. Raise and support the vehicle.
3. See **AIR CONDITIONING (A/C) SYSTEM RECOVERY, EVACUATION AND CHARGING (V8 5.0L PETROL/V8 S/C 5.0L PETROL)** .
4. See **AUTOMATIC TRANSMISSION/TRANSAXLE** .
5. See **COOLING FAN V8 S/C 5.0L PETROL** .
6. See **Cooling System Draining, Filling and Bleeding (V8 S/C 5.0L Petrol) - General Procedures** .
7. See **FRONT HALFSHAFT LH (VEHICLES WITHOUT: HIGH PERFORMANCE BRAKES)** .
8. See **FRONT HALFSHAFT RH (VEHICLES WITHOUT: HIGH PERFORMANCE BRAKES)** .
9. Secure the hood in the service position.
10. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



11. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



WARNING: Do not smoke or carry lighted tobacco or open flame of any type when working on or near any fuel related components. Highly flammable vapors are always present and may ignite. Failure to follow these instructions may result in personal injury.

CAUTION: Be prepared to collect escaping fuel.

 © 2011 Mitchell Repair Information Company, LLC.

12. See figure.



CAUTION: Be prepared to collect escaping coolant.

13. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



WARNING: **Be prepared to collect escaping fluids.**

14. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



15. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Be prepared to collect escaping coolant.

16. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Be prepared to collect escaping coolant.

17. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



18. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that all openings are sealed. Use new blanking caps.

19. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



CAUTION: Make sure that all openings are sealed. Use new blanking caps.

20. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: RHD illustration shown, LHD is similar.

21. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



22. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



23. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



24. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



25. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



26. See figure.

CAUTION: Install new o-ring seals

 © 2011 Mitchell Repair Information Company, LLC.



27. See figure.

CAUTION: Be prepared to collect escaping coolant.

 © 2011 Mitchell Repair Information Company, LLC.



28. See figure.

CAUTION: Be prepared to collect escaping coolant.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

Right hand drive vehicles

29. See figure



30. See figure

 © 2011 Mitchell Repair Information Company, LLC.



Left hand drive vehicles

31. See figure

 © 2011 Mitchell Repair Information Company, LLC.



All vehicles

32. See figure

NOTE: RHD illustration shown, LHD is similar.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: RHD illustration shown, LHD is similar.

33. See figure.

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

34. See figure.



35. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

36. See figure.



NOTE: Remove and discard the gasket.

37. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Remove and discard the gasket.

38. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



39. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



40. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



41. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



42. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: This step requires the aid of another technician.

43. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



INSTALLATION

ENGINE

Special Tools

 © 2011 Mitchell Repair Information Company, LLC.

	303-1435 Engine Lifting Brackets Rear
	303-1436 Engine Lifting Bracket Front

NOTE: **Some variation in the illustrations may occur, but the essential information is always correct.**

All Vehicles

 © 2011 Mitchell Repair Information Company, LLC.

NOTE: This step requires the aid of another technician.

1. Special Tool(s): 303-1436, 303-1435



2. Torque: 100 Nm

 © 2011 Mitchell Repair Information Company, LLC.



3. Torque: 100 Nm

 © 2011 Mitchell Repair Information Company, LLC.



4. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



5. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Install a new gasket

6. Torque: 48 Nm

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: Install a new gasket

7. Torque: 48 Nm

 © 2011 Mitchell Repair Information Company, LLC.



8. Torque: 10 Nm

 © 2011 Mitchell Repair Information Company, LLC.



9. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



 © 2011 Mitchell Repair Information Company, LLC.

10. Torque: 10 Nm



NOTE: RHD figure shown, LHD is similar.

11. Torque: 25 Nm

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

NOTE: RHD illustration shown, LHD is similar.

12. Torque: 25 Nm



Left-hand drive vehicles

 © 2011 Mitchell Repair Information Company, LLC.

13. Torque: 10 Nm



Right-Hand Drive Vehicles

14. Torque: 10 nm

 © 2011 Mitchell Repair Information Company, LLC.



15. Torque: 10 Nm

 © 2011 Mitchell Repair Information Company, LLC.



All Vehicles

CAUTION: Be prepared to collect escaping coolant.

16. Torque: 12 Nm

 © 2011 Mitchell Repair Information Company, LLC.





 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Be prepared to collect escaping coolant.

17. See figure:



 © 2011 Mitchell Repair Information Company, LLC.

CAUTION: Install new O-ring seals

CAUTION: Lubricate the O-ring seals

18. Torque: 25 Nm



19. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



20. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



21. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



22. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: RHD figure shown, LHD is similar.

23. Torque: 8 Nm

 © 2011 Mitchell Repair Information Company, LLC.



24. Torque: 25 Nm

CAUTION: Make sure that the mating faces are clean and free of foreign material.

 © 2011 Mitchell Repair Information Company, LLC.



NOTE: **Remove and discard the blanking caps.**

CAUTION: **Make sure that the mating faces are clean and free of foreign material.**

 © 2011 Mitchell Repair Information Company, LLC.

25. Torque: 25 Nm



26. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



27. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



28. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



29. See figure.

CAUTION: Be prepared to collect escaping fluids.

 © 2011 Mitchell Repair Information Company, LLC.



30. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



31. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



WARNING: Do not smoke or carry lighted tobacco or open flame of any type when working on or near any fuel related components. Highly flammable vapors are always present and may ignite. Failure to follow these instructions may result in personal injury.

CAUTION: Be prepared to collect escaping.

 © 2011 Mitchell Repair Information Company, LLC.

32. See figure.



33. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



34. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



35. See figure.

 © 2011 Mitchell Repair Information Company, LLC.



36. Refer to **FRONT HALFSHAFT LH (VEHICLES WITHOUT: HIGH PERFORMANCE BRAKES)** .
37. Refer to **FRONT HALFSHAFT RH (VEHICLES WITHOUT: HIGH PERFORMANCE BRAKES)** .
38. Refer to **Cooling System Draining, Filling and Bleeding (V8 S/C 5.0L Petrol) - General Procedures** .
39. Refer to **COOLING FAN V8 S/C 5.0L PETROL** .

 © 2011 Mitchell Repair Information Company, LLC.

40. Refer to **AUTOMATIC TRANSMISSION/TRANSAXLE** .
41. Refer to **AIR CONDITIONING (A/C) SYSTEM RECOVERY, EVACUATION AND CHARGING (V8 5.0L PETROL/V8 S/C 5.0L PETROL)** .
42. Lower the vehicle.
43. Connect the battery ground cable. Refer to **SPECIFICATIONS** .
44. Using the approved diagnostic equipment, clear the powertrain control module (PCM) adaptions.

 © 2011 Mitchell Repair Information Company, LLC.